


Set up the network connection

-

When do I need to setup the network connection? You need to setup the controller’s network connection when the controller is connected to a network for the first time or when the network addressing scheme changes.

Preparations If an IP address is to be obtained automatically, make sure there is a server running that supplies the network with IP addresses (a DHCP server). Otherwise you will not be able to access the controller via the controller network.
It is still possible to access the controller via the service PC connection.

Network connection dialog box The illustration shows the network connection dialog box.



Set up the network connection Regardless of how you choose to set up the network connections, the first steps are common:

Action

Info

- 1 Perform an X-start to start the Boot Application.
- 2 In the Boot Application, tap **Settings**.
The network connection dialog is displayed.
- 3 If you choose to use no IP address, then tap **Use no IP address**. Otherwise, proceed below!
- 4 If you choose to obtain an IP address automatically, then tap **Obtain an IP address automatically**. Otherwise, proceed below!
- 5 If you choose to use a fixed IP address, tap **Use the following IP address**.
Enter the IP address, subnet mask, and default gateway.

How to perform an X-start is detailed in section [Restart and select another system \(X-start\)](#).


In some cases it can be useful to disconnect the controller from the network, without disconnecting the network cable. Without IP address the controller cannot be accessed from other equipment on the same network.



Note
Make sure a valid address is used so there are no conflicts in the network. A conflict may cause other controllers to malfunction



Note
Do not use leading zeros in the numbers in IP settings. A number with a leading zero is interpreted as an octal number.

Action	Info
6 Tap OK to save the new setting.	
7 In the Boot Application, tap Select System and select the system to restart.	How to select a system is detailed in section Selecting system .
8 In the Boot Application, tap Restart Controller and tap OK to restart the controller with new settings.	<div>Note You can verify the new settings by tapping ABB -> System Info -> Controller properties -> Network connections -> LAN</div>