

26.A/C Filter**A: REPLACEMENT**

Refer to “AC” section for A/C filter replacement. <Ref. to AC-95, REPLACEMENT, A/C Filter.>

ENGINE 1 SECTION

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

FUEL INJECTION (FUEL SYSTEMS)**FU(STI)****EMISSION CONTROL
(AUX. EMISSION CONTROL DEVICES)****EC(STI)****INTAKE (INDUCTION)****IN(STI)****MECHANICAL****ME(STI)****EXHAUST****EX(STI)****COOLING****CO(STI)****LUBRICATION****LU(STI)****SPEED CONTROL SYSTEMS****SP(STI)****IGNITION****IG(STI)****STARTING/CHARGING SYSTEMS****SC(STI)****ENGINE (DIAGNOSTICS)****EN(STI)
(diag)****GENERAL DESCRIPTION****GD(STI)**

FUEL INJECTION (FUEL SYSTEMS)

FU(STI)

	Page
1. General Description	2
2. Throttle Body	15
3. Intake Manifold	17
4. Engine Coolant Temperature Sensor	33
5. Crankshaft Position Sensor	34
6. Camshaft Position Sensor	35
7. Knock Sensor	38
8. Throttle Position Sensor	39
9. Mass Air Flow and Intake Air Temperature Sensor	40
10. Manifold Absolute Pressure Sensor	41
11. Fuel Injector	43
12. Tumble Generator Valve Assembly	46
13. Tumble Generator Valve Actuator	47
14. Oil Flow Control Solenoid Valve	48
15. Wastegate Control Solenoid Valve	50
16. Front Oxygen (A/F) Sensor	52
17. Rear Oxygen Sensor	54
18. SI-DRIVE (SUBARU Intelligent Drive) Selector	55
19. Engine Control Module (ECM)	56
20. Main Relay	57
21. Oxygen Sensor Relay	58
22. Electronic Throttle Control Relay	60
23. Fuel Pump Relay	62
24. Fuel Pump Control Unit	63
25. Fuel	64
26. Fuel Tank Protector	66
27. Fuel Tank	67
28. Fuel Filler Pipe	77
29. Fuel Pump	82
30. Fuel Level Sensor	84
31. Fuel Sub Level Sensor	85
32. Fuel Filter	87
33. Pulsation Damper Assembly	91
34. Pressure Regulator & Damper Assembly	92
35. Fuel Delivery, Return and Evaporation Lines	94
36. Fuel System Trouble in General	100