

11. General Diagnostic Table

A: INSPECTION

Symptoms	Possible cause	Corrective action
AT select lever	Starter does not run.	Adjust the select cable and inhibitor switch, or inspect the circuit.
	Back-up light does not illuminate.	Adjust the select cable and inhibitor switch, or inspect the circuit.
	AT shift lock system does not operate normally.	Adjust the select cable and inhibitor switch, or inspect the circuit.
	Manual mode can not be set.	Inspect the mode switch and select lever, or inspect the circuit.
MT gear shift lever (STI model)	Cannot shift into reverse.	Adjust the reverse check cable.
	Can shift into reverse when the slider is not pulled up.	Adjust or replace the reverse check cable.
	Slider cannot be pulled up or sticks in the pulled-up position.	<ul style="list-style-type: none"> • Check the reverse check system of the transmission. • Adjust or replace the reverse check cable.
MT gear shift lever (Except for STI model)	Cannot shift into reverse.	Adjust the MT gear select cable.
	Shifted to 6th though it shifted to reverse.	Adjust or replace the MT gear select cable.
	Can shift into reverse when the slider is not pulled up.	Adjust or replace the MT gear select cable.
	Slider cannot be pulled up or sticks in the pulled-up position.	<ul style="list-style-type: none"> • Check the shift link system of the transmission. • Adjust or replace the MT gear select cable.

General Diagnostic Table

CONTROL SYSTEMS

CONTINUOUSLY VARIABLE TRANSMISSION

CVT(TR690)

	Page
1. General Description	3
2. CVTF	36
3. Differential Gear Oil	41
4. Variator Chain Break-in	44
5. Road Test	45
6. Stall Test	47
7. Time Lag Test	48
8. Secondary Pressure (Line Pressure) Test	49
9. Transfer Clutch Pressure Test	52
10. Automatic Transmission Assembly	56
11. Transmission Mounting System	83
12. Extension Case Oil Seal	87
13. Differential Side Retainer Oil Seal	89
14. Inhibitor Switch	92
15. Secondary Speed Sensor	99
16. Primary Speed Sensor	102
17. Front Wheel Speed Sensor	105
18. Rear Wheel Speed Sensor	107
19. Secondary Pressure Sensor	110
20. Control Valve Body	112
21. Transmission Harness	123
22. Transmission Control Module (TCM)	126
23. CVTF Cooler (With Warmer Function)	129
24. Air Breather Hose	136
25. Drive Plate	137
26. Preparation for Overhaul	139
27. Torque Converter Assembly	140
28. Extension Case	142
29. Rear Drive Shaft	146
30. Transfer Clutch	151
31. Center Differential Carrier	154
32. Transfer Reduction Driven Gear	158
33. Parking Pawl	163
34. Intermediate Case	165
35. CVTF Filter	171
36. Reverse Brake Assembly	172
37. Forward Clutch Assembly	181
38. Reduction Driven Gear	201
39. Transmission Control Device	208
40. Transmission Case	212
41. Primary Pulley and Secondary Pulley	228
42. Variator Chain	243
43. Drive Pinion Shaft Assembly	244

44.	Front Differential Assembly	265
45.	Oil Pump	284
46.	Oil Pump Chain	285
47.	Converter Case Cover	292
48.	Front Reduction Drive Gear	302
49.	Front Reduction Driven Gear	310
50.	Converter Case	318
51.	Diagnostics with Phenomenon	322