



## 8. MT Gear Shift Cable

### A: REMOVAL

- 1) Disconnect the ground terminal from battery sensor. <Ref. to NT-5, BATTERY, NOTE, Note.>
- 2) Lift up the vehicle.
- 3) Remove the center exhaust pipe (rear). <Ref. to EX(w/o STI)-35, REMOVAL, Center Exhaust Pipe.>
- 4) Remove the center exhaust cover.



- 5) Remove the cable clamp.




(A) Cable clamp

## MT Gear Shift Cable


### CONTROL SYSTEMS

6) Remove the dust cover.



(A) Dust cover


7) Remove the snap pin and washer.



(A) Snap pin


(B) Washer

8) Remove the bolts holding the shift bracket.



(A) Shift bracket

9) Remove the shift bracket together with the MT gear shift cable.




(A) MT gear shift cable

(B) Shift bracket

## MT Gear Shift Cable

### CONTROL SYSTEMS

10) Remove the cable cover plate.




11) Disconnect the MT gear shift cable.

**CAUTION:**

**Be careful not to deform the cable inner.**


**NOTE:**

Pull out down the MT gear shift cable to spread the spring.



(A) MT gear shift cable

12) Remove the clamp.




(A) Clamp

(B) MT gear shift cable

13) Pull out the MT gear shift cable.

**CAUTION:**

- Do not bend MT gear shift cable at a sharp angle.
- Do not twist the cable inner excessively.




# MT Gear Shift Cable

## CONTROL SYSTEMS

### B: INSTALLATION

#### CAUTION:

- Do not bend MT gear shift cable at a sharp angle.
- When replacing the new MT gear shift cable, secure it to shift bracket with the clamps, be careful not to mistake the installing direction.



(A) Old MT gear shift cable


(B) New MT gear shift cable

(C) Shift bracket

1) Install the shift bracket together with the MT gear shift cable.


#### Tightening torque:

**18 N·m (1.8 kgf-m, 13.3 ft-lb)**



(A) MT gear shift cable


(B) Shift bracket



CS-01479

(A) Shift bracket

2) Install the snap pin and washer.



CS-01850

(A) Snap pin

(B) Washer

3) Install the dust cover.


**Tightening torque:**

**15 N·m (1.5 kgf-m, 11.1 ft-lb)**

## MT Gear Shift Cable

### CONTROL SYSTEMS

4) Insert the MT gear shift cable into cable cover assembly, and install the clamp.



(A) Clamp

(B) MT gear shift cable

5) Connect the MT gear shift cable.

6) Attach the cable cover plate.


**Tightening torque:**

**7.5 N·m (0.8 kgf-m, 5.5 ft-lb)**

7) Insert the MT gear shift cable into cable clamp, and install to the transmission.

**Tightening torque:**

**18 N·m (1.8 kgf-m, 13.3 ft-lb)**



(A) Cable clamp



8) Install the center exhaust cover.

***Tightening torque:***

***18 N·m (1.8 kgf-m, 13.3 ft-lb)***

9) Install the center exhaust pipe (rear). <Ref. to EX(w/o STI)-41, INSTALLATION, Center Exhaust Pipe.>

10) Lower the vehicle.

11) Connect the ground terminal to battery sensor. <Ref. to NT-5, BATTERY, NOTE, Note.>

12) Make sure the gears can be shifted accurately into each gear.