

## General Diagnostic Table

PARKING BRAKE

---

### 5. General Diagnostic Table

#### A: INSPECTION

Symptoms	Possible cause	Corrective action
Brake drag	Lever assembly - hand brake is maladjusted.	Adjust.
	Parking brake cable does not move.	Repair or replace.
	Parking brake shoe clearance is maladjusted.	Adjust.
	Spring - shoe return is faulty.	Replace.
Noise from brake	Spring - shoe return is faulty.	Replace.
	Spring - shoe clamp is faulty.	Replace.

# POWER ASSISTED SYSTEM (POWER STEERING)

# *PS*

---

	Page
1. General Description .....	2
2. Power Steering System .....	15
3. Steering Wheel .....	16
4. Universal Joint .....	21
5. Steering Column .....	25
6. Steering Gearbox .....	30
7. Electric Power Steering Gearbox .....	56
8. Pipe Assembly .....	70
9. Oil Pump .....	77
10. Reservoir Tank .....	82
11. Power Steering Fluid .....	83
12. Power Steering Control Module .....	84
13. General Diagnostic Table .....	87