

### **8. Fuel Gauge**

#### **A: SPECIFICATION**

Since the meter - main assembly cannot be disassembled, do not remove or inspect the fuel gauge alone.  
(Do not remove the cover on the back surface.)