

System Operation Check Mode

HVAC SYSTEM (AUTO A/C) (DIAGNOSTICS)

12. System Operation Check Mode

A: OPERATION

For detailed operation procedures, refer to “PC application help for Subaru Select Monitor”.

B: LIST

- 1) On «Main Menu» display, select {Each System Check}.
- 2) On «Each System Check» display, select {Air Condition System}.
- 3) On «Air Condition System» display, select {Work Support}.
- 4) On «Work Support» display, select {System Operation Check Mode}.

NOTE:

If not equipped (based on area or condition), some items are not displayed.

System operation check mode item	Display	Unit	Note
In-vehicle Air Temperature setting	-72.47 — 193.82	°C	—
Ambient Air Temperature Setting	-40 — 80	°C	—
Quantity of Sunload Setting	0 — 4448	W/m ²	—
Heater Water Temperature Setting	-40 — 215	°C	—
AUTO SW setting	—	—	—
Air mix door actuator target open (driver's side)	-32.68 — 133.33	%	—
Air mix door actuator target open (passenger's side)	-32.68 — 133.33	%	—
Fresh/Rec Air Dr act open angle target	REC/FRS	—	—
Mode Door Actuator Opening Angle Target	-32.68 — 133.33	%	—
Blower Fan Level Setting	1 — 7	—	—
Rear Defogger Setting	ON/OFF	—	—
PTC steps	—	—	—
A/C Change Setting	—	—	—
Actuator origin reset	—	—	—
Heater core temperature setting	-40 — 215	°C	—