

Table of Contents

1.	Introduction	4
1.1	About SME Company	4
1.2	About this manual.....	4
1.3	About warning, caution and information notices.....	4
1.4	Product warranty information	5
1.5	How to find us	5
2.	AC SmartMotion AC-L1 Overview	6
2.1	Product description.....	6
2.2	General technical specifications	7
2.3	Packaging configuration.....	9
2.4	Product indication label	9
3.	Installation and wiring	10
3.1	General description.....	10
3.2	Mounting the controller.....	10
3.2.1	Overview	10
3.2.2	Screw torque for the power connections.....	11
3.2.3	Connector parts	11
3.3	Cooling requirements.....	11
3.3.1	AC-L1 with aluminium baseplate and additional heatsink	11
3.3.2	AC-L1 with aluminium baseplate	11
3.3.3	Clearances.....	12
3.4	List of complete pin-out	13
3.5	Typical connection diagram for basic TRACTION system.....	15
3.5.1	AC-L1 pin-out for basic TRACTION application	16
3.6	Typical connection diagram for basic PUMP system	18
3.6.1	AC-L1 pin-out for basic PUMP application.....	19
3.7	SME external devices description	21
3.7.1	Encoder	21
3.7.2	Displays	21
3.8	Programmable parameters.....	22
3.9	Initial setup.....	22
4.	Main Functions	23
4.1	System configuration	23
4.2	Battery Discharge Algorithm (BDI)	23
4.3	Battery protections	23
4.4	Mains power management.....	23
4.5	Operating profiles	23
4.6	Generic outputs.....	23
4.7	LIN display	23
4.8	Service	24
4.9	Motor & control	24