



**\* danger!** battery Must go to Vin.  
Vin is the only pin that  
can handle 9v.

You only need 9v to Vin if you're not  
connected to USB