



# **Kinetis SDK Demo Applications User's Guide**

**Freescale Semiconductor, Inc.**

KSDKDEMOUG

1.0.0

Jul 2014



# Contents

## Chapter 1 ADC Hardware Trigger Demo

<b>1.1</b>	<b>Overview</b>	<b>1</b>
1.1.1	Trigger by PIT	1
1.1.2	Trigger by PDB	1
1.1.3	Trigger by LPTMR	1
1.1.4	Input signal for ADC	2
<b>1.2</b>	<b>Supported Platforms</b>	<b>2</b>
<b>1.3</b>	<b>Getting Started</b>	<b>2</b>
1.3.1	Prepare the Demo	2
<b>1.4</b>	<b>Run the demo</b>	<b>2</b>
<b>1.5</b>	<b>Customization Options</b>	<b>3</b>
1.5.1	Default configurations	3
1.5.1.1	ADC configurations	3
1.5.1.2	Sample frequency	3
1.5.2	Configure the number of samples	3
1.5.3	Configure the signal frequency	3
1.5.4	Configure the ADC instance	3
1.5.5	Configure the ADC input pin	4

## Chapter 2 ADC Low Power Demo

<b>2.1</b>	<b>Overview</b>	<b>5</b>
<b>2.2</b>	<b>Supported Platforms</b>	<b>5</b>
<b>2.3</b>	<b>Getting Started</b>	<b>5</b>
2.3.1	Prepare the Demo	5
2.3.2	Run the demo	6

Section number	Title	Page
<b>Chapter 3</b> <b>DAC ADC Demo</b>		
<b>3.1</b>	<b>Overview</b> . . . . .	<b>7</b>
<b>3.2</b>	<b>Supported Platforms</b> . . . . .	<b>7</b>
<b>3.3</b>	<b>Getting Started</b> . . . . .	<b>7</b>
3.3.1	Hardware Settings . . . . .	7
3.3.2	Prepare the Demo . . . . .	7
<b>3.4</b>	<b>Run the demo</b> . . . . .	<b>8</b>
<b>3.5</b>	<b>Key Functions</b> . . . . .	<b>9</b>
<b>Chapter 4</b> <b>DSPI eDMA Demo</b>		
<b>4.1</b>	<b>Overview</b> . . . . .	<b>13</b>
<b>4.2</b>	<b>Supported Platforms</b> . . . . .	<b>13</b>
<b>4.3</b>	<b>Getting Started</b> . . . . .	<b>13</b>
4.3.1	Hardware Settings . . . . .	13
4.3.2	Prepare the Demo . . . . .	15
<b>4.4</b>	<b>Run the demo</b> . . . . .	<b>15</b>
<b>4.5</b>	<b>Key Functions</b> . . . . .	<b>17</b>
<b>Chapter 5</b> <b>Flash Demo</b>		
<b>5.1</b>	<b>Overview</b> . . . . .	<b>21</b>
<b>5.2</b>	<b>Supported Platforms</b> . . . . .	<b>21</b>
<b>5.3</b>	<b>Getting Started</b> . . . . .	<b>21</b>
5.3.1	Prepare the Demo . . . . .	21
<b>5.4</b>	<b>Commands/Directions</b> . . . . .	<b>22</b>

Section number	Title	Page
<p style="text-align: center;"><b>Chapter 6</b> <b>FlexCAN and UART communication Demo</b></p>		
<b>6.1</b>	<b>Overview . . . . .</b>	<b>23</b>
<b>6.2</b>	<b>Supported Hardware . . . . .</b>	<b>23</b>
<b>6.3</b>	<b>Getting Started . . . . .</b>	<b>23</b>
6.3.1	Hardware configuration . . . . .	23
6.3.2	Prepare the Demo . . . . .	23
<b>6.4</b>	<b>Run the demo . . . . .</b>	<b>24</b>
<p style="text-align: center;"><b>Chapter 7</b> <b>FlexTimer PWM Demo</b></p>		
<b>7.1</b>	<b>Overview . . . . .</b>	<b>25</b>
<b>7.2</b>	<b>Supported Platforms . . . . .</b>	<b>25</b>
<b>7.3</b>	<b>Getting Started . . . . .</b>	<b>25</b>
7.3.1	Prepare the Demo . . . . .	25
7.3.2	Run the demo . . . . .	26
<p style="text-align: center;"><b>Chapter 8</b> <b>GPIO I2C Demo</b></p>		
<b>8.1</b>	<b>Overview . . . . .</b>	<b>27</b>
<b>8.2</b>	<b>Supported Platforms . . . . .</b>	<b>27</b>
<b>8.3</b>	<b>Getting Started . . . . .</b>	<b>27</b>
8.3.1	Prepare the Demo . . . . .	27
8.3.2	Run the demo . . . . .	28
8.3.3	Customization Options . . . . .	28
<p style="text-align: center;"><b>Chapter 9</b> <b>Hello World Demo</b></p>		
<b>9.1</b>	<b>Overview . . . . .</b>	<b>31</b>

Section number	Title	Page
<b>9.2</b>	<b>Supported Platforms</b> . . . . .	<b>31</b>
<b>9.3</b>	<b>Getting Started</b> . . . . .	<b>31</b>
9.3.1	Hardware Settings . . . . .	31
9.3.2	Prepare the Demo . . . . .	31
<b>9.4</b>	<b>Run the demo</b> . . . . .	<b>32</b>
<b>9.5</b>	<b>Communication Interface Settings:</b> . . . . .	<b>32</b>
9.5.1	Customization Options . . . . .	32

## Chapter 10 Hardware Timer Demo

<b>10.1</b>	<b>Overview</b> . . . . .	<b>33</b>
<b>10.2</b>	<b>Supported Platforms</b> . . . . .	<b>33</b>
<b>10.3</b>	<b>Getting Started</b> . . . . .	<b>33</b>
10.3.1	Prepare the Demo . . . . .	33
10.3.2	Run the demo . . . . .	33
<b>10.4</b>	<b>Customization Options</b> . . . . .	<b>34</b>
10.4.1	Configure the Hardware Timer Used . . . . .	34
10.4.2	Configure which clock is used by the hardware timer . . . . .	34
10.4.3	Configure which instance of the module is used . . . . .	34
10.4.4	Hardware Timer Period . . . . .	34

## Chapter 11 I2C Communication Demo

<b>11.1</b>	<b>Overview</b> . . . . .	<b>35</b>
<b>11.2</b>	<b>Supported Platforms</b> . . . . .	<b>35</b>
<b>11.3</b>	<b>Getting Started</b> . . . . .	<b>35</b>
11.3.1	Hardware configuration . . . . .	35
11.3.2	Terminal configuration . . . . .	37
11.3.3	Run the demo . . . . .	37

Section number	Title	Page
<b>Chapter 12</b>		
<b>I2C Demo with RTOS</b>		
<b>12.1</b>	<b>Overview</b> . . . . .	<b>39</b>
<b>12.2</b>	<b>Supported RTOS</b> . . . . .	<b>39</b>
<b>12.3</b>	<b>Supported Platforms</b> . . . . .	<b>39</b>
<b>12.4</b>	<b>Getting Started</b> . . . . .	<b>40</b>
12.4.1	Build with different RTOS support . . . . .	40
12.4.2	Hardware configuration . . . . .	40
12.4.3	Prepare the Demo . . . . .	42
<b>12.5</b>	<b>Run the demo</b> . . . . .	<b>42</b>
<b>Chapter 13</b>		
<b>LPTMR Demo</b>		
<b>13.1</b>	<b>Overview</b> . . . . .	<b>43</b>
<b>13.2</b>	<b>Supported Platforms</b> . . . . .	<b>43</b>
<b>13.3</b>	<b>Getting Started</b> . . . . .	<b>43</b>
13.3.1	Prepare the Demo . . . . .	43
<b>13.4</b>	<b>Run the demo</b> . . . . .	<b>43</b>
<b>Chapter 14</b>		
<b>HTTP Server Demo on lwIP TCP/IP Stack</b>		
<b>14.1</b>	<b>Overview</b> . . . . .	<b>45</b>
<b>14.2</b>	<b>Supported RTOS</b> . . . . .	<b>45</b>
<b>14.3</b>	<b>Supported Hardware</b> . . . . .	<b>45</b>
<b>14.4</b>	<b>Getting Started</b> . . . . .	<b>45</b>
14.4.1	Prepare the Demo . . . . .	45
14.4.2	Network Configuration . . . . .	46
14.4.3	Run the demo . . . . .	46

Section number	Title	Page
<b>Chapter 15</b>		
<b>Ping Demo on lwIP TCP/IP Stack</b>		
<b>15.1</b>	<b>Overview . . . . .</b>	<b>47</b>
<b>15.2</b>	<b>Supported RTOS . . . . .</b>	<b>47</b>
<b>15.3</b>	<b>Supported Hardware . . . . .</b>	<b>47</b>
<b>15.4</b>	<b>Getting Started . . . . .</b>	<b>47</b>
15.4.1	Prepare the Demo . . . . .	47
15.4.2	Network Configuration . . . . .	48
<b>15.5</b>	<b>Run the demo . . . . .</b>	<b>48</b>
<b>Chapter 16</b>		
<b>TCP Echo Demo on lwIP TCP/IP Stack</b>		
<b>16.1</b>	<b>Overview . . . . .</b>	<b>49</b>
<b>16.2</b>	<b>Supported RTOS . . . . .</b>	<b>49</b>
<b>16.3</b>	<b>Supported Hardware . . . . .</b>	<b>49</b>
<b>16.4</b>	<b>Getting Started . . . . .</b>	<b>49</b>
16.4.1	Prepare the Demo . . . . .	49
16.4.2	Network Configuration . . . . .	50
<b>16.5</b>	<b>Run the demo . . . . .</b>	<b>50</b>
<b>Chapter 17</b>		
<b>UDP Echo Demo on lwIP TCP/IP Stack</b>		
<b>17.1</b>	<b>Overview . . . . .</b>	<b>51</b>
<b>17.2</b>	<b>Supported RTOS . . . . .</b>	<b>51</b>
<b>17.3</b>	<b>Supported Hardware . . . . .</b>	<b>51</b>
<b>17.4</b>	<b>Getting Started . . . . .</b>	<b>51</b>
17.4.1	Prepare the Demo . . . . .	51
17.4.2	Network Configuration . . . . .	52



Section number	Title	Page
<b>17.5</b>	<b>Run the demo</b> . . . . .	<b>52</b>

## Chapter 18 RTC Function Demo

<b>18.1</b>	<b>Overview</b> . . . . .	<b>53</b>
<b>18.2</b>	<b>Supported Hardware</b> . . . . .	<b>53</b>
<b>18.3</b>	<b>Getting Started</b> . . . . .	<b>53</b>
18.3.1	Prepare the Demo . . . . .	53
<b>18.4</b>	<b>Run the demo</b> . . . . .	<b>54</b>

## Chapter 19 SAI Demo

<b>19.1</b>	<b>Overview</b> . . . . .	<b>55</b>
<b>19.2</b>	<b>Supported Hardware</b> . . . . .	<b>55</b>
<b>19.3</b>	<b>Getting Started</b> . . . . .	<b>55</b>
19.3.1	GCC Compiler notes . . . . .	55
19.3.2	Hardware Settings . . . . .	55
19.3.3	Prepare the Demo . . . . .	56
<b>19.4</b>	<b>Run the demo</b> . . . . .	<b>56</b>
<b>19.5</b>	<b>Key Functions</b> . . . . .	<b>58</b>

## Chapter 20 SD Card Demo

<b>20.1</b>	<b>Overview</b> . . . . .	<b>61</b>
<b>20.2</b>	<b>Supported Hardware</b> . . . . .	<b>61</b>
<b>20.3</b>	<b>Getting Started</b> . . . . .	<b>61</b>
20.3.1	Prepare the Demo . . . . .	61
<b>20.4</b>	<b>Run the demo</b> . . . . .	<b>62</b>

Section number	Title	Page
	<b>Chapter 21</b>	
	<b>Watchdog Timer Reset Demo</b>	
<b>21.1</b>	<b>Overview . . . . .</b>	<b>63</b>
<b>21.2</b>	<b>Supported Hardware . . . . .</b>	<b>63</b>
<b>21.3</b>	<b>Getting Started . . . . .</b>	<b>63</b>
21.3.1	Hardware configuration . . . . .	63
21.3.2	Prepare the Demo . . . . .	64
<b>21.4</b>	<b>Run the demo . . . . .</b>	<b>64</b>

# Chapter 1

## ADC Hardware Trigger Demo

This demo application demonstrates how to use the ADC drivers with different hardware triggers.

### 1.1 Overview

This is an ADC demo application which shows how to use different hardware trigger sources to handle the ADC hardware trigger function. These trigger sources are supported:

- PIT (Periodic Interrupt Timer)
- PDB (Programmable Delay Block)
- LPTMR (Low Power Timer)

#### 1.1.1 Trigger by PIT

The Periodic Interrupt Timer (PIT) is a period timer source and the ADC hardware trigger event. Because the PIT trigger event can only be used to trigger one of the ADC channels (channel 0 or 1), this demo uses PIT as a trigger source for the ADCx channel 0. The PIT triggers the ADC in a fixed frequency and the demo gets the ADC conversion result in the ADC Conversion Complete (COCO) interrupt.

#### 1.1.2 Trigger by PDB

The Programmable Delay Block (PDB) is a continuous trigger event for ADC. It uses the software trigger as the first trigger input event and turns on the PDB continuous mode to generate a period trigger source. Because the PDB can trigger different channels inside one ADC instance, this demo shows the Ping-Pong triggering which occurs by sampling the channel 0/1 with the PDB Pre-trigger A/B channel.

#### 1.1.3 Trigger by LPTMR

The Low Power Timer (LPTMR) is a period timer source and the ADC hardware trigger event. Because the LPTMR trigger event can only be used to trigger one of the ADC channels (channel 0 or 1), this demo uses the LPTMR as a trigger source for the ADCx channel 0. The LPTMR triggers the ADC in a fixed frequency and the demo gets the ADC conversion result in the ADC Conversion Complete (COCO) interrupt.

## Run the demo

### 1.1.4 Input signal for ADC

Use the DAC module to generate a sine wave as the ADC input on the DAC0\_OUT pin. Because the DAC0\_OUT is internally connected to the ADC0\_SE23 (DAC0\_OUT is a source of ADC0\_SE23), there is no need to connect any external signals for this demo.

This demo samples the input digital signal from the ADC0\_SE23 pin and records each sample point with the appropriate amplitude. After 2 period samples are complete, it prints out the rough shape of the signal wave on the debug console like a primitive oscilloscope.

## 1.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK ADC Hardware Trigger demo.

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

## 1.3 Getting Started

### 1.3.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

## 1.4 Run the demo

1. Select and open one project from the three projects available: `adc_pit_trigger`, `adc_lptmr_trigger` and `adc_pdb_trigger`.
2. Open the UART console on a PC.
3. Download and run the program on the target.
4. The signal waveform is displayed on the console.

## 1.5 Customization Options

This demo application is customizable to show different kinds of input signal waves.

### 1.5.1 Default configurations

The configuration macro is located in the `adc_hw_trigger.h` header file.

#### 1.5.1.1 ADC configurations

1. Use ADC0 instance.
2. Use ADC\_SE23 input pin as sample pin.
3. Use VREFH/L as reference voltage.

#### 1.5.1.2 Sample frequency

The default sample rate is  $20 \text{ Hz} * 100 / 2$ , which enables the demo application to get 100 samples per two periods. To change the sample rate, see the next section.

### 1.5.2 Configure the number of samples

Printing of the signal wave shape depends on the console size. A console can be 100x40. To get the best printing effect, align the number of samples to the console column numbers and convert the amplitude range to the  $[0, \text{row} - 1]$  range. The console column number should be same as sample numbers. Configuring the number of samples means configuring the console column size:

```
#define CHART_ROWS 30U // chart row for sampled data
#define CHART_COLS 100U // chart column for sampled data
#define NR_SAMPLES 100U // number of samples in one period
```

### 1.5.3 Configure the signal frequency

Change the following macro to configure the desired frequency in Hz units.

```
#define INPUT_SIGNAL_FREQ 20U // in Hz
```

### 1.5.4 Configure the ADC instance

Change the `ADC_INST` macro to configure the ADC instance you want to use.

```
#define ADC_INST 0U // ADC instance
```

## Customization Options

### 1.5.5 Configure the ADC input pin

If you do not use the DAC0\_OUT as a input signal, disable the macro in the project:

```
//#USE_DAC_OUT_AS_SOURCE
```

After disabling the DAC output, configure one ADC input source pin to get the signal:

```
#define ADC_INPUT_CHAN    23U // default input signal channel
```

## Chapter 2

# ADC Low Power Demo

This demo application demonstrates how to use the ADC drivers in low power modes.

## 2.1 Overview

The ADC Low Power Demo project is a demonstration program that uses the KSDK software. The microcontroller is set to a very low power stop (VLPS) mode, and every 500 ms an interrupt wakes up the ADC module and takes the current temperature of the microcontroller. While the temperature remains within boundaries, both LEDs are off. If the temperature is higher than average, a red LED comes on. If it is lower, a blue LED comes on. This demo provides an example to show how ADC works during a VLPS mode and a simple debugging, "golden" project.

## 2.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the Kinetis software development kit ADC Low Power demo.

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

## 2.3 Getting Started

The ADC Low Power project is designed to work with the Tower System or in a stand alone setting.

### 2.3.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

## Getting Started

### 2.3.2 Run the demo

1. Set your target board in a place where the temperature is constant.
2. Press the reset button on your development board.
3. "ADC LOW POWER DEMO" message and some instructions should be displayed on the terminal.
4. Wait until the green or white LED light turns on.
5. Increment or decrement the temperature to see the changes.



## Chapter 3

### DAC ADC Demo

This demo application demonstrates the DAC and ADC demo.

#### 3.1 Overview

This application demonstrates how to configure the DAC and set the output on the DAC using software. It also demonstrates how to configure the ADC in 'Blocking Mode' and read ADC values.

#### 3.2 Supported Platforms

This demo supports these Freescale Freedom development platforms and Tower System modules:

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

#### 3.3 Getting Started

##### 3.3.1 Hardware Settings

This table shows the connections that are required for each of the supported platforms:

Platform	DAC Out		ADC In	
	Pin Name	Board Location	Pin Name	Board Location
<b>FRDM-K22F</b>	DAC0_OUT	J24-11	PTB0/ADC0_SE8	J24-2 (Arduino:A0)
<b>FRDM-K64F</b>	DAC0_OUT	J4-11	PTB2/ADC0_SE12	J4-2 (Arduino:A0)
<b>TWR-K22F120M</b>	DAC0_OUT	Primary Elevator - A32	PTB0/ADC0_SE8	Primary Elevator - B27
<b>TWR-K64F120M</b>	DAC0_OUT	Primary Elevator - A32	PTB4/ADC1_SE10	Primary Elevator - B27
<b>TWR-KV31F120-M</b>	DAC0_OUT	Primary Elevator - A32	PTE2/ADC1_SE6a	Primary Elevator - B27

##### 3.3.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.

## Run the demo

2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

### 3.4 Run the demo

This example shows how to run the demo on TWR-K22F120M:

```
DAC ADC Demo!
```

```
-----  
These pins are used for this demo.  
-----  
-----
```

```
DAC Out  
-----
```

```
DAC0_OUT (J24A-A32)  
-----  
-----
```

```
ADC In  
-----
```

```
PTB0/ADC0_SE8 (J24A-B27)  
-----  
-----
```

```
Press space bar to start the demo.
```

The user is prompted to enter a voltage to output on the DAC:

```
Select DAC output level:
```

1. 1.0 V
2. 1.5 V
3. 2.0 V
4. 2.5 V
5. 3.0 V

```
->
```

After entering a valid input, the ADC captures the voltage set by the DAC and displays the result in the terminal:

Select DAC output level:

1. 1.0 V
2. 1.5 V
3. 2.0 V
4. 2.5 V
5. 3.0 V

->3

ADC Value: 2471

ADC Voltage: 1.99

What next?:

1. Test another DAC output value.
2. Terminate demo.

->

At this point, the user can test another DAC output value or terminate the demo.

This configuration exhibits up to 2% error when reading back voltage.

### 3.5 Key Functions

#### **uint8\_t demo\_start(demo\_state\_t \*prevState)**

Prints out a welcome message and pins required by the demo.

Parameters

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

Returns

msg Returns the character entered into the terminal by user.

#### **uint8\_t device\_config(demo\_state\_t \*prevState)**

Configures the DAC and the ADC. The DAC is configured for software updates. The ADC is set in 'Blocking Mode'.

## Key Functions

### Parameters

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

### Returns

msg Returns 0.

### **uint8\_t dac\_set(demo\_state\_t \*prevState)**

Sets output level on the DAC.

### Parameters

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

### Returns

msg Returns the character entered into the terminal by user.

### **uint8\_t wait\_state(demo\_state\_t \*prevState)**

Performs a wait and possible state change based on the \*prevState.

### Parameters

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

### Returns

msg Returns 0.

### **uint8\_t adc\_get(demo\_state\_t \*prevState)**

Gets ADC values from a channel connected to the DAC output.

### Parameters

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

### Returns

msg Returns the character entered into the terminal by user.

**uint8\_t device\_deinit(demo\_state\_t \*prevState)**

Deinitializes the DAC and the ADC module following a user command to terminate the demo. Also frees allocated memory.

## Key Functions

### Parameters

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

### Returns

msg Returns 0.

### **uint8\_t demo\_end(demo\_state\_t \*prevState)**

Indicates to the user that the demo has been terminated.

### Parameters

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

### Returns

msg Returns 0.

## Chapter 4

### DSPI eDMA Demo

This demo application demonstrates how to use the DSPI and eDMA drivers.

#### 4.1 Overview

This application demonstrates how to configure the DSPI transfers using eDMA in both send and receive modes.

#### 4.2 Supported Platforms

This demo supports the following Freescale Freedom development platforms and Tower System modules:

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

#### 4.3 Getting Started

##### 4.3.1 Hardware Settings

Make these connections between the signals listed by using external wires . This demo uses the same board for both master and slave connections.

##### FRDM-K22F:

	Master			Connects To	Slave		
Signal	Pin Name	Board	Location		Pin Name	Board	Location
SS	PTD0	J2	- Pin 6	->	PTD4	J6	- Pin 4
SCK	PTD1	J2	- Pin 12	->	PTD5	J6	- Pin 5
Data In	PTD2	J2	- Pin 8	->	PTD7	J6	- Pin 7
Data Out	PTD3	J2	- Pin 10	->	PTD6	J6	- Pin 6

##### FRDM-K64F:

	Master		Connects To	Slave
--	--------	--	-------------	-------

## Getting Started

Signal	Pin Name	Board Location		Pin Name	Board Location
SS	PTD0	J2 - Pin 6	->	PTD4	J6 - Pin 4
SCK	PTD1	J2 - Pin 12	->	PTD5	J6 - Pin 5
Data In	PTD2	J2 - Pin 8	->	PTD7	J6 - Pin 7
Data Out	PTD3	J2 - Pin 10	->	PTD6	J6 - Pin 6

### TWR-K22F120M:

	Master		Connects To	Slave	
Signal	Pin Name	Board Location		Pin Name	Board Location
SS	PTD0	Primary Elevator - B46	->	PTB10	Primary Elevator - B9
SCK	PTD1	Primary Elevator - B48	->	PTB11	Primary Elevator - B7
Data In	PTD2	Primary Elevator - B45	->	PTB17	Primary Elevator - B11
Data Out	PTD3	Primary Elevator - B44	->	PTB16	Primary Elevator - B10

### TWR-K64F120M:

	Master		Connects To	Slave	
Signal	Pin Name	Board Location		Pin Name	Board Location
SS	PTD0	Primary Elevator - B46	->	PTB10	Primary Elevator - B9
SCK	PTD1	Primary Elevator - B48	->	PTB11	Primary Elevator - B7
Data In	PTD2	Primary Elevator - B45	->	PTB17	Primary Elevator - B11
Data Out	PTD3	Primary Elevator - B44	->	PTB16	Primary Elevator - B10

### TWR-KV31F120M :

	Master		Connects To	Slave	
Signal	Pin Name	Board Location		Pin Name	Board Location



<b>SS</b>	PTE16	Primary Elevator - B46	->	PTB10	Primary Elevator - B9
<b>SCK</b>	PTE17	Primary Elevator - B48	->	PTB11	Primary Elevator - B7
<b>Data In</b>	PTE18	Primary Elevator - B45	->	PTE3	Primary Elevator - B11
<b>Data Out</b>	PTE19	Primary Elevator - B44	->	PTE1	Primary Elevator - B10

### 4.3.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with the following settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

## 4.4 Run the demo

This output appears in the terminal window:

```
-----
-----
DSPI eDMA Demo
-----
```

```
DSPI Transfers using eDMA
-----
```

```
-----
-----
Configuration:
-----
```

```
Setting          | Value
```

```
:----- | :-----
```

```
Terminal Baud:  | 115200 bps
```

```
DSPI Bit rate: | User defined (3 kHz to 2 MHz)
```

## Run the demo

```
DSPI Master:   | DSPI0
DSPI Slave:    | DSPI1
```

The user enters the desired bit rate when this prompt appears:

```
Enter a SPI clock frequency between 3,000 Hz & 2,000,000 Hz below.
NOTE: If the number is less than 1,000,000 press enter after typing the number.
```

```
->
```

Upon successful completion of the demo this message appears in the terminal window:

```
Demo Complete.
```

```
128 loops completed.
```

```
g_slaveRxBuffer
```

00000123	00004567	000089AB	0000CDEF
0000FEDC	0000BA98	00007654	00003210
00000123	00004567	000089AB	0000CDEF
0000FEDC	0000BA98	00007654	00003210
00000123	00004567	000089AB	0000CDEF
0000FEDC	0000BA98	00007654	00003210
00000123	00004567	000089AB	0000CDEF
0000FEDC	0000BA98	00007654	00003210
00000123	00004567	000089AB	0000CDEF
0000FEDC	0000BA98	00007654	00003210
00000123	00004567	000089AB	0000CDEF
0000FEDC	0000BA98	00007654	00003210
00000123	00004567	000089AB	0000CDEF
0000FEDC	0000BA98	00007654	00003210
00000123	00004567	000089AB	0000CDEF
0000FEDC	0000BA98	00007654	00003210

```
Success! Slave received all the bytes from the Master.
```

```
masterRxBuffer
```

```

00000100      00000302      00000504      00000706
00000908      00000B0A      00000D0C      00000F0E
00001110      00001312      00001514      00001716
00001918      00001B1A      00001D1C      00001F1E
00002120      00002322      00002524      00002726
00002928      00002B2A      00002D2C      00002F2E
00003130      00003332      00003534      00003736
00003938      00003B3A      00003D3C      00003F3E
00004140      00004342      00004544      00004746
00004948      00004B4A      00004D4C      00004F4E
00005150      00005352      00005554      00005756
00005958      00005B5A      00005D5C      00005F5E
00006160      00006362      00006564      00006766
00006968      00006B6A      00006D6C      00006F6E
00007170      00007372      00007574      00007776
00007978      00007B7A      00007D7C      00007F7E

```

Final value of g\_slaveTxCount sent: 0x7F

Success! The Master received all the bytes from the slave correctly.

End of demo.

## 4.5 Key Functions

**void dspi\_edma\_master\_setup(uint8\_t instance, uint32\_t baudRateHz, uint8\_t transferSize-Bits)**

This function takes in the DSPI module instance, the desired data rate of DSPI transfers, the frame size of the data transfer, and initializes the DSPI master instance.

Parameters

<i>instance</i>	DSPI module instance
<i>baudRateHz</i>	Pass in the desired baud rate of DSPI transfers in Hz.
<i>transferSizeBits</i>	Pass data frame size (8 or 16 bit)

**void dspi\_edma\_slave\_setup(uint8\_t instance, uint8\_t transferSizeBits)**

This function takes in the DSPI module instance, the frame size of the data transfer, and initializes the DSPI slave instance.

## Key Functions

### Parameters

<i>instance</i>	DSPI module instance
<i>transferSizeBits</i>	Pass data frame size (8 or 16 bit)

### **dspi\_status\_t data\_source(uint8\_t \* sourceWord, uint32\_t instance)**

This is a callback function for the DSPI slave which transmits data from the slave. In this application, the function generates the slave data out which is a count.

### Parameters

<i>sourceWord</i>	8-bit data variable to be passed to slave PUSH register.
<i>instance</i>	Instance of the DSPI module.

### **void on\_error(dspi\_status\_t error, uint32\_t instance)**

This is a callback function for the DSPI slave which handles errors. In this application, the function sets the error flag to signal the end of the demonstration.

### Parameters

<i>error</i>	Uses dspi_status_t value given by driver interrupt handler.
<i>instance</i>	Instance of the DSPI module.

### **void setup\_edma\_loop(edma\_loop\_setup\_t \*loopSetup, uart\_state\_t \*uart)**

This function configures an eDMA transfer loop by using a loopSetup structure. If a valid uart\_state\_t is passed, the function prints out the TCD for that loop.

### Parameters

<i>loopSetup</i>	Data structure defined by user containing all parameters for the eDMA loop.
<i>uart</i>	Pointer to a valid uart_state_t for debug printing.

### **void disable\_edma\_loop(edma\_loop\_setup\_t \*loopSetup, uart\_state\_t \*uart)**

This function disables the user-configured eDMA transfer loop. It also frees memory allocated by the eDMA transfer loop. If a valid uart\_state\_t is passed to it, it prints out the TCD for that loop.

## Parameters

<i>loopSetup</i>	Data structure defined by user containing all parameters for the eDMA loop.
<i>uart</i>	Pointer to a valid <code>uart_state_t</code> for debug printing.

**void \*mem\_align(size\_t ptrSize, uint32\_t alignment)**

This function performs the aligned data memory allocation and is useful when the `mem_align` is not available.

## Parameters

<i>ptrSize</i>	<code>size_t</code> variable to pass size of memory to be allocated
<i>alignment</i>	<code>uint32_t</code> variable to pass byte size to align data with

## Returns

pointer to aligned & allocated memory

**void free\_align(void \*ptr)**

This function frees the memory allocated by the `mem_align`.

## Parameters

<i>ptr</i>	Pointer that has been allocated with the <code>mem_align</code> .
------------	---



## Key Functions

## Chapter 5

### Flash Demo

This demo application demonstrates how to use the Flash drivers.

#### 5.1 Overview

The Flash demo project shows how to erase, program, and performs swap (if available) on the Flash module. Targets exist for both Flash and SRAM memory space. The features include:

1. Full Flash erase and programming support
2. Flash Erase by block or sector, including margin read options
3. Programming region defined by user
4. Flash verify and checksum support
5. Flash Swap (if supported on device)

#### 5.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK Flash demo.

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

#### 5.3 Getting Started

The Flash Demo example code shows how to erase and program the Flash content and use the swap feature if it is supported on the device.

##### 5.3.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.

## Commands/Directions

4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

### 5.4 Commands/Directions

1. Select the Debug target from within the IDE and build the project selected for the target hardware. The default Debug target runs from flash and demonstrates the Swap feature for devices that support Swap (K64F).
2. Connect one end of the USB cable to a PC host and the other end to the OpenSDA connector on the board.
3. Open Terminal program such as TeraTerm, Putty, or Hyperterminal.
4. Configure the Terminal program to select the OpenSDA COMx port for the board using 115200 8N1: 115200 baud, 8 data bits, No parity, 1 Stop bit.
5. Connect to the board with the debugger (download & debug), run the program, and view the Terminal messages for Flash operations being performed.
6. For devices that support Swap, the Flash\_Debug target copies (programs) the application that is running from the lower block to the upper block and then issues swap commands.
7. Flash memory blocks are swapped at the next reset. Disconnect debug session and hit the reset button on the board. Note: During swap, memory locations 0x7F000 & 0xFF000 are swapped and displayed on the terminal showing how the memory map changes.
8. For devices that do not support swap, view the terminal messages for Flash operations that are occurring for the demo.
9. Terminal displays the message "Flash Demo Complete!" when finished.  
Note: Callback functions are not currently supported during flash erase or program operations  
Note: For K22F, Flash erase and program operations are not allowed in High-Speed RUN modes. Therefore, the core clock speed is restricted to 80 MHz or less.



## Chapter 6

# FlexCAN and UART communication Demo

This demo application demonstrates how to use the FlexCAN and UART drivers.

### 6.1 Overview

This is a FlexCAN and UART communication demo which demonstrates the communication between two boards which is handled by FlexCAN and the UART input/output. On one board, the user inputs characters by using the UART debug terminal and sends the data with the FlexCAN interface. On the other board, the FlexCAN receives the data and prints them to the UART terminal.

### 6.2 Supported Hardware

This Tower System module is supported by the KSDK FlexCAN and UART demo.

- TWR-K64F120M

### 6.3 Getting Started

#### 6.3.1 Hardware configuration

TWR-SER Tower System module configuration

1. Short J5(1-2), J5(3-4), J5(5-6), J5(7-8), and J5(9-10) to enable CAN connection.
2. Connect the two TWR-SER modules through the CAN port (J7).

#### 6.3.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.



## Run the demo

### 6.4 Run the demo

1. Select the node ID for each board by typing A/a or B/b followed by Enter.
2. You may now transfer characters by using serial terminals. For more details, see the video in the //video folder.

## Chapter 7

### FlexTimer PWM Demo

This demo application demonstrates the FlexTimer PWM demo.

#### 7.1 Overview

This application demonstrates the FTM edge-aligned PWM function. It outputs the PWM to control the intensity of the LED.

#### 7.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK FlexTimer demo.

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

#### 7.3 Getting Started

##### Hardware configuration

This table lists which FTM channels and MCU pins control which LEDs for this demo application. This table also lists which connections should be made (if any) to ensure proper demo operation.

Platform	FTM Instance/Chnl	MCU Pin	LED/Color	Jumper Config
FRDM-K22F	FTM0 - CH5	PTD5	D14 - Blue	N/A
FRDM-K64F	FTM0 - CH0	PTC1	D12 - Green	J1/P5 - J2/P1
TWR-K22F120M	FTM0 - CH4	PTD4	D7 - YEL/GRN	J16/P1-P2
TWR-K64F120M	FTM3 - CH1	PTE6	D5 - YEL/GRN	J30/P1-P2
TWR-KV31F120-M	FTM0 - CH7	PTD7	D7 - YEL/GRN	J17/P7-P8

NOTE: The FRDM-K64 requires an external jumper wire to make the appropriate connections.

##### 7.3.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.

## Getting Started

2. Open a serial terminal with the following settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

### 7.3.2 Run the demo

1. Download and run the `ftm_pwm` code to the board.
2. Terminal prints the message "Welcome to FTM PWM demo!"
3. The LED on board increases/decreases intensity according to PWM pulse width changes. The LED affected is indicated in the table in the Hardware Configurations part.

## Chapter 8

### GPIO I2C Demo

This demo application demonstrates the GPIO I2C demo.

#### 8.1 Overview

This demo application is a simulator which uses the GPIO to simulate the I2C protocol and control the MMA8451 or the FXOS8700CQ microcontrollers on the board. The UART console shows values received from the MMA8451 or the FXOS8700CQ.

#### 8.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK GPIO I2C demo.

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

#### 8.3 Getting Started

##### 8.3.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

#### Hardware configuration

These pins are used to connect to the accelerometer on the board:

## Getting Started

Platform	SCL	SDA
FRDM-K22F	PTB2	PTB3
FRDM-K64F	PTE24	PTE25
TWR-K22F120M	PTC10	PTC11
TWR-K64F120M	PTC10	PTC11
TWR-KV31F120M	PTD2	PTD3

### 8.3.2 Run the demo

1. Download the program to a target board.
2. Connect the USB cable to the PC host and open a serial terminal configured as shown in the table.
3. For the MMA8451, the UART outputs values in the X, Y, and Z direction, received from the MMA8451.

```
== Accelerometer Test ==
```

```
Reading acceleration data...  
x=4, y=1, z=1
```

4. For the FXOS8700CQ, UART provides output values in the X, Y, Z direction and magnetism.

```
== Accelerometer Test ==
```

```
Jan  8 2014   15:12:40  
Initializing FXOS...  
Resetting FXOS...  
Reading acceleration data...  
xAcc = 28, yAcc = -100, zAcc = 2075, xMag = 89, yMag = -55, zMag = 336
```

### 8.3.3 Customization Options

Parameters are available and can be configured to meet other requirements.

#### SCL and SDA configurations

The BOARD\_I2C\_GPIO\_SCL and BOARD\_I2C\_GPIO\_SDA macros define which GPIO pins are used to emulate I2C pins for the MMA8451 or FXOS8700CQ I2C interface.

These macros can be configured in mcu-sdk\boards\<board\_name>\board.h

```
#define BOARD_I2C_GPIO_SCL          GPIO_MAKE_PIN(HW_GPIOE, 24)  
#define BOARD_I2C_GPIO_SDA        GPIO_MAKE_PIN(HW_GPIOE, 25)
```

#### Baudrate configuration

To get the correct I2C baudrate, use an oscilloscope to look at the baudrate waveform.

A delay is used in this demo application for a correct baudrate. This is defined in the `mcu-sdk\boards\<board_name>\board.h` file.

```
#define BOARD_I2C_DELAY \
do \
{ \
    int32_t i; \
    for (i = 0; i < 500; i++) \
    { \
        __asm("nop"); \
    } \
} while (0)
```

Important things to remember:

- For a higher baudrate, reduce the delay time and loop count.
- For a lower baudrate, increase the delay time and loop count.
- Keep in mind code execution time.
- Use an oscilloscope to get the correct baudrate waveform.
- There is no delay in code execution in this demo application. Therefore, this might be the highest baudrate.
- See the I2C protocol and the MMA8451 and the FXOS microcontroller details for more information.





## Chapter 9

# Hello World Demo

This demo application demonstrates the Hello World demo.

### 9.1 Overview

The Hello World project is a simple demonstration program that uses the KSDK software. It prints the "Hello World" message to the terminal using the KSDK UART drivers. The purpose of this demo is to show how to use the UART and to provide a simple project for debugging and further development.

### 9.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK Hello World demo.

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

### 9.3 Getting Started

#### 9.3.1 Hardware Settings

The Hello World project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board jumper settings and configurations in default state when running this demo.

#### 9.3.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

## Communication Interface Settings:

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

### 9.4 Run the demo

This is an example how to run the demo.

```
Hello World!
```

### 9.5 Communication Interface Settings:

This part provides the information to customize the Hello World demo. The Hello World demo is configured to use these port pins for the platforms by default. If applicable for the board, jumpers are specified to select between serial output via OpenSDA and serial output via TWR-SER.

Platform	TX MCU Pin (Board Pin)	RX MCU Pin (Board Pin)	Module Instance
FRDM-K22F	PTE0 (N/A)	PTE1 (N/A)	UART1
FRDM-K64F	PTB17 (N/A)	PTB16 (N/A)	UART0
TWR-K22F120M	PTE0 (J30)	PTE1 (J29)	UART1
TWR-K64F120M	PTC4 (J15)	PTC3 (J10)	UART1
TWR-KV31F120M	PTB17 (J23)	PTB16 (J22)	UART0

#### 9.5.1 Customization Options

The `USE_STDIO_FUNCTIONS` define determines if the demo uses standard I/O functions, such as `printf`. If it is not defined, then the demo accesses the UART driver directly.

## Chapter 10

### Hardware Timer Demo

This demo application demonstrates using the hardware timer driver.

#### 10.1 Overview

The Hardware Timer project is a demonstration program to show how to use the Hardware Timer driver. An hwtimer interrupt is created and fires multiple times until it reaches the requested number.

#### 10.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the Kinetis SDK Hardware Timer demo.

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

#### 10.3 Getting Started

##### 10.3.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with the following settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

##### 10.3.2 Run the demo

1. Press the reset button on your board.
2. "Hwtimer Example" message is displayed on the terminal.

## Customization Options

3. A dot is printed when an hwtimer interrupt occurs until the `HWTIMER_DOTS_PER_LINE * HWTIMER_LINES_COUNT` (defined in `hwtimer_demo.c`) interrupts occur.
4. Finally, the "End" message is displayed.

```
Hwtimer Example
.....
.....
End
```

## 10.4 Customization Options

This demo application is customizable to show different types of hardware timers.

### 10.4.1 Configure the Hardware Timer Used

Determine which timer the hardware timer driver uses. The ARM core systick timer is used by default.

```
#define HWTIMER_LL_DEVIF    kSystickDevif
```

### 10.4.2 Configure which clock is used by the hardware timer

Determine which clock source is used by the hardware timer.

```
#define HWTIMER_LL_SRCCLK   kCoreClock
```

### 10.4.3 Configure which instance of the module is used

Determine which instance of the selected hardware module to use. For the systick timer only '0' is valid. If the PIT is used, use this to select the PIT channel.

```
#define HWTIMER_LL_ID       0
```

### 10.4.4 Hardware Timer Period

Determine the timer period (in microseconds).

```
#define HWTIMER_PERIOD      100000
```

---

## Chapter 11

### I2C Communication Demo

This demo application demonstrates the I2C demo.

#### 11.1 Overview

The I2C communication application demonstrates I2C data communication between two boards. It also features low power wakeup of the slave board by using I2C address matching.

First, the I2C slave board enters the low power wait mode. An LED on the I2C slave board is on to indicate that the MCU is in sleep mode and no code is running.

Then, the I2C slave board is woken up by the I2C address matching interrupt when the I2C master boards sends the proper address. The LED on the I2C slave board is toggled during the data communication.

After power on, the I2C master starts reading data from the I2C slave data buffer. The I2C slave has "sub" addresses to access a specific byte of data on the slave board. The master prints this data out via the serial terminal. The master can then modify the data at a specific "sub" address on the slave board. When the data is received, the I2C slave changes the content at that requested "sub" address. This change is reflected when the master reads the slave data buffer again.

#### 11.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK I2C Communication demo.

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

#### 11.3 Getting Started

##### 11.3.1 Hardware configuration

This demo requires two separate boards. Make these connections between the two boards by using external wires:

##### FRDM-K22F:

---

## Getting Started

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTB2/I2C0_SCL	J24 Pin 12	->	PTB2/I2C0_SCL	J24 Pin 12
PTB3/I2C0_SDA	J24 Pin 10	->	PTB3/I2C0_SDA	J24 Pin 10
GND	J2 Pin 14	->	GND	J2 Pin 14

### FRDM-K64F:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTE24/I2C0_SCL	J2 Pin 20	->	PTE24/I2C0_SCL	J2 Pin 20
PTE25/I2C0_SDA	J2 Pin 18	->	PTE25/I2C0_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

### TWR-K22F120M & TWR-KV31F120M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTE24/I2C0_SCL	Primary Elevator A7	->	PTE24/I2C0_SCL	Primary Elevator A7
PTE25/I2C0_SDA	Primary Elevator A8	->	PTE25/I2C0_SDA	Primary Elevator A8
GND	Primary Elevator A6	->	GND	Primary Elevator A6

### TWR-K64F120M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTC10/I2C1_SCL	Primary Elevator A75	->	PTC10/I2C1_SCL	Primary Elevator A75
PTC11/I2C1_SDA	Primary Elevator A60	->	PTC11/I2C1_SDA	Primary Elevator A60
GND	Primary Elevator A65	->	GND	Primary Elevator A65

### 11.3.2 Terminal configuration

Configure the PC host serial console as shown:

- 115200 baud rate
- 8 data bits
- No parity
- One stop bit
- No flow control

### 11.3.3 Run the demo

1. Connect the I2C slave board to the master board using the connections listed above.
2. Power on the I2C slave board.
3. Download and run the `i2c_comm_slave` project to the I2C slave board.
4. The terminal of the I2C slave board prints out a "=====`I2C Slave`====" message.
5. Power on the I2C master board.
6. Download and run the `i2c_comm_mstr` project to the I2C master board.
7. The terminal of the I2C master board prints out a "=====`I2C Master`====" message and the data received from the I2C slave.
8. The I2C slave project creates some "sub" addresses to access a specific byte of data on the slave board. The master reads all these "sub" addresses and prints out the data.

Slave Sub Address	Character
[0]	I
[1]	2
[2]	C
[3]	-
[4]	C
[5]	O
[6]	M
[7]	M

9. To change the I2C slave sub address content, input a new character in the I2C master command line:

```
Input slave sub address and the new character.
Slave Sub Address: 5
Input New Character: F
```

10. The master then displays the updated content on the terminal output.

Slave Sub Address	Character
[0]	I
[1]	2

## Getting Started

[2]	C
[3]	-
[4]	C
[5]	F
[6]	M
[7]	M



## Chapter 12

### I2C Demo with RTOS

This demo application demonstrates the I2C demo on different RTOS.

#### 12.1 Overview

This I2C application demonstrates the SDK Peripheral drivers working on different RTOSes. The application acts as both the I2C master and the slave device on different I2C buses, such as the I2C Master on the I2C0 bus and the I2C Slave on the I2C1 bus. It can run on a single board or on two different boards. When connecting the two I2C buses on one board, the master sends the command using the I2C0 bus to the slave using the I2C1 bus. When connecting the I2C0 bus to the I2C1 bus on the other board, the application running on the first board is a master and sends a command to the other board which acts as a slave. This means that the first board can send a command and get a response from the other board by using the I2C bus. The basic purpose of this demo is:

1. Read the Kinetis chip UID (low 32bits) from the slave board
2. Read the Kinetis chip internal temperature from the slave board
3. Control the RED/GREEN/BLUE color LEDs on the slave board

The application creates three different tasks to handle events concurrently:

1. Master task: responds to the user interface interaction, runs as a I2C master, and acts as a simple UI. It accepts user's commands to read the basic chip UID, chip temperature and control the on board LED, and power mode on the slave.
2. Slave task: responds to the command received from the I2C master and returns the result to the master.
3. ADC sample task: responds to getting the chip temperature in a period.
4. For the bare metal version, the master and slave tasks are separated into two separate projects.

#### 12.2 Supported RTOS

- Freescale MQX™ RTOS
- FreeRTOS
- µC/OS-II
- µC/OS-III
- Bare Metal (no RTOS)

#### 12.3 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK I2C demo with RTOS.

- FRDM-K22F
- FRDM-K64F

## Getting Started

- TWR-K22F120M
- TWR-K64F120M

### 12.4 Getting Started

The I2C RTOS application is designed to work on one single board or two different boards. Note that the bare-metal version only supports two boards.

#### 12.4.1 Build with different RTOS support

Before running this application, build it with the RTOS you want to use. The projects for different RTOSes are differentiated by the workspace file name in the format of `i2c_rtos_<rtos>.eww`. For example, in IAR, the `i2c_rtos_ucosii.eww` workspace file is the  $\mu$ C/OS-II version of this application. After opening the appropriate workspace, build the `ksdk_<rtos>_lib` project and build the application project. A binary named `i2c_rtos_<rtos>.out` is generated.

#### 12.4.2 Hardware configuration

Make the connections between the listed signals by using the external wires.

#### Freescal Freedom FRDM-K22F

FRDM-K22F Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
PTB2/I2C0_SCL	J24 - Pin 12	->	PTC10/I2C1_SCL	J1 - Pin 13
PTB3/I2C0_SDA	J24 - Pin 10	->	PTC11/I2C1_SDA	J2 - Pin 7

FRDM-K22F Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
PTB2/I2C0_SCL	J24 - Pin 12	->	PTC10/I2C1_SCL	J1 - Pin 13
PTB3/I2C0_SDA	J24 - Pin 10	->	PTC11/I2C1_SDA	J2 - Pin 7
GND	TP21	->	GND	TP21

#### Freescal Freedom FRDM-K64F

FRDM-K64F Single Board
------------------------

Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
PTE24/I2C0_SCL	J2 - Pin 20	->	PTC10/I2C1_SCL	J4 - Pin 12
PTE25/I2C0_SDA	J2 - Pin 18	->	PTC11/I2C1_SDA	J4 - Pin 10

FRDM-K64F Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
PTE24/I2C0_SCL	J2 - Pin 20	->	PTC10/I2C1_SCL	J4 - Pin 12
PTE25/I2C0_SDA	J2 - Pin 18	->	PTC11/I2C1_SDA	J4 - Pin 10
GND	J2 - Pin 14	->	GND	J2 - Pin 14

### TWR-K22F120M Tower System module

TWR-K22F120M Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
PTE24/I2C0_SCL	Primary Elevator - Pin A7	->	PTC10/I2C1_SCL	Primary Elevator - Pin B50
PTE25/I2C0_SDA	Primary Elevator - Pin A8	->	PTC11/I2C1_SDA	Primary Elevator - Pin B51

TWR-K22F120M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
PTE24/I2C0_SCL	Primary Elevator - Pin A7	->	PTC10/I2C1_SCL	Primary Elevator - Pin B50
PTE25/I2C0_SDA	Primary Elevator - Pin A8	->	PTC11/I2C1_SDA	Primary Elevator - Pin B51
GND	Primary Elevator - Pin A65	->	GND	Primary Elevator - Pin A65

### TWR-K64F120M Tower System module

TWR-K64F120M Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location

## Run the demo

PTD8/I2C0_SCL	Primary Elevator - Pin A7	->	PTC10/I2C1_SCL	Primary Elevator - Pin A75
PTD9/I2C0_SDA	Primary Elevator - Pin A8	->	PTC11/I2C1_SDA	Primary Elevator - Pin B71

TWR-K64F120M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
PTD8/I2C0_SCL	Primary Elevator - Pin A7	->	PTC10/I2C1_SCL	Primary Elevator - Pin A75
PTD9/I2C0_SDA	Primary Elevator - Pin A8	->	PTC11/I2C1_SDA	Primary Elevator - Pin B71
GND	Primary Elevator - Pin A65	->	GND	Primary Elevator - Pin A65

### 12.4.3 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

### 12.5 Run the demo

This menu displays in the terminal window:

```
Available Commands:
LED Red Toggle (1)   - Red Light toggles on/off
LED Green Toggle (2) - Green Light toggles on/off
LED Blue Toggle (3)  - Blue Light toggles on/off
Read Temperature (4) - Get temperature of client
Read Id (5)          - Read client unique ID
```

Enter your choice (1 - 5):

You can select to toggle the RGB LED, read the temperature of the client board, and read the client unique ID.

## Chapter 13

### LPTMR Demo

This demo application demonstrates the LPTMR demo.

#### 13.1 Overview

The LPTMR (Low Power Timer) project is a simple demonstration program to show how to use the LPTMR driver. It triggers an LPTMR interrupt once every second, and prints out the number of interrupts that have occurred since the program started running.

#### 13.2 Supported Platforms

This demo supports the following Freescale Freedom development platforms and Tower System modules:

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

#### 13.3 Getting Started

##### 13.3.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with the following settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

#### 13.4 Run the demo

An LPTMR interrupt occurs every second and prints out to the serial terminal the number of interrupts that have occurred since the program started running. The LPTMR module uses the internal 1 kHz Low Power Oscillator (LPO) as its clock source for this demo.

The output on the serial terminal is as shown:

## Run the demo

```
Low Power Timer Example
Started LPTMR
1 2 3 4 5 6 7
```

## Chapter 14

# HTTP Server Demo on lwIP TCP/IP Stack

This demo application demonstrates the HTTPServer demo on lwIP TCP/IP stack with bare metal SDK or different RTOSes.

### 14.1 Overview

This is an HTTPServer set up on lwIP TCP/IP stack with bare metal SDK or different RTOSes. The user uses an Internet browser to send a request for connection. The board acts as an HTTP server and sends a Web page back to the PC.

### 14.2 Supported RTOS

- Freescale MQX™ RTOS
- FreeRTOS
- µC/OS-II
- µC/OS-III
- Bare Metal (no RTOS)

### 14.3 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the Kinetis software development kit HTTPServer demo.

- FRDM-K64F
- TWR-K64F120M

### 14.4 Getting Started

See the *lwIP TCPIP Stack and Kinetis SDK Integration User's Guide* (document KSDKLWIPUG) for more information about the setup and requirements.

#### 14.4.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with the following settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.

## Getting Started

4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions steps, see a Kinetis SDK User's Guide for your board.

### 14.4.2 Network Configuration

Configure the IP address of PC network adapters as shown: IP address - 192.168.2.100 Subnet Mask - 255.255.255.0

### 14.4.3 Run the demo

1. Download the program to target board, which should be installed in TWR or FRDM.
2. Connect the Ethernet cable between the PC and the board.
3. When successfully connected, reset the board to run the demo.
4. Open the PC command window, type in "ping 192.168.2.102" to test whether lwIP stack is running.  
If successful,  
four echo request packets are successfully replied.
5. Input "192.168.2.102" in the URL of an Internet browser on a PC. If successful, the web page the board returns opens in the browser.



## Chapter 15

### Ping Demo on lwIP TCP/IP Stack

This demo application demonstrates the Ping demo on lwIP TCP/IP stack with bare metal SDK or different RTOSes.

#### 15.1 Overview

This is a Ping Demo on the lwIP TCP/IP stack which uses the ICMP protocol. The application on board periodically sends the ICMP echo request to a PC and processes the PC reply. Type the "ping \$board\_address" in the PC command window to send an ICMP echo request to the board. The lwIP stack sends the ICMP echo reply back to the PC.

#### 15.2 Supported RTOS

- Freescale MQX™ RTOS
- FreeRTOS
- µC/OS-II
- µC/OS-III
- Bare Metal (no RTOS)

#### 15.3 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK Ping demo.

- FRDM-K64F
- TWR-K64F120M

#### 15.4 Getting Started

See the *lwIP TCPIP Stack and Kinetis SDK Integration User's Guide* (document KSDKLWIPUG) for instructions and requirements.

##### 15.4.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control

## Run the demo

3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

### 15.4.2 Network Configuration

Configure the IP address of PC network adapters as shown:

- 192.168.2.100

### 15.5 Run the demo

1. Download the program to the target board.
2. Connect the Ethernet cable between the PC and the board.
3. When successfully connected, reset the board to run the demo.
4. Open the terminal. Ping send and ping receive are successful.
5. Type in "ping 192.168.2.102" in PC command window. If the operation is successful, four packets are successful replied.

## Chapter 16

### TCP Echo Demo on lwIP TCP/IP Stack

This demo application demonstrates the TCP Echo demo on lwIP TCP/IP stack with bare metal SDK or different RTOSes.

#### 16.1 Overview

This is a TCP echo demo on the lwIP TCP/IP stack with bare metal SDK or different RTOSes, which uses the TCP protocol and acts as an echo server. The application on board sends back the TCP packets from the PC, which can be used to test whether the TCP connection is available.

#### 16.2 Supported RTOS

- Freescale MQX™ RTOS
- FreeRTOS
- µC/OS-II
- µC/OS-III
- Bare Metal (no RTOS)

#### 16.3 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK TCP Echo demo.

- FRDM-K64F
- TWR-K64F120M

#### 16.4 Getting Started

See the *lwIP TCPIP Stack and Kinetis SDK Integration User's Guide* (document KSDKLWIPUG) for instructions and requirements.

##### 16.4.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.

## Run the demo

4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

### 16.4.2 Network Configuration

Configure the IP address of PC network adapters as shown:

- 192.168.2.100

## 16.5 Run the demo

1. Download the program to the target board.
2. Connect the Ethernet cable between the PC and the board.
3. When successfully connected, reset the board to run the demo.
4. Open the command window on PC, type in "ping 192.168.2.102" to test whether the LwIP is running.
5. If it is running, use an external echo tool to perform the echo request. This tool sends TCP packets to the board and checks whether the content sent back from board is the same. A similar tool named "echotool" can be downloaded from the: <http://bansky.net/echotool/> [example: echotool 192.168.2.102 /p tcp /r 7 /d hello]
6. If the operation is successful, all packets sent back are same as the packets sent to the board.

## Chapter 17

### UDP Echo Demo on lwIP TCP/IP Stack

This demo application demonstrates the UDP Echo demo on lwIP TCP/IP stack with bare metal SDK or different RTOSes.

#### 17.1 Overview

This is a UDP echo demo on the lwIP TCP/IP stack with bare metal SDK or different RTOSes, which uses the UDP protocol and acts as an echo server. The application on board sends back the UDP packets from the PC, which can be used to test whether the UDP connection is available.

#### 17.2 Supported RTOS

- Freescale MQX™ RTOS
- FreeRTOS
- µC/OS-II
- µC/OS-III
- Bare Metal (no RTOS)

#### 17.3 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK UDP Echo demo.

- FRDM-K64F
- TWR-K64F120M

#### 17.4 Getting Started

See the *lwIP TCPIP Stack and Kinetis SDK Integration User's Guide* (document KSDKLWIPUG) for instructions and requirements.

##### 17.4.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.

## Run the demo

4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

### 17.4.2 Network Configuration

Configure the IP address of PC network adapters as shown:

- 192.168.2.100

### 17.5 Run the demo

1. Download the program to the target board.
2. Connect the Ethernet cable between the PC and the board.
3. When successfully connected, reset the board to run the demo.
4. Open the command window on PC, type in "ping 192.168.2.102" to test whether the lwIP is running.
5. If it is running, use an external echo tool to perform the echo request. This tool sends UDP packets to the board and checks whether the content sent back from board is the same. A similar tool named "echotool" can be downloaded from the: <http://bansky.net/echotool/> [example: echotool 192.168.2.102 /p udp /r 7 /d hello]
6. If the operation is successful, all packets sent back are the same as the packets sent to the board.

## Chapter 18

### RTC Function Demo

This demo application demonstrates how to use the RTC driver.

#### 18.1 Overview

This RTC demo application demonstrates the important features of the RTC Module by using the RTC Peripheral Driver. It supports these features:

- Calendar
  - Get the current date time with Year, Month, Day, Hour, Minute and Second.
  - Set the current date time with Year, Month, Day, Hour, Minute and Second.
- Alarm
  - Set the alarm based on the current time.
  - Application prints a notification when the alarm expires.
- Seconds interrupt
  - Use second interrupt function to display a digital time blink every second.
- Compensation
  - Configure the compensation with cycles.
  - The 1 Hz RTC clock with compensation configured is output to a pin. Use an oscilloscope to check the compensation result.

#### 18.2 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK RTC Function demo.

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M

#### 18.3 Getting Started

##### 18.3.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with the following settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control

## Run the demo

3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

## 18.4 Run the demo

This menu is displayed on the serial terminal:

```
Please choose the sub demo to run:
1) Get current date time.
2) Set current date time.
3) Alarm trigger show.
4) Second interrupt show (demo for 20s).
5) Set RTC compensation.
```

Select:



## Chapter 19

### SAI Demo

This demo application demonstrates how to use the SAI drivers.

#### 19.1 Overview

The SAI Demo project is a digital audio demonstration program that uses the KSDK software. It performs audio playback from either a .wav file, stored in Flash, or from the line-in on a TWR-AUDIO-SGTL Tower System module using the KSDK I2S and I2C drivers. On the TWR-K22F120M and the TWR-K64F120M Tower System modules, the project also uses the CMSIS-DSP library to perform a Fast Fourier Transform, and return the fundamental frequency of the line-in audio.

#### 19.2 Supported Hardware

This demo supports the following Freescale Freedom development platforms and Tower System modules:

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

#### 19.3 Getting Started

##### 19.3.1 GCC Compiler notes

When building the demo with GCC, ensure that the demo and platform library are built with this option:

```
CHOOSE_FLOAT=HARD_FP
```

Otherwise, the project does not use the Kinetis device's hardware floating point when using the CMSIS--DSP library.

##### 19.3.2 Hardware Settings

These Tower System modules are required to run the sai\_demo:

- TWR-ELEV
- TWR-AUDIO-SGTL

## Run the demo

### 19.3.3 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

## 19.4 Run the demo

To hear the audio playback, connect a set of headphones to the headphone output on the TWR-AUDIO--SGTL card. For input to the codec, connect an audio source to the Line-In on the TWR-AUDIO-SGTL.

When the demo starts, this message is displayed in the terminal output window:

```
Audio Demo!
```

```
Press spacebar to start demo.
```

```
Demo begin...
```

The user can either play back audio from the line-in source, or play a .wav file stored in the Flash.

The line-in option plays the audio gathered from the codec line-in for approximately 15 seconds.

```
Select player:
```

- 1. Line-In Playback
- 2. Wav File Playback

```
->1
```

If selecting playback from the line-in source, decide whether to perform an FFT analysis to find the fundamental frequency of the audio input. Finding the fundamental frequency is best suited for pure tones played into the line-in of the TWR-AUDIO-SGTL card.

```
Select filter:
```

- 1. FFT - Find Fundamental Frequency
- 2. None

```
->1
```

The user is prompted to select from a list of headphone output levels:

Choose headphone dB level:

1. +3.0 dB
2. 0.0 dB
3. -3.0 dB
4. -6.0 dB
5. -12.0 dB
6. -24.0 dB
7. -48.0 dB

->5

Frequency is 93 Hz

The table shows the terminal display after playback has completed and the FFT option was selected.

These are the options for the .wav file option:

Select player:

1. Line-In Playback
2. Wav File Playback

->2

Select Wav file:

1. Audio Demo

->1

Choose headphone dB level:

1. +3.0 dB
2. 0.0 dB
3. -3.0 dB
4. -6.0 dB
5. -12.0 dB
6. -24.0 dB
7. -48.0 dB

->5

The quality of the .wav file PCM data depends on the demo system and the compiler.

The table below shows the audio sample rate, channels and bit depth of the .wav file for the various platforms and compilers.

Hardware System	Sample Rate (kHz)				Bit Depth				Channels			
	IAR	ARM	GN- U-G- CC	KDS- GCC	IAR	ARM	GN- U-G- CC	KDS- GCC	IAR	ARM	GN- U-G- CC	KDS- GCC
<b>TW- R-- K64- F120- M</b>	44.1	44.1	44.1	44.1	32	32	32	32	2	2	2	2

## Key Functions

<b>TW-R-K22-F120-M</b>	44.1	44.1	11.-025	11.-025	16	16	16	16	2	2	2	2
<b>TW-R-K22-F120-M256</b>	11.-025	11.-025	11.-025	11.-025	16	16	16	16	2	2	1	1
<b>TW-R-K22-F120-M128</b>	11.-025	11.-025	11.-025	11.-025	16	16	16	16	2	2	1	1

Quality differences of the .wav playback depend on the size constraints of the target device, the Flash size, and the density of the code generated by the compiler.

Note that all supported platforms play audio from the line-in option with the same quality: 16-bit, 44.1 kHz, 2 channels.

## 19.5 Key Functions

### **void audio\_stream\_init(void)**

Initializes the I2S, I2C, and TWR-AUDIO-SGTL Tower System module for streaming audio from Line-In.

### **void audio\_wav\_init(wave\_file\_t \*newWav)**

Initializes the I2S, I2C, and TWR-AUDIO-SGTL Tower System module for playing back WAV file in Flash.

Parameters

<i>newWav</i>	Pointer to wave file data structure.
---------------	--------------------------------------

### **uint32\_t config\_volume(sgtl\_handler\_t \*handler, sgtl\_module\_t module, uint32\_t volume-Ctrl)**

Sets volume from the user input.

## Parameters

<i>handler</i>	pointer to codec handler structure.
<i>module</i>	name of module on codec to set the volume for.
<i>volumeCtrl</i>	user input data from terminal menu.

## Returns

status\_t Return kStatus\_Success if function completed successfully, return kStatusFail if function failed.

**snd\_status\_t stream\_audio(dsp\_types\_t dspType, uint8\_t volumeCtrl)**

Plays a stream of audio.

## Parameters

<i>dspType</i>	Used to select one DSP function to perform on the data.
<i>volumeCtrl</i>	Value used to set decibel level on codec.

## Returns

Returns soundcard status

**snd\_status\_t get\_wav\_data(wave\_file\_t \*waveFile)**

Collects data from WAV file header.

## Parameters

<i>waveFile</i>	Data structure of pcm data array.
-----------------	-----------------------------------

## Returns

status\_t Return kStatus\_Success if function completed successfully, return kStatusFail if function failed.

**snd\_status\_t play\_wav(uint32\_t \*pcmBuffer, uint8\_t volumeCtrl)**

Plays the PCM audio data from the WAV format array.

## Key Functions

### Parameters

<i>pcmBuffer</i>	Pointer to data array containing WAV formatted audio data.
<i>volumeCtrl</i>	Value used to set decibel level on codec.

### Returns

status\_t Return kStatus\_Success if function completed successfully, return kStatusFail if function failed.

**void send\_wav(uint8\_t \*dataBuffer, uint32\_t length, sai\_data\_format\_t \*dataFormat)**

Sends audio data to the sound card.

### Parameters

<i>pdataBuffer</i>	Pointer to data array containing WAV formatted audio data.
<i>length</i>	length of WAV file to send.
<i>dataFormat</i>	Point to audio_data_format_t for sound card.

**float32\_t do\_fft(sai\_data\_format\_t \*dataFormat, uint8\_t \*buffer, float32\_t \*fftData, float32\_t \*fftResult)**

Performs frequency analysis and finds fundamental frequency of the PCM data.

### Parameters

<i>dataFormat</i>	Pointer to audio data format structure.
<i>buffer</i>	Pointer to data array to store modulated PCM data.
<i>fftData</i>	Pointer to data array for storing Fast Fourier Transform data.
<i>fftResult</i>	Point to data array for storing real frequency bins from FFT.

### Returns

float32\_t Returns fundamental frequency in Hz.

## Chapter 20

### SD Card Demo

This demo application demonstrates the SD Card demo.

#### 20.1 Overview

The SD Card demo application demonstrates the use of SD card driver. It displays the card information followed by a write-read compare test and the erase operation.

#### 20.2 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK SD Card demo.

- FRDM-K64F
- TWR-K64F120M

#### 20.3 Getting Started

##### Hardware configuration

There is no specific hardware requirement. The default configuration of the supported targets is sufficient for this demo. The demo uses the on-board connector support for the card detect signal which is connected to a GPIO line for card detection.

##### 20.3.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with the following settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

## **Run the demo**

### **20.4 Run the demo**

1. Insert an SD or a micro-SD card depending on the connector on board. Ensure that the card doesn't contain any important content because the demo will erase and overwrite some sectors.
2. After the card detection, the card-specific information, such as capacity, is shown. Then, the user is encouraged to back up data as needed. A write-read-compare access is performed to demonstrate the use case.
3. If the card was not inserted as mentioned in step 1, the demo waits for the card insertion. Once a card is inserted, it auto-detects and proceeds as shown in step 3.



## Chapter 21

# Watchdog Timer Reset Demo

This demo application demonstrates the Watchdog Timer Reset demo.

### 21.1 Overview

The Watchdog Timer Reset demo application demonstrates how the Watchdog module can be used to reset a device. The overflow time for a Watchdog timer is approximately 2 seconds.

### 21.2 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK Watchdog Timer Reset demo.

- FRDM-K22F
- FRDM-K64F
- TWR-K22F120M
- TWR-K64F120M
- TWR-KV31F120M

### 21.3 Getting Started

#### 21.3.1 Hardware configuration

These switch buttons are used by this demo:

Platform	Switch	Notes
FRDM-K22F	SW2	
FRDM-K64F	SW2	
TWR-K22F120M	SW1	
TWR-K64F120M	SW1	
TWR-KV31F120M	SW1	Jumper J26 should be removed

Note that on the some boards, the reset source information printed out to the terminal may be incorrect and may sometimes display an "External Pin Reset" message. This occurs when the Watchdog resets the system, and the OpenSDA circuit also sends a pin reset to the target MCU through the voltage level translator. Sometimes this translator can't pull up the pin in time and the duration of the low level of this pin is long. When this occurs, the Watchdog reset status is overridden by the external pin reset and the message "External Pin Reset" is output to the terminal.

## Run the demo

### 21.3.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with the following settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Press either the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

### 21.4 Run the demo

1. When the program is running, the Watchdog is enabled. The program continuously refreshes the Watchdog to prevent the CPU reset.
2. The message: "Watchdog example running, Loop #: xx, press <SW> to start watchdog timeout..." displays on the terminal.
3. An LED also blinks. The color of the LED depends on the board:

Platform	LED Color
FRDM-K22F	Red
FRDM-K64F	Red
TWR-K22F120M	Yellow
TWR-K64F120M	Yellow
TWR-KV31F120M	Red

1. When the SW button is pressed, the LED begins to blink rapidly, signifying that the Watchdog is about to expire.
2. When the Watchdog signals a reset, the "Watchdog (COP) Reset" message and "Watchdog (COP) reset count: xx" message is output to the terminal.

/\*!

## Chapter 22

### Revision History

This table summarizes revisions to this document.

Revision History		
Revision number	Date	Substantial changes
1.0.0	7/2014	Initial release

***How to Reach Us:***

**Home Page:**  
[freescale.com](http://freescale.com)

**Web Support:**  
[freescale.com/support](http://freescale.com/support)

Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address:

[freescale.com/SalesTermsandConditions](http://freescale.com/SalesTermsandConditions).

Freescale, the Freescale logo, and Kinetis are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. Tower is a trademark of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. ARM and Cortex are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere.

© 2014 Freescale Semiconductor, Inc.

