

## Raspberry Pi - VNC autostart

**Noteboo...** iraspberrypi

**Created:** 8/31/2014 3:06 PM

**Updated:** 8/31/2014 3:26 PM

**Author:** Navan Muiadiva

**Location:** Bangalore Urban, Karnataka...

---

install tightvncserver on RPi

```
sudo apt-get update
```

```
sudo apt-get install tightvncserver
```

if you want the VNC server to automatically start whenever you restart your Raspberry Pi, follow these steps:

```
cd /home/pi
```

```
cd .config
```

```
mkdir autostart
```

```
cd autostart
```

```
nano tightvnc.desktop
```

Paste the following into the editor window :

```
[Desktop Entry]
```

```
Type=Application
```

```
Name=TightVNC
```

```
Exec=vncserver :1
```

```
StartupNotify=false
```