



When Cura4.4 is installed, open the main interface.



Click on the top right corner to add a new machine model.



Add Printer

Add a printer

Add a networked printer

Add a non-networked printer

Ultimaker B.V.

Custom

Custom FFF printer

DeltaBot

101Hero

3Dator GmbH

3DMaker

ABAX 3d Technologies

Alfawise

Anet

Anycubic

Printer name

LK4

Cancel

Add

Add Printer

Machine Settings

Printer

Printer Settings

X (Width)

220

440 mm

Y (Depth)

220

440 mm

Z (Height)

250

450 mm

Build plate shape

Rect...

Origin at center

Heated bed

Heated build volume

G code flavor

Marlin

Start G-code

G90

G28 ;Home

G1 Z15.0 F6000 ;Move the pla

Extruder 1

Printhead Settings

X min

20

40 mm

Y min

10

10 mm

X max

10

10 mm

Y max

10

10 mm

Gantry Height

9999999

9999999 mm

Number of Extruders

1


End G-code

M104 S0

M140 S0

;Retract the filament

Next

 Add Printer

X

Machine Settings

Printer

Extruder 1

Nozzle Settings

Nozzle size

0.4mm

0.4

Compatible material diameter

1.75mm

1.75

Nozzle offset X

0

mm

Nozzle offset Y

0

mm

Cooling Fan Number


0

Extruder Start G-code

Extruder End G-code

Next

The PLA default configuration parameters of Cura4.4 are reasonable, so they can be used without modification.



After adding the model, select the precision of the print will automatically generate the slice, save it to the TF card and print it normally.