

6-3. Initialization

Items to initialize

The following items must be initialized for normal system operation in cases such as after maintenance is performed on the vehicle.

Item	When to initialize	Reference
Maintenance data (U.S.A. only)	After the maintenance is performed	P. 321
Tire pressure warning system (if equipped)	<ul style="list-style-type: none"><li>• When rotating the tires on vehicles differing with front and rear tire inflation pressure.</li><li>• When changing the tire size.</li></ul>	P. 350

