

## Recommended Practice (RP-021) Sound Controller Defaults (Revised)

---

CC # 70 through 79 are defined as Sound Controllers. Some have default names, and some are left undefined. Details:

Control Change (CC) #75-78 (Sound Controllers 6-9) have been given the following default names.

CC# (hex)	Control Function	Default Name
=====		
70 (46H)	Sound Controller 1	*Sound Variation
71 (47H)	Sound Controller 2	*Timbre/Harmonic Intensity
72 (48H)	Sound Controller 3	*Release Time
73 (49H)	Sound Controller 4	*Attack Time
74 (4AH)	Sound Controller 5	*Brightness
75 (4BH)	Sound Controller 6	Decay Time
76 (4CH)	Sound Controller 7	Vibrato Rate
77 (4DH)	Sound Controller 8	Vibrato Depth
78 (4EH)	Sound Controller 9	Vibrato Delay
79 (4FH)	Sound Controller 10	undefined

\*Items marked with an asterisk are unchanged from the current MIDI Specification.

### Comments

Pages of the MIDI Specification will be revised to strike the language about forbidding Sound Controllers. This is an inconsistency in the MIDI Specification that was overlooked when the existing Sound Controllers were defined.

Any default assignment specified by this proposal may be changed using Universal Real Time System Exclusive message "Controller Destination Setting". This new message enables selecting the destination for any controller message.

Approved by MMA 02/99 / Approved by AMEI 05/99. Contents Copyright 1999-2004 MIDI Manufacturers Association Incorporated. All rights reserved. No part of this text may be reproduced in any form or by any means electronic or mechanical without express permission in writing from the MIDI Manufacturers Association.

---