

Addresses

Discrete coils	000001 – 065535
Discrete inputs (contacts)	100001 – 165535
Input registers	300001 – 365535
Holding registers	400001 – 465535

If other than default slave address is used it should be prefixed. For example 100:000001, where 100 is the slave address.