

A380航空器运行规则

Operational Rules for A380

1. A380无限制运行区运行规则

1.1 无限制运行区

1.1.1 跑道：01/19跑道、36R/18L跑道；

1.1.2 滑行道：Y4（含）以东的所有滑行道；

1.1.3 停机位：507-509、361、463、955；

1.2 A380在上述区域运行，按塔台管制员指令滑行。

2. A380限制性运行区运行规则

2.1 限制性运行区

2.1.1 滑行道：E0-E8、A0、A1、G、H、Y1、Y2、Y3(H以西)、G0-G7、H0-H2、H4-H7、T1-T4(Y4以西)、T5-T6、J1-J2(T5以北)、J5(951机位以南)、J6(955机位以南)、W2、W7、F2、F3、F4(Z3以东)、W3、M4(Z3与F之间)、M7、Z3(M4与F2之间)、F(W2与W7之间)、M5(Z3与F之间)。

2.1.2 停机位：212、221、701、702、951。

2.2 A380在上述区域运行时，除按塔台管制员指令或引导车引领的路线滑行外，还应：

2.2.1 进港航空器，应在脱离跑道后将外侧发动机(1号、4号)置于怠速状态；

2.2.2 出港航空器，应使外侧发动机(1号、4号)置于怠速状态，直至进入跑道。

3. 除上述区域外，其他区域禁止A380飞机运行。

1. Rules for areas without operational limits:

1.1 Areas without operational limits:

1.1.1 RWY: 01/19, 18L/36R;

1.1.2 TWYs east of TWY Y4 (including);

1.1.3 Stands Nr. 507-509, 361, 463, 955.

1.2 A380 operating within the above area, shall taxi following ATC instructions.

2. Rules for areas with operational limits:

2.1 Areas with operational limits:

2.1.1 TWYs E0-E8, A0, A1, G, H, Y1, Y2, Y3(west of H), G0-G7, H0-H2, H4-H7, T1-T4(west of Y4), T5-T6, J1-J2(north of T5), J5(south of stand 951), J6(south of stand 955), W2, W7, F2, F3, F4(east of Z3), W3, M4(BTN Z3 & F), M7, Z3(BTN M4 & F2), F(BTN W2 & W7), M5(BTN Z3 & F).

2.1.2 Stands Nr. 212, 221, 701, 702, 951.

2.2 When operating within the above area, A380 shall taxi following ATC instructions or follow-me vehicle, and shall obey the following:

2.2.1 Arrival aircraft shall keep the outboard engines(Nr.1 and Nr.4) in idle state after vacating RWY.

2.2.2 Departure aircraft, shall keep the outboard engines(Nr.1 and Nr.4) in idle state until entering RWY.

3. Areas not mentioned in item 1 and 2, A380 are strictly forbidden to operate within.

Changes: Operational area for A380.