

#	Function	TLC5925 outputs														TLC5925 code
		SET_SERIAL	SET_PARALLEL	OUT_ENABLE1	OUT_ENABLE2	SENSE1_ON	SENSE2_ON	Out+ (LED_O2+)	S+ (LED_S2+)	S- (LED_S2-)	Out- (LED_O2-)	Out- (LED_O1+)	S- (LED_S1+)	S+ (LED_S1-)	Out+ (LED_O1-)	
1	Serial (no remote sensing)	1	X	1	1	0	0									0144h
2	Parallel (no remote sensing)	0	1	1	1	0	X									0244h
3	Parallel (with remote sensing)	0	1	1	1	1	0									0276h
4	Ch#2 only (no remote sensing)	0	0	0	1	X	0									2400h
5	Ch#2 only (with remote sensing)	0	0	0	1	X	1									7C00h
6	Ch#1 only (no remote sensing)	0	0	1	0	0	X									0088h
7	Ch#1 only (with remote sensing)	0	0	1	0	1	X									00BAh
8	Both ch (no remote sensing)	0	0	1	1	0	0									2488h
9	Both ch (with remote sensing)	0	0	1	1	1	1									7CBAh
10	Both ch (#1 no remote sensing)	0	0	1	1	0	1									7C88h
11	Both ch (#2 no remote sensing)	0	0	1	1	1	0									24BAh
12	PSU in stand-by mode	0	0	0	0	X	X									8000h

X – don't care

#### Notes:

- The Remote sense ([OUTPut:SENSe](#)) is forbidden when channels are grouped in serial (SYSTem:GROup:SERial).
- Before channel grouping in serial or parallel all outputs has to be switched off ([OUTPut OFF](#)). New output enable can follow only after 20ms guard time that is required for relay contacts to stabilize ([debouncing](#)).
- Regardless of built-in hardware protection never turn on Out8 and Out9 concurrently.