



PCI Video Board

Centaurus II LT

Installation Guide

Centaurus II LT Installation Guide

Introduction

Overview

Installation

Maintenance

Appendix

Index

1

2

3

4

A

I

Installation Guide Version 1.1 for Centaurus II LT

Copyright © 2006-2007 by DVS Digital Video Systems GmbH, Hanover. All rights reserved.

The manuals as well as the soft- and/or hardware described here and all their constituent parts are protected by copyright. Without the express permission of DVS Digital Video Systems GmbH any form of use which goes beyond the narrow bounds prescribed by copyright legislation is prohibited and liable to prosecution.

This particularly applies to duplication, copying, translation, processing, evaluation, publishing, and storing and/or processing in an electronic system.

Specifications and data may change without notice. We offer no guarantee that this documentation is correct and/or complete. In no event shall DVS Digital Video Systems GmbH be liable for any damages whatsoever (including without limitation any special, indirect, or consequential damages, and damages resulting from loss of use, data, or profits, or business interruption) arising out of the use of or inability to use the hardware, software and/or manual materials.

Those parts of this documentation that describe optional software or hardware features usually contain a corresponding note. Anyway, a lack of this note does not mean any commitment from DVS Digital Video Systems GmbH.

Centaurus and DVS are registered trademarks of DVS Digital Video Systems GmbH. Pentium and Pentium 4 are trademarks, service marks or registered trademarks of Intel Corporation. Linux is a registered trademark of Linus Torvalds. DirectShow, Microsoft, MS DOS, Windows, and Windows Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Red Hat and Fedora are either registered trademarks or trademarks of Red Hat, Inc. in the United States and other countries.

Any other product names mentioned in this documentation may be trademarks or registered trademarks of their respective owners and as such are subject to the usual statutory provisions.



Headquarters:

DVS Digital Video Systems GmbH
Krepenstr. 8
30165 Hannover
GERMANY

Phone: +49-511-67807-0
Fax: +49-511-630070
E-mail: info@dvs.de
Internet: <http://www.dvs.de>

Support:

Phone: +49-511-67807-25
Fax: +49-511-67807-31
E-mail: support@dvs.de

For the Americas:**U.S. Headquarters:**

DVS Digital Video, Inc.
300 East Magnolia Boulevard, Suite 102
Burbank, CA 91502
USA

Phone: +1-818-846-3600
Fax: +1-818-846-3648
E-mail: info@dvsus.com
Internet: <http://www.dvsus.com>

Support:

E-mail: support@dvsus.com

Registration Form

Dear customer,

this product was developed and tested thoroughly. Unfortunately, the possibility of problems and errors can never be ruled out. To support us in helping you as fast as possible if such a case occurs, please fill in this registration form and send or fax it to the address on the right.

You may also use our online registration form which can be accessed from the following internet page: <http://www.dvs.de/english/support/support.html>

PLEASE SEND TO:

DVS GmbH
Krepenstr. 8
30165 Hannover
GERMANY
Fax: +49-511-630070

Customer

Name: _____
Company: _____
Contact: _____
Address: _____

Phone: _____
Fax: _____
Vendor: _____

Centaurus II LT

Serial No.: _____
Remarks: _____


Computer

Brand: _____ Type: _____
Operating System: _____ Version: _____

Connected devices

(Brand and type of edit controller, VTR, color grading system, etc.)

Contents



1	Introduction	1-1
1.1	Overview	1-3
1.2	Target Group	1-3
1.3	Conventions Used in this User Guide	1-4
1.4	Safety Instructions	1-5
1.5	Important Notes	1-7
1.6	System Requirements	1-9
2	Overview	2-1
2.1	Overview of the OEM Product	2-2
2.2	Overview of the Board	2-3
2.2.1	Centaurus II LT Board Layout	2-3
2.2.2	Digital Video I/Os of the Centaurus II LT Board	2-5
2.2.3	LEDs	2-6
2.3	Overview of the Panels	2-7
2.3.1	SDI Panel	2-8
2.3.2	Audio Panels	2-9
2.3.3	GPI and Wordclock Panel	2-11
2.3.4	GPI (Optocoupler Based) and LTC Panel	2-13
3	Installation	3-1
3.1	Hardware Installation	3-2
3.1.1	Preparations	3-2
3.1.2	Installation of the Board	3-5
3.1.3	Installation of the Panels	3-5
3.1.4	Finishing the Installation	3-11
3.2	Software Installation	3-12

3.3	Setting the License Key	3-12
3.3.1	Setting of License Key (Windows Only)	3-12
3.3.2	Setting of License Key (All Operating Systems)	3-14
3.4	Upgrading the PCI Interface	3-16
3.4.1	Determining the PCI Interface Version	3-16
3.4.2	Upgrading the PCI Interface	3-17
3.5	Testing the Installation	3-19
3.5.1	Testing the Installation (Windows Only)	3-19
3.5.2	Testing the Installation (All Operating Systems)	3-21
4	Maintenance	4-1
A	Appendix	A-1
A.1	Technical Data	A-1
A.2	Hardware Specifications	A-2
A.3	Baud Rate of RS-422 Ports	A-3
A.4	Optocoupler GPI	A-4
A.4.1	Technical Data	A-4
A.4.2	Block Diagrams	A-4
A.5	Video Rasters	A-6
A.6	Signal In- and Outputs	A-7
A.7	Conformity Declarations	A-13
A.7.1	RoHS Compliance	A-13
A.7.2	EC Declaration of Conformity (CE Marking)	A-13
A.8	Short Reference: Centaurus II LT Board	A-14
I	Index	I-1


Introduction



This documentation describes Centaurus II LT, a high-end uncompressed video and audio I/O hardware manufactured by DVS. Based on its big brother Centaurus II this DVS OEM product has been down-scaled in its feature set to be a perfect partner when dealing with basic audio and video I/O applications. By reducing it to the most required features Centaurus II LT comes as a very cost-effective solution and, of course, is fully compatible to Centaurus II and thus an easy replacement in already existing applications.

Centaurus II LT is centered around the Centaurus II LT board, a half-length PCIe bus single board for the real-time input and output of uncompressed video and audio signals. All major video and film formats are supported from SD video up to 4K film via SDI I/O, supplemented by eight (optionally 16) channels audio either over AES/EBU or embedded in the video stream. With the help of the DVS software development kit (SDK) you can build your own powerful video and film solutions, for example, for broadcast applications.

Coming with a concise licensing Centaurus II LT can be adapted to your or your customers needs easily making future hardware upgrades or replacements in most cases unnecessary.



Key Features

- SD-/HD-SDI input and output in YUV 8/10 bit
- Dual-link SD-/HD-SDI output for RGB 8/10 bit
- Key channel output for SD/HD YUVA and RGBA
- Up to 16 channels of AES/EBU and embedded audio (48 kHz 20/24 bit) with audio embedder/de-embedder
- Dynamic 1D LUT in 10 bit for output
- 3:2 and 2:3 pulldown insertion/removal
- Analog reference genlock (bilevel, trilevel) input
- Cross-sync: SD or HD sync for HD rasters
- On-board color space conversion and low-pass 4:4:4 ↔ 4:2:2 filtering
- RS-422 remote in or out, software switchable


- Watchdog with hardware relay for a bypass between SDI input and SDI output (automatic switching to the live signal, reacts also on loss of power)
- LTC I/O, VITC I/O with generator and reader
- SMPTE 201 film, production TC & keycode (3-line VITC)
- Vertical ancillary data (VANC) I/O including closed captioning
- GPI I/O (optionally with optocoupler technology) and wordclock output
- SDK and drivers available for 32 and 64 bit operating systems
- Support for DirectShow under Windows
- Modular breakout boxes for easy plugging and handling
- Libraries to encode/decode MPEG 1 and 2

1.1 Overview

This guide informs you about the installation of Centaurus II LT as well as all connection possibilities. Furthermore, it provides information about the setting of license keys, the upgrade of the PCI interface, the testing of the installation, and of maintenance work that you may perform on your own.

In detail the chapters contain the following information:

Chapter 1	Begins with a short introduction to Centaurus II LT, followed by a note regarding the audience this manual is written for and an explanation of the conventions used in this manual. Beside the system requirements necessary to run Centaurus II LT, it provides safety instructions that you must adhere to and some important notes that you should read.
Chapter 2	Gives an overview of Centaurus II LT as an OEM product and describes shortly its individual components. Furthermore, the items, switches and connectors of the Centaurus II LT board and its additional panels are detailed in this chapter.
Chapter 3	Describes the installation of Centaurus II LT. First the hardware installation is explained, followed by some hardware related settings and upgrades to be effected with the software.
Chapter 4	Details service and maintenance work in case of a PCI interface upgrade failure.
Appendix	Provides technical details and general information about Centaurus II LT. This chapter also contains a short reference to the items available on the Centaurus II LT board.
Index	This chapter facilitates the search for specific terms.



1.2 Target Group

To use this manual you should have experience installing hardware components in a computer system and be familiar with the hardware structure and interior of such a system. Additionally, you should have knowledge in the field of digital video in general and be used to operate with computer software.

1.3 Conventions Used in this User Guide

The following typographical conventions will be used in this documentation:

- Texts preceded by this symbol describe activities that you must perform in the order indicated.
- Texts preceded by this symbol are parts of a list.



Texts preceded by this symbol are general notes intended to facilitate work and help avoid errors.



You must pay particular attention to text that follows this symbol to avoid errors and possible resulting damages thereof.



Texts following this symbol you must pay particular attention to to avoid dangers and personal injuries.

“ ” Texts enclosed by quotation marks are references to other manuals, guides, chapters, or sections.

'Window'	Text in bold with single quotation marks indicates a window name
BUTTON	Text in small caps and bold indicates push buttons
<i>Menu</i>	Text in italic and bold indicates either a menu name or options in a menu list
Item	Text in bold only stands for other labeled items of a user interface
<i>File</i>	Directory structure or file
Command	Command, for example, at a prompt; a bold typeface indicates that this has to be typed in exactly as written
Command	In the standard text flow a regular typeface of a command indicates commands, variables or parameters; it may also indicate a file syntax or contents of a file; when used in conjunction with a command in bold , it stands for optional parameters
[Key]	A key on a keyboard

1.4 Safety Instructions

To use Centaurus II LT correctly please heed the following:




Please read the following safety instructions very carefully before attempting any installation and/or performing any work on Centaurus II LT.

If Centaurus II LT is not used in compliance with the safety instructions, the warranty and all resulting liability claims will be void.

General

Centaurus II LT has been built according to the applying safety regulations. To minimize the possibility of a faulty operation of the device all manuals and guides must be available at all times at the operation site. Before installing and/or using Centaurus II LT the manuals and guides delivered with Centaurus II LT must be read and observed.

- Use Centaurus II LT only in apparent good technical order.
- The system you are trying to install Centaurus II LT in usually works with voltages that can be hazardous to your health. Never work on the system or access its interior with the power cable(s) being plugged in. Make sure the power supply is disconnected from the components you intend to work on.
- Computer hardware contains components that are sensitive to electrostatic discharge. If you touch them without precautionary measures, they can be destroyed. Use a wrist strap connected to ground when accessing electronic parts and take care of grounding the video system. Avoid touching the components of the computer system and Centaurus II LT whenever possible.
- Computer hardware contains components that are sensitive to changing voltages. Connecting or disconnecting Centaurus II LT to or from peripheral hardware while any of them is switched on may damage the hardware. Switch off all peripheral hardware before connecting or disconnecting anything.
- Use the board only in compliance with the technical data laid out in section "Technical Data" on page A-1.
- Centaurus II LT may not be misused, abused, physically damaged, neglected, exposed to fire, water or excessive changes in the climate or temperature, or operated outside maximum rating.
- Do not perform any changes or extensions to Centaurus II LT whatsoever.



Environmental Conditions

For error-free working and a long service life, Centaurus II LT needs some basic environmental conditions:

- Do not expose Centaurus II LT to sources of heat, such as direct sunlight or a radiator.
- The chassis of the computer system where the Centaurus II LT board is installed must be equipped with a sufficient ventilation for cooling reasons.
- Avoid areas with high humidity or dust. Best operating conditions are given in an air-conditioned site.
- Do not expose Centaurus II LT to strong electric or magnetic fields.
- Avoid areas where Centaurus II LT will be subject to vibrations or shocks.

1.5 Important Notes

The following provides information about warranty and the conformity of the product. Furthermore, it includes an important note if you want to unplug cables and some information about optionally available breakout boxes.

Warranty Information

This product is warranted to be free of defects in materials and workmanship for a period of one year from the date of purchase. DVS extends this Limited Warranty to the original purchaser.

In the event of a defect or failure to confirm to this Limited Warranty, DVS will repair or replace the product without charge. In order to make a claim under this Limited Warranty, the purchaser must notify DVS or their representative in writing of the product failure. In this Limited Warranty the customer must upon DVS' request return the product to the place of purchase or send the defective device to a given address for the necessary repairs to be performed. If the customer is not satisfied with the repair, DVS will have the option to either attempt a further repair, exchange the product or refund the purchase price.


This warranty does not cover:

- Products not developed by DVS Digital Video Systems GmbH.
- Products not used in compliance with the safety instructions detailed in section "Safety Instructions" on page 1-5.
- Products on which warranty stickers or product serial numbers have been removed, altered or rendered illegible.
- The costs of installations, removals, transportations, or reinstallations.
- Costs for transportation damages.
- Damages caused to any other item.
- Any special, indirect, or consequential damages, and damages resulting from loss of use, data, or profits, or business interruption.

Declaration of Conformity



This product has been tested according to the applying national and international directives and regulations. Further information about this can be found in section "Conformity Declarations" on page A-13.



Unplugging Cables

If you want to unplug one of the flat cables after its installation on the board, please observe the following:

Flat cable connectors are equipped with a locking mechanism to prevent them from becoming disconnected after they were plugged in.



Don't use any force to disconnect flat cable plugs, otherwise the socket on the board may be damaged or even break off.

To unplug the connector use your index finger and thumb to press the locking wings together.




Figure 1-1: Unplugging flat cables

Then you can easily remove the connector.

Breakout Box

A modular breakout box is optionally available for Centaurus II LT to replace the breakout cables and reduce the amount of panels. Due to its modular design – each module provides connectors on a half-19" front panel – you can adapt the overall configuration to your personal needs. To connect to the breakout box a different slot panel will be included in its delivery which will replace most of the additional slot panels described in this manual (see section "Overview of the Panels" on page 2-7).

For more information about the different types of breakout boxes available for Centaurus II LT please refer to the "Breakout Box II" installation guide which can be found on the DVS OEM web site (<http://private.dvs.de/oem>), or contact your local vendor or DVS directly.

1.6 System Requirements

Required Hardware

These are the minimum hardware requirements that the computer system has to meet if you want to use Centaurus II LT.

- Pentium 4 or similar with at least 1.8 GHz
- Mainboard with 64-bit, PCIe x4 bus
- 1 free slot in a bus-master capable PCI segment that supports PCIe
- 512 MB RAM

Supported Operating Systems

Centaurus II LT can be used with the following operating systems:


- Windows 2000, XP or Vista
- Linux (Red Hat and Fedora)




Be sure that you have installed the newest Service Packs for your system, otherwise you may encounter soft- and/or hardware problems.

Required Software

Centaurus II LT needs the DVS video board driver. Furthermore, to be programmed for applications the SDK by DVS is necessary. Both software items should be included in your delivery. They are also available online on the DVS OEM web site (<http://private.dvs.de/oem>).



Overview



This chapter shows an overview of Centaurus II LT thereby detailing all items, switches and connectors of the Centaurus II LT board and its additional panels. First the components of the DVS OEM product as it is delivered to you are described shortly. Afterwards an overview of the Centaurus II LT board is provided. The chapter will be concluded with a detailed overview of the delivered slot panels.



Please note that some of the panels may not be included in your Centaurus II LT configuration. They belong to optional features of Centaurus II LT and are only necessary if you ordered the respective feature.



2.1 Overview of the OEM Product

Centaurus II LT as an OEM product consists of various individual components that combined will give you the opportunity to develop your own real-time video and film solutions. The following diagram shows the different components included in the delivery of Centaurus II LT:




Figure 2-1: Centaurus II LT overview

The components of Centaurus II LT can be divided into hardware and software components:

To the hardware components belong the items described in this installation guide. Centaurus II LT is centered around the Centaurus II LT board, a half-length PCIe bus single board for a real-time input and output of video and audio signals. All major video and film formats are supported from SD video up to 4K film via SDI I/O, supplemented by up to 16 channels audio either over AES/EBU or embedded in the video stream. To use all the features of Centaurus II LT several slot panels may have been included in your delivery as well as other accessories such as breakout cables. All these items and their installation will be described in this manual.

Among the software components you can find the DVS software development kit (DVS SDK) which can be used to build editing and storage solutions with Centaurus II LT. The DVS SDK is compatible among the OEM products by DVS meaning your code can be used with other DVS OEM boards as well. Several tools for basic hardware setup and diagnostics such as the DVSConf program complement the SDK. To run properly the video board driver has to be loaded prior to using Centaurus II LT which can be done with the tools for the hardware setup. The video board driver controls the Centaurus II LT board and thus the in- and output of signals. The DVS SDK as well as all other software components are described in the separate SDK documentation.

2.2 Overview of the Board

The PCI video board delivered with Centaurus II LT is a complex piece of technology. This section provides an overview of the Centaurus II LT board including a detailed description of the items, switches and connectors present on the PCI video board.

2.2.1 Centaurus II LT Board Layout

The following provides an overview of the Centaurus II LT board, describing all items, switches and connectors.



The connectors and switches on the Centaurus II LT board which are not described in the following are used during the manufacturing process only and without function in normal operation mode.

For a concise overview of the PCI video board see section “Short Reference: Centaurus II LT Board” on page A-14.





Figure 2-2: Overview of the items and connectors on the Centaurus II LT board

No.	Item	Explanation
1	Ref. In	BNC connector for the reference input

No.	Item	Explanation
2	(HD) SDI OUT A	BNC connector for a video output at port A (serial digital interface); usually used for an output of YUV in single-link or the first stream of YUVA or RGB[A] in dual-link mode
3	(HD) SDI IN A	BNC connector for a video input at port A (serial digital interface); usually used for an input of YUV in single-link mode
4	Ref. Term	Termination switch for the reference input; switches off the termination of the genlock signal manually, e.g. if the Centaurus II LT board is not the last link in a genlock connection chain
5	RMT	DB-9 connector (female), configurable serial RS-422 interface (remote port) for an out- or input of master/slave control signals
6	LEDs	Two status LEDs indicating the presence of correct video and sync signals (see section "LEDs" on page 2-6)
7	(HD) SDI OUT B	MCX connector for a video output at port B (serial digital interface); usually used for an output of YUV in single-link or the second stream of YUVA or RGB[A] in dual-link mode
8	GPI	Flat cable connector for the general purpose interface
9	RS-422	Flat cable connector for an in- or output of RS-422 signals; by default connected to RMT (see item 5)
10	AUDIO 1-8/LTC	Flat cable connector for the digital audio channels 1 to 8 and LTC
11	DIP Switch for Flash Controller	This switch controls the operation of the on-board Flash controller; it defines the version set of the map file that will be loaded at startup
		 <p>Default setting of the DIP switch for the Flash controller; please observe the orientation of the switch on the board</p>

No.	Item	Explanation
12	AUDIO 9-16	Flat cable connector for the digital audio channels 9 to 16
13	breaking lines	The printed circuit board provides at its bottom and right side extensions void of any electrical parts; these may serve to stabilize the installation of the board in a computer system; when not needed or interfering, you can break them off the circuit board at the breaking lines

2.2.2 Digital Video I/Os of the Centaurus II LT Board

DVS usually names the external connectors for the in- and output of the digital video signals alphabetically. For YUV you will normally use one channel (connectors named 'A', single link). For YUVA you will need two channels ('A' for YUV and 'B' for the key signal). With RGB you will always need two channels ('A' and 'B', dual link). The same applies to transmitting rasters of a higher resolution such as 2K.

Via the delivered software by DVS you can configure the digital video I/Os of the Centaurus II LT board freely:


- The A ports are used in single link for YUV or in dual link for the first part of RGB.
- The output B port provides either the key channel, a mirrored output of port A or the second part of RGB.

The following table shows the signal distribution over the I/O ports for the different video rasters (color modes):

Table 2-1: I/O signal distribution for Centaurus II LT

Raster	Video Mode	(HD) SDI		
		IN A	OUT A	OUT B ¹
SD	YC _b C _r 4:2:2	Y, C _b , C _r	Y, C _b , C _r	Y, C _b , C _r
	YC _b C _r A 4:2:2:4	Y, C _b , C _r	Y, C _b , C _r	A
	RGB 4:4:4	–	G, ½ R, ½ B	½ R, ½ B
	RGBA 4:4:4:4	–	G, ½ R, ½ B	½ R, ½ B, A
HD ¹	YC _b C _r 4:2:2	Y, C _b , C _r	Y, C _b , C _r	Y, C _b , C _r
	YC _b C _r A 4:2:2:4	Y, C _b , C _r	Y, C _b , C _r	A
	RGB 4:4:4	–	G, ½ R, ½ B	½ R, ½ B
	RGBA 4:4:4:4	–	G, ½ R, ½ B	½ R, ½ B, A

1) Available as options.



2.2.3 LEDs

The Centaurus II LT board panel holds two status LEDs that signal whether correct video and sync signals are available at the respective digital inputs. In detail they indicate the following:

LED	Function	Modus	Meaning
green	Signals the status of the sync input	on	A correct sync signal is detected, i.e.: <ul style="list-style-type: none"> – Sync mode 'internal' is set. – Sync mode 'external' is set and a correct signal is connected. – sync mode 'analog' is set and an analog genlock signal is connected. – Sync mode 'digital' is set and a correct signal is connected.
		off	A wrong input signal is detected, i.e.: <ul style="list-style-type: none"> – Sync mode 'external' is set and no SDI input signal. – Sync mode 'analog' is set and no genlock signal connected. – Sync mode 'digital' is set and no SDI input signal.
red	Signals the status of the video raster detection feature	blinking slowly	No input signal is available.
		blinking fast	A wrong input signal is detected (e.g. Centaurus II LT is set to NTSC video mode, but a PAL signal is connected to the active input).
		off	A correct input signal is detected.


2.3 Overview of the Panels

To provide all the connection possibilities for the various features of Centaurus II LT at a computer casing, several panels are delivered with the board. This section provides an overview of the different panels.



Please note that some of the panels may not be included in your Centaurus II LT configuration. They belong to optional features of Centaurus II LT and are only necessary if you ordered the respective feature.

A modular breakout box is optionally available for Centaurus II LT which will replace most additional slot panels described in this section. Further information about the breakout box can be found in section "Breakout Box" on page 1-8.



2.3.1 SDI Panel

The SDI panel is optionally available and provides the connector for the second link of the dual-link output connection. In case it is not included in your delivery but your Centaurus II LT comes with dual-link capability, this port will be available on either one of the GPI panels (see section “GPI and Wordclock Panel” on page 2-11 or section “GPI (Optocoupler Based) and LTC Panel” on page 2-13).




Figure 2-3: Panel with SDI connection

Item	Explanation
(HD) SDI Out B	BNC connector for a video output at port B (serial digital interface); usually used for an output of YUV in single-link or the second stream of YUVA or RGB[A] in dual-link mode

2.3.2 Audio Panels

The audio panels are available as optional features. In a setup with 16 channels digital audio two audio panels are required, each providing a DB-25 connector for digital audio (AES/EBU) and/or LTC signals.



The analog stereo headphone outputs currently available on these panels provide no function.

To the DB-25 connectors you can either connect a breakout cable providing eight XLR connectors to interface directly with audio devices, or a half-19" audio breakout box which is optionally available. The latter will then provide the necessary connections in one place. Further information about the breakout box can be found in section "Breakout Box" on page 1-8. Pin-outs of the DB-25 connectors can be found in section "Signal In- and Outputs" on page A-7.






Figure 2-4: Panels for digital audio



Audio Panel	Item	Explanation
1	Digital Audio (AES/EBU)	DB-25 connector (female) for audio signal and/or LTC in- and output; provides either four stereo channels digital audio (channels 1 to 8) or three channels audio plus LTC
	 In conjunction with the optocoupler GPI you can receive for Centaurus II LT with this panel four stereo channels plus LTC (see section "GPI (Optocoupler Based) and LTC Panel" on page 2-13).	
2	Digital Audio (AES/EBU)	DB-25 connector (female) for audio signal in- and output; provides the digital audio channels 9 to 16



Prior to the installation of the audio panels you have to set/check the jumpers on their printed circuit boards to the appropriate settings for your setup (see section "Jumper Settings of the Audio Panels" on page 3-3).

2.3.3 GPI and Wordclock Panel

The GPI and audio wordclock panel is optionally available and provides the general purpose interface and the audio wordclock output.



Instead of this panel you may have received the optocoupler based GPI (see section “GPI (Optocoupler Based) and LTC Panel” on page 2-13).

If your Centaurus II LT board comes with dual-link capability, this panel may also hold one of the SDI ports, i.e. the connector for the second link of the dual-link output connection.

The GPI port could be used for all kinds of triggers that have to be sent to your audio/video system. The provided plug is a DB-9 male connector. A pin-out of this connector can be found in section “Signal In- and Outputs” on page A-7.

A clock frequency according to the currently adjusted audio mode will be supplied by the wordclock output to synchronize external audio equipment.




Figure 2-5: Panel for GPI and wordclock

Item	Explanation
GPI	DB-9 connector (male), general purpose interface



Item	Explanation
Wordclock Out	BNC connector providing a wordclock signal for the synchronization of external audio equipment
(HD) SDI Out B	Optionally available BNC connector for a video output at port B (serial digital interface); usually used for an output of YUV in single-link or the second stream of YUVA or RGB[A] in dual-link mode



Prior to the installation of the GPI and audio wordclock panel you have to check the jumpers on the printed circuit board of the GPI for their correct settings. This is described in detail in section “Jumper Settings of the GPI Panel(s)” on page 3-4.

2.3.4 GPI (Optocoupler Based) and LTC Panel

The GPI and LTC panel is optionally available and provides a galvanically isolated GPI based on the opto-isolator technique. Because the interface harbors LTC as well, with it you can even receive four stereo audio channels plus LTC for Centaurus II LT. This is made possible because the source signals coming from the Centaurus II LT board are looped-through to identical plugs on the connected printed circuit board which are then used to reroute the signals.



Instead of this panel you may have received the GPI and word-clock panel (see section “GPI and Wordclock Panel” on page 2-11).

If your Centaurus II LT board comes with dual-link capability, this panel may also hold one of the SDI ports, i.e. the connector for the second link of the dual-link output connection.

This panel is also available in a low profile version, i.e. with a height of about two-third of the full-size panel. However, then the optional SDI port will not be present on this panel. Instead, when equipped with dual-link capability it can be found on the SDI panel (see section “SDI Panel” on page 2-8).

To interface with other systems easily a breakout cable (15-pin-D-Sub to 2 × XLR and 1 × 25-pin-D-Sub) is included in the delivery that conducts the different signals to standard connectors. Pin-outs of the DB-15 connector on the slot panel and the DB-25 connector available via the breakout cable can be found in section “Signal In- and Outputs” on page A-7.






Figure 2-6: Panel with GPI and LTC connection



Item	Explanation
GPI/LTC	<p>DB-15 connector (male) providing the general purpose interface as well as LTC in- and output, a breakout cable to two XLR and one DB-25 is included in the delivery:</p>  <p>LTC Out LTC In GPI</p> <p><i>Figure 2-7: GPI/LTC breakout cable</i></p>
(HD) SDI Out B	<p>Optionally available BNC connector for a video output at port B (serial digital interface); usually used for an output of YUV in single-link or the second stream of YUVA or RGB[A] in dual-link mode</p>



Prior to the installation of the GPI and LTC panel you have to check the jumper on the printed circuit board for its correct setting. This is described in detail in section “Jumper Settings of the GPI Panel(s)” on page 3-4.

Installation



This chapter details all the information necessary to install Centaurus II LT in a computer system.


First, the installation of the board itself is described. After that follows a description on how to activate the ordered features. Centaurus II LT offers a lot of features to the user. Some of these are included in the standard version of Centaurus II LT, some belong to optional packages and have to be ordered explicitly if you want to use them. Via a license key the whole feature set that you have ordered with Centaurus II LT can be activated.

For some installations it may be necessary to upgrade the PCI interface (firmware) of Centaurus II LT. This is described in this chapter as well.

Once everything is set, you may test your installation and system configuration if everything is working properly.



The DVS driver to control the board is part of the SDK software package. For information on how to install the DVS driver please refer to the separate SDK documentation.



3.1 Hardware Installation

How to install Centaurus II LT in a computer system is described in this section. The installation has to be performed in several steps: First, you have to prepare the computer system and the panels for the installation. After that the board itself must be installed. This is followed by the installation of the different panels. As the last step the hardware installation has to be finished.



If you want to disconnect flat cables from the board once they are plugged in, please read section “Unplugging Cables” on page 1-8.

3.1.1 Preparations

Before installing the Centaurus II LT board the computer system and some of the panels have to be prepared for the installation. The necessary preparations will be described in the following.

Preparing the Computer System

To prepare the computer system where Centaurus II LT has to be installed perform the following:

- Disconnect all cables (especially the power cords) from the computer system where Centaurus II LT should be installed.



The computer system you are trying to install Centaurus II LT in usually works with voltages that can be hazardous to your health.

Never work on the system or access its interior with the power cable(s) being plugged in. Make sure the power supply is disconnected from the components you intend to work on.

- Open the computer casing. For details on how to do this please refer to the respective manufacturer's manual.



Computer hardware contains components that are sensitive to electrostatic discharge. If you touch them without precautionary measures, they can be destroyed.

Use a wrist strap connected to ground when accessing electronic parts and take care of grounding the video system. Avoid touching the components of the computer and Centaurus II LT whenever possible.

The computer system is now ready for the installation of the Centaurus II LT board and you have to proceed with the checking of

the panels, i.e. checking the audio and the GPI panels for their correct jumper settings.

Jumper Settings of the Audio Panels

On the audio panel that should be installed as the audio panel no. 1 (see section "Audio Panels" on page 2-9 and section "Connecting the Audio Panels" on page 3-7) up to four stereo channels of AES/EBU or three stereo channels of AES/EBU and one LTC in- and output can be transmitted over the DB-25 connector. This signal configuration has to be configured via jumper settings on the printed circuit board mounted to the audio slot panel.

- Before installing the audio panel 1 please check whether the jumpers on the printed circuit board are set to your desired configuration and, if appropriate, adjust them:



To receive four audio channels plus LTC when provided with the GPI and LTC panel (see section "GPI (Optocoupler Based) and LTC Panel" on page 2-13), configure the jumper settings of the audio panel 1 to four channels of audio (i.e. to '4th audio channel activated').





Figure 3-1: Jumper settings for audio circuit board

- Next check the jumper settings of the audio panel that should be installed as the audio panel 2. They should be set as the indicated in the left drawing (figure above, 4th audio channel activated).



After checking and, if appropriate, adjusting the jumpers of the audio panels to their correct settings you have to check the settings of the GPI panel(s).

Jumper Settings of the GPI Panel(s)

Prior to the installation of one of the GPI panels (see section “GPI and Wordclock Panel” on page 2-11 and section “GPI (Optocoupler Based) and LTC Panel” on page 2-13), you have to check the jumpers on the printed circuit board of the GPI for their correct settings. If they are not set correctly, using this interface may result in an unexpected behavior of Centaurus II LT.

- Please check whether the jumpers are set as shown in the figure below. It shows the printed circuit boards of the available GPI panels:




Figure 3-2: Jumper settings on GPI's printed circuit boards

After checking and, if appropriate, adjusting the jumpers on the printed circuit board for the GPI you can go on with the next step and install the board into the computer system.

3.1.2 Installation of the Board

With the second step the Centaurus II LT board will be installed in the prepared computer system. For this perform the following:

- In the computer system remove the slot bracket from the PCI slot where the Centaurus II LT board should be installed.



During the next step please observe not to break off any parts of the PCI video board. Apply pressure to the slot panel and/or the printed circuit board only, not to any of its attached parts.



For an optimum performance of Centaurus II LT it is recommended to have no other data transfers running in the same PCI bus.

- Insert the Centaurus II LT board into the PCI slot without using excessive force or bending it.
- Afterwards fasten the board with the screw from the slot bracket.



The chassis of the computer system where the Centaurus II LT board is installed must be equipped with a sufficient ventilation for cooling reasons.

After this the Centaurus II LT board is installed in the computer system and you can move on to the next step, i.e. the installation of the panels.

3.1.3 Installation of the Panels


As the third step you have to connect the delivered panels internally to the Centaurus II LT board and install them in your computer system. For this perform the following:

- Remove as many slot brackets as you need for the additional panels.



The number of additional panels depends on the optional features ordered with Centaurus II LT.

- Now install the panels: Insert the panels of Centaurus II LT into the empty slots and fasten each with a screw from the slot brackets.
- Connect the cables to the appropriate Centaurus II LT board interfaces as detailed in the following:



Connecting the SDI Panel

With the dual-link version of Centaurus II LT the second HD SDI connector has to be linked to the labeled B output port on the PCI video board. Then it will provide a multi-rate connection in accordance with the specifications SMPTE 259, SMPTE 292 and SMPTE 372.

The connection can be found at the top of the Centaurus II LT board.




Figure 3-3: Internal connection of SDI panel

Connecting the Audio Panels

The audio slot panels are connected via 26-pin flat cables to the Centaurus II LT board. To perform the internal connections connect the two audio panels to the board as shown in the following figure:



Prior to the installation of the audio panels you have to set the jumpers on their printed circuit boards to the desired settings. This is described in detail in section “Jumper Settings of the Audio Panels” on page 3-3.

If you are provided with the GPI and LTC panel (see section “GPI (Optocoupler Based) and LTC Panel” on page 2-13), connect the audio panel 1 to the printed circuit board of the GPI and LTC panel instead of connecting to the Centaurus II LT board directly as detailed below (see section “Connecting the GPI and LTC Panel” on page 3-10).




Figure 3-4: Internal connections of audio panels

Connecting the GPI and Wordclock Panel

The printed circuit board behind the GPI connector plugs via a 12-pin flat cable to the top of the Centaurus II LT board. Additionally, if available, the (HD) SDI output connector has to be linked to the second link of the SDI output. To perform the internal connections connect the panel to the board as shown in the following figure:



Prior to the installation of the GPI and audio wordclock panel you have to check the jumpers on the printed circuit board of the GPI for their correct settings. This is described in detail in section “Jumper Settings of the GPI Panel(s)” on page 3-4.




Figure 3-5: Internal connections of GPI and wordclock panel

The power line to be connected to the printed circuit board of the GPI has to be a standard power distribution line of your computer system. It should be of the same type as, for example, used to power your CD-ROM, with the following specifications:




Figure 3-6: Power line specification



The connected extra power line of the GPI makes the GPI signal stronger and clearer. However, if you do not have a power line available, the GPI will still be functional.



Connecting the GPI and LTC Panel

The printed circuit board of the GPI and LTC panel has to be connected via 12-pin and 26-pin flat cables to the top of the Centaurus II LT board. Additionally, if available, the (HD) SDI output connector has to be linked to the second link of the SDI output. To perform the internal connections connect the panel to the board as shown in the following figure:



Prior to the installation of the GPI and LTC panel you have to check the jumper on the printed circuit board of the GPI for its correct setting. This is described in detail in section "Jumper Settings of the GPI Panel(s)" on page 3-4.




Figure 3-7: Internal connections of GPI and LTC panel

If provided with audio, connect the audio panel 1 to the Centaurus II LT board as detailed above. With this setup you will receive four stereo channels audio (via audio panel) as well as LTC (via GPI and LTC panel) when the audio panel is configured to '4th audio channel activated' (see section "Jumper Settings of the Audio Panels" on page 3-3).


When the internal connections are all set up, Centaurus II LT is properly connected to your computer system. As a last step you must now finish the installation.

3.1.4 Finishing the Installation

This step of installing the Centaurus II LT board is the last step to be performed. To finish the hardware installation do the following:

- Close the computer casing.
- Connect all cables to the computer system again.
- Connect your audio and video equipment to the Centaurus II LT connectors.
- After this start the computer system.

Once the computer system has finished the loading of the operating system, the installation of Centaurus II LT as a hardware is complete. To use the board and activate its features you have to install the DVS software as well (see section "Software Installation" on page 3-12).



3.2 Software Installation

Beside the files for software development, the DVS SDK software package also includes the Centaurus II LT board driver and tools for a basic hardware setup and diagnostics.

For descriptions of the software and driver as well as their installations please refer to the separate SDK documentation.

Once the software installation is completed, you have to activate the feature set available for Centaurus II LT with the delivered license key.

3.3 Setting the License Key

This section explains how to set the license key on the computer system equipped with Centaurus II LT. The license key activates the individual features that you have ordered for your DVS product. After the SDK and the driver are installed, you have to set the license key for Centaurus II LT to be able to use the full feature set.

Centaurus II LT is capable of holding three license keys. The first key (key 1) is usually used for licensing the features that were ordered with Centaurus II LT. Keys 2 and 3 are usually used for temporary licenses that you may have received for evaluation purposes. Each license key enables one or more (optional) features of Centaurus II LT until date of expiration (if applicable). Each time Centaurus II LT starts all keys are checked and their features are combined.

Because DVS supports several operating system platforms, this section is divided into the different setup procedures for the respective operating system (i.e. 'Windows Only' and 'All Operating Systems').

3.3.1 Setting of License Key (Windows Only)

Once the DVS SDK and the driver are properly installed, you have to set the license key for Centaurus II LT to be able to use all ordered features.

To set the license key Windows offers you with the DVSCnf program the possibility to use a standard graphical user interface.



You may also use the procedure described in section "Setting of License Key (All Operating Systems)" on page 3-14.

The following assumes that the DVSConf program is already running and that the driver is correctly loaded.



In case the driver is not already loaded, load the driver with the 'Driver' tab of the DVSConf program.

Further information on how to operate the DVSConf program can be found in the separate SDK documentation.

To set the license key with the help of the DVSConf program perform the following:

- Change to the 'Card 0' tab.



For each installed Centaurus II LT board there is a 'Card' tab available. If you have more than one Centaurus II LT board installed in your computer system, you have to repeat the following steps with 'Card 1', 'Card 2', etc.

- Click on the button **SETUP** and select from the opening menu the option **Set Licence**:




Figure 3-8: 'Card 0' tab

The following dialog window opens:




Figure 3-9: 'Licence' dialog window

- In the field 'Key 1' enter the license key that you have received with Centaurus II LT and click the **SET KEY 1** button.

The '**Licence**' dialog window closes. The new license key is now set and will be stored non-volatile in Centaurus II LT.



The features activated with this license key can be displayed by clicking the button **SETUP** and selecting from the menu the option **Info Licence**.

- Repeat the described steps above to activate the features for keys 2 and 3, if appropriate.
- If you have more than one Centaurus II LT board installed in your computer system, change to their respective card tabs and repeat the steps to activate their features.
- Reboot the computer system.

Once the system has started, all licensed features will be available to Centaurus II LT.



Depending on the SDK version, you may need to upgrade the PCI interface (firmware) of the Centaurus II LT board. More information about this can be found in section "Upgrading the PCI Interface" on page 3-16.

To be sure your Centaurus II LT board works properly, you may also test your installation. Details on how to perform a testing of your installation can be found in section "Testing the Installation" on page 3-19.

3.3.2 Setting of License Key (All Operating Systems)

Once the DVS SDK and the driver are properly installed, you have to set the license key for Centaurus II LT to be able to use all ordered features.



The following procedure uses the command line (shell, or in case of Windows MS DOS prompt). This is the common way for most operating systems to perform such a procedure.

To set the license key with the command line (shell), you have to open the shell first. After that perform the following:



In case the driver is not already loaded, load the driver. Further information about this can be found in the separate SDK documentation.

In case you have several Centaurus II LT boards installed, use the environment variable `SCSIVIDEO_CMD` and set it to `PCI, card:<x>` (with `<x>` as the number of the board) to access a particular board. Please refer to the SDK documentation for details about setting the variable `SCSIVIDEO_CMD`.

- Enter the command **svram licence key1** `<key value>`. For `<key value>` insert the license key that you have received with Centaurus II LT.

The new license key is now set and will be stored non-volatile in Centaurus II LT.



The features activated with this license key can be checked with the command **svram licence show**.


- Repeat the described steps to activate the features for keys 2 and 3, if appropriate, by altering the command respectively.
- If you have more than one Centaurus II LT board installed in your computer system, use the environment variable `SCSIVIDEO_CMD` to access the respective board and repeat the steps to activate its features.
- Reboot the computer system.

Once the system has started, all licensed features will be available to Centaurus II LT.



Depending on the SDK version, you may need to upgrade the PCI interface (firmware) of the Centaurus II LT board. More information about this can be found in section “Upgrading the PCI Interface” on page 3-16.

To be sure your Centaurus II LT board works properly, you may also test your installation. Details on how to perform a testing of your installation can be found in section “Testing the Installation” on page 3-19.



3.4 Upgrading the PCI Interface

Depending on the DVS SDK version you may need to upgrade the PCI interface (firmware) of the Centaurus II LT board. This can be done with a program named *lucyltup###*. This section explains how to determine whether you need and how to perform a PCI interface upgrade.



An upgrade should be performed by qualified personnel only. Before you upgrade the PCI interface you have to close all other applications.

Be aware of a power failure. If this happens, you have to use the fallback PCI version of the Centaurus II LT board as detailed in chapter "Maintenance" on page 4-1.



For the newest version of the firmware (*lucyltup###*) check the DVS OEM web site (<http://private.dvs.de/oem>).

3.4.1 Determining the PCI Interface Version

Before upgrading the PCI interface you have to determine whether a PCI interface upgrade is necessary. For this you need to know the PCI interface version that is required at least to work properly with the DVS SDK installed. You can find this information on the DVS OEM web site (<http://private.dvs.de/oem>, see the respective page of your installed SDK). Look for the line that says 'Required firmware version: Version 4.2.68.7_11_2' or similar. The numbers tell you the PCI interface version.

Next you have to check the PCI interface version of your Centaurus II LT board:



The following procedure uses the command line (shell, or in case of Windows MS DOS prompt).

- Open a command line (shell).



If the driver is not already loaded, load the driver. Further information about this can be found in the separate SDK documentation.

In case you have several Centaurus II LT boards installed, use the environment variable `SCSIVIDEO_CMD` and set it to `PCI, card: <x>` (with `<x>` as the number of the board) to access a particular board. Please refer to the SDK documentation for details about setting the variable `SCSIVIDEO_CMD`.

- Enter at the command line **svram version info**.

- In the output look for the line that says 'Firmware Version: 4.2.68.8_11_2' or similar.

The numbers indicate the PCI interface version of your Centaurus II LT board. In detail they stand for three version numbers that are separated by underscores, i.e. with the pattern $\langle v_1 \rangle_ \langle v_2 \rangle_ \langle v_3 \rangle$.



The first version number ($\langle v_1 \rangle$) consists of four figures which have to be treated as one version number, whereas the other two version numbers ($\langle v_2 \rangle$ and $\langle v_3 \rangle$) provide only one figure.

- Compare the three version numbers separately with the numbers stated on the DVS OEM web site.

If one of the version numbers is lower than the respective numbers stated on the DVS OEM web site, the PCI interface has to be upgraded.



In our example above the PCI video board does not need a PCI interface upgrade because a firmware version of 4.2.68.8_11_2 and higher is sufficient.

3.4.2 Upgrading the PCI Interface

In case you determined that a PCI interface upgrade is necessary, perform the following:

- Download the required firmware version from the DVS OEM web site.
- Open a command line (shell).
- Run the update program `lucyltup###`:




`###` is the PCI interface version that `lucyltup###` upgrades the Centaurus II LT board to. Make sure that a `lucyltup###` of a high enough version is available.

The program `lucyltup###` upgrades all Centaurus II LT boards installed in the computer system.

- First you have to wait while the program is inspecting the system.
 - After this you will be asked if you really want to upgrade the firmware. To confirm type in `Y` and press [Enter].
 - Then wait until the program terminates itself which may take several minutes.
- When `lucyltup###` has finished the upgrade procedure, shut down the computer and wait at least one minute before rebooting it.

This will safely erase the old PCI interface from the Centaurus II LT board.



- Start the computer and, after the operating system has loaded, check the PCI interface version as described in section "Determining the PCI Interface Version" on page 3-16.

If the interface version is upgraded, the procedure is finished. If it is not upgraded, perform the procedure again and give the board more time to erase the old information.

3.5 Testing the Installation

After having installed and set up everything, you should test if the Centaurus II LT installation has been successful. The tools delivered with the DVS SDK software package offer you the possibility to generate and display test pictures to check the Centaurus II LT hardware.

Because DVS supports several operating system platforms, this section is divided into the different procedures for the respective operating system (i.e. 'Windows Only' and 'All Operating Systems').

3.5.1 Testing the Installation (Windows Only)

To test the installation Windows offers you with the DVSConf program the possibility to use a standard graphical user interface. Perform the following:



You may also use the procedure described in section "Testing the Installation (All Operating Systems)" on page 3-21.

- Connect a video monitor to the video output connectors of Centaurus II LT (see chapter "Overview" on page 2-1).
- Open the DVSConf program.



In case the driver is not already loaded, load the driver with the 'Driver' tab of the DVSConf program.

Further information on how to operate the DVSConf program can be found in the separate SDK documentation.


- Optionally you may change the settings on the 'Settings' and 'Server' tabs if desired.

Now the computer system is ready to generate test frames:

- Change to the 'Card 0' tab.



For each installed Centaurus II LT board there is a 'Card' tab available. If you have more than one Centaurus II LT board installed in your computer system, you have to repeat the following steps with 'Card 1', 'Card 2', etc.






Figure 3-10: 'Card' tab overview of DVSConf program

- Use the buttons at the top of the 'Card' tab to select the desired video and audio settings.
- Use the **FILL**, **x2**, **x3**, or **x4** buttons to fill the Centaurus II LT board buffer with a test pattern.
- Perform the display operations with the lower buttons.

If this works, you have successfully completed the Centaurus II LT installation. Together with the DVS SDK some sample programs are delivered that can also be used for testing.



The DVSConf program only affects the buffer and the I/O functions of the Centaurus II LT board. For testing optionally installed video hard disks you have to use your own test routines.

3.5.2 Testing the Installation (All Operating Systems)

To test the installation perform the following:



The following procedure uses the command line (shell, or in case of Windows MS DOS prompt). This is the common way for most operating systems to perform such a procedure.

- Connect a video monitor to the video output connectors of Centaurus II LT (see chapter "Overview" on page 2-1).
- Open a command line (shell).



If the driver is not already loaded, load the driver. Further information about this can be found in the separate SDK documentation.

Now the computer system is ready to display test frames:




In case you have several Centaurus II LT boards installed, use the environment variable `SCSIVIDEO_CMD` and set it to `PCI, card: <x>` (with `<x>` as the number of the board) to access a particular board. Please refer to the SDK documentation for details about setting the variable `SCSIVIDEO_CMD`.

- Use `svram mode`, `svram sync`, `svram analog`, etc. to select the desired video and audio settings (further information about the commands can be found in the SDK documentation).
- Enter **`svram colorbar`** to display a color bar at the output.

If this works, you have successfully completed the Centaurus II LT installation. Together with the DVS SDK some sample programs are delivered that can also be used for testing.



The `svram` program only affects the buffer and the I/O functions of the Centaurus II LT board. For testing optionally installed video hard disks you have to use your own test routines.



Maintenance



This chapter explains maintenance work that you may perform on your own, i.e. it will be explained in detail what to do in case of a PCI upgrade failure (see section “Upgrading the PCI Interface” on page 3-17).

An upgrade of the PCI interface (see section “Upgrading the PCI Interface” on page 3-17) is a delicate procedure comparable to a BIOS upgrade of a computer motherboard. If, for example, an environmental extreme like a power failure occurs while the upgrade program is running, the PCI video board may lose all its programming.



Prior to performing the procedure for a PCI upgrade failure contact the DVS service department to make sure that this procedure is really necessary.

When an environmental extreme happens during a PCI upgrade and the programming of the PCI video board is lost, act as described in the following to restore it:



The computer system you are working on usually works with voltages that can be hazardous to your health.


Never work on the system or access its interior with the power cable(s) being plugged in. Make sure the power supply is disconnected from the components you intend to work on.



Computer hardware contains components that are sensitive to electrostatic discharge. If you touch them without precautionary measures, they can be destroyed.

Use a wrist strap connected to ground when accessing electronic parts and take care of grounding the video system. Avoid touching the components of the computer and the printed circuit boards of Centaurus II LT.

- If appropriate, turn off the computer system where Centaurus II LT is installed and disconnect its power cable(s).



- Open the casing of the computer system.



For details on how to do this please refer to the respective manufacturer's manual.

- Set the DIP switch for the Flash controller on the PCI video board (cf. section "Centaurus II LT Board Layout" on page 2-3) to the setting indicated in the following figure:




Figure 4-1: Setting of Flash controller DIP switch

This setting will load a safe mode programming (fallback map) when the PCI video board is initialized during start-up. Now use this fallback map to perform the PCI upgrade once again:

- Close the casing of the computer system and plug in its power cables.
- Turn on the computer system.
- After the start-up of the computer and the loading of the operating system run the PCI upgrade program (`lucyltup###`) once again:




The PCI upgrade program upgrades all installed Centaurus II LT boards in your system.

- First you have to wait while the program is inspecting the system.
 - After this you will be asked to confirm the upgrade of the firmware. For this type in Y and press [Enter].
 - Then wait until the program terminates itself which may take several minutes.
- When the update program has finished the procedure, shut down the computer.


You must now set the DIP switch for the Flash controller back to its default position. For this perform the following:

- Disconnect the power cable(s) of the computer system.
- Open the casing of the computer system.
- Then set the DIP switch for the Flash controller back to its default setting as shown in the respective figure on page 2-4.
- Close the casing and plug in the power cable(s).
- Now start the computer.
- After the operating system has loaded check the PCI interface version as described in section "Upgrading the PCI Interface" on page 3-16.

If the interface version is upgraded, the procedure is finished.



Appendix



This chapter provides technical data and general information about Centaurus II LT.


A.1 Technical Data

The following shows the technical data of the Centaurus II LT board.



The chassis of the computer system where the Centaurus II LT board is installed must be equipped with a sufficient ventilation for cooling reasons.

PCI bus requirements	PCIe x4
Board size	Half-length, single-slot
Electrical type	3.3/12 volt
Conformity	Specification 1.0a
Operating environmental conditions	5°C (41°F) to 40°C (104°F) 20% to 80% relative humidity, non-condensing
Storage environmental conditions	-17°C (0°F) to 70°C (158°F) 10% to 80% relative humidity, non-condensing



A.2 Hardware Specifications

The following table shows the hardware specifications of Centaurus II LT.

Table A-1: Centaurus II LT specifications

Video	Input	Output
Serial Digital 4:2:2 8/10 bit	1 BNC	1 BNC
Serial Digital 4:4:4 8/10 bit (Dual Link)	–	2 BNC
Key	Input	Output
Serial Digital 4:0:0 8/10 bit for 4:2:2:4 and 4:4:4:4 Mode		1 BNC
Reference	Input	Output
Analog Reference Genlock	1 BNC	
Wordclock		1 BNC
Audio	Input	Output
Embedded Audio, 8 Digital Channels (16 optionally)	1 BNC (via Video In)	1 BNC (via Video Out)
AES/EBU, 8 Digital Channels (16 optionally)	4 (8) XLR female or 4 (8) BNC via breakout boxes	4 (8) XLR male or 4 (8) BNC via breakout boxes
Timecode	Input	Output
Longitudinal (LTC)	1 XLR female	1 XLR male
Vertical (VITC)	1 BNC (via Video In)	1 BNC (via Video Out)
Data and Control Interfaces	Input	Output
Serial RS-422	1 DB-9 female (software switchable)	
GPI (1 DB-9/DB-25)	2 TTL	3 TTL (1 for hardware watchdog)

Table A-1: Centaurus II LT specifications (cont.)

Data Formats	
Color Modes	YCbCr 4:2:2 YCbCrA 4:2:2:4 RGB 4:4:4 RGBA 4:4:4:4
Storage Format	Uncompressed YUV(A) 4:2:2(:4) / RGB(A) 4:4:4(:4) 8/10 bit, user selectable
Internal Processing	Color space conversion (RGB to YUV) Low-pass filtering (4:4:4 ↔ 4:2:2) User definable LUT (1D LUT in 10 bit) Frame repetition 3:2 & 2:3 pulldown insertion/removal Watchdog with hardware relay
Audio Formats	48 kHz, 20/24 bit

A.3 Baud Rate of RS-422 Ports

The baud rate (data transfer speed) of the RS-422 ports of Centaurus II LT can be set up via the DVS software.




For more information about how to set the baud rate of the RS-422 ports please refer to the SDK documentation.

The following settings are possible:

- 9600 baud
- 19200 baud
- 38400 baud
- 57600 baud

The maximum baud rate is 57600 baud.



A.4 Optocoupler GPI

This section provides further details about the GPI based on optocoupler technology (see section “GPI (Optocoupler Based) and LTC Panel” on page 2-13).

A.4.1 Technical Data


The following shows some technical data of the optocoupler GPI:

Output	DC or peak AC load voltage	200 V
	continuous DC load current	200 mA bidirectional
Input	min. voltage to turn to ON	2 V DC
	max. voltage to turn to ON	14 V DC

A.4.2 Block Diagrams


This section shows block diagrams of the GPI in- and output.

GPI Input



The inputs turn on if you feed a current between 2 mA and 40 mA to the positive pins, negative must then be connected to ground.

GPI Output



The output can switch loads with a maximum current of 200 mA at a voltage range from 0 V to 200 V, or up to 200 V (peak with AC) at no current.

1

2

3

4

A

I

A.5 Video Rasters

The following table shows the supported video rasters. All frequencies indicate the frame rate.

Table A-2: Supported video rasters

Raster	Total lines per frame	x size	y size	Aspect ratio
525i /29.97 (NTSC)	525	720	486	4:3
625i /25 (PAL)	625	720	576	4:3
525i /29.97 (NTSC HR)	525	960	486	16:9
625i /25 (PAL HR)	625	960	576	16:9
720p /23.976/24/25/29.97/30 /50/59.94/60	750	1280	720	16:9
1035i /29.97/30	1125	1920	1035	16:9
1080i /23.976/24/25/29.97/30	1250	1920	1080	16:9
1080p /23.976/24/25/29.97/30	1125	1920	1080	16:9
1080psF /23.976/24/25/29.97 /30	1125	1920	1080	16:9
2048p /23.976/24	1025	2048	1080	16:9
2048p /24	1600	2048	1556	4:3
2048psF /14.985/15/19.98/20 /24/30	1980	2048	1556	4:3
2048psF /24	1600	2048	1536	4:3
4096p /5	3125	4096	3112	4:3
4096psF /5	3125	4096	3112	4:3




You can find information about the internal data representation of video, audio and timecode in the SDK documentation.

A.6 Signal In- and Outputs

This section provides pin-out information about some of the connectors provided by Centaurus II LT.


GPI (9-Pin D-Sub Connector)



(external view;
male on interface, female on cable)


Pin No.	Signal
1	–
2	GND
3	GPI_OUT0 (GPI output 0)
4	GPI_IN0 (GPI input 0)
5	–
6	–
7	GPI_OUT1 (GPI output 1)
8	GPI_IN1 (GPI input 1)
9	GND

The GPI inputs are voltage sensing inputs with TTL trigger levels ($> 2V$ = high, $< 0,8V$ = low). Without any input they are set to 'high'. Thus, with a connected switch the user will be able to connect the voltage level to ground (GND) and no extra power supply has to be set for the GPI inputs.



GPI/LTC Pin-out (15-Pin D-Sub Connector)

The DB-15 plug provides the optocoupler GPI as well as LTC in- and output. It can be connected to a breakout cable providing one DB-25 and two XLR connectors.




(external view;
male on interface, female on breakout cable)

Pin	Signal	Pin	Signal
1	GPI_IN0 (GPI input 0)	9	/GPI_IN0 (GPI input 0)
2	GPI_IN1 (GPI input 1)	10	/GPI_IN1 (GPI input 1)
3	GPI_OUT0 (GPI output 0)	11	/GPI_OUT0 (GPI output 0)
4	GPI_OUT1 (GPI output 1)	12	/GPI_OUT1 (GPI output 1)
5	GPI_OUT2 (GPI output 2)	13	/GPI_OUT2 (GPI output 2)
6	LTC OUT	14	/LTC OUT
7	LTC IN	15	/LTC IN
8	LTC GND		


GPI Pin-out (25-Pin D-Sub Connector Breakout Cable)


The DB-25 connector of the breakout cable provides the following pin-out once connected to the GPI/LTC plug of the GPI and LTC panel:



(external view;
male on breakout cable, female on cable)

Pin	Signal	Pin	Signal
1	–	14	–
2	–	15	–
3	/GPI_OUT2 (GPI output 2)	16	GPI_OUT2 (GPI output 2)
4	–	17	/GPI_OUT1 (GPI output 1)
5	GPI_OUT1 (GPI output 1)	18	–
6	/GPI_OUT0 (GPI output 0)	19	GPI_OUT0 (GPI output 0)
7	–	20	–
8	–	21	–
9	–	22	–
10	–	23	–
11	–	24	GPI_IN1 (GPI input 1)
12	/GPI_IN1 (GPI input 1)	25	GPI_IN0 (GPI input 0)
13	/GPI_IN0 (GPI input 0)		



Digital Audio (25-Pin D-Sub Connector)

(external view;
female on interface, male on cable)

Table A-3: Digital Audio Ch. 1-8/LTC

Pin No.	Signal	Pin No.	Signal
1	Audio OUT CH 7/8, or LTC OUT	14	/Audio OUT CH 7/8, or /LTC OUT
2	GND	15	Audio OUT CH 5/6
3	/Audio OUT CH 5/6	16	GND
4	Audio OUT CH 3/4	17	/Audio OUT CH 3/4
5	GND	18	Audio OUT CH 1/2
6	/Audio OUT CH 1/2	19	GND
7	Audio IN CH 7/8, or LTC IN	20	/Audio IN CH 7/8, or /LTC IN
8	GND	21	Audio IN CH 5/6
9	/Audio IN CH 5/6	22	GND
10	Audio IN CH 3/4	23	/Audio IN CH 3/4
11	GND	24	Audio IN CH 1/2
12	/Audio IN CH 1/2	25	GND
13	–		

Table A-4: Digital Audio Ch. 9-16

Pin No.	Signal	Pin No.	Signal
1	Audio OUT CH 15/16	14	/Audio OUT CH 15/16
2	GND	15	Audio OUT CH 13/14
3	/Audio OUT CH 13/14	16	GND
4	Audio OUT CH 11/12	17	/Audio OUT CH 11/12
5	GND	18	Audio OUT CH 9/10
6	/Audio OUT CH 9/10	19	GND

Table A-4: Digital Audio Ch. 9-16 (cont.)

Pin No.	Signal	Pin No.	Signal
7	Audio IN CH 15/16	20	/Audio IN CH 15/16
8	GND	21	Audio IN CH 13/14
9	/Audio IN CH 13/14	22	GND
10	Audio IN CH 11/12	23	/Audio IN CH 11/12
11	GND	24	Audio IN CH 9/10
12	/Audio IN CH 9/10	25	GND
13	–		

1

2

3


4

A

I

RMT (9-Pin D-Sub Connector)

The RS-422 connector available on the slot panel of Centaurus II LT can be switched between master and slave mode via the software, i.e. between RMT OUT and RMT IN.



(external view;
female on interface, male on cable)

RMT IN	
Pin No.	Signal
1	–
2	/TX_B_CON
3	RX_B_CON
4	GND
5	–
6	GND
7	TX_B_CON
8	/RX_B_CON
9	–

RMT OUT	
Pin No.	Signal
1	–
2	/RX_A_CON
3	TX_A_CON
4	GND
5	–
6	GND
7	RX_A_CON
8	/TX_A_CON
9	–

A.7 Conformity Declarations

Centaurus II LT has been tested according to the applying national and international directives and regulations. The following states further information about the compliances and conformities.

A.7.1 RoHS Compliance

The EU directive 2002/95/EC 'Restriction of Hazardous Substances (RoHS)' prohibits the use of certain substances in electrical and electronic equipment. All DVS products are manufactured in compliance with this directive.

A.7.2 EC Declaration of Conformity (CE Marking)

DVS Digital Video Systems GmbH herewith declares that the following product(s) according to the provisions of the mentioned EC Directives – including their relevant revisions at the time of this declaration – is (are) in conformity with the detailed standards or other normative documents:

Centaurus II LT	EC Directives: <ul style="list-style-type: none">– EMC Directive 2004/108/EC– Low-Voltage Directive 2006/95/EC
	Applied Harmonized Standards: <ul style="list-style-type: none">– EN50081-1– EN50082-2– EN55022– EN55024– EN61000-4-2– EN61000-4-3– EN61000-4-4– EN61000-4-5– EN61000-4-6

1

2

3


4

A


I

A.8 Short Reference: Centaurus II LT Board

This section provides a short reference to the Centaurus II LT board.



Index



Numerics


- 9-pin D-Sub connector pin-out A-7, A-12
- 15-pin D-Sub connector pin-out A-8
- 25-pin D-Sub connector pin-out A-9, A-10

A-C

- analog stereo output 2-9
- audio
 - analog stereo output 2-9
 - breakout box 2-9
 - digital 2-4, 2-5, 2-9, 2-10, A-10
 - GPI (opto.) 2-13, 3-3
 - GPI (opto.) installation 3-7, 3-10
 - jumper settings 3-3
 - panel 2-9, 3-7
 - pin-out A-10
 - wordclock 2-11, 3-8
- audio panel 2-9
 - installation 3-7
- baud rate (RS-422 ports) A-3
- breaking line 2-5
- breakout box 1-8, 2-7
 - audio 2-9
- breakout cable 2-2
 - audio 2-9
 - GPI & LTC 2-13, A-8
 - replacement 1-8
- Centaurus II LT
 - see OEM product
- Centaurus II LT board
 - see PCI video board
- chapter overview 1-3
- color modes 2-5
- conformity declaration 1-7, A-13
- conventions of user guide 1-4
- cooling 1-6

D-F

- DB-9 connector ... 2-4, 2-11, A-7, A-12
- DB-15 connector 2-13, A-8
- DB-25 connector . 2-9, 2-13, A-9, A-10
- declaration of conformity 1-7, A-13
- digital audio 2-9
 - Ch. 1-8/LTC 2-4, 2-10, A-10
 - Ch. 9-16 2-5, 2-10, A-10
- digital video 2-4, 2-8, 2-12, 2-14
- DIP switch for Flash controller .. 2-4, 4-2, 4-3
 - default/factory setting 2-4
- DOS prompt 3-16
 - setting license key 3-14
 - test of installation 3-21
- driver 3-1, 3-12
- dual link 2-4, 2-5, 2-8, 2-12, 2-14, 3-6
 - capability 2-8, 2-11, 2-13
- DVS driver 3-1, 3-12
- DVS OEM web site 1-8, 1-9, 3-16
- DVS SDK 2-2
 - installation 3-12
- DVSConf
 - overview 3-20
 - setting license key 3-13
 - test of installation 3-19
- environmental conditions 1-6
- environmental extreme 4-1
- factory setting
 - DIP switch for Flash controller 2-4



fallback map	4-2
flat cable connectors	1-8

G-I

genlock	2-4
GPI	2-4, 2-11, 3-8
jumper settings	3-4
pin-out	A-7, A-9
power line	3-8
GPI (opto.)	2-4, 2-13, 3-10
audio	2-13, 3-3
jumper settings	3-4
pin-out	A-8
GPI & audio WCLK panel	2-11
installation	3-8
GPI & LTC panel	2-13
audio	2-13, 3-3
installation	3-10
installation with audio	3-7, 3-10
guarantee	1-7
hardware	2-2
important notes	1-7
installation	
audio with GPI (opto.)	3-7, 3-10
driver	3-12
DVS SDK	3-12
OEM product	3-2
panels	3-5
PCI video board	3-5
test	3-19
instructions	
hardware installation	3-2
PCI interface upgrade	3-16
PCI interface upgrade failure	4-1
safety	1-5
setting of license key	3-12
software installation	3-12
test of installation	3-19

J-L

jumper settings	
audio	3-3
GPI/GPI (opto.)	3-4
key channel	2-5, A-2
layout (video board)	2-3, A-14
LED	2-4, 2-6
license key	3-12
DVSCnf	3-13
MS DOS prompt	3-14
setting	3-12

shell	3-14
low profile slot panel	2-13
LTC	2-4, 2-9, 2-13, 3-3, 3-10, A-10
pin-out	A-8
lucyltup###	3-16, 4-2

M-O

maintenance	4-1
master control	2-4, A-12
MS DOS prompt	
PCI interface upgrade	3-16
setting license key	3-14
test of installation	3-21
OEM product	1-1
audio breakout cable	2-9
board overview	2-3, A-14
breakout box	1-8, 2-7
breakout cable	1-8, 2-2
dual link	2-8, 2-11, 2-13, 3-6
GPI & LTC breakout cable	2-13, A-8
installation	3-2
maintenance	4-1
overview	2-2
specifications	A-2
technical data	A-1, A-4
OEM web site	1-8, 1-9, 3-16
optimum performance	3-5
overview	
DVSCnf	3-20
of chapters	1-3
of OEM product	2-2
of panels	2-7
of PCI video board	2-3, A-14

P-R

panel	
audio	2-9, 3-7
GPI & audio WCLK	2-11, 3-8
GPI & LTC	2-13, 3-10
installation	3-5
low profile	2-13
overview	2-7
SDI	2-8, 3-6
PCI interface upgrade	3-16
failure	4-1
MS DOS prompt	3-16
shell	3-16
PCI video board	1-1, 2-2
installation	3-5
layout	2-3, A-14

- LED 2-6
- overview 2-3, A-14
- PCI interface upgrade 3-16
- short reference A-14
- technical data A-1, A-4
- performance 3-5
- pin-out
 - 9-pin D-Sub connector A-7, A-12
 - 15-pin D-Sub connector A-8
 - 25-pin D-Sub connector .. A-9, A-10
 - audio A-10
 - GPI A-7, A-9
 - GPI (opto.)/LTC A-8
 - remote control (9-pin D-Sub) ... A-12
- power failure 4-1
- power line (GPI) 3-8
- Ref. In 2-3
- Ref. Term 2-4
- reference input 2-3
 - termination 2-4
- remote control pin-outs
 - 9-pin D-Sub A-12
- RS-422 2-4, A-12
 - baud rate A-3
- jumper for audio 3-3
- jumper for GPI/GPI (opto.) 3-4
- shell
 - PCI interface upgrade 3-16
 - setting license key 3-14
 - test of installation 3-21
- single link 2-4, 2-5, 2-8, 2-12, 2-14
- slave control 2-4, A-12
- software 2-2
- specifications of OEM product A-2
- svram program 3-16, 3-21
- sync signal 2-6
- synchronization 2-12
- system requirements 1-9
- target group 1-3
- technical data A-1, A-4
- termination of Ref. In 2-4
- test of installation 3-19
 - DVSConf 3-19
 - MS DOS prompt 3-21
 - shell 3-21
- test pictures 3-19
- typographical conventions 1-4

S-T

- safety instructions 1-5
- SCSIVIDEO_CMD 3-15, 3-16
- SDI panel 2-8
 - installation 3-6
- SDK
 - see DVS SDK
- serial digital interface 2-4, 2-8, 2-12, 2-14
- setting
 - default/factory 2-4

U-Z

- unplugging flat cables 1-8
- video board
 - see PCI video board
- video raster A-6
- video signal 2-6
- warranty 1-7
- WCLK 2-11, 3-8
- wordclock 2-11, 3-8
- XLR connectors 2-9, 2-13, A-8

1

2

3

4

A

I

