

# TSDZ2 w/860C

## OSF Upgrade V20.1C.3

### Features and Configuration

#### CAUTION:

- Before flashing, if there is already an older version on the display, make a note of the Odometer value, so that it can be entered in the new version.
- Battery Setting. Do not exceed 15 Amps (36 Volts battery), 12 Amps (48 Volts battery), 10 Amps (52 Volts battery) or you run the risk of overheating your motor.
- Always use the same firmware version for both the TSDZ2 motor controller and display!
- Before using the TSDZ2 and display with new firmware, you must correctly configure the options on the display. For example, you should configure your battery's low voltage cut-off so as not to over-discharge the battery. Do set all other parameters also to ensure proper operation.
- When installing new firmware, always check that no unwanted functions have become enabled or disabled during the install process.
- It is recommended that when installing OSF V20.1C configuring the display and motor using this guide that you take safety precautions. You should have the rear wheel off the ground in case the motor activates. For extra precaution, you should install brake cutoffs and have them easily accessible as well as be ready to disconnect or cut off power to the battery.
- Each time the display is turned on, do not touch the pedals for at least 5 seconds, until the system finishes booting...
- Never connect or disconnect the charger from the battery with mains power applied. Always connect or disconnect mains power before connecting or disconnecting the battery.

## 860C Display Navigation

### Main screen

NOTE: The display has 3 different main screens with customized numeric and graph fields on each main screen. You can change the information/variables shown on these customized fields.

- Turn on/off: POWER long-press,
- Change assist level: UP or DOWN click
- Change assist mode: At level 0, ON/OFF click to view the current mode, UP/DOWN click to change, ON/OFF click to confirm.
- Turn on/off the lights: UP long press
- Walk assist: Hold DOWN pressed (walk-assist is only enabled while DOWN button is pressed)
- Street mode on/off: While pressing DOWN, long-press POWER

- Motor max power: While pressing UP, long-press POWER
- Virtual throttle: in "Motor max power" mode, while pressing UP, long-press POWER
- Alternate main screen: POWER click, with assistance level greater than zero.
- Enter configurations screen: simultaneous POWER, UP and DOWN, long press
- To set a shortcut key to the 860C Configuration menu. Enter as above and go to the Display menu item. By enabling this function (yes), with an assistance level greater than zero, it is possible to directly access the configuration menu by pressing and holding the M key.
- Only with level = 0, long pressing of the M button activates the customization of the numerical fields and graphs in the 3 main screens.

## Change variables on numeric fields or graph

- Select the variable: simultaneous UP and DOWN, long-press MENU, press
- Leave: POWER long press
- Choose new variable: UP or DOWN click
- Jump to next field: POWER click
- UP and DOWN long press to select on the graph the X-axis scale from 15m, 1h, 4h or automatic
- UP or DOWN click to change X axis scale
- POWER long-press to leave

## Assist mode

There are 5 assistance modes available, the choice is on the main screen.

- POWER ASSIST assistance proportional to the power on the pedals
- TORQUE ASSIST assistance proportional to the torque on the pedals
- CADENCE ASSIST assistance subordinated to the movement of the pedals
- EMTB ASSIST assistance with a progressive percentage of the torque on the pedals
- HYBRID ASSIST combined torque + power assistance

At level 0, ON/OFF button to view the current mode, UP/DOWN button to change, ON/OFF button to confirm.

Assistance values for all modes from 1 to 254, for eMTB from 1 to 20.

“Hybrid assist” is a combination of the “Torque assist” and “Power assist” modes. The result is excellent low-cadence assistance typical of Torque mode, and the extension of high-cadence Power mode. The assistance parameters are the same used in the two modes, combined with the same level.

## Available information to show on display

There are a few variables that can be selected to be shown on the customized numeric fields or

graph. Note that only some of them are available to be shown on the graph. The underlined variables can be shown on the graph as well as in the numeric fields.

Variable	Description
<u>speed</u>	Tracking speed changes during trips.
<u>trip distance</u>	Amount of km/mi counted from the startup of the system.
<u>cadence</u>	Pedal cadence measured using the PAS sensor inside the TSDZ2 motor.
<u>human power</u>	<p>Pedal human power. This is calculated with a torque sensor ADC value obtained from calibration with a weight in kg or lbs.</p> <p>pedal-torque in Nm is calculated as pedal-torque = weight Kgs on pedals * 9.81 (gravity) * 0.17 (0.17 is the arm cranks size)</p> <p>pedal power in watts is calculated as: pedal power = (pedal-torque * pedal cadence * 2 * pi) / 60</p>
<u>motor power</u>	This value is calculated by multiplying the battery current by the battery voltage.
<u>Wh/m</u>	Battery power used by each mile.
<u>batt voltage</u>	Battery voltage measured by the TSDZ2 motor controller.
<u>batt current</u>	Battery current measure by the TSDZ2 motor controller.
<u>battery SOC</u>	Battery state of charge, based on counting the amount of power pulled from the battery to power the TSDZ2 motor.
<u>motor current</u>	Motor current. This value is calculated as: motor current = measured battery current / PWM duty-cycle. Note that PWM duty-cycle value varies between 0 and 1.
<u>motor temp</u>	Motor temperature. Note that if the temperature sensor is not installed, this value has no meaning.
<u>motor speed</u>	In ERPS (electric rotation per second) units. The motor has 8 pairs of magnets inside, meaning each 1 ERPs equal to one RPS (rotation per second).

<u>motor pwm</u>	Motor PWM duty-cycle. This value can fluctuate between 0% and 100% max. Where 0 means 0 battery voltage applied to motor coils while 100 means max battery voltage applied. When this value hits the max of 100, means that the motor max power possible is being applied.
<u>motor foc</u>	Angle calculated by FOC algorithm, between 0 and 30. Higher motor phase current and/or higher motor speed makes this value increase.

## Navigating the Configuration Menu

- Enter Configuration Menu: Press and hold UP, DOWN, then immediately long-press POWER.  
(There is a shortcut key on the 860C that is a long press on MENU. This shortcut must be enabled in Display Menu below.)
- Exit: POWER long press to go back
- Scroll up or down: UP or DOWN click
- Edit item: MENU click
- Apply: MENU click

## Configuration Menu

### Trip Memories

Name	Recommended value	Description
<u>An Auto Reset</u>	Enable	This setting will auto-reset your trip A after the number of hours defined in “Auto Reset Hours”.
<u>An Auto Reset Hours</u>	24h, 1 day	The number of hours before reset.
<u>B Auto Reset</u>	Enable	This setting will auto-reset your trip B after the number of hours defined in “B Auto Reset Hours”.
<u>B Auto Reset Hours</u>	168h, 1 week	The number of hours before reset.
<u>Reset Trip A</u>	N	If you change this to Y, it clears Trip A.
<u>Reset Trip B</u>	N	If you change this to Y, it clears Trip B.

## Wheel

Name	Recommended value	Description
Max speed	25 km/h 35 mph	Enter the speed limit from where the motor will fade out power from.
Circumference	2060	<p>Enter your wheel circumference so that speed and distance are correctly calculated.</p> <p>Tip: Search on Google how to measure the wheel circumference. Below are approximate values for a quick setup. Remember to calibrate with GPS for finer adjustments.</p> <p>20-inch wheel = 1595 mm 24-inch wheel = 1830 mm 26-inch wheel = 2060 mm 27-inch wheel = 2150 mm 27.5-inch wheel = 2215 mm 28-inch wheel = 2250 mm 29-inch wheel = 2300 mm</p>

## Battery

Name	Recommended value	Description
------	-------------------	-------------

<u>Max current</u>	11 Amp	<p>Set maximum allowable current to be pulled from the battery - this value is a technical characteristic of your battery, you need to find it on your battery user manual or ask the manufacturer. Also, the TSDZ2 has its own limit of the max current it can pull from the battery that is 18 amps so the TSDZ2 firmware limits this value (no point for you to set up a higher value than 18).</p> <p>Maximum recommended values: 15 Amps (36 Volts battery), 12 Amps (48 Volts battery), 10 Amps (52 Volts battery).</p> <p>If you set it above these values, do not run this motor above 450 watts for more than a few minutes without installing the temperature sensor..</p>
<u>Low cut-off</u>	39 volts	<p>The controller will reduce power to stay over this limit! NOTE: You should only use a battery with a BMS to avoid dangerous conditions.</p> <p>Calculate the Low cut-off limit by multiplying the number of cells in series with the safe cut-off-voltage per cell, which is usually between 2.8 - 3.0 volts. Example: 30.0 volts: 10 cells in series * 3.0 volts = 30.0 volts. 39.0 volts: 13 cells in series * 3.0 volts = 39.0 volts. 42.0 volts: 14 cells in series * 3.0 volts = 42.0 volts.</p> <p>Note that by setting a high Low cut-off limit you will make less deep discharging cycles of your battery meaning the battery life will be increased AND you will then have less power available to use and so less range.</p>
<u>Resistance</u>	200 milliohms	<p>The battery SOC (State Of charge) indicator uses the battery resistance to consider the power loss inside the battery resistance and also the resistance on the cables. See Resistance set field instructions to know how you can get this value. See Resistance auto estimate to enter as this number.</p>
<u>Voltage auto estimate</u>	-	<p>Real-time battery voltage value that is filtered using the battery pack resistance. If the battery resistance value is correct, this voltage should almost not change when the motor is not running or when the motor is running and pulling a high current from the battery.</p>

<u>Resistance auto estimate</u>	-	<p>Battery resistance estimated value that is automatically calculated so you can assess his value and then configure the Resistance field.</p> <p>How to start the automatic battery pack resistance estimation:</p> <p>start with the battery already discharged, with any value between 75% and 25%</p> <ul style="list-style-type: none"> <li>• start pedaling for 10 consecutive seconds, make the motor pull high current value from the battery like 10 amps (use a high assist level). After 10 seconds you should see a value on the field. For battery pack of 14S3P 3500 mAh cells, I get a value near 200 milliohms.</li> <li>• repeat the previous step a few times to make sure you always get a similar value</li> <li>• set the measured value Resistance field (I always round up the value)</li> </ul>
<u>Power loss auto estimate</u>	-	Power loss estimated value that happens inside the battery pack due to battery and cables resistance.

## SOC

For correct configuration of SOC: 1. set battery Watt-hour value 2. set battery voltage to reset the SOC counter 3. set the battery internal resistance

The battery needs to be charged to at least the predefined battery voltage to reset the counter. You can set the reset voltage to any voltage you like.

Name	Recommended value	Description
<u>Text</u>	Volts	"SOC %" to show on the main screen, near the battery symbol, the value of SOC in percentage. Or "Volts" to show the battery voltage and "disable" to show nothing'

<u>Reset at voltage / Reset at</u>	54.0	<p>Threshold voltage to reset the SOC watt-hour meter: when powering on the display this value is compared to the battery voltage. If the battery voltage is higher, then the battery is expected to be fully charged and the SOC watt-hour meter is reset, effectively resetting the SOC to 100%.</p> <p>Tip: To find a suitable value, fully charge the battery and measure the voltage on the display, use a slightly lower value for the threshold voltage.</p> <p>For example:  36V battery charge up to 42.0 volts, set threshold to 41.5.  48V battery charge up to 54.6 volts, set threshold to 54.1.  52V battery charge up to 58.8 volts, set threshold to 58.3.</p>
<u>Battery total Watt-hour / Battery total</u>	500	<p>Set the total capacity in watt-hours less 10% of what your battery has.</p> <p>Tip: fully charge the battery and then discharge it completely and use the measured value to input here. NOTE that you also need first to set up the correct value of your battery internal resistance as also the low cut-off voltage.</p> <p>Tip: the capacities stated by the suppliers are often too high, expect a value of around 80 % - 90 % of the stated value.</p> <p>Tip: roughly calculate the capacity by multiplying the nominal voltage with the nominal amp hours. For example a 52 Volt, 10 Ah battery has a nominal watt-hour capacity of 520 Wh.</p>
<u>Used Watt-hour</u>	0	<p>This value shows the SOC watt-hour meter value. You can change this value if you need, like in the event that the battery was not fully charged and this value is not accurate anymore.</p>
<u>Manual reset</u>	no	<p>Use when putting on an incompletely charged battery or at the first power on after the flashing. In this case, "Used Wh" is calculated with reference to voltage. When the battery is fully charged, the reset to 100% is automatic.</p>

## Motor



Name	Recommended value	Description
<u>Motor voltage</u>	48V	Depending on the type of motor, set the appropriate value so that FOC calculations are correctly executed. The voltage of the battery does not matter, this value should always be set depending on the type of motor. Set "48V" for a 48V brushless motor (TSDZ2 52V version has a 48V brushless motor). Set "36V" for a 36V brushless motor.
<u>Max motor power</u>	450W	Maximum motor power, set an adequate value to contain the motor heating and compatible with the power that the battery can deliver. A maximum value of 450W is recommended. Attention, it does not have to be continuous!
<u>Motor Acceleration</u>	see table	<p>Acceleration of the motor. As a first setting, use low values, then gradually increase if necessary. Consider the values in the table as maximum values. Set carefully, aware that setting a higher value than necessary can cause greater stress on the transmission.</p> <p>Recommended values:  36 Volt motor, 36 volt battery = 35  36 Volt motor, 48 volt battery = 5  36 Volt motor, 52 volt battery = 0  48 Volt motor, 36 volt battery = 45  48 Volt motor, 48 volt battery = 35  48 Volt motor, 52 volt battery = 30</p>
<u>Motor Deceleration</u>	0	<p>Set to zero, the default deceleration ramp is active, if set to 100% the minimum deceleration ramp (faster stop).</p> <p>Feature deactivated with "Motor fast stop" enabled.</p>
<u>Motor fast stop</u>	no	Enabling the motor to stop immediately when you stop pedaling. If the motor stops too abruptly, disable and use the deceleration ramp
<u>Field weakening</u>	enabled	<p>Enabled / Disabled. The field weakening function increases the motor cadence (up to 120 RPM when possible) but there is also a loss of efficiency.</p> <p>If enabled, field weakening is automatically activated when the PWM value is greater than 100%.</p>

## Torque sensor

Name	Recommended value	Description
<u>Assist w/o pedal rotation</u>	Enable	Enable to get motor assistance once you press the pedals even without rotating them. Recommended keeping disabled if you do not have brake sensors installed.
<u>Torque s ADC threshold</u>	10	Works in addition to the initial assistance with just the push on the pedals - without rotation for an immediate start. Now, this function is also activated with the bike in motion, when you resume pedaling after a break. CAUTION: By enabling the BOOST function at the same time, the effect increases! This can cause greater transmission stress.
<u>Coast brake</u>	Enable	Needs to be enabled if you have a TSDZ2 coast brake version.
<u>Coast brake ADC</u>	10	The sensitivity of the coaster brake in ADC steps when pushing pedals backward. Low value takes less strength, high value takes more strength. See for yourself the optimal value. Limits from 5 to 40
<u>Calibration</u>	Enable	Enable only after having entered the actual values of "Pedal torque ADC offset" and "Pedal torque ADC max", obtained from the calibration. Enabling without having entered the correct values can lead to unpredictable operations. Calibration procedure: see "ADC torque sensor" in the "Technical" menu, enter the ADC value of the torque sensor without any push on the pedals in "Pedal torque ADC offset". Enter the ADC value of the torque sensor with the maximum thrust applied to the pedal (cyclist standing on the right pedal in horizontal position) in "Pedal torque ADC max". Torque sensor calibration is required if the working range is limited. "Pedal torque ADC max" - "Pedal torque ADC offset" Caution. The ADC values of the torque sensor over time may change, check periodically.

<u>Torque sensor ADC step</u>	67	<p>A conversion factor of the torque applied to the pedal.</p> <p>It is used to calculate the correct ratio between the assistance factor and the human power (only in "Power assist"), the actual value obtained from the calibration can be entered.</p> <p>This parameter is not used for the calculation of the human power shown on the display.</p>
<u>Torque sensor ADC offset</u>		<p>ADC value of the torque sensor without any push on the pedals.</p> <p>It is obtained from the calibration procedure to be carried out on the display.</p> <p>When you need to increase the sensitivity at the start, for example with an arm-bike, subtract a number from 1 to 10 from the value obtained. If the power assist wants to go before you do add a number to the value.</p> <p>Caution: Decreasing the offset value too much can cause an unwanted start and/or a delayed motor stop.</p>
<u>Torque ADC max</u>		<p>ADC value of the torque sensor with the maximum thrust applied to the pedal (cyclist standing, on the right pedal in horizontal position).</p> <p>It is obtained from the calibration procedure to be carried out on the display.</p> <p>This parameter is used to amplify the range of use of the torque sensor when it is too limited.</p> <p>Check that the assistance is well distributed overall levels and in all modes, if necessary correct the value obtained in plus or minus. Lower value = higher amplification.</p>
<u>Weight on pedal</u>	25 kg or 55 lb	<p>Weight to be applied to the pedal for the calibration of the ADC value of the torque sensor used for the calculation of the human power to be shown on the display. Use a weight of 25 Kg. or 55 lb.</p> <p>It is not essential, it does not affect the operation of the motor, it only serves for a correct display of human power.</p>
<u>Torque ADC on weight</u>		<p>ADC value of the torque sensor for the calculation of human power to be shown on the display, it is not used for the calculation of the assistance factor.</p> <p>It is obtained from the calibration procedure with a weight, to be carried out on the display.</p>

<u>Default weight</u>	no	After having entered the calibration values in "Torque ADC offset" and "Torque ADC max", with this function it is possible to calculate an estimated value of "Torque ADC on weight" for a weight of 25Kg. The value is less accurate than that obtained with real calibration, but it is adequate for the purpose.
-----------------------	----	---

## Assist level / Assist

Name	Recommended value	Description
<u>Number of assist levels / Num levels</u>	5	Select the desired number of assist levels from a minimum of 1 to a maximum of 9. If you choose for instance 5, only the first 5 levels will be available.
<u>Power Assist</u>	I use 1-5	<p>"Power assist" is an assistance mode proportional to the power on the pedals.  Levels available from 1 to 9. Set assistance levels according to your needs. Value% / 2, maximum 254.  For example, applying 100 Watt to the pedals, with 150 assist level, the motor delivers 300 Watt.  These assistance parameters are also used in the hybrid mode.</p> <p>DEFAULTS:  Level 1: 25  Level 2: 50  Level 3: 75  Level 4: 100  Level 5: 130  Level 6: 160  Level 7: 190  Level 8: 220  Level 9: 250</p>

<u>Torque Assist</u>	I use 1-5	<p>“Torque assist” is an assistance mode proportional to the torque on the pedals. Levels available from 1 to 9. The power delivered by the motor is proportional to the applied torque and the set assistance values. Set assistance levels according to your needs. Relative values, maximum 254. These assistance parameters are also used in the hybrid mode.</p> <p>DEFAULTS: Level 1: 50 Level 2: 70 Level 3: 90 Level 4: 120 Level 5: 140 Level 6: 160 Level 7: 190 Level 8: 220 Level 9: 250</p>
<u>Cadence Assist</u>	I don't use	<p>“Cadence assist” is an assistance mode that uses cadence only and does not use the torque sensor. Levels available from 1 to 9. The power supplied by the motor depends partly on the assistance values set and partly on the cadence of the pedals. Relative values, maximum 254. It is recommended to use this assistance mode with the brake sensors installed and enabled.</p> <p>DEFAULTS Level 1: 100 Level 2: 120 Level 3: 130 Level 4: 140 Level 5: 160 Level 6: 180 Level 7: 200 Level 8: 220 Level 9: 250</p>

<u>eMTB assist</u>	L9: 20	<p>“eMTB assist” is an assistance mode with a progressive percentage of the torque on the pedals. Levels available from 1 to 9. The power delivered by the motor is progressively proportional to the applied torque. There are 1-20 predefined sensitivities.</p> <p>Higher values correspond to more responsive assistance, quicker to reach maximum motor power.</p> <p>DEFAULTS</p> <p>Level 1: 4</p> <p>Level 2: 6</p> <p>Level 3: 8</p> <p>Level 4: 10</p> <p>Level 5: 12</p> <p>Level 6: 14</p> <p>Level 7: 16</p> <p>Level 8: 18</p> <p>Level 9: 20</p>
--------------------	--------	---

## Walk assist

Name	Recommended value	Description
<u>Feature</u>	enable	Enable or disable the walk assist function.
<u>Level</u>	5	<p>DEFAULTS:</p> <p>Level 1: 35</p> <p>Level 2: 40</p> <p>Level 3: 45</p> <p>Level 4: 50</p> <p>Level 5: 55</p> <p>Level 6: 55</p> <p>Level 7: 55</p> <p>Level 8: 55</p> <p>Level 9: 55</p>

<u>Cruise Feature</u>	Disable	<p>Enable/Disable the cruise function. It can only be enabled with Walk assist enabled.</p> <p>By pressing the DOWN button for a long time at speeds above 9 km/h and with the function enabled, the current speed is stored and maintained for as long as the button is pressed. Speed may not be achieved due to limited motor power.</p> <p>The speed limit has priority.</p> <p>It is recommended to use cruise mode with brake sensors installed.</p> <p>Find out about the legal restrictions in your country.</p>
-----------------------	---------	--

## Startup BOOST / Start Power

Name	Recommended value	Description
<u>Feature</u>	Enable	<p>"Startup boost" must be enabled. The feature only works in POWER mode. Uses torque and cadence to give additional power at startup.</p>
<u>Boost Torque Factor</u>	300	<p>It is used to increase the starting assistance and at a low cadence.</p> <p>Available only in "Power assist" mode.</p> <p>It works both with a standing start and with resuming the pedaling in motion.</p> <p>The value of this parameter is the percentage increase in torque applied to the pedals with cadence = 0. This value gradually decreases as the cadence increases, depending on the next parameter.</p> <p>Set carefully, aware that setting too high a value can cause greater stress to the transmission. Value in %, recommended 250, maximum 500.</p>
<u>Startup boost cadence step</u>	20	<p>It is used to calculate the decrease in the boost torque factor as the cadence increases until extinction.</p> <p>Recommended value 25. Limits from 10 to 50, higher value = shorter effect.</p>

## Motor temperature

Here you can enable or disable the throttle or the motor temperature protection that will let you push the motor limits. Note that you must first install the [motor temperature sensor](#).

#### NOTES:

- The throttle and the motor temperature protection cannot be active simultaneously. This is because they use the same hardware ports to operate.
- If the motor temperature sensor is installed it is not possible to use the throttle. Do NOT enable throttle if that is the case.

Name	Recommended value	Description
<u>Feature</u>	Throttle	NOTE: THIS SETTING ENABLES THROTTLE. You must also enable throttle in STREET MODE to fully activate. "disabled" means that neither motor temperature limit function nor throttle is enabled. Set to "temperature" to enable the automatic motor temperature control limit or set to "throttle" to enable the throttle.  NOTE: Do NOT enable the throttle if you have installed the <a href="#">motor temperature sensor</a> . If you have the temp sensor installed you need to either have the motor temperature limit function enabled or everything disabled.
<u>Min limit</u>	149F or 75°C	Set the minimum motor temperature at which the power will start to be limited.
<u>Max limit</u>	185F or 85°C	Set the maximum motor temperature at which the power will be completely blocked, i.e. no motor assistance. Max recommended value is 85 degrees Celsius.

## Street mode

This feature enables users to limit speed and power when using the bike on public roads (useful in the case the local laws impose such limitations - YOU MUST CHECK YOUR OWN LOCAL LAWS AND COMPLY WITH THEM). It is also possible to disable the throttle function when in Street Mode.

On the 860C display, you will see the ASSIST label with orange color when the street mode is disabled.

Name	Recommended value	Description
------	-------------------	-------------



<u>Enable Mode</u>	No	When this feature is disabled, you cannot activate it from the main screen.
<u>Enable at startup</u>	No	Determines whether Street mode should be active on system startup.
<u>Speed limit</u>	25 km/h 35 mph	Set the speed limit for when Street Mode is active. The motor will fade out power from -0.5 km/h to + 2,0 km/h to prevent overspeeding.
<u>Motor power limit</u>	250 W	The power limit in watts when Street Mode is active.
<u>Throttle enable</u>	Yes	Determines if the throttle is enabled in Street Mode.
<u>Cruise enable</u>	No	Enable/disable the cruise function in "Street mode".
<u>Hotkey enable</u>	No	No / Yes, enable activation via a combination of buttons, the functions: Street mode: on / off Motor max power: set value Virtual throttle: set and use

## Variables

This configuration lets you configure some options of the possible variables shown on the numeric field and on graphs.

Name	Recommended value	Description
<u>Graph auto max min</u>	x	Should the graph use automatic values for max and min or use the following manual values.
<u>Graph max</u>	x	Set the graph max value. Will be set up to when a new value on the graph is lower than this value.
<u>Graph min</u>	x	Set the graph min value. Will be set up to when a new value on the graph is higher than this value.
<u>Thresholds</u>	x	Thresholds will make the graph or numeric field values fade to yellow or red color, depending on the variable value. For instance, as soon as motor speed starts to approach near its max value, the color will fade first to yellow and then to red. You can disable, set to manual or automatic the thresholds.

<u>Max threshold</u>	x	Set the value for manual max threshold, for red color.
<u>Max threshold</u>	x	Set the value for manual max threshold, for yellow color.

## Various

Name	Recommended value	Description
<u>Lights configuration</u>	x	<p>Choose your preferred mode from the 9 available. With light control ON:</p> <ul style="list-style-type: none"> <li>0 – on</li> <li>1 – flashing</li> <li>2 - on and fast flashing when braking</li> <li>3 - flashing and on when braking</li> <li>4 - flashing and fast flashing when braking</li> <li>5 - on and on during braking also with light control OFF</li> <li>6 - on and fast flashing when braking even with the light control OFF</li> <li>7 - flashing and switched on when braking even with the light control OFF</li> <li>8 - flashing and fast flashing when braking even with the light control OFF</li> </ul> <p>The braking modes are only available with the brake sensors installed.</p>
<u>Assist with error</u>	0	<p>Enabled / Disabled. The presence of an error disables assistance in all modes. It is however possible to force assistance even with an error if this is caused by a problem with a sensor. Torque, cadence or speed sensor. You will have to choose the assistance mode that does not involve the use of the faulty sensor. Use only in case of need, with this function enabled there are limitations in assistance. See error codes below.</p>
<u>Virtual throttle step</u>	5	Amount steps for each increase and decrease of Virtual throttle.
<u>Odometer</u>	0	This field shows the current odometer value. You can also edit the value, like set to 0 to reset the odometer.

## Display

Name	Recommended value	Description
<u>Clock hours</u>	0	See current hour value or set a different value.
<u>Clock minutes</u>	0	See current minutes value or set a different value.
<u>Brightness on</u>	100%	Set display backlight brightness when lights are on.
<u>Brightness off</u>	30%	Set display backlight brightness when lights are off.
<u>Auto power off</u>	25m	Set the number of minutes for the display automatic power off. The auto power-off timer counter is reset when wheel speed or battery current is higher than 0, or if brakes or buttons are active.
<u>Units</u>	Imp	Set units to SI or Imperial.
<u>LCD type</u>	x	This is read-only and is the LCD type on the display and is relevant for developers. Actual options are ILI9481, ST7796 and unknown.
<u>Reset to defaults</u>	no	Set yes to reset all the configurations to default values.
<u>Config Shortcut Key for 860C</u>	Yes	By enabling this function (yes), with an assistance level greater than zero, it is possible to directly access the configuration menu with a long press of the M button. Only with level = 0, long pressing of the M button activates the customization of the numerical fields and graphs in the 3 main screens.  It is always possible to access the configuration menu with the UP + DOWN + POWER buttons.

## Technical

Here you can see the values of some variables of the system. This can help debug issues on TSDZ2

or help you understand how the system works.

Name	Recommended value	Description
<u>ADC Battery Current</u>	x	How much current is being drawn from the battery?
<u>ADC throttle sensor</u>	x	The current value of the input signal from the throttle, from 0 to 255.
<u>Throttle sensor</u>	x	The current value of the input signal from the throttle, without offset, from 0 to 255.
<u>ADC torque sensor</u>	x	The current value of the input signal from the torque sensor, from 0 to 1023.
<u>ADC torque delta</u>	x	ADC value of the torque sensor without offset. It is possible to observe and analyze the variations resulting from the calibration.
<u>ADC torque boost</u>	x	ADC value of the torque sensor without offset and with the increase of the "Startup boost" function if enabled. Only in "Power assist" mode.
<u>ADC torque step calc</u>	x	The conversion factor of the torque applied to the pedal obtained from the weight calibration. Used for the calculation of the human power shown on the display. This value can be entered in the "ADC torque step" parameter for a correct ratio in the assistance calculation (only in "Power assist").
<u>Pedal cadence</u>	x	The instantaneous value of the pedal cadence.
<u>PWM duty-cycle</u>	x	These values can fluctuate between 0 and 100 max. Where 0 means 0 battery voltage applied to motor coils while 100 means max battery voltage applied. When this value hits the max of 100, means that the max motor power possible is being applied.
<u>Motor speed</u>	x	In ERPS (electric rotation per second) units. The motor has 8 pairs of magnets inside, meaning each 1 ERPs equal to one RPS (rotation per second).

<u>Motor FOC</u>	x	Angle calculated by FOC algorithm, between 0 and 30. Higher motor phase current and/or higher motor speed makes this value increase.
<u>Hall sensors</u>	x	The current value of the motor hall sensor. You can rotate very slowly the bicycle wheel back backward to see this value changing and it must always follow the next same sequence and values must be only the next ones: 4, 6, 2, 3, 1, 5.

## Error codes

Error codes and description:

### E02 - ERROR\_TORQUE\_SENSOR

A mechanical problem may have occurred with the torque sensor or the calibration at startup has not been performed correctly. A torque was probably applied to the pedals during power on. Switch off and on again so that the system can recalibrate, without forcing the pedals. If the "Torque sensor calibration" function is enabled, check on the display if the value of "Pedal torque ADC offset" with free pedals and "Pedal torque ADC max" with maximum effort, correspond to those entered.

### E03 - ERROR\_CADENCE\_SENSOR

While pedaling, no pulses are generated by the cadence sensor, possibly faulty.

### E04 - ERROR\_MOTOR\_BLOCKED

Motor or wheel blocked, excessive current absorption without motor rotation.  
Check the cause. After 6 seconds the error disappears and the bike can be reused.

### E08 - ERROR\_SPEED\_SENSOR

Faulty speed sensor or magnet too far away.