

Projector Control Command Reference Manual

Projector Control Command Reference Manual Appendixes

The Appendixes provide supplementary information about the control commands.

No.BDT140014

Revision History

Revision	Date	Description	Reference	Supported models
6.0	September 28, 2015	Added the supported models.	3.0	NP-M403X / NP-M363X / NP-M323X / NP-M283X / NP-M403W / NP-M363W / NP-M323W / NP-M333XS / NP-M353WS / NP-M303WS / NP-M403H / NP-M323H / NP-M353HS / NP-M323HS / NP-M303HS / NP-M402W / NP-M362W / NP-M402X / NP-M362X / NP-M322X / NP-M282X / NP-M322W / NP-M352WS / NP-M302WS / NP-M332XS <i>NP-P502HL / NP-P502WL</i> NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X / NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X NP-PH1202HL / PH1002HL NP-PX651X / NP-PX581W NP-PX602UL / PX602WL NP-U321H NP-UM301X / NP-UM301W / NP-UM361X / NP-UM351W / NP-UM352W NP-V332X / NP-V332W / NP-V302X / NP-V302W / NP-V302H
5.0	August 7, 2015	Added the supported models.	3.0	NP-M403X / NP-M363X / NP-M323X / NP-M283X / NP-M403W / NP-M363W / NP-M323W / NP-M333XS / NP-M353WS / NP-M303WS / NP-M403H / NP-M323H / <i>NP-M353HS / NP-M323HS / NP-M303HS</i> NP-M402W / NP-M362W / NP-M402X / NP-M362X / NP-M322X / NP-M282X / NP-M322W / NP-M352WS / NP-M302WS / NP-M332XS NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X / NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X NP-PH1202HL / PH1002HL NP-PX651X / NP-PX581W NP-PX602UL / PX602WL NP-U321H NP-UM301X / NP-UM301W / NP-UM361X / NP-UM351W / NP-UM352W NP-V332X / NP-V332W / NP-V302X / NP-V302W / NP-V302H
4.0	August 3, 2015	Added the supported models. Corrected [3. Supported Command List] sheet. (NP-U321H : "024. ONSCREEN MUTE ON" command is not supported.)	3.0	<i>NP-M403X / NP-M363X / NP-M323X / NP-M283X / NP-M403W / NP-M363W / NP-M323W / NP-M333XS / NP-M353WS / NP-M303WS / NP-M403H / NP-M323H</i> NP-M402W / NP-M362W / NP-M402X / NP-M362X / NP-M322X / NP-M282X / NP-M322W / NP-M352WS / NP-M302WS / NP-M332XS NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X / NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X NP-PH1202HL / PH1002HL NP-PX651X / NP-PX581W NP-PX602UL / PX602WL NP-U321H NP-UM301X / NP-UM301W / NP-UM361X / NP-UM351W / NP-UM352W <i>NP-V332X / NP-V332W / NP-V302X / NP-V302W / NP-V302H</i>
3.0	June 16, 2015	Added the supported command.	3.0	Same as Revision 2.0.
2.0	May 29, 2015	Changed the supported models. Added the supported commands.	2.0	NP-M402W / NP-M362W / NP-M402X / NP-M362X / NP-M322X / NP-M282X / NP-M322W / NP-M352WS / NP-M302WS / NP-M332XS NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X / NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X NP-PH1202HL / PH1002HL NP-PX651X / NP-PX581W NP-PX602UL / PX602WL NP-U321H NP-UM301X / NP-UM301W / NP-UM361X / NP-UM351W / NP-UM352W

1.0	August 22, 2014	First version	1.0	NP4100 / NP4100W NP-M420X / NP-M420XV / NP-M350X / NP-M300X / NP-M260X / NP-M230X / NP-M300W / NP-M260W / NP-M350XS / NP-M300XS / NP-M260XS / NP-M300WS / NP-M260WS NP-M402W / NP-M362W / NP-M402X / NP-M362X / NP-M322X / NP-M282X / NP-M322W / NP-M352WS / NP-M302WS / NP-M332XS NP-M361X / NP-M311X / NP-M271X / NP-M311W / NP-M271W NP-ME360X / NP-ME310X / NP-ME270X NP-P501X / NP-P451X / NP-P451W / NP-P401W / NP-PE501X NP-P420X / NP-P350X / NP-P350W NP-PE401H NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X / NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X NP-PA600X / NP-PA500X / NP-PA550W / NP-PA500U NP-PH1400U NP-PH1000U NP-PX750U / NP-PX700W / NP-PX800X NP-PX620X / NP-PX550W NP-U300X / NP-U250X / NP-U310W / NP-U260W NP-UM330X / NP-UM280X / NP-UM330W / NP-UM280W NP-V311W / NP-V281W / NP-V311X NP-V300X / NP-V260X / NP-V300W / NP-V260W / NP-V230X / NP-V260 / NP-V230 / NP-V260R NP-VE281X / NP-VE280X / NP-VE281 / NP-VE280
-----	-----------------	---------------	-----	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Contents

1. Connecting an External Device	3
2. Standby Mode setting for receiving commands	4
3. Supported Command List	5
4. Supplementary Information by Command	
Input terminal	6
[018. INPUT SW CHANGE]	
Aspect	7
[030-12. ASPECT ADJUST]	
Eco mode	8
[097-8. ECO MODE REQUEST]	
[098-8. ECO MODE SET]	
Base model type	9
[078-1. SETTING REQUEST]	
[305-1. BASE MODEL TYPE REQUEST]	
Selection signal type	10
[078-3. INPUT STATUS REQUEST]	
[305-3. BASIC INFORMATION REQUEST]	
Sub input	11
[097-198. PIP/PICTURE BY PICTURE REQUEST]	
[098-198. PIP/PICTURE BY PICTURE SET]	

1. Connecting an External Device

<Conventions>

○ : Supported

— : Not supported

■ Projector

Model name	Serial port					LAN port	Wireless LAN unit
	4800bps	9600bps	19200bps	38400bps	115200bps		
NP-M403X / NP-M363X / NP-M323X / NP-M283X / NP-M403W / NP-M363W / NP-M323W / NP-M333XS / NP-M353WS / NP-M303WS / NP-M403H / NP-M323H / NP-M353HS / NP-M323HS / NP-M303HS	○	○	○	○	—	○	○
NP-M402W / NP-M362W / NP-M402X / NP-M362X / NP-M322X / NP-M282X / NP-M322W / NP-M352WS / NP-M302WS / NP-M332XS	○	○	○	○	—	○	○
NP-P502HL / NP-P502WL	○	○	○	○	—	○	○
NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X	○	○	○	○	○	○	—
NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X	○	○	○	○	○	○	○
NP-PH1202HL / PH1002HL	○	○	○	○	○	○	—
NP-PX651X / NP-PX581W	—	○	○	○	—	○	—
NP-PX602UL / PX602WL	○	○	○	○	○	○	—
NP-U321H	—	—	—	○	—	○	—
NP-UM301X / NP-UM301W / NP-UM361X / NP-UM351W / NP-UM352W	○	○	○	○	—	○	○
NP-V332X / NP-V332W / NP-V302X / NP-V302W / NP-V302H	—	—	—	○	—	○	—

2. Standby Mode setting for receiving commands

The Standby Mode setting that can receive commands is different depending on the model.
Please see the table below.

Target command: "015. POWER ON"

■ Projector

Model name	Setting of the Standby Mode	
	When connected using a serial cable	When connected using via a wired LAN
NP-M403X / NP-M363X / NP-M323X / NP-M283X / NP-M403W / NP-M363W / NP-M323W / NP-M333XS / NP-M353WS / NP-M303WS / NP-M403H / NP-M323H / NP-M353HS / NP-M323HS / NP-M303HS	NORMAL, NETWORK STANDBY	NETWORK STANDBY
NP-M402W / NP-M362W / NP-M402X / NP-M362X / NP-M322X / NP-M282X / NP-M322W / NP-M352WS / NP-M302WS / NP-M332XS	NORMAL, NETWORK STANDBY	NETWORK STANDBY
NP-P502HL / NP-P502WL	NORMAL, NETWORK STANDBY	NETWORK STANDBY
NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X	NORMAL, HTBaseT STANDBY	HTBaseT STANDBY
NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X	NORMAL, NETWORK STANDBY	NETWORK STANDBY
NP-PH1202HL / PH1002HL	NORMAL, NETWORK STANDBY	NETWORK STANDBY
NP-PX651X / NP-PX581W	NORMAL, NETWORK STANDBY	NETWORK STANDBY
NP-PX602UL / PX602WL	NORMAL, NETWORK STANDBY	NETWORK STANDBY
NP-U321H	NORMAL, NETWORK STANDBY	NETWORK STANDBY
NP-UM301X / NP-UM301W / NP-UM361X / NP-UM351W / NP-UM352W	NORMAL, NETWORK STANDBY	NETWORK STANDBY
NP-V332X / NP-V332W / NP-V302X / NP-V302W / NP-V302H	NORMAL, NETWORK STANDBY	NETWORK STANDBY

3. Supported Command List

<Conventions>
 ○ : Supported
 — : Not supported

■ Projector

Command	NP-M403X NP-M363X NP-M323X NP-M283X NP-M403W NP-M363W NP-M323W NP-M333XS NP-M353WS NP-M303WS NP-M403H NP-M323H NP-M353HS NP-M323HS NP-M303HS	NP-M402W NP-M362W NP-M402X NP-M362X NP-M322X NP-M282X NP-M322W NP-M352WS NP-M302WS NP-M332XS	NP-P502HL NP-P502WL	NP-PA622U NP-PA522U NP-PA672W NP-PA572W NP-PA722X NP-PA622X NP-PA621U NP-PA521U NP-PA671W NP-PA571W NP-PA721X NP-PA621X	NP-PH1202HL NP-PH1002HL	NP-PX651X NP-PX581W	NP-PX602UL NP-PX602WL	NP-U321H	NP-UM301X NP-UM301W NP-UM361X NP-UM351W	NP-V332X NP-V332W NP-V302X NP-V302W NP-V302H
009. ERROR STATUS REQUEST	○	○	○	○	○	○	○	○	○	○
015. POWER ON	○	○	○	○	○	○	○	○	○	○
016. POWER OFF	○	○	○	○	○	○	○	○	○	○
018. INPUT SW CHANGE	○	○	○	○	○	○	○	○	○	○
020. PICTURE MUTE ON	○	○	○	○	○	○	○	○	○	○
021. PICTURE MUTE OFF	○	○	○	○	○	○	○	○	○	○
022. SOUND MUTE ON	○	○	○	○	—	—	—	○	○	○
023. SOUND MUTE OFF	○	○	○	○	—	—	—	○	○	○
024. ONSCREEN MUTE ON	○	○	○	○	○	—	○	○	○	—
025. ONSCREEN MUTE OFF	○	○	○	○	○	—	○	—	—	—
030-1. PICTURE ADJUST	○	○	○	○	○	○	○	○	○	○
030-2. VOLUME ADJUST	○	○	○	○	—	—	—	○	○	○
030-12. ASPECT ADJUST	○	○	○	○	○	○	○	○	○	○
030-15. OTHER ADJUST	—	—	—	○	○	—	○	—	—	—
037. INFORMATION REQUEST	○	○	○	○	○	○	○	○	○	○
037-3. FILTER USAGE INFORMATION REQUEST	—	—	—	○	○	○	—	○	○	—
037-4. LAMP INFORMATION REQUEST 3	○	○	○	○	○	○	○	○	○	○
037-6. CARBON SAVINGS INFORMATION REQUEST	○	○	○	○	○	—	○	—	○	—
050. REMOTE KEY CODE	○	○	○	○	○	○	○	○	○	○
053. LENS CONTROL	—	—	—	—	○	○	○	—	—	—
053-1. LENS CONTROL REQUEST	—	—	—	—	○	—	—	—	—	—
053-2. LENS CONTROL 2	—	—	—	—	○	—	—	—	—	—
053-3. LENS MEMORY CONTROL	—	—	—	—	○	—	—	—	—	—
053-4. REFERENCE LENS MEMORY CONTROL	—	—	—	—	○	—	—	—	—	—
053-5. LENS MEMORY OPTION REQUEST	—	—	—	—	○	—	—	—	—	—
053-6. LENS MEMORY OPTION SET	—	—	—	—	○	—	—	—	—	—
053-7. LENS INFORMATION REQUEST	—	—	—	—	○	—	—	—	—	—
053-10. LENS PROFILE SET	—	—	—	—	○	—	—	—	—	—
053-11. LENS PROFILE REQUEST	—	—	—	—	○	—	—	—	—	—
060-1. GAIN PARAMETER REQUEST 3	—	—	—	○	○	—	○	—	—	—
078-1. SETTING REQUEST	○	○	○	○	○	○	○	○	○	○
078-2. RUNNING STATUS REQUEST	○	○	○	○	○	○	○	○	○	○
078-3. INPUT STATUS REQUEST	○	○	○	○	○	○	○	○	○	○
078-4. MUTE STATUS REQUEST	○	○	○	○	○	○	○	○	○	○
078-5. MODEL NAME REQUEST	○	○	○	○	○	○	○	○	○	○
078-6. COVER STATUS REQUEST	○	○	—	—	○	—	○	—	○	—
079. FREEZE CONTROL	○	○	○	○	○	○	○	○	○	○
084. INFORMATION STRING REQUEST	○	○	○	○	○	—	○	—	○	—
097-8. ECO MODE REQUEST	○	○	○	○	○	○	○	○	○	○
097-45. LAN PROJECTOR NAME REQUEST	○	○	○	○	○	—	○	○	○	○
097-155. LAN MAC ADDRESS STATUS REQUEST2	○	○	○	○	○	○	○	○	○	○
097-198. PIP/PICTURE BY PICTURE REQUEST	—	—	—	○	○	—	○	—	—	—
097-243-1. EDGE BLENDING MODE REQUEST	—	—	—	○	○	—	○	—	—	—
098-8. ECO MODE SET	○	○	○	○	○	○	○	○	○	○
098-45. LAN PROJECTOR NAME SET	○	○	○	○	○	—	○	○	○	○
098-198. PIP/PICTURE BY PICTURE SET	—	—	—	○	○	—	○	—	—	—
098-243-1. EDGE BLENDING MODE SET	—	—	—	○	○	—	○	—	—	—
305-1. BASE MODEL TYPE REQUEST	○	○	○	○	○	○	○	○	○	○
305-2. SERIAL NUMBER REQUEST	○	○	○	○	○	○	○	○	○	○
305-3. BASIC INFORMATION REQUEST	○	○	○	○	○	○	○	○	○	○
319-10. AUDIO SELECT SET	—	—	○	○	—	—	—	—	○	—

4. Supplementary Information by Command

018. INPUT SW CHANGE

■ Input terminal

Model name	Input terminal																		
	COMPUTER	COMPUTER2	COMPUTER3	BNC	VIDEO	BNC(CV)	S-VIDEO	BNC(Y/C)	Component	HDMI	HDMI2	DisplayPort	SLOT	USB-A	LAN	ETHERNET	HDBaseT	USB-B	APPS
NP-M403X / NP-M363X / NP-M323X / NP-M283X / NP-M403W / NP-M363W / NP-M323W / NP-M333XS / NP-M353WS / NP-M303WS / NP-M403H / NP-M323H / NP-M353HS / NP-M323HS / NP-M303HS	01h	—	—	—	06h	—	—	—	—	A1h	A2h	—	—	1Fh	20h	—	—	22h	—
NP-M402W / NP-M362W / NP-M402X / NP-M362X / NP-M322X / NP-M282X / NP-M322W / NP-M352WS / NP-M302WS / NP-M332XS	01h	—	—	—	06h	—	—	—	—	A1h	A2h	—	—	1Fh	20h	—	—	22h	—
NP-P502HL / NP-P502WL	01h	—	—	—	06h	—	—	—	—	A1h	A2h	—	—	—	—	—	BFh	—	23h
NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X	01h	—	—	02h	—	06h	—	0Bh	—	A1h	A2h	A6h	—	—	—	—	20h	—	—
NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X	01h	—	—	02h	—	06h	—	0Bh	—	A1h	A2h	A6h	—	1Fh	—	20h	—	—	—
NP-PH1202HL / NP-PH1002HL	01h	—	—	02h	—	06h	—	0Bh	—	A1h	—	A6h	ABh	—	—	—	20h	—	—
NP-PX651X / NP-PX581W	01h	02h	9Ch	—	06h	—	0Bh	—	10h	A1h	—	—	—	—	—	—	20h	—	—
NP-PX602UL / NP-PX602WL	01h	—	—	02h	—	06h	—	0Bh	—	A1h	—	A6h	ABh	—	—	—	20h	—	—
NP-U321H	01h	—	—	—	06h	—	—	—	—	A1h	A2h	—	—	—	—	—	—	—	—
NP-UM352W	01h	—	—	—	06h	—	—	—	—	A1h	A2h	—	—	—	—	—	—	22h	23h
NP-UM301X / NP-UM301W / NP-UM361X / NP-UM351W	01h	—	—	—	06h	—	—	—	—	A1h	A2h	—	—	1Fh	20h	—	—	22h	—
NP-V332X / NP-V332W / NP-V302X / NP-V302W / NP-V302H	01h	—	—	—	06h	—	—	—	—	A1h	A2h	—	—	—	—	—	—	—	—

4. Supplementary Information by Command

030-12. ASPECT ADJUST

■ Aspect

Model name	DATA01															
	00h	01h	02h		03h	04h	05h	06h		07h	08h	0Bh	0Ch	0Dh	0Eh	0Fh
NP-M403X / NP-M363X / NP-M323X / NP-M283X / NP-M403W / NP-M363W / NP-M323W / NP-M333XS / NP-M353WS / NP-M303WS / NP-M403H / NP-M323H / NP-M353HS / NP-M323HS / NP-M303HS	AUTO	WIDE ZOOM	16:9		NATIVE	4:3	15:9	16:10		LETTER BOX	—	—	—	—	—	—
NP-M402W / NP-M362W / NP-M402X / NP-M362X / NP-M322X / NP-M282X / NP-M322W / NP-M352WS / NP-M302WS / NP-M332XS	AUTO	WIDE ZOOM	16:9		NATIVE	4:3	15:9	16:10		LETTER BOX	—	—	—	—	—	—
NP-P502HL / NP-P502WL	AUTO	—	16:9		NATIVE	4:3	15:9	16:10		LETTER BOX	—	—	—	—	—	—
NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X / NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X	4:3 (WINDOWS)	LETTER BOX	WIDE SCREEN	16:9	—	—	—	ZOOM	FULL	—	—	5:4	16:10	15:9	NATIVE	AUTO
NP-PH1202HL / NP-PH1002HL	4:3 (WINDOWS)	LETTER BOX	WIDE SCREEN	16:9	—	—	—	ZOOM	FULL	—	—	5:4	16:10	15:9	NATIVE	AUTO
NP-PX651X / NP-PX581W	4:3	—	16:9		1.85:1	2.35:1	Auto	16:10		—	—	5:4	16:10	—	Native	Auto
NP-PX602UL / NP-PX602WL	4:3 (WINDOWS)	LETTER BOX	WIDE SCREEN	16:9	—	—	—	ZOOM	FULL	—	—	5:4	16:10	15:9	NATIVE	AUTO
NP-U321H	AUTO	—	16:9		NATIVE	4:3	15:9	16:10		—	5:4	—	—	—	—	—
NP-UM301X / NP-UM361X NP-UM301W / NP-UM351W / NP-UM352W	AUTO	WIDE ZOOM	CHINEMA	16:9	NATIVE	4:3	15:9	16:10		LETTERBOX	—	—	—	—	—	—
NP-V332X / NP-V332W / NP-V302X / NP-V302W / NP-V302H	AUTO	—	16:9		NATIVE	4:3	15:9	16:10		—	5:4	—	—	—	—	—

4. Supplementary Information by Command

097-8. ECO MODE REQUEST

098-8. ECO MODE SET

■ Eco mode

Model name	DATA01				
	00h	01h	02h	03h	04h
NP-M403X / NP-M363X / NP-M323X / NP-M283X / NP-M403W / NP-M363W / NP-M323W / NP-M333XS / NP-M353WS / NP-M303WS / NP-M403H / NP-M323H / NP-M353HS / NP-M323HS / NP-M303HS	OFF	AUTO ECO	NORMAL	ECO	—
NP-M402W / NP-M362W / NP-M402X / NP-M362X / NP-M322X / NP-M282X / NP-M322W / NP-M352WS / NP-M302WS / NP-M332XS	OFF	AUTO ECO	NORMAL	ECO	—
NP-P502HL / NP-P502WL	OFF	ECO1	ECO2	—	—
NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X / NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X	OFF	ON	—	—	—
NP-PH1202HL / PH1002HL	NORMAL	—	ECO1	ECO2	LONG LIFE
NP-PX651X / NP-PX581W	NORMAL	ECO	—	—	—
NP-PX602UL / PX602WL	NORMAL	—	ECO1	ECO2	—
NP-U321H	OFF	ECO	—	—	—
NP-UM301X / NP-UM301W / NP-UM361X / NP-UM351W / NP-UM352W	OFF	AUTO ECO	NORMAL	ECO	—
NP-V332X / NP-V332W / NP-V302X / NP-V302W / NP-V302H	OFF	ECO	—	—	—

4. Supplementary Information by Command

078-1. SETTING REQUEST

305-1. BASE MODEL TYPE REQUEST

■ Base model type

Model name		078-1. SETTING REQUEST		
		DATA01	DATA02	DATA03
	305-1. BASE MODEL TYPE REQUEST			
	DATA01	DATA02	DATA12	DATA13
NP-M282X	FFh	22h	03h	10h
NP-M283X	FFh	22h	03h	12h
NP-M302WS	FFh	22h	09h	10h
NP-M303HS	FFh	22H	04H	11H
NP-M303WS	FFh	22h	09h	12h
NP-M322H	FFh	22h	01h	11h
NP-M322W	FFh	22h	06h	10h
NP-M322X	FFh	22h	02h	10h
NP-M323H	FFh	22h	0Bh	12h
NP-M323HS	FFh	22H	03H	11H
NP-M323W	FFh	22h	06h	12h
NP-M323X	FFh	22h	02h	12h
NP-M332XS	FFh	22h	07h	10h
NP-M333XS	FFh	22h	07h	12h
NP-M352WS	FFh	22h	08h	10h
NP-M353HS	FFh	22H	02H	11H
NP-M353WS	FFh	22h	08h	12h
NP-M362W	FFh	22h	05h	10h
NP-M362X	FFh	22h	01h	10h
NP-M363W	FFh	22h	05h	12h
NP-M363X	FFh	22h	01h	12h
NP-M402H	FFh	22h	00h	11h
NP-M402W	FFh	22h	04h	10h
NP-M402X	FFh	22h	00h	10h
NP-M403H	FFh	22h	0Ah	12h
NP-M403W	FFh	22h	04h	12h
NP-M403X	FFh	22h	00h	12h
NP-P502HL	FFh	22h	00h	13h
NP-P502WL	FFh	22h	01h	13h
NP-PA521U	FFh	21h	01h	10h
NP-PA522U	FFh	21h	01h	11h
NP-PA571W	FFh	21h	03h	10h
NP-PA572W	FFh	21h	03h	11h
NP-PA621U	FFh	21h	00h	10h
NP-PA621X	FFh	21h	05h	10h
NP-PA622U	FFh	21h	00h	11h
NP-PA622X	FFh	21h	05h	11h
NP-PA671W	FFh	21h	02h	10h
NP-PA672W	FFh	21h	02h	11h
NP-PA721X	FFh	21h	04h	10h
NP-PA722X	FFh	21h	04h	11h
NP-PH1002HL	FFh	26h	01h	10h
NP-PH1202HL	FFh	26h	00h	10h
NP-PX581	FFh	27h	01h	10h
NP-PX602UL	FFh	25h	00h	10h
NP-PX602WL	FFh	25h	01h	10h
NP-PX651	FFh	27h	00h	10h
NP-U321H	FFh	28h	00h	10h
NP-UM301W	FFh	20h	02h	11h
NP-UM301X	FFh	20h	00h	11h
NP-UM351W	FFh	20h	03h	11h
NP-UM352W	FFh	20h	04h	11h
NP-UM361X	FFh	20h	01h	11h
NP-V302H	FFh	2Ah	04h	10h
NP-V302W	FFh	2Ah	03h	10h
NP-V302X	FFh	2Ah	02h	10h
NP-V332W	FFh	2Ah	01h	10h
NP-V332X	FFh	2Ah	00h	10h

4. Supplementary Information by Command

078-3. INPUT STATUS REQUEST

305-3. BASIC INFORMATION REQUEST

■ Selection signal type

Model name	DATA03	01h	01h	01h	01h	01h	01h	01h	01h	02h	02h	02h	02h	01h	04h	05h
	DATA04	01h	02h	03h	06h	07h	21h	22h	23h	01h	06h	07h	21h	27h	07h	07h
NP-M403X / NP-M363X / NP-M323X / NP-M283X / NP-M403W / NP-M363W / NP-M323W / NP-M333XS / NP-M353WS / NP-M303WS / NP-M403H / NP-M323H / NP-M353HS / NP-M323HS / NP-M303HS		COMPUTER	VIDEO	—	—	USB-A	HDMI1	—	—	—	—	LAN	HDMI2	—	USB-B	—
NP-M402W / NP-M362W / NP-M402X / NP-M362X / NP-M322X / NP-M282X / NP-M322W / NP-M352WS / NP-M302WS / NP-M332XS		COMPUTER	VIDEO	—	—	USB-A	HDMI1	—	—	—	—	LAN	HDMI2	—	USB-B	—
NP-P502HL / NP-P502WL		COMPUTER	VIDEO	—	—	—	HDMI1	—	—	—	—	—	HDMI2	HDBaseT	—	APPS
NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X		COMPUTER	BNC(CV)	BNC(Y/C)	—	—	HDMI1	DiaplayPort	—	BNC	—	HDBaseT	HDMI2	—	—	—
NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X		COMPUTER	BNC(CV)	BNC(Y/C)	—	USB-A	HDMI1	DiaplayPort	—	BNC	—	ETHERNET	HDMI2	—	—	—
NP-PX651X / NP-PX581W		Computer1	Video	S-Video	Component	—	—	Computer3	HDMI	—	Computer2	—	HDBaseT	—	—	—
NP-PX602UL / NP-PX602WL		COMPUTER	BNC(CV)	BNC(Y/C)	—	—	HDMI	DiaplayPort	SLOT	BNC	—	HDBaseT	—	—	—	—
NP-PH1202HL / NP-PH1002HL		COMPUTER	BNC(CV)	BNC(Y/C)	—	—	HDMI	DiaplayPort	SLOT	BNC	—	HDBaseT	—	—	—	—
NP-U321H		COMPUTER	VIDEO	—	HDMI1(078-3)	—	HDMI1(305-3)	—	—	—	HDMI2(078-3)	—	HDMI2(305-3)	—	—	—
NP-UM352W		COMPUTER	VIDEO	—	—	—	HDMI1	—	—	—	—	—	HDMI2	—	USB-B	APPS
NP-UM301X / NP-UM301W / NP-UM361X / NP-UM351W		COMPUTER	VIDEO	—	—	USB-A	HDMI1	—	—	—	—	LAN	HDMI2	—	USB-B	—
NP-V332X / NP-V332W / NP-V302X / NP-V302W / NP-V302H		COMPUTER	VIDEO	—	HDMI1(078-3)	—	HDMI1(305-3)	—	—	—	HDMI2(078-3)	—	HDMI2(305-3)	—	—	—

4. Supplementary Information by Command

097-198. PIP/PICTURE BY PICTURE REQUEST

098-198. PIP/PICTURE BY PICTURE SET

■ Sub input

モデル名	DATA02									
	00h	01h	02h	03h	04h	05h	06h	07h	08h	09h
NP-PA621U / NP-PA521U / NP-PA671W / NP-PA571W / NP-PA721X / NP-PA621X	OFF	BNC(CV)	BNC(Y/C)	HDMI1	HDMI2	DisplayPort	COMPUTER	BNC	ETHERNET	USB-A
NP-PA622U / NP-PA522U / NP-PA672W / NP-PA572W / NP-PA722X / NP-PA622X	OFF	BNC(CV)	BNC(Y/C)	HDMI1	HDMI2	DisplayPort	COMPUTER	BNC	HDBaseT	—
NP-PH1202HL / NP-PH1002HL	OFF	BNC(CV)	BNC(Y/C)	HDMI	SLOT	DisplayPort	COMPUTER	BNC	HDBaseT	—
NP-PX602UL / NP-PX602WL	OFF	BNC(CV)	BNC(Y/C)	HDMI	SLOT	DisplayPort	COMPUTER	BNC	HDBaseT	—