




















Default Control	Keyboard Config		Button Color
Left Flipper		Left Flipper	
Left MagnaSave		Left MagnaSave	
Right Flipper		Right Flipper	
Right MagnaSave		Right MagnaSave	
Start		Start Game	
Coin In		Coin In	
Exit/Cancel		Exit to menu	
Launch Ball		Plunger/Launch Ball	
Extra Ball		Extra Ball (Buy-In)	
Fire!	To be assigned on Visual Pinball		

Service Button Board – Default Assignments:

