



VIRTUATILT – ZACCARIA PINBALL SETUP


Following some basic instructions to have your VirtuaTilt up and running with Zaccaria Pinball.

NOTE: Zaccaria Pinball does not support DOFLinx, so you will have feedback from VirtuaTilt's flippers solenoids.

PREREQUISITES:

- **VTConfig-ZaccariaPinball_v1.X.json** profile loaded in **Pinscape Pico Config Tool**





Accelerometer/Analog Plunger configuration


NOTE: Zaccaria Pinball does not support accelerometer and analog plunger natively.

Accelerometer-based nudging does not work properly in this game, so we suggest assigning left and right magna buttons for this function.


Analog Plunger works like a charm instead.

Steam settings and Game settings

Start **Steam** and go to Steam **Settings** → **Controller**



Disable everything under "**External Gamepad Settings**".



Now Start Zaccaria Pinball and go to **Options --> Controller**, select **XINPUT** as input method and replicate following mapping:



If everything was set up correctly you should be able to use analog plunger and digital nudging (with buttons).

Have fun!