


## VIRTUATILT – Switch SETUP GUIDE

Following some basic instructions to set up your new VirtuaTilt for Switch systems.


**IMPORTANT NOTE: You need a proper USB dongle (not provided and not supported) to make VirtuaTilt compatible with above devices. If you connect directly, it won't be recognized as a controller.**

### Load Profile


Load **VTConfig-Switch\_v1.X.json** profile in **Pinscape Pico Config Tool**:



Click on **“Program Pico”** to save new configuration:



**NOTE:** Once this profile is loaded, Pico will go offline because the Windows X-Input device driver now is claiming exclusive access to the device, preventing anyone from seeing its other USB interfaces:




# 3DPTronics


## System/Games Settings


VirtuaTilt RP2040 – Switch Setup Guide v1.2

Select the following option in **System Settings** → **Controllers & Accessories**:




**PinballFX 3** settings:





## Pinball M settings:



## The Pinball Arcade settings:





# 3DPTronics

## Restore Profile

VirtuaTilt RP2040 – Switch Setup Guide v1.2



To load/restore a different profile keep **VirtuaTilt's Reset button** pressed for 2 seconds; device will reboot in **Factory mode**:

The screenshot shows the Pinscape Pico Config Tool interface. On the left, there's a sidebar with 'Pinscape Pico Unit #1' and a 'New Device Setup' button. The main area displays device information for 'Pinscape Pico', including hardware ID, firmware version, and target board. It also shows uptime statistics, USB interfaces, recent main loop counters, recent secondary core loop counters, and memory usage. On the right, there's a detailed diagram of a Raspberry Pi Pico board with pins labeled GP0 through GP15, VBUS, VSYS, GND, 3V3\_EN, 3V3\_OUT, ADCVREF, GP28, GP27, GP26, RUN, GP22, GP21, GP20, GP19, GP18, GP17, and GP16.

Go to **Configuration** → **File** → **Import From File** and choose the profile you need:

The screenshot shows the Pinscape Pico Config Tool interface with the 'File' menu open. The 'Import From File...' option is highlighted with a red box. The menu also includes options like 'Save to Pico', 'Reload from Pico', 'Save a Copy As...', 'Import from Template File...', 'Page Setup...', 'Print...', and 'Exit'. The background shows the 'Configuration' tab selected in the top bar.

Click on **Program Pico** to save new configuration and you're done:



That's it, enjoy!

## Default Buttons Mapping

This is the default buttons mapping for Switch profile. You can of course change assignments in Pinscape Pico Config Tool.

