

Knob screen EXP1
GND PD8 PC11 PA10 PA8
5V PC12 PC10 PA9 PC9

Knob screen EXP2
GND PC8 PC7 PC6 PB14
3.3V RESET PB15 PB12 PB13

Mainboard

