

STM32L4 Seminar

EMEA MCU Marketing and FAE Team



Seminar objectives

2

- Present the new STM32L4 Cortex-M4® family
- Get familiar with the features and capabilities
- Show performance in both simple and complex tasks
- Get familiar with new peripherals
- Practice through Hands-On



Agenda morning

4

- 8:30 Tools installation checking
- 9:00 Marketing introduction
- 9:45 STM32L4 System architecture and overview



- 10:15 Break
- 10:30 System operating modes in real application scenarios



- 12:00 Lunch



Agenda - afternoon

5

- 13:00 New peripherals and BOM reduction
- 14:00 Putting all together – Hands-On – Part I
- 14:45 Break
- 15:00 Putting all together – Hands-On – Part II
- 16:00 Tips and Tricks for app design
- 17:00 Session end, Q&A



You will get out of the training with:

- A good understanding of the new STM32L4 main features & tools
- The skills to make your HW and FW design using ST ecosystem
- A Discovery Board to start your development



Prerequisites 7

- STM32L4 discovery kit
 - provided free of charge by ST
- IAR 7.4x in full / evaluation version
 - 5 days full version provided free of charge by ST
- 1x USB micro, 1x USB mini cable
- Java + .NET installed
- STM32CubeMX 4.11.0
- STM32CubeL4 HAL V1.1.1 from STM32CubeMX
- Multimeter with uA/mA range with wires to connect to header
 - we will measure consumptions down to ~40nA
- Headphones (3.5mm jack)



- Extract the file STM32L4_workshop.zip to C:\
- It includes
 - Documentation
 - Hands-On projects Examples
 - Slides presentations
- If you don't have installed IAR 7.4x then copy also \PC_tools\IAR_740\
- Pass it to your neighbor, please



- We'll need full version of IAR
 - Valid full license
 - Evaluation license 30-days
 - Temporary training license
- No valid installation?
 - \PC_Tools\IAR_740\EWARM-CD-7407-9865.exe
- IAR → Help → License Manager select License → Offline Activation → Use an activation response file from IAR Systems
- Browse to PC_tools\IAR_740\ActivationResponse.txt. Then complete the dialog sequence.



STM32CubeMX

- \PC_Tools\STM32CubeMX\SetupSTM32CubeMX-4.11.0.exe

ST-link Utility

\PC_Tools\ST link utility\STM32 ST-LINK Utility_v3.7.0.exe

Termite Serial Port terminal SW

\PC_Tools\Termite\termite-3.2.exe





www.st.com/stm32l4