

BUSINESS CLASS M2 WORKSHOP MANUAL

**Models: M2 100
M2 106
M2 106V
M2 112
M2 112V**

Foreword

The purpose of this manual is to assist the service technician when the vehicle is serviced. Major drivetrain component service information is not included in this manual, but is located in each manufacturer's service manual.

Instructions and procedures are those recommended by Freightliner Trucks or the component manufacturer.

Maintenance schedules and additional service information are included in the **Business Class® M2 Maintenance Manual**.

IMPORTANT: Descriptions and specifications in this manual were in effect at the time of printing. Freightliner Trucks reserves the right to discontinue models, and to change specifications or design at any time without notice and without incurring obligation. Descriptions and specifications contained in this publication provide no warranty, expressed or implied, and are subject to revision and editions without notice.

Refer to www.Daimler-TrucksNorthAmerica.com and www.FreightlinerTrucks.com for more information, or contact Daimler Trucks North America LLC at the address below.

Environmental Concerns and Recommendations

Whenever you see instructions in this manual to discard materials, you should attempt to reclaim and recycle them. To preserve our environment, follow appropriate environmental rules and regulations when disposing of materials.

NOTICE: Parts Replacement Considerations

Do not replace suspension, axle, or steering parts (such as springs, wheels, hubs, and steering gears) with used parts. Used parts may have been subjected to collisions or improper use and have undetected structural damage.

© 2002–2015 Daimler Trucks North America LLC

All rights reserved. No part of this publication, in whole or in part, may be translated, reproduced, stored in a retrieval system, or transmitted in any form by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Daimler Trucks North America LLC. Daimler Trucks North America LLC is a Daimler company.

**Daimler Trucks North America LLC
Service Systems and Documentation (CVI-SSD)
P.O. Box 3849
Portland, OR 97208-3849**

Descriptions of Service Publications

Daimler Trucks North America LLC distributes the following major service publications in paper and electronic (via ServicePro®) formats.

Workshop/Service Manual

Workshop/service manuals contain service and repair information for all vehicle systems and components, except for major components such as engines, transmissions, and rear axles. Each workshop/service manual section is divided into subjects that can include general information, principles of operation, removal, disassembly, assembly, installation, specifications, and troubleshooting.

Maintenance Manual

Maintenance manuals contain routine maintenance procedures and intervals for vehicle components and systems. They have information such as lubrication procedures and tables, fluid replacement procedures, fluid capacities, specifications, and procedures for adjustments and for checking the tightness of fasteners. Maintenance manuals do not contain detailed repair or service information.

Driver's/Operator's Manual

Driver's/operator's manuals contain information needed to enhance the driver's understanding of how to operate and care for the vehicle and its components. Each manual contains a chapter that covers pretrip and post-trip inspections, and daily, weekly, and monthly maintenance of vehicle components. Driver's/operator's manuals do not contain detailed repair or service information.

Service Bulletins

Service bulletins provide the latest service tips, field repairs, product improvements, and related information. Some service bulletins are updates to information in the workshop/service manual. These bulletins take precedence over workshop/service manual information, until the latter is updated; at that time, the bulletin is usually canceled. The service bulletins manual is available only to dealers. When doing service work on a vehicle system or part, check for a valid service bulletin for the latest information on the subject.

IMPORTANT: Before using a particular service bulletin, check the current service bulletin validity list to be sure the bulletin is valid.

Parts Technical Bulletins

Parts technical bulletins provide information on parts. These bulletins contain lists of parts and BOMs needed to do replacement and upgrade procedures.

Web-based repair, service, and parts documentation can be accessed using the following applications on the AccessFreightliner.com website.

ServicePro

ServicePro® provides Web-based access to the most up-to-date versions of the publications listed above. In addition, the Service Solutions feature provides diagnostic assistance with Symptoms Search, by connecting to a large knowledge base gathered from technicians and service personnel. Search results for both documents and service solutions can be narrowed by initially entering vehicle identification data.

PartsPro

PartsPro® is an electronic parts catalog system, showing the specified vehicle's build record.

EZWiring

EZWiring™ makes Freightliner, Sterling, Western Star, Thomas Built Buses, and Freightliner Custom Chassis Corporation products' wiring drawings and floating pin lists available online for viewing and printing. EZWiring can also be accessed from within PartsPro.

Descriptions of Service Publications

Warranty-related service information available on the AccessFreightliner.com website includes the following documentation.

Recall Campaigns

Recall campaigns cover situations that involve service work or replacement of parts in connection with a recall notice. These campaigns pertain to matters of vehicle safety. All recall campaigns are distributed to dealers; customers receive notices that apply to their vehicles.

Field Service Campaigns

Field service campaigns are concerned with non-safety-related service work or replacement of parts. All field service campaigns are distributed to dealers; customers receive notices that apply to their vehicles.

Page Description

For an example of a *Business Class M2 Workshop Manual* page, see [Fig. 1](#).

The diagram illustrates the layout of a Business Class M2 Workshop Manual page. Labels A through G point to specific components:

- A:** Section Title (Threaded Fasteners)
- B:** Section Number (00.04)
- C:** Subject Title (General Instructions)
- D:** Manual Title (Business Class M2, Workshop Manual, Supplement 0, January 2002)
- E:** Release (Supplement) Date (January 2002)
- F:** Subject Number (100/1)
- G:** Subject Page Number (100/1)

The page content includes the following sections:

Threaded Fasteners

Fastener Replacement

When replacing fasteners use only identical bolts, washers, and nuts. They must be the same size, strength, and finish as originally specified. See the Freightliner Service Parts Catalog for fastener specifications.

When replacing graded (or metric class) bolts and cap screws, use only fasteners that have the manufacturer's trademark or identification on the bolt head. Do not use substandard bolts. Interior, counterbore fasteners are difficult to identify; buy your fasteners from a reputable supplier.

Fastener Selection and Installation

When using nuts with bolts, use a grade (or class) of nut that matches the bolt.

When installing non-flanged fasteners, use hardened steel flatwashers under the bolt (cap screw) head and under the hexnut or locknut.

For bolts 4 inches (100 mm) or less in length, make sure that at least 1-1/2 threads and no more than 5/8 inch (16 mm) bolt length extends through the nut after it has been tightened. For bolts longer than 4 inches (100 mm), allow a minimum of 1-1/2 threads and a maximum of 3/4-inch (19 mm) bolt length.

Never hammer or screw bolts into place. Align the holes of the parts being attached, so that the nut and bolt surfaces are flush against the washers, and the washers are flush against the parts.

When installing fasteners in aluminum or plastic parts with threaded holes, start the fasteners by hand to ensure straight starting and to prevent damaged threads.

Do not use lockwashers (split or locktite) next to aluminum surfaces.

When installing studs that do not have an interference fit, install them with thread locking compound as instructed in this subject.

When installing parts that are mounted on studs, use free-spinning (non-locking) nuts and helical-spring (split) lockwashers or internal-loop lockwashers. Do not use locknuts, because they tend to loosen the studs during removal. Do not use plain washers (flatwashers).

Do not use lockwashers and flatwashers in combination (against each other); each defeats the other's purpose.

Use stainless steel fasteners against chrome plating, unpainted aluminum or stainless steel.

Fastener Tightening

Before installing fasteners, clean all fastener (and parts) threads, and all surfaces being clamped.

To ensure they are always torqued accurately, Freightliner recommends that all fasteners be lubricated with oil (unless specifically instructed to install them dry), then torqued to the values for lubricated and plated thread fasteners. When locking compound or anti-seize compound is recommended for a fastener, the compound acts as a lubricant, and oil is not needed.

Bring parts and fasteners into contact, with no gaps between them, before using a torque wrench to tighten fasteners to their final torque values.

Tighten the nut, not the bolt head. This will give a truer torque reading by eliminating bolt body friction.

Always use a torque wrench to tighten fasteners, and use a slow, smooth, even pull on the wrench. Do not overtorque fasteners; overtightening causes permanent stretching of the fasteners, which can result in breakage of the parts or fasteners.

If specific torque values are not given for countersunk bolts, use the torque value for the corresponding size and grade of regular bolt, as given in Subject 400.

Always follow the torque sequence or torque interval when provided, to ensure that clamping forces are even, and parts and fasteners are not distorted.

Thread Locking Compound Application

When the use of thread locking compound is recommended or desired, for studs, cap screws, and bolts with a thread diameter of 1 inch (25 mm) or less, use Loctite® 271 or Perma-Lok® HM 128.

For thread diameters over 1 inch (25 mm), use Loctite 277.

Business Class M2, Workshop Manual, Supplement 0, January 2002

100/1

12/21/2001

1020132

A. Section Title
B. Section Number (made up of the Group Number—first two digits, followed by a sequence number—last two digits)
C. Subject Title
D. Manual Title
E. Release (Supplement) Date
F. Subject Number
G. Subject Page Number

Fig. 1, Example of a Business Class M2 Workshop Manual Page

Group No.	Group Title
00	General Information
01	Engine
09	Air Intake
13	Air Compressor
15	Alternators and Starters
20	Engine Cooling/Radiator
25	Clutch
26	Transmission
30	Throttle Control
31	Frame and Frame Components
32	Suspension
33	Front Axle
35	Rear Axle
40	Wheels and Tires
41	Driveline
42	Brakes
46	Steering
47	Fuel
49	Exhaust
54	Electrical, Instruments, and Controls
60	Cab
72	Doors
82	Windshield Wipers and Washer
83	Heater and Air Conditioner
88	Hood, Grille, and Cab Fenders
90	Fire Suppression Systems
91	Seats and Restraint Systems
98	Paint