


1. Select model and serial port


1) First, You need a uno board, arduino, and Bluetooth communication program. Then double-click the Bluetooth program to open the program.




the Bluetooth program :

2) please connect the uno board to the computer and start the second step.

3) Configuring arduion's board models: First, Click "Tools" on the interface border, Then choose "Board", Finally choose your board model.




4) Select serial port:




2. Burning of arduino


1) Click the compile button:




After the compilation is successful, the following is displayed:




2) Compilation completed, Click the upload button to burn the program:




After the upload is successful, the following is displayed:



3) Open the serial port and wait for communication:



Click on the serial port button will jump out of this interface:




3. Use app to communicate with the serial port

- 1) Install BLETestToos.apk, then turn on Bluetooth.
- 2) Open app, you will be asked to allow location permission at first, please allow it.



App:


- 3) If Bluetooth information is not displayed, please pull down and refresh, Eventually not enough please close and reopen the app.




- 4) Open the app and select the corresponding Bluetooth model:




5) Click to enter the message box will pop up to indicate successful connection and jump to the operation interface:




6) Click on the second, after clicking the first one:




7) In the end you will jump to the user interface, and you can click "WRITING" to send:




8) Click on the red line to write data, then click on “send” to send:



Serial port display is as follows:



9) You can also send information on the serial input data:



10) The result is shown below:

China Unicom
China Unicom

Feature operation

Description list:

Eigenvalues:

WRITING START NOTIFICATION

0123
123

bytes: 11 EMPTY SAVE

☒ String ☐ Hexadecimal