



SNIB2

Configuration Guide

Rev. F September, 2007

SUPP009-0907

The National Institute of Standards and Technology (NIST) has awarded the SNIB2 AES Certificate #280

Copyright © 2007 Hirsch Electronics Corporation. All rights reserved. SCRAMBLE*NET™ (abbreviated S*NET) is a trademark of Hirsch Electronics Corporation.

Hirsch Electronics Corporation
1900-B Carnegie Avenue
Santa Ana, CA 92705-5520

Phone: (949) 250-8888
Fax: (949) 250-7372
Web: www.HirschElectronics.com



Getting Help

If you encounter a problem that is not discussed in this guide and you need technical support, do the following:

1. Contact your local dealer or the provider of this product.
2. If your dealer is not available, contact Hirsch Technical Support directly. This can be done in a number of ways:

Mail: Hirsch Electronics Corporation
1900-B Carnegie Avenue
Santa Ana, CA 92705-5520

Attn: Technical Services

Phone: 877-HIRSCHX (877-447-7249) toll-free

Fax: (949) 250-7362

Email: support@HirschElectronics.com

WWW: www.HirschElectronics.com

Whenever you call your local dealer or Hirsch, be sure to have your registration material, serial number and software version number available.

For future reference, record these numbers here.

SNIB2 MAC Address: _____

SNIB2 Firmware #: _____

Dealer: _____

Dealer Phone #: _____

CCM Firmware #: _____


CCM BIOS #: _____

Table of Contents


Getting Help	iii
SNIB2 Configuration Guide	1
Configuration Options.....	4
Installing the SNIB2	6
Cabling the SNIB2	8
Setting Up the SNIB2	9
Deploying the SNIB2.....	12
Configuring a Master SNIB2 on the Same Subnet	13
Configuring a Master SNIB2 in a Different Subnet	15
Resetting SNIB2 Encryption Keys.....	18
Controller and SNIB2 LED Diagnostics	19
Special Light Patterns: Start Up	19
Normal Operation	19
Checking CCM and BIOS Version.....	22

SNIB2 Configuration Guide


The SNIB2 is a high-security encryption Secure Network Interface Board. An example of the SNIB2 is shown below:



The SNIB2 is a controller-resident communication board that enables a host PC running Velocity 2.6 SP2 or higher to program, monitor, and control up to 63 SNIB2-resident controllers per SNIB2 Ethernet port. A NET*MUX4 is required whenever there are more than 16 controllers. Additional NET*MUX4s may be required to ensure that there are never more than 16 controllers per port.




Each connected controller must have its own SNIB2 or SNIB board installed. The SNIB2 provides RS-485, RS-232, and 10/100BaseT Ethernet ports. The SNIB2 supports the XNET2 protocol.

 ***XNET2 is only supported by Velocity version 2.6 with Service Pack 2 or higher.***

Physically, the SNIB2 board differs from the original SNIB in three obvious respects. The SNIB2 has:

- three switch banks (SW1, SW2, and SW3)
- an Ethernet RJ-45 connector with its accompanying daughterboard
- three pairs of status LEDs (see page 19)

With the SNIB2 board, a host PC running Velocity can program, monitor, and control up to 63 controllers with NET*MUX4 (as shown in the example below), or up to 16 without NET*MUX4. Each connected controller must have its own SNIB2 or SNIB board installed. The SNIB2 provides a downstream/multi-drop RS-485 port as well as an upstream 10/100 Mbps Ethernet port and an RS-232 port for direct host connections (not dial-up).




The SNIB2 provides these functional advantages over the original SNIB:

- AES encryption
- Ethernet connectivity (if required)
- Xbox functionality

Each of these features is explained below.

AES Encryption

The SNIB2 employs AES-Rijndael asymmetric 128-bit block data encryption.

 ***The National Institute of Standards and Technology (NIST) has awarded the SNIB2 AES Certificate #280.***

Ethernet Connectivity

A standard RJ-45 Ethernet port is included on the SNIB2. This enables the connected controller installed with a SNIB2 to communicate with the server using TCP/IP over 10BaseT or 100BaseT Ethernet networks. This eliminates the need for external device servers for LAN connectivity.

XBox Functionality

The SNIB2 also incorporates full Xbox gateway functionality, thereby eliminating the need for an Xbox. This enables the SNIB2 to function as a gateway for up to 63 controllers (with inclusion of the NET*MUX4), and provides the ability to globalize certain features.

Globalizing is the task of connecting two or more controllers in order to share credential user management and control zone information amongst all connected controllers. Globalization can only be performed within a local Xbox node. One SNIB2 acting as an Xbox cannot talk to and share information with another Xbox or another master SNIB2.

Higher Serial Communication Speeds

Communications between multidropped SNIB2s are now supported at speeds up to 115,200 bps with Cat5/Cat6 cable.

When using one or more NET*MUX4s, the maximum SNIB2 speed is limited to 9600 bps. When combining SNIBs and SNIB2s, the maximum speed is limited to the lower SNIB speed – that is, the lowest speed that all connected devices have in common.

Communications become less robust as baud rates increase, wire gauge decreases, and distances increase. Most tables in the DIGI*TRAC Design and Installation Guide for wire gauge and distance are based on 9600 bps.

At higher baud rates, maximum distances are decreased and minimum wire gauge is increased. It may not be possible to implement the higher baud rates supported by the SNIB2 if you have long wire runs or small wire gauges.




In order to use the SNIB2, your controller must be running CCM 7.3.08 or higher; use Vn. 7.4.00 or higher if your computer has Velocity 3.0. To check your current version number, refer to “Checking CCM and BIOS Version” on page 22.




You can install the SNIB2 board in any Hirsch DIGI*TRAC controller except the M1N.

Configuration Options

The SNIB2's Ethernet port provides high-speed TCP/IP communication over an Ethernet network between the host computer and the controller.



In a multiple controller sequence, the configuration can look like this example:



 = this cable segment swaps the RX± and TX± wires. See page 8 for details.

This enables communication between the controller with the master SNIB2 and host PC at 10/100BaseT. Speeds between the master SNIB2 and other connected downstream SNIB2s range up to 115200 bps when using Cat5/Cat6 cable. Speeds between a master SNIB2 and downstream SNIBs are limited by the top speed of the older SNIBs (38400 bps).


Higher baud rates are also more dependent on the number of twists per foot, so capacitance specifications must be strictly followed: total wire run per port is not to exceed 100,000 pf per foot.

Before the Velocity server can communicate over Ethernet with a SNIB2, you must first configure the SNIB2 through Velocity. For more on this, refer to "Configuring a Master SNIB2 on the Same Subnet" starting on page 13.


Whenever an Ethernet connection is employed between the host and the SNIB2, Velocity views the SNIB2 as an XNET port since the SNIB2 includes XBox functionality. The host communicates with the Ethernet-connected SNIB2 using AES-encrypted XNET 2.

Controller-to-controller speeds range from 9600 to 115200 bps. For each string of controllers, the first (master) SNIB2 with the Ethernet connection must be assigned the same address as the XBox port.

For more on this, refer to “Configuring a Master SNIB2 on the Same Subnet” starting on page 13.


 **When the host is connected to a SNIB2 using Ethernet, Velocity views the first (master) SNIB2 as both a DIGI*TRAC controller and an XBox residing on an XNET port. Subsequent multidropped controllers in the sequence do not appear as XBox controllers.**


You can also use the SNIB2 with the NET*MUX4. The NET*MUX4 consists of a single input for either RS-232 or RS-485 and four outputs to which a series of controllers or additional NET*MUX4s can be wired as shown in the following illustration:



 = this cable segment swaps the RX± and TX± wires. See page 8 for details.

If required, you can add a second level of NET*MUX4s to create additional controller runs; however, Hirsch does not support more than two levels of NET*MUX4s.



 **NET*MUX4 speeds are dictated by wire gauge and distance. We recommend using Cat5/Cat6 cable.**

Installing the SNIB2

To install the SNIB2:




1. Download CCM 7.3.08 or later firmware to the required controllers.
For instructions on doing this, refer to “Download Firmware Revision” in Velocity help or the *Velocity Administrator’s Guide*.
2. Make sure each controller in the sequence shows the CCM version as 7.3.08 or later, and the BIOS as Version 7.2.19 or later.
For more on checking this, refer to “Checking CCM and BIOS Version” on page 22.
If these version numbers do not appear, replace the controller’s CCM.
3. Pull the original SNIBs from each required controller.

Hint We recommend removing the SNIBs controller-by-controller to ensure that each SNIB2 comes online successfully.



Follow the instructions in Chapter 7 of the *DIGI*TRAC Design & Installation Guide*.

4. Run the required network cable to the controller(s) with the master SNIB2s.
The Ethernet cable you are connecting to each master SNIB2 should be connected to the Velocity host through a hub or switch.
5. Run RS-485 cable downstream from the master SNIB2.
The run between the master SNIB2 and the second SNIB2 should be wired according to the instructions in “Cabling the SNIB2” starting on page 8.
6. Set the DIP switches on each SNIB2.

In general, do this:

	Switch Bank	Switch	Setting	Comments
	Master SNIB2			
	SW1	S1-S4	all ON	This SNIB2 is either first (master) or last (termination) in the multidrop sequence
	SW2	S1	OFF	Encryption key reset
		S2 - S3	OFF	Reserved
		S4	ON	Indicates this SNIB2 is first in the sequence (master) and is connected to the host via Ethernet or direct RS-232 connection (not dial-up). This SNIB2 controls polling.
	SW3	S1 S2 S3-S8	OFF ON —	Set downstream RS-485 speed (38400 in this example) Address as required (Address 1 shown)

Switch Bank	Switch	Setting	Comments
SNIB2s in the middle			
SW1	S1-S4	all OFF	Indicates this is middle SNIB2 of run
SW2	S1	OFF	Encryption key reset
	S2-S3	OFF	Reserved
	S4	OFF	SNIB2 not first
SW3	S1	OFF	Set downstream RS-485 (38400 in this example)
	S2	ON	Address as required (Address 2 shown)
	S3-S8	—	
Last SNIB2 in run			
SW1	S1-S4	all ON	Indicates this is last SNIB2 in run
SW2	S1	OFF	Encryption key reset
	S2-S3	OFF	Reserved
	S4	OFF	SNIB2 not first
SW3	S1	OFF	Set downstream RS-485 (38400 in this example)
	S2	ON	Address as required (Address 3 shown)
	S3-S8	—	



For specific cases, refer to “Setting Up the SNIB2” starting on page 9.

7. Install the new SNIB2s into their controllers.

Follow the instructions in Chapter 7 of the *DIGI*TRAC Design & Installation Guide*.




Handle the SNIB2 with care. The board is very sensitive to static discharges. Observe the normal anti-static precautions by using grounded wrist straps and anti-static devices when installing the board.


8. Plug the RJ-45 connector from the cable into the Ethernet connector on the SNIB2.
9. Connect the RS-485 cables to their respective SNIB2.
10. Reconnect and power up the controllers.
11. At the host, open Velocity and configure the new SNIB2s using the instructions in “Configuring a Master SNIB2 on the Same Subnet” starting on page 13.

Cabling the SNIB2

The cable linking the first controller (master) to the second (subordinate) in a multidropped RS-485 series must cross the RX± and TX± wires in this manner:



If more than two controllers are connected in the series, the wiring would look like this:



At 9600 baud, the maximum allowed cable run between controllers is shown in the following table:

Connection	Maximum Distance
Total Max. Run from Master SNIB2 to Last Downstream SNIB2	4000 feet (1,220 m.)

In general, communications become less robust as baud rates increase, wire gauge decreases, and distances increase. For this reason, it may not be possible to implement the higher baud rates supported by the SNIB2 if you have long wire runs or small wire gauges.

Higher baud rates are also more dependent on the number of twists per foot, so capacitance specifications must be strictly adhered to: total wire run per port is not to exceed 100,000 pf per foot.

Hint We recommend using Cat5/Cat6 cable for your cable runs. Use 1 pair for the RX pair, 1 pair for the TX pair, and 1 conductor or pair for the ground connection.

Setting Up the SNIB2

The SNIB2 includes three DIP switch banks. The first bank (SW1) and second bank (SW2) have four DIP switches each. The third bank (SW3) possesses eight DIP switches.

Switch Bank 1 (SW1)

SNIB2s can be used throughout a multidrop run; however, you must specify whether a specific SNIB2 is connected to a controller that is in the beginning, middle, or at the end of a run.

To do this, set S1-S4 on switch bank SW1 to all ON or all OFF in this way:

S1-S4	OFF	This SNIB2 is in the middle of a multidrop sequence.
	ON	This SNIB2 is either first (master) or last (termination) in the multidrop sequence.

Switch Bank 2 (SW2)

The second switch bank at SW2 has 4 switches which configure such properties as the type of XNET protocol you are using and the SNIB2's location in the multidrop run.

S1	OFF	The SNIB2 communicates with the host PC in XNET 2 using the encryption keys stored in memory.
	ON	Return the encryption keys to their default settings. If this switch is set when the SNIB2 powers up or reboots after a firmware upgrade, the keys reset. <i>Note: This switch should be turned off after the LED patterns begin to light. See the SNIB2 Troubleshooting Guide for details.</i> If this is the master SNIB2, you must also 'Reset Encryption' on the Velocity Port settings. All downstream units must have their encryption keys reset as well. If this is a downstream unit, the master SNIB2 automatically detects that the keys have been reset.
S2-S3	OFF	Reserved.
S4	OFF	Indicates this SNIB2 is NOT first in the multidrop sequence, or you only have one controller.
	ON	Indicates this SNIB2 is first in the sequence (master) and is connected to the host via Ethernet or direct RS-232 connection (not dial-up). This SNIB2 controls polling.

Switch Bank 3 (SW3)

Switch bank SW3 is used to specify the SNIB2 speed (S1-S2) and the SNIB2 address (S3-S8). DIP switch settings for this are:

S1	OFF	OFF	ON	ON
S2	OFF	ON	OFF	ON
Baud Rate	9600	38400	57600	115200

This controls the baud rate for the RS-485 multi-drop line and the RS-232 connection. 57600 and 115200 bps are only available if your RS-485 cables are made from Cat5/Cat6 data grade wire. These speeds are not recommended for installations using:

- RS-232 connections to host
- 18- to 22-gauge shielded twisted-pair cable
- NET*MUX4s
- Mixed SNIBs/SNIB2s

Baud rates only apply to the SNIB2's RS-485 and RS-232 ports. The SNIB2's Ethernet port is used for host-to-controller connections and runs at 10/100 BaseT speeds. All SNIBs/SNIB2s in an RS-485 multi-drop sequence must be set to the same speed, and if connected to a host PC using RS-232 direct connection, the same speed must also be used. For example, if one SNIB2 in the sequence is set to 9600, all other SNIBs and SNIB2s (and the RS-232 host connection, if used) must be set to the same baud rate.

The remaining DIP switches on SW3 set the SNIB2 address:

Address	S3	S4	S5	S6	S7	S8
1	OFF	OFF	OFF	OFF	OFF	ON
2	OFF	OFF	OFF	OFF	ON	OFF
3	OFF	OFF	OFF	OFF	ON	ON
4	OFF	OFF	OFF	ON	OFF	OFF
5	OFF	OFF	OFF	ON	OFF	ON
6	OFF	OFF	OFF	ON	ON	OFF
7	OFF	OFF	OFF	ON	ON	ON
8	OFF	OFF	ON	OFF	OFF	OFF
9	OFF	OFF	ON	OFF	OFF	ON
10	OFF	OFF	ON	OFF	ON	OFF
11	OFF	OFF	ON	OFF	ON	ON
12	OFF	OFF	ON	ON	OFF	OFF
13	OFF	OFF	ON	ON	OFF	ON
14	OFF	OFF	ON	ON	ON	OFF
15	OFF	OFF	ON	ON	ON	ON
16	OFF	ON	OFF	OFF	OFF	OFF
17	OFF	ON	OFF	OFF	OFF	ON
18	OFF	ON	OFF	OFF	ON	OFF
19	OFF	ON	OFF	OFF	ON	ON
20	OFF	ON	OFF	ON	OFF	OFF
21	OFF	ON	OFF	ON	OFF	ON
22	OFF	ON	OFF	ON	ON	OFF
23	OFF	ON	OFF	ON	ON	ON
24	OFF	ON	ON	OFF	OFF	OFF
25	OFF	ON	ON	OFF	OFF	ON
26	OFF	ON	ON	OFF	ON	OFF
27	OFF	ON	ON	OFF	ON	ON


Address	S3	S4	S5	S6	S7	S8
28	OFF	ON	ON	ON	OFF	OFF
29	OFF	ON	ON	ON	OFF	ON
30	OFF	ON	ON	ON	ON	OFF
31	OFF	ON	ON	ON	ON	ON
32	ON	OFF	OFF	OFF	OFF	OFF
33	ON	OFF	OFF	OFF	OFF	ON
34	ON	OFF	OFF	OFF	ON	OFF
35	ON	OFF	OFF	OFF	ON	ON
36	ON	OFF	OFF	ON	OFF	OFF
37	ON	OFF	OFF	ON	OFF	ON
38	ON	OFF	OFF	ON	ON	OFF
39	ON	OFF	OFF	ON	ON	ON
40	ON	OFF	ON	OFF	OFF	OFF
41	ON	OFF	ON	OFF	OFF	ON
42	ON	OFF	ON	OFF	ON	OFF
43	ON	OFF	ON	OFF	ON	ON
44	ON	OFF	ON	ON	OFF	OFF
45	ON	OFF	ON	ON	OFF	ON
46	ON	OFF	ON	ON	ON	OFF
47	ON	OFF	ON	ON	ON	ON
48	ON	ON	OFF	OFF	OFF	OFF
49	ON	ON	OFF	OFF	OFF	ON
50	ON	ON	OFF	OFF	ON	OFF
51	ON	ON	OFF	OFF	ON	ON
52	ON	ON	OFF	ON	OFF	OFF
53	ON	ON	OFF	ON	OFF	ON
54	ON	ON	OFF	ON	ON	OFF
55	ON	ON	OFF	ON	ON	ON
56	ON	ON	ON	OFF	OFF	OFF
57	ON	ON	ON	OFF	OFF	ON
58	ON	ON	ON	OFF	ON	OFF
59	ON	ON	ON	OFF	ON	ON
60	ON	ON	ON	ON	OFF	OFF
61	ON	ON	ON	ON	OFF	ON
62	ON	ON	ON	ON	ON	OFF
63	ON	ON	ON	ON	ON	ON

Deploying the SNIB2

Each master SNIB2 (Velocity port) must be assigned a unique IP address in order to communicate with Velocity on the host PC. Depending on the network location of the master SNIB2, this is accomplished in one of two ways:

- If the SNIB2 is located within the same subnet as the host PC, then you can use Velocity to assign the IP address. For more on this, refer to “Configuring a Master SNIB2 on the Same Subnet” starting on page 13.
- If the master SNIB2 is located outside the host PC’s subnet, you must use the SNIB2 Configuration Utility. For more on this, refer to “Configuring a Master SNIB2 in a Different Subnet” starting on page 15.

What is a subnet? Put simply, a subnet is any group of PCs and other devices, such as printers and scanners, connected by network cable to a network router. Anything behind the router is considered part of the subnet. Anything beyond this router is not part of the subnet.




In the preceding illustration, the master SNIB2 and controller labeled 1 is located in the same subnet as the host PC (Subnet A). This SNIB2 can therefore be configured using Velocity; however, the master SNIB2 and controller labeled 2 is located behind a different router, in a different subnet (Subnet B), and must be configured using the SNIB2 Configuration Utility.

Any number of computers and devices can be behind a single router, but for reasons of security and speed, a company network often incorporates many routers. It isn't uncommon to find that each department within a company has its own router. Routers not only find the quickest way to ferry packets of information between two points, but also could serve as a rudimentary firewall against potential intrusion.

Configuring a Master SNIB2 on the Same Subnet

When a master SNIB2 is connected via Ethernet to the host PC sharing the same subnet, configure and assign a new IP address through the Velocity port properties dialog box.

To do this:

1. At the System Tree window, click and expand the DIGI*TRAC Configuration system folder, .


Three port folders are currently available: SNET, XNET, or Dial-Up.

2. Expand the XNET Port folder.

When the Velocity host is connected to a SNIB2 via Ethernet, it treats it as an XNET port.

3. Double click **Add New XNET Port** in the Components window.


The Port Properties dialog box appears like this:



4. Click to select the **TCP/IP** radio button.

The dialog box changes to show the 'IP Address', 'Port', and 'Max Attempts' fields.

5. Check the **XNET 2 Protocol** checkbox to indicate this port is using encrypted XNET 2 protocol.



Notice when you check this box...

... this **Search** button is activated.


6. Click the **Search** button.

Velocity searches on the subnet for all SNIB2s that Velocity is not using.



If a SNIB2 is currently logged on, the search feature will not detect it.

A dialog box appears listing all new SNIB2s like the following example:



— New SNIB2 detected


Drag the slide bar over to the right to see the MAC Address column. While a newly detected SNIB2 does not have an assigned IP address, it always has a unique MAC address.

Since all SNIB2 MAC addresses start with the same six digits (00:90:C2), the label on the SNIB2 only lists the last six digits.

While a newly-detected SNIB2 does not possess an IP address, port number, or name, it should have a unique MAC address. To see this MAC address, drag the slide bar at the bottom of the dialog box to the right. The MAC address for each SNIB2 is printed on a white label located on the left side of the SNIB2's daughterboard. This label contains both a barcode and a six-digit number. This number is the last six digits of the MAC address.

7. From this list, double click the SNIB2 entry you want to configure.

The SNIB2 Configuration dialog box appears like this example:



8. In the 'Name' field, enter the name you want to assign to the SNIB2.
9. At the 'IP Address' field, enter the IP address for the SNIB2 connected to this Velocity PC.

In version 5.95 and later, all SNIB2s will have a factory default IP address in the format 10.x.y.z where the variables are supplied from a hash of the MAC address. For versions earlier than this, you must enter the required IP address.

10. At the 'Port' field, enter the correct port number.

All network ports possess an address used to identify the SNIB2's physical port address. The default Velocity port is **10001**.



Consult your system administrator for the correct values for both the IP and port address.

11. Click **OK**. The Searching screen reappears.

12. Click **OK**.

The Port Properties screen reappears with the Name, IP Address, and IP Port fields populated.

13. At the 'Max retry attempts' field, specify the maximum number of retries this PC will attempt. Increment or decrement the value using the counter buttons.


If you get port errors, increase this number.

14. Check the 'Enable this Port' box if this port is currently active. Clear this box if the port is not currently active.

15. If required, click the **Advanced** button to access the Advanced Settings dialog box to specify additional options for this port.

16. When you're finished, click **OK**.

The new SNIB2 port appears in the Components window.

 **If you ever need to reassign an IP address, repeat this procedure.**


Configuring a Master SNIB2 in a Different Subnet

To connect a master SNIB2 via Ethernet to a host PC residing outside the host PC's subnet, configure and assign a new IP address for the master SNIB2 on its own subnet using the SNIB2 Configuration Utility as described in this section.

To configure a master SNIB2 using the SNIB2 Configuration Utility:

1. If you haven't already, install the SNIB2 Configuration Utility in a PC in the same subnet as the master SNIB2 you want to configure. To do this:
 - a. Insert the Velocity CD in your CD drive or go to the `\Velocity` folder.
 - b. Using Windows Explorer, navigate to the `\SNIB2` folder. The file `SNIB2CONFIG.EXE` should be located here.
2. Double click **SNIB2CONFIG.EXE**.

The SNIB2 Configuration Utility appears like this example:



3. Select one of these radio buttons:

Search for all devices Select this option to search for all SNIB2s on this subnet.

Note: If a SNIB2 is currently logged on, the utility will not detect it.

Offline devices only Select this option to search only for SNIB2s that are currently offline. It automatically eliminates all SNIB2s that are already configured for this subnet. This is the default selection.


Search this IP Address Select this option if you know the address of the SNIB2 you are programming, then enter the SNIB2s current IP address in the field to the right of this radio button.

Use this option to change the IP or port address of a previously-configured SNIB2.

4. Click the **Search for SNIB2** button.

The utility scans the network within the current subnet and returns a list of all devices meeting the criterion specified by the radio button.

- Click the 'Devices' pick list to display all devices currently detected by the utility, like the following example:



Since all SNIB2 MAC addresses start with the same six digits (00:90:C2), the label on the SNIB2 only lists the last six digits.


- Select the correct SNIB2.

You can identify which SNIB2 you need, by its MAC address (id=). The MAC address for each SNIB2 is printed on a white label located on the left side of the SNIB2's daughterboard. This label contains both a barcode and a six-digit number. This number is the second half of the MAC address.

- Select the **Get Configuration From Device** button.


A list of variables specific to this SNIB2 appear in the 'Variable Name' window.

The three options used for SNIB2 configuration are: **Device_IP_Address**, **Device_Port**, and **Device_Hostname** as shown in the following example:




- From the 'Variable Name' pick list, select **Device_IP_Address**.

A screen like this example appears:



- In the 'Value' field, enter the IP address you require for this SNIB2.

A screen like this example appears:



Consult your IT or Security Administrator for the proper address.

- From the 'Variable Name' pick list, select **Device_Port**.

11. At the 'Value' field, enter a port address for this SNIB2.
All network ports possess an address used to identify the SNIB2's physical port address. The default Velocity port is **10001**.
12. From the 'Variable Name' pick list, select **Device_Hostname**.
13. At the 'Value' field, enter a name for this SNIB2.
14. Click the **Send Configuration to Device** button to send the information to the SNIB2.
15. Click the **Search for SNIB2** button again to verify that the SNIB2 has correctly received the information.

Make sure to write down the address, port, and host name you assigned for each SNIB2. These values are required when you configure the SNIB2 in Velocity.

Hint If there are a lot of master SNIB2s to configure remotely, we recommend using a dedicated portable computer with SNIB2CONF already installed. This should enable the installer to do the job more rapidly. But be careful: make sure you are on-site when you do this. A SNIB2 does not retain its IP address for more than 5 minutes after being unplugged from a controller. If you are planning to program several SNIB2s from a controller then move them to a remote site, you probably won't have time before the IP address in each SNIB2 is irrevocably lost.

Once the installer has assigned the remote master SNIB2 an IP address and port, use Velocity on the host PC to identify it to the system. To do this:

1. Create a new XNET port as specified in Steps 1–5 of "Configuring a Master SNIB2 on the Same Subnet" starting on page 13.


 ***Do not use the Search button. This only works for finding SNIB2s that are currently residing on the host PC's subnet.***



2. In the 'Name' field, enter the name you assigned to the SNIB2 using the SNIB2 Configuration Utility (Device_Hostname).
3. At the 'IP Address' field, enter the IP address you assigned to this device using the SNIB2 Configuration Utility (Device_IP_Address).
4. At the 'Port' field, enter the port number you assigned to this device using the utility (Device_Port). The default value is **10001**.
5. Make sure the 'Enable this Port' box is checked.
6. Click **OK**.

This enables Velocity to find and monitor the remote SNIB2.

Resetting SNIB2 Encryption Keys

Once Velocity creates the encryption keys required for secure Host-to-SNIB2 communication, it continues to use those keys. If, for whatever reason, you need to change these keys, there are several ways to do it.


 *Several of these techniques reset not only the SNIB2 encryption keys but also the controller.*

Set SW2-1 to:	Procedures/Results
 OFF	<ul style="list-style-type: none"> • Cycle power on controller. SNIB2 retains encryption keys. Controller retains setups. • Press the blue button on the controller until it resets. SNIB2 retains encryption keys. Controller loses setups. • Download SNIB2 firmware through Velocity. SNIB2 retains encryption keys. Controller retains setups.
 ON	<ul style="list-style-type: none"> • Cycle power on controller. SNIB2 resets encryption keys. Controller retains setups. • Press the blue button on the controller until it resets. SNIB2 resets encryption keys. Controller loses setups. • Download SNIB2 firmware through Velocity. SNIB2 resets encryption keys. Controller retains setups.
OFF or ON	Download CCM firmware through Velocity. SNIB2 retains encryption keys. Controller retains setups.

Once you have reset the encryption key to its default value (set SW2-1 to ON, recycle controller power, then reset SW2-1 to OFF), you must assign a new key so that Velocity and the master SNIB2 can talk to each other. To do this:

1. From the Velocity Administrator system tree, click and expand the DIGi*TRAC Configuration system folder until the master SNIB2 port you require appears.
2. Right click on the SNIB2 port and select **Properties**.

The Port Properties dialog box appears. The master SNIB2 Properties should look like this example:




3. Check the 'Reset Encryption' box and click **OK**.

This resets and syncs the encryption key at host SNIB2.

Controller and SNIB2 LED Diagnostics


The SNIB2 has three pairs of LEDs that show you how the SNIB2 is communicating with the host PC.



Special Light Patterns: Start Up


This consists of the following light patterns during start up.

First comes the **Lamp Test**.



Power-up might include the first two patterns. If you've just reflashed the SNIB2, the sequence starts with the ones in the box.









This pattern is followed by:



This is the **SNIB2/CCM Synchronization**. This pattern repeats until the CCM and SNIB2 are synchronized. This light pattern should not persist longer than four minutes if there are no memory expansion boards on the controller.

Normal Operation

This table illustrates the various light patterns displayed during normal operation for both the master and subordinate SNIB2s:

Master or Subordinate	
P1   P2  	Ordinary communication between master and subordinates. Lights may blink or stay lit during heavy data transfers. They will go out every 4 seconds during idle or low-traffic periods; this is normal, indicating the master is hunting for new addresses, such as newly-added controllers or controllers that went offline and are expected back online.
Legend: <div>  = LED OFF  = LED ON  = LED Flashing or ON  = LED Flashing </div>	

Master	
P1 ○ ○ P2 ● ● P3 ● ●	This could be programming activity (downloads) or events, or both.
P1 ○ ○ P2 ● ★ P3 ● ●	P2's red LED flashes while P2 green and P3 red and green stays lit. This normally means that the Velocity server is in the process of downloading CCM or SNIB2 firmware to one or more controllers.
P3 ★ ★	Heartbeat. If the P3 LED flashes appear to be about 5 seconds apart, it means the host is keeping the communication link open.
Subordinate	
P1 ○ ○ P2 ○ ★ P3 ○ ○	The master is polling a different SNIB2. This SNIB2 ignores those polls.
P1 ○ ○ P2 ○ ● P3 ○ ○	If this stays lit and doesn't go out every 4 seconds, that means there's a lot of data going to or coming from some other controller(s). If you don't see any green flashes at all, this unit won't come online until the data traffic decreases. This pattern may also alternate with occasional red or green P3 flashes.
P1 ○ ○ P2 ★ ● P3 ○ ○	If these stay flashing and lit, it means there is a lot of data going to or coming from several controllers. This occurs particularly when you have many controllers.
P1 ○ ○ P2 ● ● P3 ○ ○	If these stay lit, it means there is a lot of data going to or coming from this particular controller.
Legend: <div> ○ = LED OFF ● = LED ON ◉ = LED Flashing or ON ★ = LED Flashing </div>	

For more on this, refer to the *SNIB2 Troubleshooting Guide* included with the SNIB2.


The SNIB2 also causes certain changes to the way the controller LEDs display as shown below:

LED Configuration	Meaning
<ul style="list-style-type: none"> ● ○ AC ○ ○ BAT ● ○ SYS ○ ○ KPD ● ○ NET 	<p>The NET green LED is on; the NET red LED blinks intermittently depending on the amount of data being received from the host. This indicates the SNIB2 is working properly.</p> <p><i>Note: The exact NET LED behavior depends on the controller version.</i></p>
<ul style="list-style-type: none"> ● ○ AC ○ ○ BAT ● ○ SYS ○ ○ KPD ○ ○ NET 	<p>Neither NET LED is blinking or only the NET green LED is on. In either case, the master SNIB2 is not communicating with the host.</p> <p>Check both your Ethernet connection and your Velocity port configuration.</p>

For more on this, refer to "Status LED Configurations" starting on page 166 of the *DIGI*TRAC Design and Installation Guide*.

Checking CCM and BIOS Version

Before you can flash your current CCM to 7.3.08 or higher, you must first check the CCM BIOS level. In order for the 7.3.08 or higher flash update to work properly, you must be running a CCM with a CCM BIOS level of 7.1.20 or higher.

 **If you are running a CCM with CCM BIOS 7.1.8, you will need to replace your CCM, since the flash will not work properly and the controller may not reboot if powered off.**


The CCM BIOS level currently shipping is 7.3.17.

To determine the CCM BIOS of your controllers, use one of two methods.


Method 1 The simplest method is to check the General page of Controller Properties for the specific controller in this way:

1. Expand the Velocity system tree until the selected controller appears.
2. Right click the selected controller and select **Properties**.

The CCM Firmware and CCM BIOS versions appear in the 'Firmware Revision' section of the General page like this example:



Method 2 The second method requires use of Velocity's Diagnostic Window. To do this:

1. From Velocity menu tool bar, select **Help > Diagnostic Window**.
The Diagnostic Window appears.
2. At the top of the window, click the red **Diagnostic Stream** button.
The button turns green.
3. From the 'Controller' pick list, select the appropriate controller.
4. From the 'Diagnostics Command' pick list, select **1 - Date, Time, Version Number**, then click the  button to the right of this pick list.

The controller displays system information in the bottom pane. Look for the following information and determine the BIOS level of your CCM:

```
1:24:40 PM 001:001:001 SNET Message 110 Current Date and Time is Thu
28-Oct-2004 13:25:19 (Regular)
1:24:40 PM 001:001:001 SNET Message 139 Device Info Device Type 3 M2
1:24:40 PM . ROM Sig. ffffffffxxxx BIOS=7.2.19 Firmware
Date=20041027 Vn. 7.3.08
```

In this example, we ran CCM BIOS 7.2.19. (The Firmware version number may be different from the BIOS number. Only determine the BIOS Level.)

5. If you are running BIOS Level 7.1.20 or higher you can use Velocity to flash your CCM with 7.3.08 or higher.

You can find the latest CCM firmware in your ... \Velocity\Firmware subfolder.