





















# Position of Parts in Engine Compartment (LHD 1VD-FTV)



D6	Starter Assembly
D7	Starter Assembly
D8	Battery (Main)
D9	Battery (Main)
I2	A/C Pressure Switch (Cooler Refrigerant Liquid Pipe B)
I25	Side Turn Signal Light Assembly RH
I32	Vacuum Warning Switch Assembly
I36	Headlight Assembly RH
I38	Headlight Assembly RH
I44	Headlight Assembly RH
I48	Thermistor Assembly
I52	Front Airbag Sensor RH
I76	Fuse Block Assembly
I84	ECM
I86	Windshield Wiper Motor Assembly
I91	Headlight Assembly RH
J1	Fog Light Assembly RH
J2	Fog Light Assembly LH
k1	No. 1 Magnet Switch Assembly
k2	Battery (Main)
m1	Winch Motor with Magnet Switch Assembly
m2	Winch Motor with Magnet Switch Assembly
m3	No. 1 Magnet Switch Assembly
m4	No. 1 Magnet Switch Assembly
r2	Suction Control Valve
r3	Fuel Temperature Sensor
s1	Winch Assembly
s2	Winch Motor with Magnet Switch Assembly
t1	Winch Motor with Magnet Switch Assembly
u1	Exhaust Fuel Addition Injector Assembly
v1	Pressure Discharge Valve Assembly (Common Rail Assembly)

# Position of Parts in Engine Compartment (LHD 1VD-FTV)



Position of Parts in Engine Compartment (LHD 1VD-FTV)

