

- [Close Window](#)
- [Print This Page](#)
- [Expand All](#) | [Collapse All](#)

How to select external R-sense for PMI8994 FG

<hr/>	
Solution Number	00030229
Please Note: If Qualcomm documentation is referenced in this solution, your access to it is based on your company's	
Language Key Words	
Detail Information	
Solution Title	How to select external R-sense for PMI8994 FG
Solution Details	PMI8994 FG can use internal R-sense and external R-sense. Default we use internal R-sense. But if use parallel charging, since charge current will be flowing from two paths, PMI8994 and SMB1357. If use external R-sense, need to move qcom,ext-sense-type from &pmi8994_charger to &pmi8994_fg in msm8994-mtp.dtsi.
Applicable Products	PM8994, PMI8994