

[Description]: how to change the vbus output at otg mode

[Platform]:msm8953 msm8937 msm8940

1. the vbus out mode is pinctrl by default.

Need to change it to cmd mode.

```
static int smbchg_hw_init(struct smbchg_chip *chip)
{
    .....

    if (chip->otg_pinctrl) {
        /* configure OTG enable to pin control active low */
        rc = smbchg_sec_masked_write(chip, chip->otg_base + OTG_CFG,
        OTG_PIN_POLARITY_BIT | OTG_EN_CTRL_MASK,
        OTG_PIN_ACTIVE_LOW | OTG_PIN_CTRL_RID_DIS);
        if (rc < 0) {
            dev_err(chip->dev, "Couldn't set OTG EN config rc = %d\n",
            rc);
            return rc;
        }
    }

    ++rc = smbchg_sec_masked_write(chip, chip->otg_base + OTG_CFG,
    OTG_EN_CTRL_MASK, OTG_CMD_CTRL_RID_EN);
    ...
}
```