



Mount input capacitors only if needed ! (battery voltage measurement), not if adc should read ir sensors or similar !