

HIGH = On
LOW = Off

HIGH = Unbuckled
LOW = Buckled

Ignition
switch

A

Seat
belt

B

C

Timer

Audible
alarm
circuit

HIGH activates
alarm.

Ignition on = HIGH for 30 s

