



## 06. ROS 2 Launch, Param, Bag

---

### Elmélet

---

#### ROS 2 Launch

---

- Launch multiple nodes
  - Set arguments
  - Monitor running nodes
  - React on changes in the state of nodes
  - Python, XML and YAML file formats
- 

#### Usage

```
ros2 launch package_name file.launch
ros2 launch irob_robot dvrk_server.launch arm_typ:=PSM1
```

---

#### ROS 2 Parameters

---

- Configure nodes at startup or during runtime without changing the code
  - Associated with individual nodes
  - Consists of: key, value, descriptor
  - Available data types: bool, int64, float64, string, byte[], bool[], int64[], float64[] or string[].
  - Useful command: `ros2 param`
-