

4.

### Router0:

Continue with configuration dialog? [yes/no]: no

Press RETURN to get started!

Router>en

Router#conf t

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#int fa0/0

Router(config-if)#ip add 192.168.2.1 255.255.255.0

Router(config-if)#no shut

Router(config-if)#

%LINK-5-CHANGED: Interface FastEthernet0/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0, changed state to up

Router(config-if)#exit

Router(config)#int fa1/0

Router(config-if)#ip add 192.168.3.1 255.255.255.0

Router(config-if)#no shut

Router(config-if)#

%LINK-5-CHANGED: Interface FastEthernet1/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet1/0, changed state to up

Router(config-if)#exit

Router(config)#int gig2/0

Router(config-if)#ip add 192.168.1.1 255.255.255.0

Router(config-if)#no shut

Router(config-if)#

%LINK-5-CHANGED: Interface GigabitEthernet2/0, changed state to up

Router(config-if)#exit

Router(config)#

%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet2/0, changed state to up

Router(config)#conf t

%Invalid hex value

Router(config)#exit

Router#

%SYS-5-CONFIG\_I: Configured from console by console

```
Router#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#router rip
Router(config-router)#version 2
Router(config-router)#net 192.168.2.0
Router(config-router)#net 192.168.3.0
Router(config-router)#net 192.168.1.0
Router(config-router)#exit
Router(config)#exit
Router#
%SYS-5-CONFIG_I: Configured from console by console
```

```
Router#wr
Building configuration...
[OK]
Router#
```

### **Router1:**

Continue with configuration dialog? [yes/no]: no

Press RETURN to get started!

```
Router>en
```

```
Router#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#int gig2/0
Router(config-if)#ip add 192.168.1.2 255.255.255.0
Router(config-if)#no shut
Router(config-if)#
%LINK-5-CHANGED: Interface GigabitEthernet2/0, changed state to up
```

```
%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet2/0,
changed state to up
```

```
Router(config-if)#exit
Router(config)#int fa0/0
```

```
Router(config-if)#ip add 192.168.4.1 255.255.255.0
```

```
Router(config-if)#no shut
```

```
Router(config-if)#
```

```
%LINK-5-CHANGED: Interface FastEthernet0/0, changed state to up
```

```
%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0,  
changed state to up
```

```
Router(config-if)#exit
```

```
Router(config)#int gig1/0
```

```
Router(config-if)#ip add 192.168.5.1 255.255.255.0
```

```
Router(config-if)#no shut
```

```
Router(config-if)#
```

```
%LINK-5-CHANGED: Interface GigabitEthernet1/0, changed state to up
```

```
Router(config-if)#exit
```

```
Router(config)#
```

```
%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet1/0,  
changed state to up
```

```
Router(config)#exit
```

```
Router#
```

```
%SYS-5-CONFIG_I: Configured from console by console
```

```
Router#conf t
```

```
Enter configuration commands, one per line. End with CNTL/Z.
```

```
Router(config)#router rip
```

```
Router(config-router)#version 2
```

```
Router(config-router)#net 192.168.1.0
Router(config-router)#net 192.168.4.0
Router(config-router)#net 192.168.5.0
Router(config-router)#exit
Router(config)#exit
Router#
%SYS-5-CONFIG_I: Configured from console by console
```

```
Router#wr
Building configuration...
[OK]
Router#
```

## **Router2:**

```
Continue with configuration dialog? [yes/no]: no
Press RETURN to get started!
Router>en
Router#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#int gig1/0
Router(config-if)#ip add 192.168.5.2 255.255.255.0
Router(config-if)#no shut
Router(config-if)#
%LINK-5-CHANGED: Interface GigabitEthernet1/0, changed state to up
%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet1/0,
changed state to up

Router(config-if)#exit
```

```
Router(config)#int fa2/0
```

```
Router(config-if)#ip add 192.168.6.1 255.255.255.0
```

```
Router(config-if)#no shut
```

```
Router(config-if)#
```

```
%LINK-5-CHANGED: Interface FastEthernet2/0, changed state to up
```

```
%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet2/0,  
changed state to up
```

```
Router(config-if)#exit
```

```
Router(config)#int gig0/0
```

```
Router(config-if)#ip add 192.168.7.1 255.255.255.0
```

```
Router(config-if)#no shut
```

```
Router(config-if)#
```

```
%LINK-5-CHANGED: Interface GigabitEthernet0/0, changed state to up
```

```
Router(config-if)#exit
```

```
Router(config)#
```

```
%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/0,  
changed state to up
```

```
Router(config)#exit
```

```
Router#
```

```
%SYS-5-CONFIG_I: Configured from console by console
```

```
Router#conf t
```

Enter configuration commands, one per line. End with CNTL/Z.

```
Router(config)#router rip
```

```
Router(config-router)#version 2
```

```
Router(config-router)#net 192.168.5.0
```

```
Router(config-router)#net 192.168.6.0
```

```
Router(config-router)#net 192.168.7.0
```

```
Router(config-router)#exit
```

```
Router(config)#exit
```

```
Router#
```

```
%SYS-5-CONFIG_I: Configured from console by console
```

```
Router#wr
```

```
Building configuration...
```

```
[OK]
```

```
Router#
```

### **Router3:**

Continue with configuration dialog? [yes/no]: no

Press RETURN to get started!

```
Router>en
```

```
Router#conf t
```

Enter configuration commands, one per line. End with CNTL/Z.

```
Router(config)#int gig2/0
```

```
Router(config-if)#ip add 192.168.7.2 255.255.255.0
```

```
Router(config-if)#no shut
```

```
Router(config-if)#
```

%LINK-5-CHANGED: Interface GigabitEthernet2/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet2/0,  
changed state to up

Router(config-if)#exit

Router(config)#int fa0/0

Router(config-if)#ip add 192.168.8.1 255.255.255.0

Router(config-if)#no shut

Router(config-if)#

%LINK-5-CHANGED: Interface FastEthernet0/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0,  
changed state to up

Router(config-if)#exit

Router(config)#int fa1/0

Router(config-if)#ip add 192.168.9.1 255.255.255.0

Router(config-if)#no shut

Router(config-if)#

%LINK-5-CHANGED: Interface FastEthernet1/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet1/0,  
changed state to up

Router(config-if)#exit

Router(config)#

Router(config)#exit

Router#

%SYS-5-CONFIG\_I: Configured from console by console

Router#conf t

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#router rip

Router(config-router)#version 2

Router(config-router)#net 192.168.7.0

Router(config-router)#net 192.168.8.0

Router(config-router)#net 192.168.9.0

Router(config-router)#exit

Router(config)#exit

Router#

%SYS-5-CONFIG\_I: Configured from console by console

Router#wr

Building configuration...

[OK]

Router#