

IntelliKeys USB Access Features Chart



NAME	DEFAULT	GENERAL DESCRIPTION	
Response Rate	15	Adjusts the time ( <i>not the pressure</i> ) required to leave a finger on a key before it is activated. 15 is the most rapid response rate, 1 the slowest.	
Required Lift Off	Off	Requires the user to lift off from IntelliKeys USB before another keypress is recognized.	
Keysound Volume	Sound Level 2	Adjusts the volume of IntelliKeys USB sounds, such as when a user presses a key, or a new overlay is inserted.	
Repeat Rate	15	Controls the rate of key repeats. 15 is the fastest repeat rate, 1 the slowest.	
Repeat	On	Turns the key repeat feature on or off.	
Repeat Latching	Off	When on, hold down a key until it starts to repeat, let it go and repeating continues. Touch the overlay anywhere and repeating stops.	
Shift Key Action (works for all modifiers)	Latching	<i>Latching</i> - for capitalization, press shift key followed by a letter. <i>Locking</i> - latching plus press the shift key twice to lock it down until it is pressed again. <i>No Latch</i> - shift keys work as regular keys.	
Indicator Lights	6	Lights indicate:	
		Shift	Alt/Option
		Caps Lock	Control/Command
		Mouse Down	Num Lock
Display Features	N/A	Press twice to open a text editor to see a list of all current settings.	
Keyboard Reset	N/A	Press twice to reset all features to default settings for the current user and clear the active overlay.	
Mouse Speed	15	Adjusts the mouse speed. 15 is the fastest mouse speed, 1 is the slowest.	
Smart Typing	Off	When you type a “q”, IntelliKeys automatically adds a “u”. Punctuation is followed by the proper number of spaces and, where appropriate, a latching shift key.	
Switch Setting	1	Redefines the switch settings. Also for using IntelliKeys USB as a keyboard with two big keys. Press this key and then press the appropriate switch setting. This switch setting replaces the currently active overlay unless there is a standard overlay in place.	
Data Send Rate	15	Adjusts the speed at which IntelliKeys USB sends characters to the computer. 15 is the fastest rate, 1 the slowest.	
Help	N/A	Press to view on-screen help for the Setup Overlay and the Control Panel.	
Show Control Panel	N/A	Press to open the on-screen Control Panel.	

Switch Settings Chart

SWITCH SETTING	SWITCH #1 LEFT SIDE OF INTELLIKEYS	SWITCH #2 RIGHT SIDE OF INTELLIKEYS
1	Control-Enter/Return	Control-Enter/Return
2	Control-Right Arrow	Control-Down Arrow
3	Space	Enter/Return
4	Click	Click
5	Click	Double Click
6	Left Arrow	Right Arrow
7	Up Arrow	Down Arrow
8	Left Arrow	Up Arrow
9	1	2
10	Tab	Enter/Return
11	Tab	Space
12	Tab	Shift-Tab
13	Left Shift	Right Shift
14	Down Arrow	Enter/Return
15	Right Arrow	Enter/Return



ITEM NO. OL - USB - SE