

How to Fix a Cassette Tape

Unscrew the cassette case, if it has screws, using a small Phillips screwdriver.



Open the cassette tape horizontally so the spools don't fall out.

