

Function name	HCarMove_vInit	
Arguments	Input	none
	Output	none
Return	none	
Description	This function is used to initialize car movement	

Function name	HCarMove_vSpeedRatio		
Arguments	Input	A_u16SpeedRatio	Data including speed ratio recived by car movement prephiral
	Output	none	
Return	none		
Description	This function is used to get the car speed ratio		

Function name	HCarMove_vForward	
Arguments	Input	none
	Output	none
Return	none	
Description	This function is used to make car move forward	

Function name	HCarMove_vBackward	
Arguments	Input	none
	Output	none
Return	none	
Description	This function is used to make car move backward	

Function name	HCarMove_vRight	
Arguments	Input	none
	Output	none
Return	none	
Description	This function is used to make car move right	

Function name	HCarMove_vLeft	
Arguments	Input	none
	Output	none
Return	none	
Description	This function is used to make car move left	

Function name	HCarMove_vStop	
Arguments	Input	none
	Output	none
Return	none	

Description	This function is used to stop car moving	
Function name	HCarMove_u32GetCarSpeed	
Arguments	Input	none
	Output	none
Return	car speed	
Description	This function is used to get car speed	