



SIM7022 Series_ AT Command Manual

LPWA Module

SIMCom Wireless Solutions Limited

SIMCom Headquarters Building, Building 3, No. 289 Linhong
Road, Changning District, Shanghai P.R. China

Tel: 86-21-31575100

support@simcom.com

www.simcom.com

Document Title:	SIM7022 Series_AT Command Manual
Version:	1.01
Date:	2021.08.12
Status:	Released

GENERAL NOTES

SIMCOM OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS, TO SUPPORT APPLICATION AND ENGINEERING EFFORTS THAT USE THE PRODUCTS DESIGNED BY SIMCOM. THE INFORMATION PROVIDED IS BASED UPON REQUIREMENTS SPECIFICALLY PROVIDED TO SIMCOM BY THE CUSTOMERS. SIMCOM HAS NOT UNDERTAKEN ANY INDEPENDENT SEARCH FOR ADDITIONAL RELEVANT INFORMATION, INCLUDING ANY INFORMATION THAT MAY BE IN THE CUSTOMER'S POSSESSION. FURTHERMORE, SYSTEM VALIDATION OF THIS PRODUCT DESIGNED BY SIMCOM WITHIN A LARGER ELECTRONIC SYSTEM REMAINS THE RESPONSIBILITY OF THE CUSTOMER OR THE CUSTOMER'S SYSTEM INTEGRATOR. ALL SPECIFICATIONS SUPPLIED HEREIN ARE SUBJECT TO CHANGE.

COPYRIGHT

THIS DOCUMENT CONTAINS PROPRIETARY TECHNICAL INFORMATION WHICH IS THE PROPERTY OF SIMCOM WIRELESS SOLUTIONS LIMITED. COPYING, TO OTHERS AND USING THIS DOCUMENT, ARE FORBIDDEN WITHOUT EXPRESS AUTHORITY BY SIMCOM. OFFENDERS ARE LIABLE TO THE PAYMENT OF INDEMNIFICATIONS. ALL RIGHTS RESERVED BY SIMCOM IN THE PROPRIETARY TECHNICAL INFORMATION, INCLUDING BUT NOT LIMITED TO REGISTRATION GRANTING OF A PATENT, A UTILITY MODEL OR DESIGN. ALL SPECIFICATION SUPPLIED HEREIN ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.

SIMCom Wireless Solutions Limited

SIMCom Headquarters Building, Building 3, No. 289 Linhong Road, Changning District, Shanghai P.R. China

Tel: +86 21 31575100

Email: simcom@simcom.com

For more information, please visit:

<https://www.simcom.com/download/list-863-en.html>

For technical support, or to report documentation errors, please visit:

<https://www.simcom.com/ask/> or email to: support@simcom.com

Copyright © 2021 SIMCom Wireless Solutions Limited All Rights Reserved.

Version History

Version	Date	Chapter	What is new
V1.00	2021.05.19	All	New version
V1.01	2021.08.12	4.2.29 AT+DMCONFIG	Removed
		6 AT Commands for Ocean Connect	Removed
		7 AT Commands for OneNET	Removed

SIMCom
Confidential

Contents

Version History	3
Contents	4
1 Introduction	9
1.1 Scope of the document	9
1.2 Related documents	9
1.3 Conventions and abbreviations	9
1.4 AT Command syntax	9
1.4.1 Basic syntax	10
1.4.2 S Parameter syntax	10
1.4.3 Extended Syntax	10
1.4.4 Combining AT commands on the same Command line	10
1.4.5 Entering successive AT commands on separate lines	11
1.5 AT Command Responses	11
1.6 AT Command definitions	11
1.7 3GPP Alignment	12
1.8 Supported character sets	12
1.9 Definitions	12
1.9.1 Parameter Saving Mode	12
1.9.2 Max Response Time	12
2 AT Commands According to V.25TER	14
2.1 Overview of AT Commands According to V.25TER	14
2.2 Detailed Description of AT Commands According to V.25TER	14
2.2.1 ATE Set Command Echo Mode	14
2.2.2 ATI Display Product Identification Information	15
3 AT Commands According to 3GPP TS 27.007	16
3.1 Overview of AT Command According to 3GPP TS 27.007	16
3.2 Detailed Descriptions of AT Command According to 3GPP TS 27.007	17
3.2.1 AT+CGMI Request Manufacturer Identification	17
3.2.2 AT+CGMM Request Model Identification	18
3.2.3 AT+CGMR Request TA Revision Identification of Software Release	18
3.2.4 AT+CGSN Request Product Serial Number Identification	19
3.2.5 AT+CREG Network Registration	20
3.2.6 AT+CEREG EPS Network Registration Status	22
3.2.7 AT+CSCON Signalling Connection Status	24
3.2.8 AT+CSQ Signal Quality Report	26
3.2.9 AT+CESQ Get Extended Signal Quality	26

3.2.10 AT+CGPADDR Show PDP Address.....	27
3.2.11 AT+COPS Operator Selection.....	29
3.2.12 AT+CGATT Attach or Detach from GPRS Service.....	31
3.2.13 AT+CGACT PDP Context Activate or Deactivate.....	33
3.2.14 AT+CIMI Request International Mobile Subscriber Identity.....	34
3.2.15 AT+CGDCONT Define PDP Context.....	35
3.2.16 AT+CFUN Set Phone Functionality.....	39
3.2.17 AT+CMEE Report Mobile Equipment Error.....	40
3.2.18 AT+CCLK Return Current Date & Time.....	41
3.2.19 AT+CPSMS Power Saving Mode Setting.....	42
3.2.20 AT+CEDRXS Extended-DRX Setting.....	44
3.2.21 AT+CEDRXRDP eDRX Read Dynamic Parameters.....	46
3.2.22 AT+CTZR Time Zone Reporting.....	47
3.2.23 AT+CTZU Automatic Time Zone Update.....	49
3.2.24 AT+CIPCA Initial PDP context activation.....	49
3.2.25 AT+CGAPNRC APN Rate Control.....	51
3.2.26 AT+CSODCP Sending of Originating Data via the Control Plane.....	52
3.2.27 AT+CRTDCP Reporting of Terminating Data via the Control Plane.....	54
3.2.28 AT+CGEREP Packet Domain Event Reporting.....	55
3.2.29 +CGEV Indicate EPS PDN Connection and Bearer Resources Operations Status.....	56
3.2.30 AT+CGCONTRDP PDP Context Read Dynamic Parameters.....	57
3.2.31 AT+CGAUTH Define PDP Context Authentication Parameters.....	60
3.2.32 AT+CPIN Enter PIN.....	61
3.2.33 AT+CLCK Facility Lock.....	62
3.2.34 AT+CMOLR Mobile Originated Location Request.....	63
3.2.35 AT+CPWD Change Password.....	66
3.2.36 AT+CPINR Remaining PIN Retries.....	67
3.2.37 AT+CCHO Open Logical Channel.....	68
3.2.38 AT+CCHC Close logical channel.....	69
3.2.39 AT+CGLA Generic UICC Logical Channel Access.....	69
3.2.40 AT+CMTLR Mobile Terminated Location Request Notification.....	71
3.2.41 AT+CMTLRA Mobile Terminated Location Request Disclosure Allowance.....	72
3.2.42 AT+CRCES Reading Coverage Enhancement Status.....	73
3.2.43 AT+CRSM Restricted SIM Access.....	74
3.2.44 AT+CSIM Generic SIM Access.....	75
3.2.45 AT+CGDATA Enter Data State.....	76
3.2.46 AT+CCIOPT Clot Optimization Configuration.....	77
3.2.47 AT+CGCMOD PDP Context Modify.....	79
3.2.48 AT+CGEQOS Define EPS Quality of Service.....	80
3.2.49 AT+CGEQOSRDP EPS Quality of Service Read Dynamic Parameters.....	81
3.2.50 AT+CGTFT Traffic Flow Template.....	83
3.2.51 AT+IPR Set UE Baud Rate.....	86

4 AT Commands for General Commands.....	88
4.1 Overview of AT Commands for General.....	88
4.2 Detailed Descriptions of Commands.....	89

4.2.1 AT\$QCBAND	Set Supported Network and Bands	89
4.2.2 AT\$QCLOGDBVER	Database Version Information	90
4.2.3 AT\$QCCFG	UE Extended Configuration	90
4.2.4 AT\$QCPING	Test IP Network Connectivity to a Remote Host	92
4.2.5 AT\$QCFREQ	Lock or Unlock Cell	94
4.2.6 AT\$QCRMFPLMN	Remove FPLMN in NVM or SIM	95
4.2.7 AT\$QCATTBEARER	Configure the PDN Info Request to Establish	95
4.2.8 AT\$QCSSENDATA	Send Data Via Control Plane or User Plane	97
4.2.9 +RECVNONIP	Indicate Downlink NON-IP Data	98
4.2.10 AT\$QCPMUCFG	Set PMU mode	98
4.2.11 AT\$QCSMSEND	Send one SMS	99
4.2.12 AT\$QCCGSN	Sets the IMEI and SN	100
4.2.13 AT\$QCRFSTAT	Shows the Status of RF Calibration	100
4.2.14 AT\$QCRST	Restart the Chip	101
4.2.15 AT\$QCPSMR	Report the Power Saving Mode Status	101
4.2.16 AT\$QCPLMNS	Used to trigger a PLMN	102
4.2.17 AT\$QCCESQS	Controls the Extended Signal Quality Change Event Reporting	103
4.2.18 AT\$QCSTATUS	Returns Some Key Parameter in UE Side	104
4.2.19 AT\$QCICCID	Causes the TA to Return the ICCID of the UICC	106
4.2.20 AT\$QCBCINFO	Return the Basic Serving Cell Information	107
4.2.21 AT\$QCDNS	Get the IP Address for a Specific URL	108
4.2.22 AT\$QCDNSCFG	Set the Default DNS Addresses Configuration	109
4.2.23 AT\$QCEMMTIME	Report and Get the Emm Time State	110
4.2.24 AT\$QCPCFG	Set Plat Configure	111
4.2.25 AT\$QCSLEEP	Power Consumption Test	112
4.2.26 AT\$QCSIMSLEEP	Set UE to Allow SIM Card Sleep for Power Consumption	113
4.2.27 AT\$QCCGSNLOCK	Set Lock Flag for IMEI and SN	113
4.2.28 AT\$QCSAVEFAC	Saves Related Regions to Default Reliable Region	114
4.2.29 AT\$QCTASKINFO	Returns All the Task's Information	115
4.2.30 AT\$QCTASKHISTINFO	Shows Most Recent Tasks' Scheduling History	115
4.2.31 AT\$QCSHOWMEM	Shows Current Heap Memory Usage	116
4.2.32 AT\$QCSYSTEST	Triggers a Test Feature	116
4.2.33 AT\$QCVOTECHK	Analyze the Reason of Sleep Failure	117
4.2.34 AT\$QCURC	Close/Open URC Report	118
4.2.35 AT\$QCPTWEDRXS	Control Whether the UE	119
4.2.36 \$QCPIN	Indicate SIM PIN State	120
4.2.37 \$QCPCFUN	Power on status URC report	121
4.2.38 \$QCPADDR	Print PDP Address	121
4.2.39 AT\$QCADC	Read ADC	121
4.2.40 AT\$QCSWC	Set the UE Operation SIM Counter	122
4.2.41 AT\$QCIPR	Operate the Baud Rate of UE	123
4.2.42 AT\$QCNPICFG	Operating NPI	124
4.2.43 AT\$QCPRMODE	Control NPI production mode	125
4.2.44 AT\$QCLEDMODE	Enable the Netlight Function	125
4.2.45 AT\$QCPOWERCLASS	Sets the Band Power Class	126

5 AT Commands for Socket.....	128
5.1 Overview of AT Commands for Socket.....	128
5.2 Detailed Descriptions of Commands.....	128
5.2.1 AT\$QCSOCR Create Socket.....	128
5.2.2 AT\$QCSOST SendTo Command (UDP only).....	129
5.2.3 AT\$QCSOSTF SendTo Command with Flags(UDP only).....	131
5.2.4 AT\$QCSOS Query Socket Messages Sent Pending Data List.....	132
5.2.5 AT\$QCSORF Receive Command.....	133
5.2.6 AT\$QCSOCO Connect Command (TCP only).....	134
5.2.7 AT\$QCSOSD Send Command (TCP only).....	135
5.2.8 AT\$QCSOCL Close Socket.....	136
5.2.9 \$QCSONMI Socket Message Arrived Indicator (Response Only).....	136
5.2.10 \$QCSOCLI Socket Close Indicator (Response Only).....	137
5.2.11 AT\$QCSONMI Set the Public Max Downlink Buffer Size.....	138
5.2.12 AT\$QCSONMIE Arrived Messages of A Specified Socket.....	139
5.2.13 \$QCSOCO Socket Connected Indicator.....	142
6 AT Commands for MQTT.....	143
6.1 Overview.....	143
6.2 Detailed Descriptions of Commands.....	143
6.2.1 AT\$QCMTCFG Creates a MQTT Client.....	143
7.1.1 AT\$QCMTOPEN Open a Network for MQTT Client.....	147
7.1.2 AT\$QCMTCLOSE Send MQTT Close Packet.....	147
7.1.3 AT\$QCMTCNN Send MQTT Subscribe Packet.....	148
7.1.4 AT\$QCMTDISC Send MQTT Disconnect Packet.....	149
7.1.5 AT\$QCMTSUB Send MQTT Subscribe Packet.....	150
7.1.6 AT\$QCMTUNS Send MQTT Unsubscribe Packet.....	150
7.1.7 AT\$QCMTPUB Send MQTT Publish Packet.....	151
7.1.8 \$QCMTSTAT Receive Data from MQTT Server.....	152
7.1.9 \$QCMTRECVR Receive Data from MQTT Server.....	152
8 AT Commands for HTTP.....	154
8.1 Overview.....	154
8.2 Detailed Descriptions of Commands.....	154
8.2.1 AT+HTTPCREATE Creates a Http Client.....	154
8.2.2 AT+HTTPCON Create a Socket and Connects with a Http Server.....	155
8.2.3 AT+HTTPDESTROY Close a Socket.....	156
8.2.4 AT+HTTPSEND SendData to the Http Server.....	156
8.2.5 +HTTPRESPH Represent response header.....	157
8.2.6 +HTTPRESPC Represent response content.....	158
8.2.7 +HTTPERR Indicate of error Message.....	158
9 Error Codes and Reset Reasons.....	160
9.1 Summary of CME ERROR Codes.....	160
9.1.1 General Errors.....	160
9.1.2 Error Code for Socket Command.....	163
9.1.3 Error Code for CTM2M.....	163

9.2 Summary of CMS ERROR Codes.....	164
9.3 Summary of Unsolicited Result Codes.....	165

SIMCom
Confidential

1 Introduction

1.1 Scope of the document

This document presents the AT Command Set for SIMCom SIM7022 Series, including SIM7022.

1.2 Related documents

You can visit the SIMCom Website using the following link:

<http://www.simcom.com>

1.3 Conventions and abbreviations

In this document, the GSM engines are referred to as following term:

- ME (Mobile Equipment);
- MS (Mobile Station);
- TA (Terminal Adapter);
- DCE (Data Communication Equipment) or facsimile DCE (FAX modem, FAX board);

In application, controlling device controls the GSM engine by sending AT Command via its serial interface. The controlling device at the other end of the serial line is referred to as following term:

- TE (Terminal Equipment);
- DTE (Data Terminal Equipment) or plainly "the application" which is running on an embedded system;

1.4 AT Command syntax

The "AT" or "at" or "aT" or "At" prefix must be set at the beginning of each Command line. To terminate a Command line enter **<CR>**.

Commands are usually followed by a response that includes. "<CR><LF><response><CR><LF>"

Throughout this document, only the responses are presented, <CR><LF> are omitted intentionally.

1.4.1 Basic syntax

These AT commands have the format of "AT<x><n>", or "AT&<x><n>", where "<x>" is the Command, and "<n>" is/are the argument(s) for that Command. An example of this is "ATE<n>", which tells the DCE whether received characters should be echoed back to the DTE according to the value of "<n>". "<n>" is optional and a default will be used if missing.

1.4.2 S Parameter syntax

These AT commands have the format of "ATS<n>=<m>", where "<n>" is the index of the **S** register to set, and "<m>" is the value to assign to it. "<m>" is optional; if it is missing, then a default value is assigned.

1.4.3 Extended Syntax

These commands can operate in several modes, as in the following table:

Table 1: Types of AT commands and responses

Test Command AT+<x>=?	The mobile equipment returns the list of parameters and value ranges set with the corresponding Write Command or by internal processes.
Read Command AT+<x>?	This command returns the currently set value of the parameter or parameters.
Write Command AT+<x>=<...>	This command sets the user-definable parameter values.
Execution Command AT+<x>	The execution command reads non-variable parameters affected by internal processes in the GSM engine.

1.4.4 Combining AT commands on the same Command line

You can enter several AT commands on the same line. In this case, you do not need to type the "AT" or "at" prefix before every command. Instead, you only need type "AT" or "at" the beginning of the command line. Please note to use a semicolon as the command delimiter after an extended command; in basic syntax or S parameter syntax, the semicolon need not enter, for example:

ATE1Q0S0=1S3=13V1X4;+IFC=0,0;+IPR=115200.

The Command line buffer can accept a maximum of 559 characters(counted from the first command without "AT" or "at" prefix) or 39 AT commands. If the characters entered exceeded this number then none of the Command will executed and TA will return **"ERROR"**.

1.4.5 Entering successive AT commands on separate lines

When you need to enter a series of AT commands on separate lines, please Note that you need to wait the final response (for example OK, CME error, CMS error) of last AT Command you entered before you enter the next AT Command.

1.5 AT Command Responses

When the AT Command processor has finished processing a line it will output either OK, ERROR or an error code indicating that it is ready to accept a new command. Solicited informational responses are sent before the final OK or ERROR. Unsolicited information responses will never occur between a solicited informational response and the final OK or ERROR.

For AT Commands aligned to the 3GPP 27.007 specification error codes are enabled with the CMEE command, else the ERROR message will be returned. For AT Commands aligned to the 3GPP 27.005 specification, a CMS error will be returned where specified.

Responses will be of the format:

<CR><LF>+CMD1: <parameters><CR><LF>

<CR><LF>OK<CR><LF>

or

<CR><LF><parameters><CR><LF>

<CR><LF>OK<CR><LF>

1.6 AT Command definitions

- <CR> Carriage return character
- <LF> Line feed character
- <..> Parameter name. Angle brackets do not appear on command line
- [..] Option parameter. Square brackets do not appear on the command line.

1.7 3GPP Alignment

3GPP commands area lined to 3GPPTS27.007v14.3.0 (2017-03). For clarification on 3GPP commands, please refer to this document.

1.8 Supported character sets

The SIM7022 Series AT Command interface defaults to the **IRA** character set. The SIM7022 Series supports the following character sets:

- UCS2
- IRA

The character set affects transmission and reception of SMS and SMS Cell Broadcast messages, the entry and display of phone book entries text field and SIM Application Toolkit alpha strings.

1.9 Definitions

1.9.1 Parameter Saving Mode

For the purposes of the present document, the following syntactical definitions apply:

- **NO_SAVE**: The parameter of the current AT command will be lost if module is rebooted or current AT command doesn't have parameter.
- **AUTO_SAVE**: The parameter of the current AT command will be kept in NVRAM automatically and take in effect immediately, and it won't be lost if module is rebooted.
- **AUTO_SAVE_REBOOT**: The parameter of the current AT command will be kept in NVRAM automatically and take in effect after reboot, and it won't be lost if module is rebooted.
- -: "-" means this AT command doesn't care the parameter saving mode.

1.9.2 Max Response Time

Max response time is estimated maximum time to get response, the unit is seconds.

"-" means this AT command doesn't care the response time.

SIMCom
Confidential

2 AT Commands According to V.25TER

2.1 Overview of AT Commands According to V.25TER

Command	Description
ATE	Set Command Echo Mode.
ATI	Display Product Identification Information.

2.2 Detailed Description of AT Commands According to V.25TER

2.2.1 ATE Set Command Echo Mode

ATE Set Command Echo Mode	
Execution Command ATE<value>	Response This setting determines whether or not the TA echoes characters received from TE during Command state. OK
Parameter Saving Mode	NO_SAVE
Maximum Response Time	
Reference	V.25ter

Defined Values

<value>	0 Echo mode off
	1 Echo mode on

Example

ATE0

OK
(ATE1)
OK
AT
OK

2.2.2 ATi Display Product Identification Information

ATiDisplay Product Identification Information	
Execution Command ATi	Response TA issues product information text. Example: SIM7022 R2110
	OK
Parameter Saving Mode	NO_SAVE
Maximum Response Time	-
Reference	V.25ter

Example

ATi
SIM7022 R2110

OK

3 AT Commands According to 3GPP TS 27.007

3.1 Overview of AT Command According to 3GPP TS 27.007

Command	Description
AT+CGMI	Request Manufacturer Identification
AT+CGMM	Request Model Identification
AT+CGMR	Request TA Revision Identification of Software Release
AT+CGSN	Request Product Serial Number Identification
AT+CREG	Network Registration
AT+CEREG	EPS Network Registration Status
AT+CSCON	Signalling connection status
AT+CSQ	Signal Quality Report
AT+CESQ	Get Extended Signal Quality
AT+CGPADDR	Show PDP Address
AT+COPS	Operator Selection
AT+CGATT	Attach or Detach from GPRS Service
AT+CGACT	PDP Context Activate or Deactivate
AT+CIMI	Request International Mobile Subscriber Identity
AT+CGDCONT	Define PDP Context
AT+CFUN	Set Phone Functionality
AT+CMEE	Report Mobile Equipment Error
AT+CCLK	Return current date & time
AT+CPSMS	Power Saving Mode Setting
AT+CEDRXS	Extended-DRX Setting
AT+CEER	Extended Error Report
AT+CEDRXRDP	eDRX Read Dynamic Parameters
AT+CTZR	Time Zone Reporting
AT+CTZU	Automatic Time Zone Update
AT+CIPCA	Initial PDP context activation
AT+CGAPNRC	APN rate control
AT+CSODCP	Sending of originating data via the control plane
AT+CRTDCP	Reporting of terminating data via the control plane
AT+CGEREP	Packet Domain Event Reporting
+CGEV	Indicate EPS PDN Connection and Bearer Resources Operations Status
AT+CGCONTRDP	PDP Context Read Dynamic Parameters

AT+CGAUTH	Define PDP Context Authentication Parameters
AT+CPIN	Enter PIN
AT+CLCK	Facility Lock
AT+CMOLR	Mobile Originated Location Request
AT+CPWD	Change Password
AT+CPINR	Remaining PIN Retries
AT+CCHO	Open Logical Channel
AT+CCHC	Close logical channel
AT+CGLA	Generic UICC Logical Channel Access
AT+CMTLR	Mobile Terminated Location Request Notification
AT+CMTLRA	Mobile Terminated Location Request Disclosure Allowance
AT+CRCES	Reading Coverage Enhancement Status
AT+CRSM	Restricted SIM Access
AT+CSIM	Generic SIM Access
AT+CGDATA	Enter Data State
AT+CCIOPT	CloT optimization configuration
AT+CGCMOD	PDP context modify
AT+CGEQOS	Define EPS quality of service
AT+CGEQOSRDP	EPS Quality of Service Read Dynamic Parameters
AT+CGTFT	Traffic flow template
AT+IPR	Set UE Baud Rate

3.2 Detailed Descriptions of AT Command According to 3GPP TS 27.007

3.2.1 AT+CGMI Request Manufacturer Identification

AT+CGMI Request Manufacturer Identification	
Test Command AT+CGMI=?	Response +CGMI: <manufacturer_ID>
	OK
Execution Command AT+CGMI	Response <manufacturer>
	OK or +CMEERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	3GPP TS 27.007 [13]

Defined Values

<manufacturer_ID>	<p>The ID of manufacturer</p> <p>the total number of characters, including line terminators, in the information text shall not exceed 2048 characters.</p> <p>Text shall not contain the sequence 0<CR> or OK<CR></p>
--------------------------------	---

3.2.2 AT+CGMM Request Model Identification

AT+CGMM Request Model Identification	
<p>Test Command</p> <p>AT+CGMM=?</p>	<p>Response</p> <p>+CGMM:<list of supported technologies>,<model></p> <p>OK</p>
<p>Execution Command</p> <p>AT+CGMM</p>	<p>Response</p> <p><model></p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CMEERROR: <err></p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	3GPP TS 27.007 [13]

Defined Values

<model>	<p>Product model identification text the total number of characters, including line terminators, in the information text shall not exceed 2048 characters.</p> <p>Text shall not contain the sequence 0<CR> or OK<CR></p>
----------------------	---

3.2.3 AT+CGMR Request TA Revision Identification of Software Release

AT+CGMR Request TA Revision Identification of Software Release	
<p>Test Command</p> <p>AT+CGMR=?</p>	<p>Response</p> <p>OK</p>
<p>Execution Command</p> <p>AT+CGMR</p>	<p>Response</p> <p>This command returns the manufacturer revision. The text is human readable and is not intended for microcontroller parsing.</p> <p>By default this will return the firmware revision – release and build.</p>

	<revision>
	OK
	If error is related to ME functionality: +CMEERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	
3GPP TS 27.007 [13]	

Defined Values

<revision>	Product software version identification text. The total number of characters, including line terminators, in the information text shall not exceed 2048 characters. Text shall not contain the sequence 0<CR> or OK<CR>
------------	---

NOTE

<revision> will change format over time. It should be treated as an opaque identifier.
SECURITY PROTOCOL and APPLICATION is the core version and will update with the firmware version.
RADIO is the specific module calibration parameter, if the module has been calibrated during the production line then we'd better not to change it during the next operation.
SSB second stage bootloader version.

3.2.4 AT+CGSN Request Product Serial Number Identification

AT+CGSN Request Product Serial Number Identification (Identical with +GSN)

Test Command AT+CGSN=?	Response when TE supports <snt> and command successful: +CGSN: (list of supported <snt>s)
Execution Command AT+CGSN[=<snt>]	OK Response when <snt>=0 (or omitted) and command successful: [+CGSN:]<sn> when <snt>=1 and command successful: +CGSN: <imei> when <snt>=2 and command successful: +CGSN: <imeisv>

	when <snt>=3 and command successful: +CGSN: <svn> or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	
3GPP TS 27.007 [13]	

Defined Values

<snt>	Integer type indicating the serial number type that has been requested. 0 returns <sn> 1 returns the IMEI (International Mobile station Equipment Identity) 2 returns the IMEISV (International Mobile station Equipment Identity and Software Version number) 3 returns the SVN (Software Version Number)
<sn>	The 128-bit UUID of the UE. The total number of characters, including line terminators, in the information text shall not exceed 2048 characters. Text shall not contain the sequence 0<CR> or OK<CR>
<imei>	string type in decimal format indicating the IMEI
<imeisv>	string type in decimal format indicating the IMEISV
<svn>	string type in decimal format indicating the current SVN which is a part of IMEISV;

3.2.5 AT+CREG Network Registration

AT+CREG Network Registration	
Test Command AT+CREG=?	Response +CREG: (list of supported <n>s) OK
Read Command AT+CREG?	Response +CREG: <n>,<stat>[,<tac>],[<ci>],[<AcT>],[<cause_type>,<reject_cause>]] OK
Write Command AT+CREG=[<n>]	Response OK or ERROR

Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<n>	integer type 0 disable network registration unsolicited result code 1 enable network registration unsolicited result code +CEREG: <stat> 2 enable network registration and location information unsolicited resultcode +CEREG: <stat>[,<tac>],[<ci>],[<AcT>]] 3 enable network registration, location information and EMM cause value information unsolicitedresultcode +CEREG: <stat>[,<tac>],[<ci>],[<AcT>],[<cause_type>,<reject_cause>]]
<stat>	Integer type; indicates the EPS registration status 0 not registered, MT is not currently searching for an operator to register to 1 registered, home network 2 not registered, but MT is currently trying to attach or searching for an operator to register to 3 registration denied 4 unknown (e.g. out of E-UTRAN coverage) 5 registered, roaming 6 registered for "SMS only", home network (not applicable) 7 registered for "SMS only", roaming (not applicable) 8 attached for emergency bearer services only 9 registered for "CSFB not preferred", home network (not applicable) 10 registered for "CSFB not preferred", roaming (not applicable)
<tac>	string type; two byte tracking area code in hexadecimal format (e.g. "00C3" equals 195 in decimal)
<ci>	string type; four byte E-UTRAN cell ID in hexadecimal format
<AcT>	integer type; indicates the access technology of the serving cell 0 GSM (not applicable) 1 GSM Compact (not applicable) 2 UTRAN (not applicable) 3 GSM w/EGPRS (not applicable) 4 UTRAN w/HSDPA (not applicable) 5 UTRAN w/HSUPA (not applicable) 6 UTRAN w/HSDPA and HSUPA (not applicable) 7 E-UTRAN 8 EC-GSM-IoT (A/Gb mode) (see NOTE 5) (not applicable)

	9 E-UTRAN (NB-S1 mode) (see NOTE 6)
<cause_type>	Integer type; indicates the type of <reject_cause>. 0 Indicates that <reject_cause> contains an EMM cause value 1 Indicates that <reject_cause> contains a manufacturer-specific cause.
<reject_cause>	Integer type; contains the cause of the failed registration. The value is of type as defined by <cause_type>.

NOTE

Set of <n> will save to NVM, and the default value is 0.

3.2.6 AT+CEREG EPS Network Registration Status

AT+CEREG EPS Network Registration Status	
Test Command AT+CEREG=?	Response +CEREG: (list of supported <n>s) OK
Read Command AT+CEREG?	Response when <n>=0, 1, 2 or 3 and command successful: +CEREG: <n>,<stat>[,<[<tac>],<[<ci>],<[<AcT>],<[<cause_type>],<[<reject_cause>]]] when <n>=4 or 5 and command successful: +CEREG: <n>,<stat>[,<[<lac>],<[<ci>],<[<AcT>],<[<rac>],<[<cause_type>],<[<reject_cause>],<[<Active- Time>],<[<Periodic-TAU>]]] If error is related to wrong AT syntax or operation not allowed: +CME ERROR: <err>
Write Command AT+CEREG=<n>	Response OK or ERROR
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<n>	<p>integer type</p> <p>0 disable network registration unsolicited result code</p> <p>1 enable network registration unsolicited result code +CEREG: <stat></p> <p>2 enable network registration and location information unsolicited resultcode</p> <p>+CEREG: <stat>[,<tac>],[<ci>],[<AcT>]]</p> <p>3 enable network registration, location information and EMM cause value information unsolicitedresultcode</p> <p>+CEREG:</p> <p><stat>[,<tac>],[<ci>],[<AcT>],[<cause_type>,<reject_cause>]]</p> <p>4 For a UE that wants to apply PSM, enable network registration and location information unsolicited resultcode</p> <p>+CEREG:</p> <p><stat>[,<tac>],[<ci>],[<AcT>][,<Active-Time>],[<Periodic-TAU>]]]]</p> <p>5 For a UE that wants to apply PSM, enable network registration, location information and EMM cause value information unsolicited resultcode</p> <p>+CEREG:</p> <p><stat>[,<tac>],[<ci>],[<AcT>],[<cause_type>],[<reject_cause>],[<Active-Time>],[<Periodic-TAU>]]]]</p>
<stat>	<p>Integer type; indicates the EPS registration status</p> <p>0 not registered, MT is not currently searching for an operator to register to</p> <p>1 registered, home network</p> <p>2 not registered, but MT is currently trying to attach or searching for an operator to register to</p> <p>3 registration denied</p> <p>4 unknown (e.g. out of E-UTRAN coverage)</p> <p>5 registered, roaming</p> <p>6 registered for "SMS only", home network (not applicable)</p> <p>7 registered for "SMS only", roaming (not applicable)</p> <p>8 attached for emergency bearer services only</p> <p>9 registered for "CSFB not preferred", home network (not applicable)</p> <p>10 registered for "CSFB not preferred", roaming (not applicable)</p>
<tac>	<p>string type; two byte tracking area code in hexadecimal format (e.g. "00C3" equals 195 in decimal)</p>
<ci>	<p>string type; four byte E-UTRAN cell ID in hexadecimal format</p>
<AcT>	<p>integer type; indicates the access technology of the serving cell</p> <p>0 GSM (not applicable)</p> <p>1 GSM Compact (not applicable)</p> <p>2 UTRAN (not applicable)</p> <p>3 GSM w/EGPRS (not applicable)</p> <p>4 UTRAN w/HSDPA (not applicable)</p> <p>5 UTRAN w/HSUPA (not applicable)</p> <p>6 UTRAN w/HSDPA and HSUPA (not applicable)</p> <p>7 E-UTRAN</p> <p>8 EC-GSM-IoT (A/Gb mode) (see NOTE 5) (not applicable)</p>

	9 E-UTRAN (NB-S1 mode) (see NOTE 6)
<cause_type>	Integer type; indicates the type of <reject_cause>. 0 Indicates that <reject_cause> contains an EMM cause value 1 Indicates that <reject_cause> contains a manufacturer-specific cause.
<reject_cause>	Integer type; contains the cause of the failed registration. The value is of type as defined by <cause_type>.
<Active-Time>	String type; one byte in an 8 bit format. Indicates the Active Time value (T3324) allocated to the UE in E-UTRAN. The Active Time value is coded as one byte (octet 3) of the GPRS Timer 2 information element coded as bit format (e.g. "00100100" equals 4 minutes). For the coding and the value range, see the GPRS Timer 2 IE in 3GPP TS 24.008 Table 10.5.163/3GPP TS 24.008. See also 3GPP TS 23.682 and 3GPP TS 23.401
<Periodic-TAU>	String type; one byte in an 8 bit format. Indicates the extended periodic TAU value (T3412) allocated to the UE in E-UTRAN. The extended periodic TAU value is coded as one byte (octet 3) of the GPRS Timer 3 information element coded as bit format (e.g. "01000111" equals 70 hours). For the coding and the value range, see the GPRS Timer 3 IE in 3GPP TS 24.008 Table 10.5.163a/3GPP TS 24.008. See also 3GPP TS 23.682 and 3GPP TS 23.401

NOTE

- NOTE 1: If the EPS MT in GERAN/UTRAN/E-UTRAN also supports circuit mode services and/or GPRS services, the +CREG command and +CREG: result codes and/or the +CGREG command and +CGREG: result codes apply to the registration status and location information for those services.
- NOTE 2: 3GPP TS 24.008 and 3GPP TS 24.301 specify the condition when the MS is considered as attached for emergency bearer services.
- NOTE 3: 3GPP TS 44.060 specifies the System Information messages which give the information about whether the serving cell supports EGPRS.
- NOTE 4: 3GPP TS 25.331 specifies the System Information blocks which give the information about whether the serving cell supports HSDPA or HSUPA.
- NOTE 5: 3GPP TS 44.018 [156] specifies the EC-SCH INFORMATION message which, if present, indicates that the serving cell supports EC-GSM-IoT.
- NOTE 6: 3GPP TS 36.331 [86] specifies the System Information blocks which give the information about whether the serving cell supports NB-IoT, which corresponds to E-UTRAN (NB-S1 mode).

3.2.7 AT+CSCON Signalling Connection Status

AT+CSCON Signalling Connection Status

Test Command	Response
AT+CSCON=?	+CSCON: (list of supported<n>s)

Read Command AT+CSCON?	OK
	Response +CSCON: <n>,<mode>[,<state>]
Write Command AT+CSCON=<n>	OK
	Response Sets which character set <n> are used by the TE. The TA can then convert character strings correctly between the TE and ME character sets.
	OK If error is related to ME functionality: +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	3GPP TS 27.007 [13]

Defined Values

<n>	Integer type
	0 disable unsolicited result code 1 enable unsolicited result code +CSCON: <mode>
<mode>	Integer type; indicates the signalling connection status
	0 idle 1 connected 2-255 <reserved for future use>
<state>	Integer type; indicates the CS or PS state while in GERAN and the RRC state information if the MT is in connected Mode while in UTRAN and E-UTRAN.
	0 UTRAN URA_PCH state
	1 UTRAN Cell_PCH state
	2 UTRAN Cell_FACH state
	3 UTRAN Cell_DCH state
	4 GERAN CS connected state
	5 GERAN PS connected state
	6 GERAN CS and PS connected state
<access>	7 E-UTRAN connected state
	Integer type; indicates the current radio access type.
	0 Indicates usage of radio access of type GERAN
	1 Indicates usage of radio access of type UTRAN TDD
	2 Indicates usage of radio access of type UTRAN FDD
	3 Indicates usage of radio access of type E-UTRAN TDD
	4 Indicates usage of radio access of type E-UTRAN FDD

3.2.8 AT+CSQ Signal Quality Report

AT+CSQ Signal Quality Report	
Test Command AT+CSQ=?	Response +CSQ: (list of supported <rss>s),(list of supported <ber>s)
	OK
Execution Command AT+CSQ	Response Execution command returns received signal strength indication <rss> and channel bit error rate <ber> from the MT. +CSQ: <rss>,<ber>
	OK If error is related to ME functionality: +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	3GPP TS 27.007 [13]

Defined Values

<rss>	0	- 113 dBm or less
	1	- 111 dBm
	2...30	- 109... - 53 dBm
	31	- 51 dBm or greater
	99	not known or not detectable
<ber>	integer type; channel bit error rate (in percent)	
	0...7	as RXQUAL values (refer to 3GPP specification)
	99	Not known or not detectable

3.2.9 AT+CESQ Get Extended Signal Quality

AT+CESQ Get Extended Signal Quality	
Test Command AT+CESQ=?	Response +CESQ: (list of supported <rxlev>s),(list of supported <ber>s, list of supported <rscp>s),(list of supported <ecno>s,(list of supported <rsrq>s),(list of supported <rsrp>s)
	OK
Execution Command AT+CESQ	Response +CESQ:

	<rxlev>,<ber>,<rscp>,<ecno>,<rsrq>,<rsrp>
	OK If error is related to ME functionality: +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<rxlev>	Integer type; not supported by NB-IoT 99 not known or not detectable
<ber>	Integer type; not supported by NB-IoT 99 not known or not detectable
<rscp>	Integer type; not supported by NB-IoT 255 not known or not detectable
<ecno>	Integer type; not supported by NB-IoT 255 not known or not detectable
<rsrq>	0 rsrq<-19.5dB 1 -19.5dB<=rsrq<-19dB 2 -19dB<=rsrq<-18.5dB ::: 32 -4dB<=rsrq<-3.5dB 33 -3.5dB<=-3 dB 34 -3 dB <=rsrq 255 not known or not detectable
<rsrp>	0 rsrp<-149dBm 1 -140dBm<=rsrp<-139dBm 2 -139dBm<=rsrp<-138dBm ::: 95 -46dBm<=rsrp<-45dBm 96 -45dBm<=rsrp<-44dBm 97 -44dBm<=rsrp 255 not known or not detectable

3.2.10 AT+CGPADDR Show PDP Address

AT+CGPADDR Show PDP Address	
Test Command AT+CGPADDR=?	Response +CGPADDR: (list of defined<cid>s)

Write Command AT+CGPADDR[=<cid>[,<cid>[,...]]]	OK or OK
	Response +CGPADDR: <cid>[,<PDP_addr>][<CR><LF>+CGPADDR: <cid>[,<PDP_addr>][...]]
	[+CGPADDR: <cid>[,<PDP_addr_1>,<PDP_addr_2>]]][<CR><LF>+CGPADDR: <cid>[,<PDP_addr_1>[,<PDP_addr_2>]] [...]]
	OK or OK or ERROR
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<cid>	A numeric parameter which specifies a particular PDP context definition (see +CGDCONT command). If no <cid> is specified, the addresses for all defined contexts are returned.
<PDP_addr>	A string that identifies the MT in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it will be the one set by the +CGDCONT command when the context was defined. For a dynamic address, it will be the one assigned during the last PDP context activation that used the context definition referred to by <cid>. <PDP_address> is omitted if none is available.
<cid>	Integer type; specifies a particular PDP context definition (see the +CGDCONT command).
<PDP_addr_1> and <PDP_addr_2>	Each is a string type that identifies the MT in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it will be the one set by the +CGDCONT command when the context was defined. For a dynamic address it will be the one assigned during the last PDP context activation that used the context definition referred to by <cid>. Both <PDP_addr_1> and <PDP_addr_2> are omitted if none is available. Both <PDP_addr_1> and <PDP_addr_2> are included when both IPv4 and IPv6 addresses are assigned, with <PDP_addr_1> containing the IPv4 address and <PDP_addr_2> containing the IPv6 address.

The string is given as dot-separated numeric (0-255) parameter of the form:
a1.a2.a3.a4 for IPv4 and
a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16 for IPv6.
When +CGPIAF is supported, its settings can influence the format of the IPv6 address in parameter <PDP_addr_1> or <PDP_addr_2> returned with the execute form of +CGPADDR.

NOTE

In dual-stack terminals (<PDP_type> IPV4V6), the IPv6 address will be provided in<PDP_addr_2>. For terminals with a single IPv6 stack (<PDP_type> IPv6) or due to backwardscompatibility, the IPv6 address can be provided in parameter <PDP_addr_1>.

3.2.11 AT+COPS Operator Selection

AT+COPS Operator Selection

<p>Test Command</p> <p>AT+COPS=?</p>	<p>Response</p> <p>TA returns a list of quadruplets, each representing an operator present in the network. Any of the formats may be unavailable and should then be an empty field. The list of operators shall be in order: home network, networks referenced in SIM, and other networks.</p> <p>+COPS: (list of supported<stat>,long alphanumeric<oper>,short alphanumeric<oper>,numeric <oper>,<Act>)s[,,(list of supported <mode>s),(list of supported <format>s)]</p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>
<p>Read Command</p> <p>AT+COPS?</p>	<p>Response</p> <p>TA returns the current mode and the currently selected operator. If no operator is selected, <format> and <oper> are omitted.</p> <p>+COPS: <mode>[,<format>,<oper>][,<Act>]</p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>
<p>Write Command</p> <p>AT+COPS=<mode>[,<format>[,<oper>[,<Act>]]]</p>	<p>Response</p> <p>TA forces an attempt to select and register the GSM network operator. If the selected operator is not available, no other operator shall be selected (except <mode>=4). The selected operator name format shall apply to further read commands (AT+COPS?).</p>

	OK If error is related to ME functionality: +CME ERROR: <err>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	Test command: 45 seconds Write command: 120 seconds
Reference	
3GPP TS 27.007 [14]	

Defined Values

<stat>	Integer type 0 Unknown 1 Operator available 2 Operator current 3 Operator forbidden
<oper>	String type; <format> indicates if the format is alphanumeric or numeric; long alphanumeric format can be upto 16 characters long and short format up to 8 characters; numeric format is the GSM Location Area Identification number which consists of a three BCD digit ITU-T country code coded, plus a two or three BCD digit network code, which is administration specific.
<mode>	Integer type 0 Automatic mode; <oper> field is ignored 1 Manual(<oper>field shall be present, and <Act> optionally) 2 Manual deregister from network 3 Set only <format> (for read Command +COPS?) - not shown in Read Command response 4 Manual/automatic(<oper>field shall be present); if manual selection fails, automatic mode (<mode>=0) is entered
<format>	Integer type 0 Long format alphanumeric <oper> 1 Short format alphanumeric <oper> 2 Numeric <oper>
<Act>	Integer type; access technology selected 0 GSM 1 GSM Compact 2 UTRAN 3 GSM w/EGPRS (see NOTE 1) 4 UTRAN w/HSDPA (see NOTE 2) 5 UTRAN w/HSUPA (see NOTE 2) 6 UTRAN w/HSDPA and HSUPA (see NOTE 2) 7 E-UTRAN

- | | |
|---|-------------------------------------|
| 8 | EC-GSM-IoT (A/Gb mode) (see NOTE 3) |
| 9 | E-UTRAN (NB-S1 mode) (see NOTE 4) |

NOTE

NOTE 1: 3GPP TS 44.060 specifies the System Information messages which give the information about whether the serving cell supports EGPRS.

NOTE 2: 3GPP TS 25.331 specifies the System Information blocks which give the information about whether the serving cell supports HSDPA or HSUPA.

NOTE 3: 3GPP TS 44.018 [156] specifies the EC-SCH INFORMATION message which, if present, indicates that the serving cell supports EC-GSM-IoT.

NOTE 4: 3GPP TS 36.331 [86] specifies the System Information blocks which give the information about whether the serving cell supports NB-IoT, which corresponds to E-UTRAN(NB-S1 mode).

- <Act>, if provided, must be set to 9
- Only <format>=2 is supported
- Only <mode>=0, <mode>=1 & <mode>=2 are supported
When <mode>=1 is used, the PLMN setting will not persist after the UE is rebooted
<mode>=1 is only for development use. <mode>=0 should be used in production, which the mode used when AUTOCONNECT is enabled.
- The test command currently returns the configured values rather than performing a PLMN search.
- Not return <ACT> for AT+COPS?
- <oper> field couldn't be present when <mode>=0;
- AT+COPS=? will start background PLMN search when MT is idle state and wait searching result, other state will return ERROR.
- Return the searched PLMN list in the network after searching.
And could be aborted by any characters when searching. See Chapter 9 for more details about abort.

3.2.12 AT+CGATT Attach or Detach from GPRS Service

AT+CGATT Attach or Detach from GPRS Service

Description

The execution command is used to attach the MT to, or detach the MT from, the Packet Domain service. After the command has completed, the MT remains in V.250 command state. If the MT is already in the requested state, the command is ignored and the OK response is returned. If the requested state cannot be achieved, an ERROR or +CME ERROR response is returned. Refer to Chapter 9: Error Values for possible <err> values.

NOTE 1: If the initial PDP context is supported, the context with <cid>=0 is automatically defined at startup.

	<p>Any active PDP contexts will be automatically deactivated when the attachment state changes to detached.</p> <p>The read command returns the current Packet Domain service state.</p> <p>The test command is used for requesting information on the supported Packet Domain service states.</p> <p>NOTE 2: This command has the characteristics of both the V.250 action and parameter commands.</p> <p>Hence it has the read form in addition to the execution/set and test forms.</p>
Test Command AT+CGATT=?	Response +CGATT: (list of supported <state>s) OK
Read Command AT+CGATT?	Response +CGATT: <state> OK
Write Command AT+CGATT=<state>	Response OK If error is related to ME functionality: +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	75 seconds
Reference	

Defined Values

<state>	<p>Integer type; indicates the state of PDP context activation. The default value is manufacturer specific</p> <p>0 Detached</p> <p>1 Attached</p> <p>Other values are reserved and will result in an ERROR response to the Write Command.</p>
---------	--

NOTE

- When <state>=1 is selected, +COPS=0 is automatically selected.
- If a CGATT is in progress, further execution of the CGATT=command prior to the attach or detach completing will return error.

3.2.13 AT+CGACT PDP Context Activate or Deactivate

AT+CGACT PDP Context Activate or Deactivate

<p>Description</p>	<p>The execution command is used to activate or deactivate the specified PDP context (s). After the command has completed, the MT remains in V.250 command state. If any PDP context is already in the requested state, the state for that context remains unchanged. If the requested state for any specified context cannot be achieved, an ERROR or +CME ERROR response is returned. Extended error responses are enabled by the +CMEE command. If the MT is not PS attached when the activation form of the command is executed, the MT first performs a PS attach and then attempts to activate the specified contexts. If the attach fails then the MT responds with ERROR or, if extended error responses are enabled, with the appropriate failure-to-attach error message. Refer to Chapter 9: Error Values for possible <err> values.</p> <p>For EPS, if an attempt is made to disconnect the last PDN connection, then the MT responds with ERROR or, if extended error responses are enabled, a +CME ERROR.</p> <p>NOTE: If the initial PDP context is supported, the context with <cid>=0 is automatically defined at startup, see subclause 10.1.0.</p> <p>For EPS, the activation request for an EPS bearer resource will be answered by the network by either an EPS dedicated bearer activation or EPS bearer modification request. The request must be accepted by the MT before the PDP context can be set in to established state.</p> <p>If no <cid>s are specified the activation form of the command activates all defined non-emergency contexts.</p> <p>If no <cid>s are specified the deactivation form of the command deactivates all active contexts.</p> <p>The read command returns the current activation states for all the defined PDP contexts.</p> <p>The test command is used for requesting information on the supported PDP context activation states.</p> <p>NOTE. This command has the characteristics of both the V.250 action and parameter commands.</p> <p>Hence it has the read form in addition to the execution/set and test forms.</p>
<p>Test Command AT+CGACT=?</p>	<p>Response +CGACT: (list of supported <state>s)</p> <p>OK</p>
<p>Read Command AT+CGACT?</p>	<p>Response +CGACT: <cid>,<state>[<CR><LF>+CGACT: <cid>,<state>...]</p> <p>OK</p>

Write Command AT+CGACT=<state>[,<cid>]	Response OK If error is related to ME functionality: +CME ERROR:<err>
Parameter Saving Mode	NO_SAVE
Max Response Time	150 seconds
Reference	

Defined Values

<state>	Indicates the state of PDP context activation 0 Deactivated 1 Activated Other values are reserved and will result in an ERROR response to the Write Command.
<cid>	A numeric parameter which specifies a particular PDP context definition (see +CGDCONT Command). If the <cid> is omitted, it only affects the first cid.

NOTE

- Could only activate or deactivate one cid one time.
- Could not be executed when PLMN searching, attaching or detaching.
- Could disconnect the last PDN connection when MT and Core Network all support without PDN connection.

3.2.14 AT+CIMI Request International Mobile Subscriber Identity

AT+CIMI Request International Mobile Subscriber Identity	
Description	Execution command causes the TA to return <IMSI>, which is intended to permit the TE to identify the individual SIM card or active application in the UICC (GSM or USIM) which is attached to MT.
Test Command AT+CIMI=?	Response OK
Execution Command AT+CIMI	Response TA returns <IMSI> for identifying the individual SIM which is attached to ME. <IMSI> OK If error is related to ME functionality: +CME ERROR: <err>

Parameter Saving Mode	NO_SAVE
Max Response Time	20s
Reference	
3GPP TS 27.007 [13]	

Defined Values

<IMSI>	International Mobile Subscriber Identity (string without double quotes)
--------	---

NOTE

IMSI may not be displayed for a few seconds after power-on

3.2.15 AT+CGDCONT Define PDP Context

AT+CGDCONT Define PDP Context

Description

The set command specifies PDP context parameter values for a PDP context identified by the (local) context identification parameter, <cid> and also allows the TE to specify whether security protected transmission of ESM information is requested, because the PCO can include information that requires ciphering. There can be other reasons for the UE to use security protected transmission of ESM information, e.g. if the UE needs to transfer an APN. The number of PDP contexts that may be in a defined state at the same time is given by the range returned by the test command. Refer to Chapter 9: Error Values for possible <err> values.

For EPS the PDN connection and its associated EPS default bearer is identified herewith.

A special form of the set command, +CGDCONT=<cid> causes the values for context number <cid> to become undefined.

If the initial PDP context is supported, the context with <cid>=0 is automatically defined at startup, see 3GPP TS 27.007 V13.5.0, subclause 10.1.0. As all other contexts, the parameters for <cid>=0 can be modified with +CGDCONT. If the initial PDP context is supported, +CGDCONT=0 resets context number 0 to its particular default settings.

The read command returns the current settings for each defined context.

The test command returns values supported as compound values. If the MT

	supports several PDP types, <PDP_type>, the parameter value ranges for each <PDP_type> are returned on a separate line.
Test Command AT+CGDCONT=?	<p>Response</p> <p>+CGDCONT: (range of supported<cid>s),<PDP_type>,,,(list of supported<d_comp>s),(list of supported<h_comp>s),(list of supported<IPv4AddrAlloc>s),(list of supported<request_type>s),(list of supported<PCSCF_discovery>s),(list of supported<IM_CN_Signalling_Flag_Ind>s),(list of supported<NSLPI>s),(list of supported<securePCO>s),(list of supported<IPv4_MTU_discovery>s),(list of supported<Local_Addr_Ind>s),(list of supported<NonIP_MTU_discovery>s),(list of supported<Reliable_Data_Service>s)[<CR><LF>+CGDCONT: (range of supported<cid>s),<PDP_type>,,,(list of supported<d_comp>s),(list of supported<h_comp>s),(list of supported<IPv4AddrAlloc>s),(list of supported<request_type>s),(list of supported<PCSCF_discovery>s),(list of supported<IM_CN_Signalling_Flag_Ind>s),(list of supported<NSLPI>s),(list of supported<securePCO>s),(list of supported<IPv4_MTU_discovery>s),(list of supported<Local_Addr_Ind>s),(list of supported<NonIP_MTU_discovery>s),(list of supported<Reliable_Data_Service>s)[...]]</p> <p>OK</p>
Read Command AT+CGDCONT?	<p>Response</p> <p>[+CGDCONT: <cid>,<PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp>[,<IPv4AddrAlloc>[,<request_type>[,<PCSCF_discovery>[,<IM_CN_Signalling_Flag_Ind>[,<NSLPI>[,<securePCO>[,<IPv4_MTU_discovery>[,<Local_Addr_Ind>[,<Non-IP_MTU_discovery>[,<Reliable_Data_Service>]]]]]]]]]]]]][<CR><LF>+CGDCONT: <cid>,<PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp>[,<IPv4AddrAlloc>[,<request_type>[,<PCSCF_discovery>[,<IM_CN_Signalling_Flag_Ind>[,<NSLPI>[,<securePCO>[,<IPv4_MTU_discovery>[,<Local_Addr_Ind>[,<Non-IP_MTU_discovery>[,<Reliable_Data_Service>]]]]]]]]]]] [...]]</p> <p>OK</p>
Write Command AT+CGDCONT=[<cid>[,<PDP_type>[,<APN>[,<PDP_addr>[,<d_comp>[,<h_comp>[,<IPv4AddrAlloc>[,<request_type>[,<PCSCF_discovery>[<p>Response</p> <p>OK or ERROR</p>


```
<IM_CN_Signalling_Flag_Ind>[,<NSLPI>[,<securePCO>[,<IPv4_MTU_discovery>][,<Local_Addr_Ind>][,<Non-IP_MTU_discovery>][,<Reliable_Data_Service>]]  
)))))))))
```

Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	

Defined Values

<cid>	Integer type; specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands. The range of permitted values is returned by the test form of the command. <cid> values of 0-10 are supported.
<PDP_type>	String type; specifies the type of packet data protocol. The default value is manufacturer specific. X.25 ITU-T/CCITT X.25 layer 3 (Obsolete) IP Internet Protocol (IETF STD 5 [103]) IPV6 Internet Protocol, version 6 IPV4V6 Virtual<PDP_type> introduced to handle dual IP stack UE capability. OSPIH Internet Hosted Octect Stream Protocol (Obsolete) PPP Point to Point Protocol (IETF STD 51 [104]) NOTE 2: Only IP, IPV6 and IPV4V6 values are supported for EPS services. NONIP None Ip
<APN>	String type; a logical name that is used to select the GGSN or the external packet data network. If the value is null or omitted, then the subscription value will be requested.
<PDP_addr>	String type; identifies the MT in the address space applicable to the PDP. This parameter can be left blank. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the read form of +CGDCONT. NOTE 3: The value of this parameter is ignored with the set command. The parameter is included in the set command for backwards compatibility reasons only.
<d_comp>	Integer type; controls PDP data compression 0 off 1 on (manufacturer preferred compression) 2 V.42bis 3 V.44
<h_comp>	Integer type; controls PDP header compression 0 off

	<p>1 on (manufacturer preferred compression)</p> <p>2 RFC 1144 [105] (applicable for SND CP only)</p> <p>3 RFC 2507 [107]</p> <p>4 RFC 3095 [108] (applicable for PDCP only)</p>
<IPv4AddrAlloc>	<p>Integer type; controls how the MT/TA requests to get the IPv4 address information</p> <p>0 IPv4 address allocation through NAS signalling</p> <p>1 IPv4 address allocated through DHCP</p>
<request_type>	<p>Integer type; indicates the type of PDP context activation request for the PDP context, see 3GPP TS 24.301 (subclause 6.5.1.2) and 3GPP TS 24.008 subclause 10.5.6.17). If the initial PDP context is supported it is not allowed to assign <cid>=0 for emergency bearer services. According to 3GPP TS 24.008 (subclause 4.2.4.2.2 and subclause 4.2.5.1.4) and 3GPP TS 24.301 (subclause 5.2.2.3.3 and subclause 5.2.3.2.2), a separate PDP context must be established for emergency bearerservices.</p> <p>NOTE 4: If the PDP context for emergency bearer services is the only activated context, only emergency calls are allowed, see 3GPP TS 23.401 subclause 4.3.12.9.</p> <p>0 PDP context is for new PDP context establishment or for handover from a non-3GPP access network (how the MT decides whether the PDP context is for new PDP context establishment or for handover is implementation specific)</p> <p>1 PDP context is for emergency bearer services</p> <p>2 PDP context is for new PDP context establishment</p> <p>3 PDP context is for handover from a non-3GPP access network</p>
<P-CSCF_discovery>	<p>Integer type; influences how the MT/TA requests to get the P-CSCF address, see 3GPP TS 24.229 [89] annex B and annex L.</p> <p>0 Preference of P-CSCF address discovery not influenced by +CGDCONT</p> <p>1 Preference of P-CSCF address discovery through NAS signalling</p> <p>2 Preference of P-CSCF address discovery through DHCP</p>
<IM_CN_Signalling_Flag_Ind>	<p>Integer type; indicates to the network whether the PDP context is for IM CN subsystem-related signalling only or not.</p> <p>0 UE indicates that the PDP context is not for IM CN subsystem-related signalling only</p> <p>1 UE indicates that the PDP context is for IM CN subsystem-related signalling only</p>
<NSLPI>	<p>Integer type; indicates the NAS signalling priority requested for this PDP context:</p> <p>0 indicates that this PDP context is to be activated with the value for the low priority indicator configured in the MT.</p> <p>1 indicates that this PDP context is to be activated with the value for the low priority indicator set to "MS is not configured for NAS signalling low priority".</p> <p>3GPP TS 24.301 [83] and 3GPP TS 24.008 .</p>
<securePCO>	<p>Integer type. Specifies if security protected transmission of PCO is requested or not</p>

	(applicable for EPS only) 0 Security protected transmission of PCO is not requested 1 Security protected transmission of PCO is requested
<IPv4_MTU_discovery>	Integer type; influences how the MT/TA requests to get the IPv4 MTU size, see 3GPP TS 24.008 subclause 10.5.6.3. 0 Preference of IPv4 MTU size discovery not influenced by +CGDCONT 1 Preference of IPv4 MTU size discovery through NAS signalling
<Local_Addr_Ind>	Integer type; indicates to the network whether or not the MS supports local IP address in TFTs (see 3GPP TS 24.301 [83] and 3GPP TS 24.008 [8] subclause 10.5.6.3). 0 indicates that the MS does not support local IP address in TFTs 1 indicates that the MS supports local IP address in TFTs
<Non-IP_MTU_discovery>	Integer type; influences how the MT/TA requests to get the Non-IP MTU size, see 3GPP TS 24.008 [8] subclause 10.5.6.3. 0 Preference of Non-IP MTU size discovery not influenced by +CGDCONT 1 Preference of Non-IP MTU size discovery through NAS signalling
<Reliable_Data_Service>	Integer type; indicates whether the UE is using Reliable Data Service for a PDN connection or not, see 3GPP TS 24.301 [83] and 3GPP TS 24.008 [8] subclause 10.5.6.3. 0 Reliable Data Service is not being used for the PDN connection 1 Reliable Data Service is being used for the PDN connection

NOTE

- Only <PDP_type>="IP","NONIP","IPV6","IPV4V6" are supported.
- Only support +CGDCONT=<cid>,<PDP_type>,<APN>,,,,,,<NSLPI>,<securePCO>.
- <cid> values of 0-10 are supported
- Only <hcomp> and <dcomp> values of 0 are supported.
- <cid> value of 7 can't be set when bip is enabled.
- The APN is a string of up to 63 characters.

3.2.16 AT+CFUN Set Phone Functionality

AT+CFUN Set Phone Functionality	
Description	Set command selects the level of functionality in the MT. Level "full functionality" is where the highest level of power is drawn. "Minimum functionality" is where minimum power is drawn. Read command returns the current setting of <fun>. Test command returns values supported by the MT as compound values.
Test Command AT+CFUN=?	Response +CFUN: (list of supported <fun>s),(list of supported <rst>s)

	<p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>
<p>Read Command</p> <p>AT+CFUN?</p>	<p>Response</p> <p>+CFUN: <fun></p>
<p>Write Command</p> <p>AT+CFUN=<fun>[,<rst>]</p>	<p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR:<err></p>
Parameter Saving Mode	-
Max Response Time	10s
Reference	3GPP TS 27.007 [13]

Defined Values

<fun>	<p>Integer type</p> <p>0 Minimum functionality</p> <p>1 Full functionality</p> <p>4 Turn off RF</p>
<rst>	<p>Integer type</p> <p>0 Do not reset the MT before setting it to <fun> power level. This shall always be defaulted when <rst> is not given.</p> <p>1 Reset the MT before setting it to <fun> power level. (not supported and will be ignored)</p>

3.2.17 AT+CMEE Report Mobile Equipment Error

AT+CMEE Report Mobile Equipment Error

Description	<p>Set command disables or enables the use of final result code +CME ERROR: <err> as an indication of an error relating to the functionality of the MT. When enabled, MT related errors cause +CME ERROR: <err> final result code instead of the regular ERROR final result code. ERROR is returned normally when error is related to syntax, invalid parameters, or TA functionality.</p> <p>Read command returns the current setting of <n>.</p>
-------------	--

	Test command returns values supported as a compound value.
Test Command AT+CMEE=?	Response +CMEE: (list of supported <n>s) OK
Read Command AT+CMEE?	Response +CMEE: <n> OK
Write Command AT+CMEE=<n>	Response TA disables or enables the use of result code +CME ERROR: <err> as an indication of an error relating to the functionality of the ME. OK If error is related to ME functionality: +CME ERROR: <err>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	
3GPP TS 27.007 [13]	

Defined Values

<n>	integer type 0 Disable +CME ERROR: <err> result code and use ERROR instead. <u>1</u> Enable+CME ERROR:<err>result codeandusenumeric <err> 2 Enable +CME ERROR: <err> result code and use verbose <err> values
-----	--

3.2.18 AT+CCLK Return Current Date & Time

AT+CCLK Return CurrentDate&Time	
Test Command AT+CCLK=?	Response OK
Read Command AT+CCLK?	Response +CCLK: [<yy/MM/dd, hh:mm:ss>[<zz>]] OK If error is related to ME functionality: +CME ERROR: <err>
Write Command AT+CCLK=<time>	Response OK If error is related to ME functionality:

	+CME ERROR: <err>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	
3GPP TS 27.007 [13]	

Defined Values

<time>	String type value; format is "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone (indicates the difference, expressed in quarters of an hour, between the local time and GMT; range -96...+96). E.g. 6th of May 1994, 22:10:00 GMT+2 hours equals to "94/05/06,22:10:00+08"
---------------------	--

NOTE

- No value will be returned before core network sent EMM INFORMATION.
- Need to send AT+NITZ=0 first before set time.
- If MT does not support time zone information then the three last characters of <time> are not returned by +CCLK?

3.2.19 AT+CPSMS Power Saving Mode Setting

AT+CPSMS Power Saving Mode Setting

Description	<p>The set command controls the setting of the UEs power saving mode (PSM) parameters. The command controls whether the UE wants to apply PSM or not, as well as the requested extended periodic RAU value and the requested GPRS READY timer value in GERAN/UTRAN, the requested extended periodic TAU value in E-UTRAN and the requested Active Time value. See the unsolicited result codes provided by command +CEREG for the Active Time value and the extended periodic TAU value that are allocated to the UE by the network in E-UTRAN.</p> <p>A special form of the command can be given as +CPSMS=2. In this form, the use of PSM will be disabled and data for all parameters in the command +CPSMS will be removed or, if available, set to the manufacturer specific default values.</p> <p>The read command returns the current parameter values.</p> <p>The test command returns the supported <mode>s and the value ranges for</p>
-------------	--

	the requested extended periodic RAU value and the requested GPRS READY timer value in GERAN/UTRAN, the requested extended periodic TAU value in E-UTRAN and the requested Active Time value as compound values.
Test Command AT+CPSMS=?	Response +CPSMS: (list of supported <mode>s),(list of supported <Requested_Periodic-RAU>s),(list of supported <Requested_GPRS-READY-timer>s),(list of supported <Requested_Periodic-TAU>s),(list of supported <Requested_Active-Time>s) OK
Read Command AT+CPSMS?	Response +CPSMS: <mode>,[<Requested_Periodic-RAU>],[<Requested_GPRS-READY-timer>],[<Requested_Periodic-TAU>],[<Requested_Active-Time>] OK
Write Command AT+CPSMS=[<mode>[,<Requested_Periodic-RAU>[,<Requested_GPRS-READY-timer>[,<Requested_Periodic-TAU>[,<Requested_Active-Time>]]]]]	Response OK If failed: +CME ERROR: <err>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	Integer type. Indication to disable or enable the use of PSM in the UE. 0 Disable the use of PSM 1 Enable the use of PSM 2 Disable the use of PSM and discard all parameters for PSM or, if available, reset to the manufacturer specific default values.
<Requested_Periodic-RAU>	String type; one byte in an 8 bit format. Requested extended periodic RAU value (T3312) to be allocated to the UE in GERAN/UTRAN. The requested extended periodic RAU value is coded as one byte (octet 3) of the GPRS Timer 3 information element coded as bit format (e.g. "01000111" equals 70 hours). For the coding and the value range, see the GPRS Timer 3 IE in 3GPP TS 24.008 [8] Table 10.5.163a/3GPP TS 24.008. See also 3GPP TS 23.682 [149] and 3GPP TS 23.060 [47]. The default value, if available, is manufacturer specific.

<Requested_GPRS-READY-timer>	String type; one byte in an 8 bit format. Requested GPRS READY timer value (T3314) to be allocated to the UE in GERAN/UTRAN. The requested GPRS READY timer value is coded as one byte (octet 2) of the GPRS Timer information element coded as bit format (e.g. "01000011" equals 3 decihours or 18 minutes). For the coding and the value range, see the GPRS Timer IE in 3GPP TS 24.008 [8] Table 10.5.172/3GPP TS 24.008. See also 3GPP TS 23.060 [47]. The default value, if available, is manufacturer specific.
<Requested_Periodic-TAU>	String type; one byte in an 8 bit format. Requested extended periodic TAU value (T3412) to be allocated to the UE in E-UTRAN. The requested extended periodic TAU value is coded as one byte (octet 3) of the GPRS Timer 3 information element coded as bit format (e.g. "01000111" equals 70 hours). For the coding and the value range, see the GPRS Timer 3 IE in 3GPP TS 24.008 [8] Table 10.5.163a/3GPP TS 24.008. See also 3GPP TS 23.682 [149] and 3GPP TS 23.401 [82]. The default value, if available, is manufacturer specific.
<Requested_Active-Time>	String type; one byte in an 8 bit format. Requested Active Time value (T3324) to be allocated to the UE. The requested Active Time value is coded as one byte (octet 3) of the GPRS Timer 2 information element coded as bit format (e.g. "00100100" equals 4 minutes). For the coding and the value range, see the GPRS Timer 2 IE in 3GPP TS 24.008 [8] Table 10.5.163/3GPP TS 24.008. See also 3GPP TS 23.682 [149], 3GPP TS 23.060 [47] and 3GPP TS 23.401 [82]. The default value, if available, is manufacturer specific.

NOTE

- RAU is not supported by NB-IOT. No value will be output, and any input will be ignored.
- <Requested_Periodic-TAU> and <Requested_Active-Time> could be quoted.

3.2.20 AT+CEDRXS Extended-DRX Setting

AT+CEDRXS Extended-DRX Setting	
Description	<p>The set command controls the setting of the UEs eDRX parameters. The command controls whether the UE wants to apply eDRX or not, as well as the requested eDRX value for each specified type of access technology.</p> <p>The set command also controls the presentation of an unsolicited result code</p> <p>+CEDRXP:</p> <p><AcT-type>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]]</p> <p>when<n>=2 and there is a change in the eDRX parameters provided by the network.</p>

	<p>A special form of the command can be given as +CEDRXS=3. In this form, eDRX will be disabled and data for all parameters in the command +CEDRXS will be removed or, if available, set to the manufacturer specific default values.</p> <p>The read command returns the current settings for each defined value of <AcT-type>.</p> <p>The test command returns the supported <mode>s and the value ranges for the access technology and the requested eDRX value as compound values.</p>
<p>Test Command</p> <p>AT+CEDRXS=?</p>	<p>Response</p> <p>+CEDRXS: (list of supported <mode>s),(list of supported<AcT-type>s),(list of supported<Requested_eDRX_value>s)</p> <p>OK</p>
<p>Read Command</p> <p>AT+CEDRXS?</p>	<p>Response</p> <p>+CEDRXS:<AcT-type>,<Requested_eDRX_value></p> <p>OK</p>
<p>Write Command</p> <p>AT+CEDRXS=[<mode>],[,<AcT-type>],[<Requested_eDRX_value>]]</p>	<p>Response</p> <p>OK</p> <p>If failed:</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	<p>Integer type, indicates to disable or enable the use of eDRX in the UE. This parameter is applicable to all specified types of access technology, i.e. the most recent setting of <mode> will take effect for all specified values of <AcT>.</p> <p>0 Disable the use of eDRX</p> <p>1 Enable the use of eDRX</p> <p>2 Enable the use of eDRX and enable the unsolicited result code +CEDRXP:<AcT-type>,<Requested_eDRX_value>,<NW-provided_eDRX_value>,<Paging_time_window>]]]</p> <p>3 Disable the use of eDRX and discard all parameters for eDRX or, if available, reset to the manufacturer specific default values.</p>
<AcT-type>	<p>Integer type, indicates the type of access technology. This AT-command is used to specify the relationship between the type of access technology and the requested eDRX value.</p> <p>5 E-UTRAN (NB-S1 mode)</p>
<Requested_eDRX_value>	<p>String type; half a byte in a 4 bit format. The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see subclause</p>

	10.5.5.32 of 3GPP TS 24.008 [8]). For the coding and the value range, see Extended DRX parameters information element in 3GPP TS 24.008 [8] Table 10.5.5.32/3GPP TS 24.008. The default value, if available, is manufacturer specific.
<NW-provided_eDRX_value>	String type; half a byte in a 4 bit format. The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008 [8]). For the coding and the value range, see Extended DRX parameters information element in 3GPP TS 24.008 [8] Table 10.5.5.32/3GPP TS 24.008.
<Paging_time_window>	String type; half a byte in a 4 bit format. The paging time window refers to bit 8 to 5 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008 [8]). For the coding and the value range, see the Extended DRX parameters information element in 3GPP TS 24.008 [8] Table 10.5.5.32/3GPP TS 24.008.

3.2.21 AT+CEDRXRDP eDRX Read Dynamic Parameters

AT+CEDRXRDP eDRX Read Dynamic Parameters	
Description	The execution command returns <AcT-type> and <Requested_eDRX_value>, <NW-provided_eDRX_value> and <Paging_time_window> if eDRX is used for the cell that the MS is currently registered to. If the cell that the MS is currently registered to is not using eDRX, AcT-type=0 is returned.
Test Command AT+CEDRXRDP=?	Response OK
Execution Command AT+CEDRXRDP	Response +CEDRXRDP: <AcT-type>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]] OK If error is related to ME functionality: +CME ERROR:<err>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<AcT-type>	Integer type, indicates the type of access technology. This AT-command is
------------	---

	used to specify the relationship between the type of access technology and the requested eDRX value 0 Access technology is not using eDRX 5 E-UTRAN(NB-S1 mode)
<Requested_Edrx_value>	String type;half a byte in a 4-bit format.The Edrx value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see sub-clause 10.5.5.32 of 3GPP TS 24.008).For the coding and the value range,see Extended DRX parameters information element in 3GPP TS 24.008 Table 10.5.5.32/3GPP TS 24.008.
<NW-provided_eDRX_value>	String type;half a byte in a 4-bit format.The eDRX value Refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see sub-clause 10.5.5.32 of 3GPP TS 24.008).For the coding and the value range,see the Extended DRX parameters information element in 3GPP TS 24.008 Table 10.5.5.32/3GPP TS 24.008.
<Paging_time_window>	String type;half a byte in a 4-bit format.The paging time window refers to bit 8 to 5 octet 3of the Extended DRX. Parameters information element (see sub-clause 10.5.5.32 of 3GPP TS 24.008).For the coding and the value range,see the Extended DRX parameters information element in 3GPP TS 24.008 Table 10.5.5.32/3GPP TS 24.008.

3.2.22 AT+CTZR Time Zone Reporting

AT+CTZR Time Zone Reporting	
Description	<p>This set command controls the time zone change event reporting. If reporting is enabled the MT returns the unsolicited result code +CTZV: <tz>, +CTZE: <tz>,<dst>,[<time>], or +CTZEU: <tz>,<dst>,[<utime>] whenever the time zone is changed. The MT also provides the time zone upon network registration if provided by the network. If setting fails in an MT error, +CME ERROR: <err> is returned. Refer to Chapter 9: Error Values for possible <err> values.</p> <p>Read command returns the current reporting settings in the MT. Test command returns supported <reporting>-values as a compound value.</p>
Test Command AT+CTZR=?	<p>Response +CTZR: (list of supported <reporting>s)</p> <p>OK</p>
Read Command AT+CTZR?	<p>Response +CTZR: <reporting></p> <p>OK</p> <p>If error is related to ME functionality:</p>

	+CME ERROR: <err>
Write Command	Response
AT+CTZR=<reporting>	OK
	If error is related to ME functionality:
	+CME ERROR: <err>
Unsolicited result code	+CTZV: <zone>
Parameter Saving Mode	AUTO_SAVE_REBOOT
Max Response Time	-
Reference	
3GPP TS 27.007 [13]	

Defined Values

<reporting>	<p>Integer type value indicating:</p> <p>0 Disable time zone change event reporting.</p> <p>1 Enable time zone change event reporting by unsolicited result code +CTZV: <tz>.</p> <p>2 Enable extended time zone and local time reporting by unsolicited result code(not support) +CTZE: <tz>,<dst>,[<time>].</p> <p>3 Enable extended time zone and universal time reporting by unsolicited result code +CTZEU: <tz>,<dst>,[<utime>].</p>
<tz>	<p>String type value representing the sum of the local time zone (difference between the local time and GMT expressed in quarters of an hour) plus daylight saving time. The format is "±zz", expressed as a fixed width, two digit integer with the range -48 ... +56. To maintain a fixed width, numbers in the range -9 ... +9 are expressed with a leading zero, e.g. "-09", "+00" and "+09".</p>
<dst>	<p>Integer type value indicating whether <tz> includes daylight savings adjustment;</p> <p>0 <tz> includes no adjustment for Daylight Saving Time</p> <p>1 <tz> includes +1 hour (equals 4 quarters in <tz>) adjustment for daylight saving time</p> <p>2 <tz> includes +2 hours (equals 8 quarters in <tz>) adjustment for daylight saving time</p>
<time>	<p>String type value representing the local time. The format is "YYYY/MM/DD, hh:mm:ss", expressed as integers representing year (YYYY), month (MM), date (DD), hour (hh), minute (mm) and second (ss). The local time can be derived by the MT from information provided by the network at the time of delivering time zone information and will be present in the unsolicited result code for extended time zone and local time reporting if the universal time is provided by the network.</p>
<utime>	<p>String type value representing the universal time. The format is "YYYY/MM/DD, hh:mm:ss", expressed as integers representing year (YYYY),</p>

month (MM), date (DD), hour (hh), minute (mm) and second (ss). The universal time can be provided by the network at the time of delivering time zone information and will be present in the unsolicited result code for extended time zone and universal time reporting if provided by the network.

3.2.23 AT+CTZU Automatic Time Zone Update

AT+CTZU Automatic Time Zone Update

Description	Set command enables and disables automatic time zone update via NITZ. If setting fails in an MT error, +CME ERROR: <err> is returned. Read command returns the current settings in the MT. Test command returns supported on- and off-values as a compound value.
Test Command AT+CTZU=?	Response +CTZU: (lists of supported <onoff>s) OK
Read Command AT+CTZU?	Response +CTZU: <onoff> OK
Write Command AT+CTZU=<onoff>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	

Defined Values

<onoff>	0 Disable automatic time zone update via NITZ. 1 Enable automatic time zone update via NITZ.
---------	---

3.2.24 AT+CIPCA Initial PDP context activation

AT+CIPCA Initial PDP context activation

Description	The set command controls whether an initial PDP context (see subclause 10.1.0) shall be established automatically following an attach procedure when the UE is attached to GERAN or UTRAN RATs
-------------	--

	<p>and whether the UE is attached to E-UTRAN with or without a PDN connection.</p> <p>For <n>≠0, deactivating the last (active) PDP context can lead to a (re)establishment of the initial PDP context. Changing setting of <n> from 0 to 1 will cause an immediate attempt to (re)establish the initial PDP context if no PDP context is active. Changing <n> from 0 to 2 will if not roaming cause an immediate attempt to (re)establish the initial PDP context if no other PDP context is active. The value of <n>=3 applies to E-UTRAN RATs and does not change the setting of PDP context activation in GERAN or UTRAN RATs. Changing <n> will never cause a PDP context deactivation.</p> <p>For <AttachWithoutPDN>=1, the EPS Attach is performed without a PDN connection.</p> <p>NOTE: For this command, the term roaming corresponds to being registered to a VPLMN which is not equivalent to HPLMN or EHPLMN.</p> <p>The read command returns the current setting of the command. The test command returns values supported as a compound value.</p> <p>Refer to Chapter 9: Error Values for possible <err> values</p>
Test Command AT+CIPCA=?	Response +CIPCA: (list of supported <n>s),(list of supported <AttachWithoutPDN>s) OK
Read Command AT+CIPCA?	Response +CIPCA: <n>[,<AttachWithoutPDN>] OK
Write Command AT+CIPCA=[<n>[,<AttachWithoutPDN>]]	Response OK If error is related to ME functionality: +CME ERROR: <err>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<n>	Integer type. Activation of PDP context upon attach. 0 Do not activate 1 Always activate 2 Activate when not roaming 3 No change in current setting
<AttachWithoutPDN>	Integer type. EPS Attach with or without PDN connection. 0 EPS Attach with PDN connection 1 EPS Attach without PDN connection

NOTE

- Only <n>=3 is supported.
- If <AttachWithoutPDN> is omitted, will use the default value 0.

3.2.25 AT+CGAPNRC APN Rate Control

AT+CGAPNRC APN Rate Control	
Description	<p>This execution command returns the APN rate control parameters (see 3GPP TS 24.008 [8]) associated to the provided context identifier <cid>.</p> <p>If the parameter <cid> is omitted, the APN rate control parameters for all active PDP contexts are returned. The test command returns a list of <cid>s associated with secondary and non-secondary active PDP contexts.</p> <p>Refer to Chapter 9: Error Values for possible <err> values.</p>
Test Command AT+CGAPNRC=?	<p>Response</p> <p>+CGAPNRC: (list of <cid>s associated with active contexts)</p> <p>OK</p> <p>or</p> <p>+CME ERROR: <err></p>
Write Command AT+CGAPNRC[=<cid>]	<p>Response</p> <p>[+CGAPNRC: <cid>[,<Additional_exception_reports>[,<Uplink_time_unit>[,<Maximum_uplink_rate>]]][<CR><LF>+CGAPNRC: <cid>[,<Additional_exception_reports>[,<Uplink_time_unit>[,<Maximum_uplink_rate>]]][...]]</p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<cid>	Integer type; specifies a particular PDP context definition (see the +CGDCONT command).
<Additional_excepti	Integer type; indicates whether or not additional exception reports are allowed

on_reports>	<p>to be sent when the maximum uplink rate is reached. This refers to bit 4 of octet 1 of the APN rate control parameters IE as specified in 3GPP TS 24.008 [8] subclause 10.5.6.3.2.</p> <p>0 Additional_exception_reports at maximum rate reached are not allowed to be sent.</p> <p>1 Additional_exception_reports at maximum rate reached are allowed to be sent.</p>
<Uplink_time_unit>	<p>Integer type; specifies the time unit to be used for the maximum uplink rate. This refers to bits 1 to 3 of octet 1 of the APN rate control parameters IE as specified in 3GPP TS 24.008 [8] subclause 10.5.6.3.2.</p> <p>0 unrestricted</p> <p>1 minute</p> <p>2 hour</p> <p>3 day</p> <p>4 week</p>
<Maximum_uplink_rate>	<p>Integer type; specifies the maximum number of messages the UE is restricted to send per uplink time unit. This refers to octet 2 to 4 of the APN rate control parameters IE as specified in 3GPP TS 24.008 [8] subclause 10.5.6.3.2.</p>

3.2.26 AT+CSODCP Sending of Originating Data via the Control Plane

AT+CSODCP Sending of Originating Data via the Control Plane

Description	<p>The set command is used by the TE to transmit data over control plane to network via MT. Context identifier <cid> is used to link the data to particular context.</p> <p>This command optionally indicates that the application on the MT expects that the exchange of data:</p> <ul style="list-style-type: none"> - will be completed with this uplink data transfer; or - will be completed with the next received downlink data. <p>This command also optionally indicates whether or not the data to be transmitted is an exception data.</p> <p>This command causes transmission of an ESM DATA TRANSPORT message, as defined in 3GPP TS 24.301 [83].</p> <p>Test command returns the maximum number of bytes of the user data container supported by the MT, supported <RAI>s and supported <type_of_user_data>s as a compound value.</p> <p>If <sequence> is not omitted, when datagram is sent by rf or discard, will report the result +CSODCPR: <cid>,<sequence>,<status>.</p>
Test Command AT+CSODCP=?	<p>Response</p> <p>+CSODCP:(range of supported <cid>s),(maximum number of bytes of the <cpdata_length>),(list of supported <RAI>s),(list of supported <type_of_user_data>s),(list of supported <sequence>s)</p>

	OK or +CME ERROR: <err>
Write Command AT+CSODCP=<cid>,<cpdata_length>,<cpdata>[,<RAI>[,<type_of_user_data>[,<sequence>]]]	Response OK If error is related to ME functionality: +CME ERROR: <err> Parameters
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<cid>	Integer type. A numeric parameter which specifies a particular PDP context or EPS bearer context definition. The <cid> parameter is local to the TE-MT interface and identifies the PDP or EPS bearer contexts which have been setup via AT command (see the +CGDCONT command).
<cpdata_length>	Integer type. Indicates the number of bytes of the <cpdata> information element. When there is no data to transmit, the value shall be set to zero.
<cpdata>	String of octets. Contains the user data container contents (refer 3GPP TS 24.301 [83] subclause 9.9.4.24). When there is no data to transmit, the <cpdata> shall be an empty string (""). This parameter shall not be subject to conventional character conversion as per +CSCS. The coding format of the user data container and the maximum length of <cpdata> are implementation specific.
<RAI>	Integer type. Indicates the value of the release assistance indication, refer 3GPP TS 24.301 [83] subclause 9.9.4.25. 0 No information available. 1 The MT expects that exchange of data will be completed with the transmission of the ESM DATA TRANSPORT message. 2 The MT expects that exchange of data will be completed with the receipt of an ESM DATA TRANSPORT message.
<type_of_user_data>	Integer type. Indicates whether the user data that is transmitted is regular or exceptional. 0 Regular data. 1 Exception data.
<sequence>	Sequence of data, range 1-255.If omit, will not report data sent status. NOTE: <sequence> is not defined by 3GPP but only used for HiSi.
<status>	The status of datagram. 0 Error 1 Sent

NOTE

- Maximum data length will be 1358 bytes when non-IP is used, otherwise will be 0.
- Only one message will be buffered at any one time.

3.2.27 AT+CRTDCP Reporting of Terminating Data via the Control Plane

AT+CRTDCP Reporting of Terminating Data via the Control Plane

Description	<p>The set command is used to enable and disable reporting of data from the network to the MT that is transmitted via the control plane in downlink direction. If reporting is enabled, the MT returns the unsolicited result code +CRTDCP: <cid>,<cpdata_length>,<cpdata> when data is received from the network. Read command returns the current settings.</p> <p>Test command returns supported values as compound values.</p> <p>Refer to Chapter 9: Error Values for possible <err> values.</p>
Test Command AT+CRTDCP=?	<p>Response</p> <p>+CRTDCP:(list of supported <reporting>s),(range of supported <cid>s),(maximum number of octets of user data indicated by <cpdata_length>)</p> <p>OK</p> <p>or</p> <p>+CME ERROR: <err></p>
Read Command AT+CRTDCP?	<p>Response</p> <p>+CRTDCP: <reporting></p> <p>OK</p> <p>or</p> <p>+CME ERROR: <err></p>
Write Command AT+CRTDCP=<reporting>	<p>Response</p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<reporting>	Integer type, controlling reporting of mobile terminated control plane data events 0 Disable reporting of MT control plane data. 1 Enable reporting of MT control plane data by the unsolicited result code +CRTDCP.
<cid>	Integer type. A numeric parameter which specifies a particular PDP context or EPS bearer context definition. The <cid> parameter is local to the TE-MT interface and identifies the PDP or EPS bearer contexts which have been setup via AT command (see the +CGDCONT command).
<cpdata_length>	Integer type. Indicates the number of bytes of the <cpdata> information element. When there is no data to transmit, the value shall be set to zero.
<cpdata>	String of octets. Contains the user data container contents (refer 3GPP TS 24.301 [83] subclause 9.9.4.24). When there is no data to transmit, the <cpdata> shall be an empty string (""). This parameter shall not be subject to conventional character conversion as per +CSCS. The coding format of the user data container and the maximum length of <cpdata> are implementation specific.

NOTE

- Maximum data length will be 1358 bytes when non-IP is used, otherwise will be 0.
- Only one message will be buffered at any one time.
- Terminating data via the control plane before enable reporting will be discarded.

3.2.28 AT+CGEREP Packet Domain Event Reporting

AT+CGEREP Packet Domain Event Reporting	
Description	Set command enables or disables sending of unsolicited result codes, +CGEV: XXX from MT to TE in the case of certain events occurring in the Packet Domain MT or the network. <mode> controls the processing of unsolicited result codes specified within this command. <bfr> controls the effect on buffered codes when <mode> 1 or 2 is entered. If a setting is not supported by the MT, ERROR or +CME ERROR: is returned. Read command returns the current mode and buffer settings. Test command returns the modes and buffer settings supported by the MT as compound values.
Test Command AT+CGEREP=?	Response +CRTDCP: (list of supported <reporting>s),(range of supported <cid>s),(maximum number of octets of user data indicated by

	<cpdata_length> OK or +CME ERROR: <err>
Read Command AT+CGEREP?	Response +CRTDCP: <reporting> OK or +CME ERROR: <err>
Write Command AT+CGEREP=<mode>[,<bfr>]	Response OK If error is related to ME functionality: +CME ERROR: <err>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<mode>	0 buffer unsolicited result codes in the MT; if MT result code buffer is full, the oldest ones can be discarded.No codes are forwarded to the TE. 1 discard unsolicited result codes when MT-TE link is reserved (e.g. in on-line data mode); otherwise forward them directly to the TE.
<bfr>	0 MT buffer of unsolicited result codes defined within this command is cleared when <mode> 1 ; Only it now

3.2.29 +CGEV Indicate EPS PDN Connection and Bearer Resources Operations Status

+CGEV Indicate EPS PDN Connection and BearerResources Operations Status

Description	This is an unsolicited message to indicate EPS PDN connection and bearer resources operations status +CGEV: NW PDN DEACT <cid>
-------------	--

Defined Values

<cid>	The format is found in command +CGDCONT.<cid> values of 1-11 are supported.
-------	---

3.2.30 AT+CGCONTRDP PDP Context Read Dynamic Parameters

AT+CGCONTRDP PDP Context Read Dynamic Parameters

Description	<p>The execution command returns the relevant information <bearer_id>, <apn>, <local_addr and subnet_mask>, <gw_addr>, <DNS_prim_addr>, <DNS_sec_addr>, <P-CSCF_prim_addr>, <P-CSCF_sec_addr>, <IM_CN_Signalling_Flag>, <LIPA_indication>, <IPv4_MTU>, <WLAN_Offload>, <Non-IP_MTU>, <Serving_PLMN_rate_control_value> and <Reliable_Data_Service> for an active non secondary PDP context with the context identifier <cid>. If the MT indicates more than two IP addresses of P-CSCF servers or more than two IP addresses of DNS servers, multiple lines of information per <cid> will be returned.</p> <p>If the MT has dual stack capabilities, at least one pair of lines with information is returned per <cid>. First one line with the IPv4 parameters followed by one line with the IPv6 parameters. If this MT with dual stack capabilities indicates more than two IP addresses of P-CSCF servers or more than two IP addresses of DNS servers, multiple of such pairs of lines are returned.</p> <p>NOTE: If the MT doesn't have all the IP addresses to be included in a line, e.g. in case the UE received four IP addresses of DNS servers and two IP addresses of P-CSCF servers, the parameter value representing an IP address that can not be populated is set to an empty string or an absent string.</p> <p>If the parameter <cid> is omitted, the relevant information for all active non secondary PDP contexts is returned.</p> <p>The test command returns a list of <cid>s associated with active non secondary contexts.</p>
Test Command AT+CGCONTRDP=?	<p>Response</p> <p>+CGCONTRDP: (list of<cid>s associated with active contexts)</p> <p>OK</p> <p>or</p> <p>OK</p>
Write Command AT+CGCONTRDP[=<cid>]	<p>Response</p> <p>[+CGCONTRDP: <cid>,<bearer_id>,<apn>[,<local_addr and subnet_mask>[,<gw_addr>[,<DNS_prim_addr>[,<DNS_sec_addr>[,<P-CSCF_prim_addr>[,<P-CSCF_sec_addr>[,<IM_CN_Signalling_Flag>[,<LIPA_indication>[,<IPv4_MTU>[,<WLAN_Offload>[,<Local_Addr_Ind>[,<Non-IP_MTU>[,<Serving_PLMN_rate_control_value>[,<Reliable_Data_Service>]]]]]]]]]]][<CR><LF>+CGCONTRDP: <cid>,<bearer_id>,<apn>[,<local_addr and subnet_mask>[,<gw_addr>[,<DNS_prim_addr>[,<DNS_sec_addr>[,<P-CSCF_prim_addr>[,<P-CSCF_sec_addr>[,<IM_CN_Signalling_Flag>[,<LIPA_indication>[,<IPv4_MTU>[,<WLAN_Offload>[,<Local_Addr_Ind>[,<Non-IP_MTU>[,<Serving_PLMN_rate_control_value>[,<Reliable_Data_Service>]]]]]]]]]]]</p>

	<p>a_Service]]]]]]]]]]]]]]]]</p> <p>[...]</p> <p>OK</p> <p>or</p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<cid>	Integer type; specifies a particular non secondary PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands (see the +CGDCONT command).
<bearer_id>	Integer type; identifies the bearer, i.e. the EPS bearer in EPS and the NSAPI in UMTS/GPRS.
<apn>	String type; a logical name that was used to select the GGSN or the external packet data network.
<local_addr and subnet_mask>	String type; shows the IP address and subnet mask of the MT.The string is given as dot-separated numeric (0-255) parameters on the form: "a1.a2.a3.a4.m1.m2.m3.m4" for IPv4 or "a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16.m1.m2.m3.m4.m5.m6.m7.m8.m9.m10.m11.m12.m13.m14.m15.m16" for IPv6. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.
<gw_addr>	String type; shows the Gateway Address of the MT. The string is given as dot-separated numeric (0-255) parameters. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.
<DNS_prim_addr>	String type; shows the IP address of the primary DNS server.When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.
<DNS_sec_addr>	String type; shows the IP address of the secondary DNS server.When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.
<P_CSCF_prim_addr>	String type; shows the IP address of the primary P-CSCF server.When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.
<P_CSCF_sec_addr>	String type; shows the IP address of the secondary P-CSCF server.When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP.

<IM_CN_Signalling_Flag>	Integer type; shows whether the PDP context is for IM CN subsystem- related signalling only or not. 0 PDP context is not for IM CN subsystem-related signalling only 1 PDP context is for IM CN subsystem-related signalling only
<LIPA_indication>	Integer type; indicates that the PDP context provides connectivity using a LIPA PDN connection. This parameter cannot be set by the TE. 0 indication not received that the PDP context provides connectivity using a LIPA PDN connection 1 indication received that the PDP context provides connectivity using a LIPA PDN connection
<IPv4_MTU>	Integer type; shows the IPv4 MTU size in octets.
<WLAN_Offload>	Integer type; indicates whether traffic can be offloaded using the specified PDN connection via a WLAN or not. This refers to bits 1 and 2 of the WLAN offload acceptability IE as specified in 3GPP TS 24.008 [8] subclause 10.5.6.20. 0 offloading the traffic of the PDN connection via a WLAN when in S1 mode or when in lu mode is not acceptable. 1 offloading the traffic of the PDN connection via a WLAN when in S1 mode is acceptable, but not acceptable in lu mode. 2 offloading the traffic of the PDN connection via a WLAN when in lu mode is acceptable, but not acceptable in S1 mode. 3 offloading the traffic of the PDN connection via a WLAN when in S1 mode or when in lu mode is acceptable.
<Local_Addr_Ind>	Integer type; indicates whether or not the MS and the network support local IP address in TFTs (see 3GPP TS 24.301 [83] and 3GPP TS 24.008 [8] subclause 10.5.6.3). 0 indicates that the MS or the network or both do not support local IP address in TFTs 1 indicates that the MS and the network support local IP address in TFTs
<Non-IP_MTU>	Integer type; shows the Non-IP MTU size in octets.
<Serving_PLMN_rate_control_value>	Integer type; indicates the maximum number of uplink messages the UE is allowed to send in a 6 minute interval. This refers to octet 3 to 4 of the Serving PLMN rate control IE as specified in 3GPP TS 24.301 [8] subclause 9.9.4.28.
<Reliable_Data_Service>	Integer type; indicates whether the UE is using Reliable Data Service for a PDN connection or not, see 3GPP TS 24.301 [83] and 3GPP TS 24.008 [8] subclause 10.5.6.3. 0 Reliable Data Service is not being used for the PDN connection 1 Reliable Data Service is being used for the PDN connection

NOTE

- Only support <cid>,<apn>,<DNS_prim_addr>,<DNS_sec_addr> now.
- <DNS_prim_addr>,<DNS_sec_addr> could display only when <PDP_type> is "IP" or "IPv6".

- Could configure PDP context dynamic parameter items to read by +NCPDPR.

3.2.31 AT+CGAUTH Define PDP Context Authentication Parameters

AT+CGAUTH Define PDP Context Authentication Parameters	
Description	<p>Set command allows the TE to specify authentication parameters for a PDP context identified by the (local) context identification parameter <cid> used during the PDP context activation and the PDP context modification procedures. Since the <cid> is the same parameter that is used in the +CGDCONT command, +CGAUTH is effectively as an extension to these commands.</p> <p>The read command returns the current settings for each defined context. The test command returns values supported as compound values.</p>
Test Command AT+CGAUTH=?	<p>Response</p> <p>+CGAUTH: (range of supported<cid>s),(list of supported<auth_prot>s),(range of supported<userid>s),(range of supported<password>s)</p> <p>OK</p>
Read Command AT+CGAUTH?	<p>Response</p> <p>[+CGAUTH: <cid>,<auth_prot>,<userid>,<password>][<CR><LF>+CGAUTH: <cid>,<auth_prot>,<userid>,<password> ...]</p> <p>OK</p>
Write Command AT+CGAUTH=<cid>[,<auth_prot>[,<userid>[,<password>]]]	<p>Response</p> <p>When <auth_prot>/<username>/<password> set:</p> <p>OK</p> <p>When no <auth_prot>/<username>/<password> set displays current auth_prot username and password for <cid>:</p> <p>+CGAUTH: <cid>,<auth_prot>,<username>,<password></p> <p>OK</p> <p>If error is related to wrong AT syntax:</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<cid>	Integer type. Specifies a particular PDP context definition (see the +CGDCONT command).
<auth_prot>	Integer type. Authentication protocol used for this PDP context. 0 None. Used to indicate that no authentication protocol is used for this PDP context. Username and password are removed if previously specified. 1 PAP 2 CHAP
<userid>	String type. User name for access to the IP network.
<password>	String type. Password for access to the IP network.

NOTE

- <userid> is needed when <auth_prot> is 1 or 2.
- Maximum <userid> string and <password> string length is 60.

3.2.32 AT+CPIN Enter PIN

AT+CPIN Enter PIN

Description

Set command sends to the MT a password which is necessary before it can be operated (SIM PIN, SIM PUK, PH-SIM PIN, etc.). If the PIN is to be entered twice, the TA shall automatically repeat the PIN. If no PIN request is pending, no action is taken towards MT and an error message, +CME ERROR, is returned to TE. Refer to Chapter 9 for possible <err> values.

NOTE 1: SIM PIN, SIM PUK, PH-SIM PIN, PH-FSIM PIN, PH-FSIM PUK, SIM PIN2 and SIM PUK2 refer to the PIN of the selected application on the UICC. For example, in an UTRAN context, the selected application on the currently selected UICC should be a USIM and the SIM PIN then represents the PIN of the selected USIM. See 3GPP TS 31.101 [65] for further details on application selection on the UICC.

If the PIN required is SIM PUK or SIM PUK2, the second pin is required. This second pin, <newpin>, is used to replace the old pin in the SIM.

NOTE 2: Commands which interact with MT that are accepted when MT is pending SIM PIN, SIM PUK, or PH-SIM are: +CGMI, +CGMM, +CGMR, +CGSN, D112; (emergency call), +CPAS, +CFUN, +CPIN, +CPINR, +CDIS (read and test command only), and +CIND (read and test command only). It is implementation specific whether additional commands can be accepted when MT is pending SIM PIN, SIM PUK, or PH-SIM.

	Read command returns an alphanumeric string indicating whether some password is required or not.
Test Command AT+CPIN=?	Response OK
Read Command AT+CPIN?	Response +CPIN: <code> OK
Write Command AT+CPIN=<pin>[,<new pin>]	Response OK If error is related to ME functionality: +CME ERROR:<err>
Parameter Saving Mode	NO_SAVE
Max Response Time	5s
Reference	
3GPP TS 27.007 [13]	

Defined Values

<code>	READY	MT is not pending for any password
	SIM PIN	MT is waiting SIM PIN to be given
	SIM PUK	MT is waiting for SIM PUK to be given
	SIM PUK BLOCKED	
<pin>	String type; password	
<new pin>	String type; If the PIN required is SIM PUK or SIMPUK2: new password	

NOTE

Set and read could execute only when power on.

3.2.33 AT+CLCK Facility Lock

AT+CLCK Facility Lock

Description	Execute command is used to lock, unlock or interrogate a MT or a network facility <fac>. Password is normally needed to do such actions. When querying the status of a network service (<mode>=2) the response line for 'not active' case (<status>=0) should be returned only if service is not active for any <class>. This command should be abortable when network facilities are set or interrogated. Test command returns facility values supported as a compound value.
-------------	---

Test Command AT+CLCK=?	Response OK
Write Command AT+CLCK=<fac>,<mode>[,<passwd>]	Response OK or +CME ERROR: <err> When <mode>=2 and command successful: +CLCK: <status>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<fac>	"SC" SIM (lock SIM/UICC card installed in the currently selected card slot) (SIM/UICC asks password in MT power-up and when this lock command issued)
<mode>	0 Unlock 1 Lock 2 Query status
<status>	0 Not active 1 active
<passwd>	String type; shall be the same as password specified for the facility from the MT user interface or with command Change Password +CPWD

3.2.34 AT+CMOLR Mobile Originated Location Request

AT+CMOLR Mobile Originated Location Request

Description	<p>Set command initiates a mobile originated location request (MO-LR). The parameter <enable> enables or disables positioning and reporting by unsolicited result codes. Reporting can be performed in the format of GAD shapes <location_parameters> or in the format of NMEA strings <NMEA-string> or both.</p> <p>The unsolicited result codes that can be provided are +CMOLRG: <location_parameters> and/or +CMOLRN: <NMEA-string>.</p> <p>Read command returns the current settings of the parameters <enable>, <method>, <hor-acc-set>, <horacc>, <ver-req>, <ver-acc-set>, <ver-acc>, <vel-req>, <rep-mode>, <timeout>, <interval>, <shape-rep>, <plane>, <NMEA-rep> and <third-party-address>. The parameters <hor-acc>, <veraccset>, <ver-acc> and <plane> are only applicable in certain</p>
-------------	---

	configurations. The parameter <interval>is only applicable if periodic reporting is specified. The parameter <NMEA-rep> is only applicable if reporting is specified by NMEA strings.The parameter <third-party-address> is only applicable if reporting to third party is specified. Test command returns the supported values and ranges.
Test Command AT+CMOLR=?	Response +CMOLR: (list of supported<enable>s),(list ofsupported<method>s),(list of supported<horacc-set>s),(list of supported <hor-acc>s),(list of supported<ver-req>s),(list of supported<veracc-set>s),(list of supported <ver-acc>s),(listof supported<vel-req>s),(list of supported<repmode>s),(list of supported<timeout>s),(list of supported <interval>s),(list of supported<shape-rep>s),(list of supported<pplane>s),(list of supported<NMEA-rep>s),(list of supported <third-party-address>s) OK
Read Command AT+CMOLR?	Response +CMOLR: <enable>,<method>,<hor-accset>,[<hor-acc>],<ver-req>,[<ver-accset>],[<ver-acc>],<vel-req>,<repmode>,<timeout>,[<interval>],<shaperep>,[<pplane>],[<NMEA-rep>],[<thirdparty-address>] OK
Write Command AT+CMOLR=[<enable> ,<method>[,<hor-accs et>[,<hor-acc>[,<ver-re q>[,<ver-accset>[,<ver- acc>[,<vel-req>[,<repm ode>[,<timeout>[,<inte rval>[,<shaperep>[,<pl ane>[,<NMEA-rep>[,<t hirdparty-address>]]]]]]]]]]]]]]]]]	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<enable>	<p>0 Disables reporting and positioning</p> <p>1 Enables reporting of NMEA strings by unsolicited result code +CMOLRN: <NMEA-string>.</p> <p>Lack of data at each timeout is indicated by an unsolicited result code</p>
-----------------------	--

	<p>+CMOLRE.</p> <p>2 Enables reporting of GAD shapes by unsolicited result code +CMOLRG: <location_parameters>.</p> <p>Lack of data at each timeout is indicated by an unsolicited result code +CMOLRE.</p> <p>3 Enables reporting of NMEA strings and GAD shapes by unsolicited result codes</p> <p>+CMOLRG: <location_parameters> and +CMOLRN: <NMEA-string>.</p> <p>Lack of data at each timeout is indicated by an unsolicited result code +CMOLRE.</p>
<method>	<p>0 Unassisted GPS. Autonomous GPS only, no use of assistance data.</p> <p>1 Assisted GPS. 2 Assisted GANSS. 3 Assisted GPS and GANSS. 4 Basic Self location (the network determines the position technology).</p> <p>5 Transfer to third party. This method makes the parameters <shape-rep> and <NMEA-rep> irrelevant (any values are accepted and disregarded).</p> <p>The third party address is given in the parameter <thirdparty-address>.</p> <p>6 Retrieval from third party. This method is to get the position estimate of the third party. The third party address is given in the parameter <third-party-address>.</p>
<hor-acc-set>	<p>0 Horizontal accuracy not set/specified.</p> <p>1 Horizontal accuracy set in parameter <hor-acc>.</p>
<hor-acc>	<p>Requested accuracy as horizontal uncertainty exponent. The value range is 0-127.</p>
<ver-req>	<p>0 Vertical coordinate (altitude) is not requested, 2D location fix is acceptable. The parameters <ver-accset> and <ver-acc> do not apply.</p> <p>1 Vertical coordinate (altitude) is requested, 3D location fix is required.</p>
<ver-acc-set>	<p>0 Vertical accuracy not set/specified.</p> <p>1 Vertical accuracy set/specified in parameter <ver-acc>.</p>
<ver-acc>	<p>Requested accuracy as vertical uncertainty exponent The value range is 0-127. The default value is implementation specific.</p>
<vel-req>	<p>0 Velocity not requested.</p> <p>1 Horizontal velocity requested.</p> <p>2 Horizontal velocity and vertical velocity requested.</p> <p>3 Horizontal velocity with uncertainty requested.</p> <p>4 Horizontal velocity with uncertainty and vertical velocity with uncertainty requested.</p>
<rep-mode>	<p>0 Single report, the timeout for the MO-LR response request is specified by <timeout>.</p> <p>1 Periodic reporting, the timeout for each MO-LR response request is specified by <timeout> and the interval between each MO-LR is specified by <interval>.</p>
<timeout>	<p>Indicates how long the MS will wait for a response after a MO-LR. The value range is in seconds from 1 to 65535.</p>
<interval>	<p>The parameter is applicable to periodic reporting only. Determine the interval between periodic MO-LRs. The value range is in seconds from 1 to 65535,</p>

	and must be greater than or equal to <timeout>.
<shape-req>	<p>This parameter is a sum of integers each representing a certain GAD shape that will be accepted in the unsolicited result code <location_parameters>. Note that only one GAD shape is present per unsolicited result code.</p> <p>1 Ellipsoid point. 2 Ellipsoid point with uncertainty circle. 4 Ellipsoid point with uncertainty ellipse. 8 Polygon. 16 Ellipsoid point with altitude. 32 Ellipsoid point with altitude and uncertainty ellipsoid. 64 Ellipsoid arc.</p>
<plane>	<p>The parameter specifies whether the control plane or SUPL will be used for MO-LR.</p> <p>0 Control plane. 1 Secure user plane (SUPL).</p>
<NMEA-rep>	<p>The supported NMEA strings are specified as a comma separated values inside one string. If the parameter is omitted or an empty string is given, no restrictions apply and all NMEA strings are supported.</p>
<third-party-address>	<p>The parameter is applicable to reporting to third party only, and specifies the address to the third party. This parameter has to be specified when <method> value is set to 5 or 6.</p>
<location-parameter s>	<p>String type in UTF-8. This parameter provides XML-formatted strings of GADshape positioning data as defined in table 8.50-2. This parameter shall not be subject to conventional character conversion as per +CSCS. The XML according to the DTD in table 8.50-2 may be provided in one or multiple unsolicited result codes.</p>

3.2.35 AT+CPWD Change Password

AT+CPWD Change Password	
Description	Command sets a new password for the facility lock function defined by command Facility Lock +CLCK. Test command returns a list of pairs which present the available facilities and the maximum length of their password.
Test Command AT+CPWD=?	<p>Response</p> <p>+CPWD: list of supported (<fac>,<pwdlength>)s OK or +CME ERROR: <err></p>
Write Command AT+CPWD=<fac>,<old pwd>,<newpwd>	<p>Response</p> <p>OK or +CME ERROR: <err></p>

Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<fac>	"SC" SIM (lock SIM/UICC card installed in the currently selected card slot) (SIM/UICC asks password in MT power-up and when this lock command issued)
<oldpwd>,<newpwd> >	<oldpwd> shall be the same as password specified for the facility from the MT user interface or with command Change Password +CPWD and <newpwd> is the new password, maximum length of password can be determined with <pwdlength>
<pwdlength>	Integer type; maximum length of the password for the facility.

3.2.36 AT+CPINR Remaining PIN Retries

AT+CPINR Remaining PIN Retries	
Description	<p>Execution command cause the MT to return the number of remaining PIN retries for the MT passwords with intermediate result code +CPINR: <code>,<retries>[,<default_retries>] for standard PINs and +CPINRE: <ext_code>,<retries>[,<default_retries>] for manufacturer specific PINs. One line with one intermediate result code is returned for every <code> or <ext_code> selected by <sel_code>.</p> <p>When execution command is issued without the optional parameter <sel_code>, intermediate result codes are returned for all <code>s and <ext_code>s.</p> <p>In the intermediate result codes, the parameter <default_retries> is an optional (manufacturer specific) parameter, per <code> and <ext_code>.</p>
Test Command AT+CPINR=?	<p>Response</p> <p>OK</p>
Write Command AT+CPINR[=<sel_code>]	<p>Response</p> <p>[+CPINR: <code>,<retries>[,<default_retries>]][<CR>,<LF>+CPINR: <code>,<retries>[,<default_retries>]</p> <p>OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	3GPP TS 27.007 [13]

Defined Values

<retries>	Integer type. Number of remaining retries per PIN.
<default_retries>	Integer type. Number of default/initial retries per PIN.
<code>	Type of PIN. All values listed under the description of the AT+CPIN command, <code> parameter, except 'READY'.
<ext_code>	Extended, manufacturer specific codes.
<sel_code>	String type. Same values as for the <code> and <ext_code> parameters. These values are strings and shall be indicated within double quotes. It is optional to support wildcard match by '*', meaning match any (sub-)string.

NOTE

Set and read could execute only when power on.

3.2.37 AT+CCHO Open Logical Channel

AT+CCHO Open Logical Channel

Description	<p>Execution of the command causes the MT to return <sessionid> to allow the TE to identify a channel that is being allocated by the currently selected UICC, which is attached to ME. The currently selected UICC will open a new logical channel; select the application identified by the <dfname> received with this command and return a session Id as the response. The ME shall restrict the communication between the TE and the UICC to this logical channel.</p> <p>This <sessionid> is to be used when sending commands with Restricted UICC Logical Channel access +CRLA or Generic UICC Logical Channel access +CGLA commands.</p> <p>NOTE: <i>The logical channel number is contained in the CLASS byte of an APDU command, thus implicitly contained in all APDU commands sent to a UICC. In this case it will be up to the MT to manage the logical channel part of the APDU CLASS byte and to ensure that the chosen logical channel is relevant to the <sessionid> indicated in the AT command. See 3GPP TS 31.101 [65] for further information on logical channels in APDU commands protocol.</i></p>
Write Command AT+CCHO=<dfname>	<p>Response</p> <p>+CCHO: <sessionid></p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>

Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	
3GPP TS 27.007 [13]	

Defined Values

<dfname>	String type in hexadecimal character format. All selectable applications in the UICC are referenced by a DF name coded on 1 to 16 bytes
<sessionid>	Integer type; a session Id to be used to target a specific application on the smart card (e.g. (U)SIM, WIM, ISIM) using logical channels mechanism. See 3GPP TS 31.101 [65] for more information about defined values

3.2.38 AT+CCHC Close logical channel

AT+CCHC Close UICC Logical Channel

Description	This command asks the ME to close a communication session with the active UICC. The ME shall close the previously opened logical channel. The TE will no longer be able to send commands on this logical channel. The UICC will close the logical channel when receiving this command.
Write Command AT+CCHC=<sessionid>	Response OK If error is related to ME functionality: +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	
3GPP TS 27.007 [13]	

Defined Values

<sessionid>	Integer type; the session used to target a specific application on the smart card (e.g. (U)SIM, WIM, ISIM) using logical channels mechanism
-------------	---

3.2.39 AT+CGLA Generic UICC Logical Channel Access

AT+CGLA Generic UICC Logical Channel Access

Description	Set command transmits to the MT the <command> it then shall send as it is to the selected UICC. In the same manner the UICC <response> shall be sent back by the MT to the TA as it is. This command allows a direct control of the currently selected UICC by a distant application on the TE. The TE shall then take care of processing
-------------	--

	<p>UICC information within the frame specified by GSM/UMTS.</p> <p>Although Generic UICC Logical Channel Access command +CGLA allows TE to take control over the UICC-MT interface, there are some functions of the UICC-MT interface that logically do not need to be accessed from outside the TA/MT. Moreover, for security reason the GSM network authentication should not be handled outside the TA/MT. Therefore it shall not be allowed to execute a Run GSM Algorithm command or an Authenticate command in GSM context from the TE using +CGLA at all time whether the +CGLA is locked or unlocked. This shall not forbid the TE to send Authenticate commands in other security contexts (e.g. EAP security context).</p> <p>For example, the TA/MT shall forbid the transfer of the Authenticate command to a USIM application when parameters P2=0 (GSM security context). See 3GPP TS 31.102 [59] for USIM authenticate command definition.</p> <p>NOTE: Compared to Restricted UICC Access command +CRLA, the definition of +CGLA allows TE to take more control over the UICC-MT interface. The locking and unlocking of the interface may be done by a special <command> value or automatically by TA/MT (by interpreting <command> parameter). In case that TE application does not use the unlock command (or does not send a <command> causing automatic unlock) in a certain timeout value, MT may release the locking.</p>
Write Command	<p>Response</p> <p>+CGLA: <length>,<response></p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>
AT+CGLA=<sessionid>,<length>,<command>	
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	3GPP TS 27.007 [13]

Defined Values

<sessionid>	Integer type; this is the identifier of the session to be used in order to send the APDU commands to the UICC. It is mandatory in order to send commands to the UICC when targeting applications on the smart card using a logical channel other than the default channel (channel "0").
<length>	Integer type; length of the characters that are sent to TE in <command> or <response>(two times the actual length of the command or response)
<command>	Command passed on by the MT to the UICC in the format as described in 3GPP TS 31.101 [65] (hexadecimal character format; refer +CSCS)
<response>	Response to the command passed on by the UICC to the MT in the format as described in 3GPP TS 31.101 [65] (hexadecimal character format; refer

+CSCS)

3.2.40 AT+CMTLR Mobile Terminated Location Request Notification

AT+CMTLR Mobile Terminated Location Request Notification

Description	<p>Set command enables Mobile Terminated Location Request (MT-LR) notifications to the TE. The parameter <subscribe> enables or disables notification by an unsolicited result code. It is possible to enable notification of MT-LR performed over the control plane or over SUPL or both. Relevant location request parameters are provided in the unsolicited result code +CMTLR:<handle-id>,<notification-type>,<locationtype>,<client-external-id>,<client-name>,<plane>].</p> <p>Read command returns the current value of <subscribe>.</p> <p>Test command returns the supported values as a compound value.</p>
Test Command AT+CMTLR=?	<p>Response</p> <p>+CMTLR: (list of supported <subscribe>s)</p> <p>OK</p>
Read Command AT+CMTLR?	<p>Response</p> <p>+CMTLR: <subscribe></p> <p>OK</p>
Write Command AT+CMTLR=[<subscribe>]	<p>Response</p> <p>OK</p> <p>or</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	

Defined Values

<subscribe>	<p>Enables and disables the subscription for MT-LR notifications</p> <p>0 Disables reporting and positioning.</p> <p>1 Subscribe for notifications of MT-LR over control plane.</p> <p>2 Subscribe for notifications of MT-LR over SUPL.</p> <p>3 Subscribe for notifications of MT-LR over control plane and SUPL.</p>
<handle-id>	ID associated with each MT-LR used to distinguish specific request in case of multiple requests. The value range is 0-255.
<notification-type>	Integer type. Information about the user's privacy.

	<p>0 The subscription may stipulate that positioning the user by a third party is allowed and the network may choose to inform the user as a matter of courtesy.</p> <p>1 Locating the user is permitted if the user ignores the notification.</p> <p>2 Locating the user is forbidden if the user ignores the notification</p>
<location-type>	<p>Integer type. Indicates what type of the location is requested.</p> <p>0 The current location.</p> <p>1 The current or last known location.</p> <p>2 The initial location.</p>
<client-external-id>	<p>String type. Indicates the external client where the location information is sent to (if required).</p>
<client-name>	<p>String type. Contains the string identifying the external client requesting the user's location</p>
<plane>	<p>Integer type. The parameter specifies whether the MT-LR came over control plane or SUPL.</p> <p>0 Control plane.</p> <p>1 Secure user plane (SUPL).</p>

3.2.41 AT+CMTLRA Mobile Terminated Location Request Disclosure Allowance

AT+CMTLRA Mobile Terminated Location Request Disclosure Allowance	
Description	<p>Set command allows or disallows disclosure of the location to the TE as a result of MT-LR by the parameter <allow>.</p> <p>Read command returns the current values.</p> <p>Test command returns the supported values.</p>
Test Command AT+CMTLRA=?	<p>Response</p> <p>+CMTLRA: (lists of supported <allow>values)</p> <p>OK</p>
Read Command AT+CMTLRA?	<p>Response</p> <p>+CMTLRA: <allow>,<handle-id></p> <p>OK</p>
Write Command AT+CMTLRA=<allow>,<handle-id>	<p>Response</p> <p>OK</p> <p>or</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	

Defined Values

<allow>	Integer type. Enables and disables the allowance for location disclosure. 0 Location disclosure allowed. 1 Location disclosure not allowed.
<handle-id>	Integer type. ID associated with each MT-LR used to distinguish specific request in case of multiple requests. The value range is 0-255.

3.2.42 AT+CRCES Reading Coverage Enhancement Status

AT+CRCES Reading Coverage Enhancement Status	
Description	This command returns the coverage enhancement status of the MT. The terminal can consider the coverage enhancement status prior to deciding to transmit data. Depending on the coverageenhancement status the terminal can refrain from transmitting data. The coverage enhancement status is only provided by the MT if the access technology of the serving cell is E-UTRAN, EC-GSM-IoT or E-UTRAN (NB-S1 mode). If the access technology of the serving cell is different, <Act>=0 is indicated.
Test Command AT+CRCES=?	Response +CRCES: <AcT>,<CE_level>,<CC> OK
Execution Command AT+CRCES	Response OK
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	

Defined Values

<AcT>	Integer type; access technology of the serving cell. 0 Location disclosure allowed. 1 E-UTRAN. 2 EC-GSM-IoT (A/Gb mode) 3 E-UTRAN (NB-S1 mode)
<CE_level>	Integer type; Coverage Enhancement (CE) level of the MT in the serving cell. Applicable only if <Act>=1 (E-UTRAN) or <Act>=3 (E-UTRAN (NB-S1 mode)). 0 No Coverage Enhancement in the serving cell 1 Coverage Enhancement level 0 2 Coverage Enhancement level 1 3 Coverage Enhancement level 2 4 Coverage Enhancement level 3

<cc>	<p>Integer type; Coverage Class (CC) of the MT in the serving cell. Applicable only if <Act>=2 (EC-GSMIoT).</p> <p>0 No Coverage Class in the serving cell</p> <p>1 Coverage Class 1</p> <p>2 Coverage Class 2</p> <p>3 Coverage Class 3</p> <p>4 Coverage Class 4</p> <p>5 Coverage Class 5.</p>
-------------------	---

3.2.43 AT+CRSM Restricted SIM Access

AT+CRSM Restricted SIM Access	
	<p>This command returns the coverage enhancement status of the MT. The terminal can consider the coverage enhancement status prior to deciding to transmit data. Depending on the coverage enhancement status the terminal can refrain from transmitting data.</p> <p>The coverage enhancement status is only provided by the MT if the access technology of the serving cell is E-UTRAN, EC-GSM-IoT or E-UTRAN (NB-S1 mode). If the access technology of the serving cell is different, <Act>=0 is indicated.</p>
<p>Test Command</p> <p>AT+CRSM=?</p>	<p>Response</p> <p>OK</p>
<p>Write Command</p> <p>AT+CRSM=<Command>[,<fileId>[,<P1>,<P2>,<P3>[,<data>]]]</p>	<p>Response</p> <p>+CRSM: <sw1>,<sw2>[,<response>]</p> <p>OK</p> <p>or</p> <p>ERROR</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	
3GPP TS 27.007	
GSM 11.11	

Defined Values

<Command>	<p>(command passed on by the MT to the SIM; refer 3GPP TS 51.011 [28]):</p> <p>176 READ BINARY</p> <p>178 READ RECORD</p> <p>192 GET RESPONSE</p>
------------------------	---

	<p>214 UPDATE BINARY</p> <p>220 UPDATE RECORD</p> <p>242 STATUS</p> <p>All other values are reserved</p>
<fileId>	Integer type; this is the identifier for an elementary data file on SIM. Mandatory for every Command except STATUS
<P1>,<P2>,<P3>	<p>Integer type, range 0 – 255</p> <p>Parameters to be passed on by the ME to the SIM; refer GSM 11.11.</p>
<data>	Information which shall be written to the SIM (hex-decimal character format)
<sw1>,<sw2>	<p>Integer type, range 0 - 255</p> <p>Status information from the SIM about the execution of the actual Command. These parameters are delivered to the TE in both cases, on successful or failed execution of the Command; refer GSM 11.11.</p>
<response>	Response of a successful completion of the Command previously issued (hexadecimal character format)

NOTE

<Command> does not support 203 and 219.

3.2.44 AT+CSIM Generic SIM Access

AT+CSIM Generic SIM Access

Description	<p>Set command transmits to the MT the <command> it then shall send as it is to the SIM. In the same manner, the SIM <response> shall be sent back by the MT to the TA as it is.</p> <p>This command allows a direct control of the SIM that is installed in the currently selected card slot, by an distant application on the TE. The TE shall then take care of processing SIM information within the frame specified by GSM/UMTS.</p> <p>NOTE: Compared to Restricted SIM Access command +CRSM, the definition of +CSIM allows TE to take more control over the SIM-MT interface. The locking and unlocking of the interface may be done by a special <command> value or automatically by TA/MT (by interpreting <command> parameter). In case that TE application does not use the unlock command (or does not send a <command> causing automatic unlock) in a certain timeout value, MT may release the locking.</p>
<p>Test Command</p> <p>AT+CSIM=?</p>	<p>Response</p> <p>OK</p>
<p>Write Command</p> <p>AT+CSIM=<length>,<Command></p>	<p>Response</p> <p>+CSIM: <length>,<response></p> <p>OK</p>

	If error is related to ME functionality: +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	
3GPP TS 27.007 [13]	

Defined Values

<length>	Integer type: length of characters sent to the TE in <Command> or <response> (i.e. twice the number of octets in the raw data).
<Command>	String type (string should be included in quotation marks): hex format: GSM 11.11 SIM Command sent from the ME to the SIM.
<response>	String type(string should be included in quotation marks): hex format: GSM 11.11 response from SIM to <Command>.

3.2.45 AT+CGDATA Enter Data State

AT+CGDATA Enter Data State	
Description	<p>The execution command causes the MT to perform whatever actions are necessary to establish communication between the TE and the network using one Packet Domain PDP types. This may include performing a PS attach and one PDP context activations. <cid> should be specified (see the +CGDCONT) in order to provide the information needed for the context activation request.</p> <p>The test command is used for requesting information on the supported <L2P> protocols.</p>
Test Command AT+CGDATA=?	Response +CGDATA: (list of supported<L2P>s) OK
Write Command AT+CGDATA=[<L2P>[, <cid>[,<cid>[,...]]]]	Response OK or ERROR
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<L2P>	String type; indicates the layer 2 protocol to be used between the TE and MT. M-PT Eigencomm specified protocol - PDP Type, such as IP/IPV6/IPV4V6/Non-IP.
<cid>	Integer type; specifies a particular PDP context definition (see the +CGDCONT command).

NOTE

- This AT command is not fully followed the 3GPP 27.007, execution command just trigger MT to activate a PDP context, just same as: +CGACT=1,<cid>.The baud rate needs to be greater than or equal to 57600.
- If PDP activation success, MT issues the result code: OK, not: CONNECT, as not support V.250 online data state now.

3.2.46 AT+CCIOTOPT CloT Optimization Configuration

AT+CCIOTOPT CloT Optimization Configuration

Description	<p>The set command controls which CloT EPS optimizations the UE indicates as supported and preferred in the ATTACH REQUEST and TRACKING AREA UPDATE REQUEST messages. The command also allows reporting of the CloT EPS optimizations that are supported by the network. A UE supporting CloT functionality may support control plane CloT EPS optimization or user plane CloT EPS optimization or both (see 3GPP TS 24.301 [83], subclause 9.9.3.34). Based on the application characteristics the UE may prefer to be registered for control plane CloT EPS optimization or for user plane CloT EPS optimization (see 3GPP TS 24.301 [83], subclause 9.9.3.0B). Further the network may support control plane CloT EPS optimization or user plane CloT EPS optimization or both (see 3GPP TS 24.301 [83], subclause 9.9.3.12A).</p> <p>The set command is used also to control the unsolicited result code +CCIOTOPTI. An unsolicited result code +CCIOTOPTI: <supported_Network_opt> is used to indicate the supported CloT EPS optimizations by the network.</p> <p>current status of unsolicited result code +CCIOTOPTI.</p> <p>The test command returns values supported as compound values.</p>
Test Command AT+CCIOTOPT=?	<p>Response</p> <p>+CCIOTOPT: (list of supported <n>s),(list of supported <supported_UE_opt>s),(list of supported <preferred_UE_opt>s)</p> <p>OK</p>

Read Command AT+CCIOTOPT?	Response +CCIOTOPT: <n>,<supported_UE_opt>,<preferred_UE_opt> OK If error is related to ME functionality: +CME ERROR: <err>
Write Command AT+CCIOTOPT=[<n>[,<supported_UE_opt>[,<preferred_UE_opt>]]]	Response OK If error is related to ME functionality: +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	3GPP TS 27.007 [13]

Defined Values

<n>	Integer type. Enables or disables reporting of unsolicited result code +CCIOTOPTI. 0 Disable reporting. 1 Enable reporting. 3 Disable reporting and reset the parameters for CIoT EPS optimization to the default values.
<supported_UE_opt> >	Integer type; indicates the UE's support for CIoT EPS optimizations. 0 No support. 1 Support for control plane CIoT EPS optimization. 2 Support for user plane CIoT EPS optimization. 3 Support for both control plane CIoT EPS optimization and user plane CIoT EPS optimization.
<preferred_UE_opt>	Integer type; indicates the UE's preference for CIoT EPS optimizations. 0 No preference. 1 Preference for control plane CIoT EPS optimization. 2 Preference for user plane CIoT EPS optimization.
<supported_Network_opt>	Integer type; indicates the Network support for CIoT EPS optimizations. 0 No support. 1 Support for control plane CIoT EPS optimization. 2 Support for user plane CIoT EPS optimization. 3 Support for both control plane CIoT EPS optimization and user plane CIoT EPS optimization.

Example

AT+CCIOTOPT=?

+CCIOTOPT: (0,1,3),(1,3),(0,1,2)

OK

AT+CCIOTOPT?

+CCIOTOPT: 0,3,1

OK

3.2.47 AT+CGCMOD PDP Context Modify

AT+CGCMOD PDP Context Modify

Description	<p>The execution command is used to modify the specified PDP context (s) with respect to QoS profiles and TFTs.</p> <p>After the command has completed, the MT returns to V.250 online data state. If the requested modification for any specified context cannot be achieved, an ERROR or +CME ERROR response is returned. Extended error responses are enabled by the +CMEE command. Refer to Chapter 9: Error Values for possible <err> values. For EPS, the modification request for an EPS bearer resource will be answered by the network by an EPS bearer modification request. The request must be accepted by the MT before the PDP context is effectively changed.</p> <p>If no <cid>s are specified the activation form of the command modifies all active contexts. The test command returns a list of <cid>s associated with active contexts</p>
Test Command AT+CGCMOD=?	<p>Response</p> <p>+CGCMOD: (list of <cid>s associated with active contexts)</p> <p>OK</p>
Write Command AT+CGCMOD[=<cid>[,<cid>[,...]]]	<p>Response</p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	3GPP TS 27.007 [13]

Defined Values

<cid>	Integer type; specifies a particular PDP context definition (see the +CGDCONT command).
-------	---

NOTE

- Could only modify one cid one time.
- Will block other commands when processing.

3.2.48 AT+CGEQOS Define EPS Quality of Service

AT+CGEQOS Define EPS Quality ofService

Description	<p>The set command allows the TE to specify the EPS Quality of Service parameters <cid>, <QCI>, [<DL_GBR> and <UL_GBR>] and [<DL_MBR> and <UL_MBR>] for a PDP context or Traffic Flows (see 3GPP TS 24.301 [83] and 3GPP TS 23.203 [85]). When in UMTS/GPRS the MT applies a mapping function to UMTS/GPRS Quality of Service. Refer to Chapter 9: Error Values for possible <err> values.</p> <p>A special form of the set command, +CGEQOS=<cid> causes the values for context number <cid> to become undefined.</p> <p>The read command returns the current settings for each defined QoS.</p> <p>The test command returns the ranges of the supported parameters as compound values.</p>
Test Command AT+CGEQOS=?	<p>Response</p> <p>+CGEQOS: (range of supported <cid>s),(list of supported <QCI>s),(list of supported <DL_GBR>s),(list of supported <UL_GBR>s),(list of supported <DL_MBR>s),(list of supported <UL_MBR>s)</p> <p>OK</p>
Read Command AT+CGEQOS?	<p>Response</p> <p>[+CGEQOS: <cid>,<QCI>,<DL_GBR>,<UL_GBR>,<DL_MBR>,<UL_MBR>][<CR><LF>+CGEQOS: <cid>,<QCI>,<DL_GBR>,<UL_GBR>,<DL_MBR>,<UL_MBR>] [...]]</p> <p>OK</p>
Write Command AT+CGEQOS=[<cid>,<QCI>,<DL_GBR>,<UL_GBR>,<DL_MBR>,<UL_MBR>]]	<p>Response</p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

3GPP TS 27.007 [13]

Defined Values

<cid>	Integer type; specifies a particular EPS Traffic Flows definition in EPS and a PDP Context definition in UMTS/GPRS (see the +CGDCONT command).
<QCI>	Integer type; specifies a class of EPS QoS 0 QCI is selected by network [1-4] Value range for guaranteed bit rate Traffic Flows 75 Value for guaranteed bit rate Traffic Flows [5-9] Value range for non-guaranteed bit rate Traffic Flows 79 Value for non-guaranteed bit rate Traffic Flows
<DL_GBR>	Integer type; indicates DL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [83]).
<UL_GBR>	Integer type; indicates UL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [83]).
<DL_MBR>	Integer type; indicates DL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [83]).
<UL_MBR>	Integer type; indicates UL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [83]).

3.2.49 AT+CGEQOSRDP EPS Quality of Service Read Dynamic Parameters

AT+CGEQOSRDP EPS Quality of Service Read Dynamic Parameters	
Description	<p>The execution command returns the quality of service parameters <QCI>,[<DL_GBR> and <UL_GBR>] and [<DL_MBR> and <UL_MBR>] of the active secondary or non-secondary PDP context associated to the provided context identifier <cid>.</p> <p>If the parameter <cid> is omitted, the quality of service parameters for all secondary and non-secondary active PDP contexts are returned.</p> <p>The test command returns a list of <cid>s associated with secondary or non-secondary active PDP contexts</p>
Test Command AT+CGEQOSRDP=?	<p>Response</p> <p>+CGEQOSRDP: (list of <cid>s)</p> <p>OK</p>
Write Command AT+CGEQOSRDP [=<cid>]	<p>Response</p> <p>+CGEQOSRDP: <cid>,<QCI>,[<DL_GBR>,<UL_GBR>],[<DL_MBR>,<UL_MBR>][<DL_A MBR>,<UL_AMBR>] [<CR><LF>+CGEQOSRDP:</p>

	<p><cid>,<QCI>,<DL_GBR>,<UL_GBR>,<DL_MBR>,<UL_MBR>,<DL_AMBR>,<UL_AMBR> [...]</p> <p>OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	3GPP TS 27.007 [13]

Defined Values

<cid>	Integer type; specifies a particular EPS Traffic Flows definition in EPS and a PDP Context definition in UMTS/GPRS (see the +CGDCONT command).
<QCI>	<p>Integer type; specifies a class of EPS QoS (see 3GPP TS 23.203 [85] and 3GPP TS 24.301 [83]).</p> <p>0 QCI is selected by network</p> <p>[1 – 4] value range for guaranteed bit rate Traffic Flows</p> <p>75 value for guaranteed bit rate Traffic Flows</p> <p>[5 – 9] value range for non-guaranteed bit rate Traffic Flows</p> <p>79 value for non-guaranteed bit rate Traffic Flows</p> <p>[128 – 254] value range for Operator-specific QCIs</p> <p>The QCI values 65, 66, 69 and 70 are not allowed to be requested by the UE. If the TE requests a QCI parameter 65, 66, 69 or 70, the MT responds with result code +CME ERROR: 181 (unsupported QCI value).</p>
<DL_GBR>	Integer type; indicates DL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [83]).
<UL_GBR>	Integer type; indicates UL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [83]).
<DL_MBR>	Integer type; indicates DL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [83]).
<UL_MBR>	Integer type; indicates UL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [83]).
<DL_AMBR>	Integer type; indicates DL APN aggregate MBR. The value is in kbit/s.
<UL_AMBR>	Integer type; indicates UL APN aggregate MBR. The value is in kbit/s.

NOTE

- Could set <QCI> only and only <QCI>=0 & 5 & 6 & 7 & 8 & 9 & 79 are supported.
- Could execute only when power on and pdp context defined.

3.2.50 AT+CGTFT Traffic Flow Template

AT+CGTFT Traffic Flow Template

Description	<p>This command allows the TE to specify a Packet Filter - PF for a Traffic Flow Template - TFT that is used in the GGSN in UMTS/GPRS and Packet GW in EPS for routing of packets onto different QoS flows towards the TE. The concept is further described in the 3GPP TS 23.060 [47]. A TFT consists of from one and up to 16 Packet Filters, each identified by a unique <packet filter identifier>. A Packet Filter also has an <evaluation precedence index> that is unique within all TFTs associated with all PDP contexts that are associated with the same PDP address.</p> <p>The set command specifies a Packet Filter that is to be added to the TFT stored in the MT and used for the context identified by the (local) context identification parameter, <cid>. The specified TFT will be stored in the GGSN in UMTS/GPRS and Packet GW in EPS only at activation or MS-initiated modification of the related context. Since this is the same parameter that is used in the +CGDCONT command, the +CGTFT command is effectively an extension to these commands. The Packet Filters consist of a number of parameters, each of which may be set to a separate value.</p> <p>A special form of the set command, +CGTFT=<cid> causes all of the Packet Filters in the TFT for context number <cid> to become undefined. At any time there may exist only one PDP context with no associated TFT amongst all PDP contexts associated to one PDP address. At an attempt to delete a TFT, which would violate this rule, an ERROR or +CME ERROR response is returned. Extended error responses are enabled by the +CMEE command. Refer to Chapter 9 for possible <err> values.</p> <p>The read command returns the current settings for all Packet Filters for each defined context.</p> <p>The test command returns values supported as compound values. If the MT supports several PDP types, the parameter value ranges for each PDP type are returned on a separate line. TFTs shall be used for PDP-type IP and PPP only. For PDP-type PPP a TFT is applicable only when IP traffic is carried over PPP. If PPP carries header- compressed IP packets, then a TFT cannot be used.</p>
Test Command AT+CGTFT=?	<p>Response</p> <p>+CGTFT: <PDP_type>,(list of supported <packet filter identifier>s),(list of supported <evaluation precedence index>s),(list of supported <remote address and subnet mask>s),(list of supported <protocol number (ipv4) /next header (ipv6)>s),(list of supported <local port range>s),(list of supported <remote port range>s),(list of supported <ipsec security parameter index (spi)>s),(list of supported <type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask>s),(list of supported <flow label (ipv6)>s),(list of supported <direction>s),(list of supported <local address</p>

	<p>and subnet mask>s)][<CR><LF>+CGTFT: <PDP_type>,(list of supported <packet filter identifier>s),(list of supported <evaluation precedence index>s),(list of supported <remote address and subnet mask>s),(list of supported <protocol number (ipv4) / next header (ipv6)>s),(list of supported <local port range>s),(list of supported <remote port range>s),(list of supported <ipsec security parameter index (spi)>s),(list of supported <type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask>s),(list of supported <flow label (ipv6)>s),(list of supported <direction>s),(list of supported <local address and subnet mask>s)</p> <p>[...]]</p> <p>OK</p>
Read Command AT+CGTFT?	<p>Response</p> <p>[+CGTFT: <cid>,<packet filter identifier>,<evaluation precedence index>,<remote address and subnet mask>,<protocol number (ipv4) / next header (ipv6)>,<local port range>,<remote port range>,<ipsec security parameter index (spi)>,<type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask>,<flow label (ipv6)>,<direction>,<local address and subnet mask>] [<CR><LF>+CGTFT: <cid>,<packet filter identifier>,<evaluation precedence index>,<remote address and subnet mask>,<protocol number (ipv4) / next header (ipv6)>,<local port range>,<remote port range>,<ipsec security parameter index (spi)>,<type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask>,<flow label (ipv6)>,<direction>,<local address and subnet mask></p> <p>[...]]</p> <p>OK</p>
Write Command AT+CGTFT=[<cid>,<packet filter identifier>,<evaluation precedence index>,<remote address and subnet mask>,<protocol number (ipv4) / next header (ipv6)>,<local port range>,<remote port range>,<ipsec securityparameter index (spi)>,<type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask>,<flow label (ipv6)>,<direction>,<local address and subnet mask>]]]]]]]]]]]	<p>Response</p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p>

Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	
3GPP TS 27.007 [13]	

Defined Values

<cid>	Integer type. Specifies a particular PDP context definition (see the +CGDCONT commands).
<PDP_type>	String type. Specifies the type of packet data protocol (see the +CGDCONT command).
	For the following parameters, see also 3GPP TS 23.060 [47]:
<packet identifier>	Integer type. Value range is from 1 to 16.
<evaluation precedence index>	Integer type. The value range is from 0 to 255.
<remote address and subnet mask>	String type. The string is given as dot-separated numeric (0-255) parameters on the form: "a1.a2.a3.a4.m1.m2.m3.m4" for IPv4 or "a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16.m1.m2.m3.m4.m5.m6.m7.m8.m9.m10.m11.m12.m13.m14.m15.m16", for IPv6. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the read form of +CGTFT.
<protocol number (ipv4) / next header (ipv6)>	Integer type. Value range is from 0 to 255.
<local port range>	String type. The string is given as dot-separated numeric (0-65535) parameters on the form "f.t".
<remote port range>	String type. The string is given as dot-separated numeric (0-65535) parameters on the form "f.t".
<ipsec security parameter index (spi)>	Numeric value in hexadecimal format. The value range is from 00000000 to FFFFFFFF.
<type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask>	String type. The string is given as dot-separated numeric (0-255) parameters on the form "t.m".
<flow label (ipv6)>	Numeric value in hexadecimal format. The value range is from 00000 to FFFFF. Valid for IPv6 only.
<direction>	Integer type. Specifies the transmission direction in which the packet filter shall be applied. 0 Pre-Release 7 TFT filter (see 3GPP TS 24.008 [8], table 10.5.162) 1 Uplink 2 Downlink

	<u>3</u> Birectional (Up & Downlink)
<local address and subnet mask>	String type. The string is given as dot-separated numeric (0-255) parameters on the form: "a1.a2.a3.a4.m1.m2.m3.m4" for IPv4 or "a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16.m1.m2.m3.m4.m5.m6.m7.m8.m9.m10.m11.m12.m13.m14.m15.m16", for IPv6. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the read form of +CGTFT.
	Some of the above listed attributes may coexist in a Packet Filter while others mutually exclude each other, the possible combinations are shown in 3GPP TS 23.060 [47].

NOTE

- Could execute only when power on and PDP context defined.
- <local address and subnet mask> is not supported yet.

3.2.51 AT+IPR Set UE Baud Rate

AT+IPR Set UE Baud Rate	
Description	Set command sets the UE baud rate to be used. Read command returns the current baud rate. Test command returns baud rates supported by the UE.
Test Command AT+IPR=?	Response +IPR:(list of supported auto detectable<rate> values),(list of fixed-only<rate>values)
Read Command AT+IPR?	OK Response +IPR:<rate>
Write Command AT+IPR=<rate>	OK Response OK or +CME ERROR: <err>
Parameter Saving Mode	SAVE
Max Response Time	-
Reference	

Defined Values

<rate>	Baud rate at which the UE will accept commands.
---------------------	---

NOTE

If <rate> is 0 for set command, UE will enter auto baud rate detection mode and 'AT' or 'at' shall be sent for baud rate detection.

SIMCom
Confidential

4 AT Commands for General Commands

4.1 Overview of AT Commands for General

Command	Description
AT\$QCBAND	Set Supported Network and Bands.
AT\$QCLOGDBVER	Database Version Information.
AT\$QCCFG	UE Extended Configuration
AT\$QCPING	Test IP Network Connectivity to a Remote Host
AT\$QCFREQ	Lock or Unlock Cell
AT\$QCRMFPLMN	Remove FPLMN in NVM or SIM
AT\$QCATTBEARER	Configure the PDN Info Request to Establish.
AT\$QCSENDDATA	Send Data Via Control Plane or User Plane
+RECVNONIP	Indicate Downlink NON-IP Data.
AT\$QCPMUCFG	Set PMU mode
AT\$QCSMSEND	Send one SMS
AT\$QCCGSN	Sets the IMEI and SN
AT\$QCRFSTAT	Shows the Status of RF Calibration
AT\$QCRST	Restart the Chip
AT\$QCPSMR	Report the Power Saving Mode Status
AT\$QCPLMNS	Used to trigger a PLMN
AT\$QCCESQS	Controls the Extended Signal Quality Change Event Reporting
AT\$QCSTATUS	Returns Some Key Parameter in UE Side
AT\$QCICCID	Causes the TA to Return the ICCID of the UICC
AT\$QCBCINFO	Return the Basic Serving Cell Information
AT\$QCDNS	Get the IP Address for a Specific URL
AT\$QCDNSCFG	Set the Default DNS Addresses Configuration
AT\$QCEMMTIME	Report and Get the Emm Time State
AT\$CPCFG	Set Plat Configure
AT\$QCSLEEP	Power Consumption Test
AT\$QCSIMSLEEP	Set UE to Allow SIM Card Sleep for Power Consumption
AT\$QCCGSNLOCK	Set Lock Flag for IMEI and SN
AT\$QCSAVEFAC	Saves Related Regions to Default Reliable Region
AT\$QCTASKINFO	Returns All the Task's Information
AT\$QCTASKHISTINFO	Shows Most Recent Tasks' Scheduling History
AT\$QCSHOWMEM	Shows Current Heap Memory Usage

AT\$QCSYSTEST	Triggers a Test Feature
AT\$QCVOTECHK	Analyze the Reason of Sleep Failure
AT\$QCURC	Close/Open URC Report
AT\$QCPTWEDRXS	Control Whether the UE
\$QCPIN	Indicate SIM PIN State
\$QPCPFUN	
\$QCPADDR	Print PDP Address
AT\$QCADC	Read ADC
AT\$QCSWC	Set the UE Operation SIM Counter
AT\$QCIPR	Operate the Baud Rate of UE
AT\$CNPICFG	Operating NPI
AT\$QCPRODMODE	Control NPI production mode
AT\$QCLEDMODE	Enable the Netlight Function
AT\$QCPowerCLASS	Sets the Band Power Class

4.2 Detailed Descriptions of Commands

4.2.1 AT\$QCBAND Set Supported Network and Bands

AT\$QCBAND Set Supported Network and Bands	
Description	The command sets the network mode and bands to be used.
Test Command AT\$QCBAND=?	Response \$QCBAND: (list of supported<mode>s),(list of supported<band>s) OK
Read Command AT\$QCBAND?	Response \$QCBAND: <mode>,<band1>,<band2>,... OK
Write Command AT\$QCBAND=<mode>[,<band1>,<band2>...]	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	0 NB-IOT mode(current support NB-IoT only)
<band>	Band list in decimal number:<band> values of 1, 3, 5, 8 are supported.

NOTE

The default value is decided by RF Calibration table.

4.2.2 AT\$QCLOGDBVER Database Version Information

AT\$QCLOGDBVER Database Version Information	
Description	This read command returns current unilog database version information.
Read Command AT\$QCLOGDBVER?	Response \$QCLOGDBVER: <LogDbVserion> OK
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

4.2.3 AT\$QCCFG UE Extended Configuration

AT\$QCCFG UE Extended Configuration	
Description	The command set UE extended configuration. The read command return current setting of each parameters. The test command returns values supported as a compound value.
Test Command AT\$QCCFG=?	Response \$QCCFG: (list of supported<param>s) OK
Read Command AT\$QCCFG?	Response \$QCCFG: <param1>,<value1>,<param2>,<value2>...<paramN>,<valueN> OK
Write Command AT\$QCCFG=<param1>	Response OK

,<value1>[,<param2>,<value2>[,<param3>,<value3>,...]]]	or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<param>	0 NB-IOT mode(current support NB-IoT only)
"AutoApn"	Whether UE auto set the attached APN according to the inserted SIM card. Supported values: (0,1)
"UsimPowerSave"	Enable/disable USIM power save. Supported values: (0,1)
"UsimSimulator"	Enable/disable virtual SIM card for instrument test, such as CMW500. Supported values: (0,1)
"Rohc"	Whether UE support ROHC. Supported values: (0,1)
"Ipv6RsDelay"	Delay in seconds then UE trigger IPv6 NDP (RS) procedure to get IPv6 prefix address. Supported values: (0-65535)
"PowerCfun"	Default CFUN state after UE power-on or reboot; Supported values: (0,1,4) a) If set to 0, UE remain CFUN0 state (neither turn on protocol/RF nor SIM) after power-on or reboot; And could turn on protocol/RF and SIM via AT+CFUN=1 b) If set to 1, UE auto turn on protocol, and connect the network after power-on or reboot; c) If set to 4, UE only turn on SIM, disable (turn off) protocol/RF, after power-on or reboot;
"PsPowerOnMaxDelay"	Max delay in seconds after power on, UE will delay in a random value between 0 to max delay value. Supported values: (0-65535)
"SupportSms"	Whether UE support SMS. Supported values: (0,1)
"TauForSms"	Whether need to trigger TAU procedure, if UE support SMS capability, while NW not support. Supported values: (0,1)
"PlmnSearchPowerLevel"	Set the PLMN search level when UE OOS; Supported values: (0,1,2,3) 0 - OOS PLMN search interval: 30 sec, 1 min, 2 min 1 - OOS PLMN search interval: 5 min, 10 min, 15 min 2 - OOS PLMN search interval: 10 min, 30 min, 1 hour 3 - OOS PLMN search interval: 30 sec, then stop PLMN search, and let AT: AT+QCPMNS to start PLMN search
"EpcO"	Whether UE need to use "EPCO" in "PDN CONNECTION REQUEST" carried in "ATTACH REQUEST", and "ESM INFORMATION RESPONSE"; If set to 0, just use "PCO". Supported values: (0,1)
"T3324MaxValueS"	Set user control T3324 value in second. Support values: (0-0xFFFFFFFF) a) If T3324MaxValueS is smaller than 0xFFFF and network configured T3324 is equal to or greater than T3324MaxValueS (or network not configured

	<p>T3324),use the configured T3324MaxValues</p> <p>b) If T3324MaxValues is smaller than 0xFFFF and network configured T3324 is smaller than T3324MaxValues , use the network configured value</p> <p>c) If T3324MaxValues is equal to or greater than 0xFFFF,just means disable this feature(use network configured value)</p>
"MultiCarrier"	Whether UE support multi-carrier feature.Support values: (0, <u>1</u>)
"MultiTone"	Whether UE support multi-tone feature.Support values: (0, <u>1</u>)
"SupportUpRai"	Whether UE support L2 (MAC layer) RAI feature, which only valid whether set to R14 version. Supported values: (<u>0</u> ,1)
"DataInactTimer"	<p>Set the value of "data inactivity timer" in seconds, if this timer is not configured by NW (in MAC-MainConfig-NB), just use this setting value. Supported value: (0,40-254)</p> <p>a) Default value: 60</p> <p>b) If set to 0, just means this timer is invalid, don't need to start.</p>
"RelaxMonitorDeltaP"	<p>Set the value of "SearchDeltaP" in DB for RelaxMonitor feature. If this value is not configured by NW (in SIB-NB), just use this setting value.</p> <p>Supported values: (0-15). Default value: 6.</p>
"DisableNCellMeas"	Whether UE support NCell measuring feature.Supported values: (<u>0</u> ,1)
"NbCategory"	Set the value of NB-IOT category. Supported values: (<u>1</u> ,2)
"RelVersion"	Set the NB release version. Supported values: (<u>13</u> ,14)
"Ipv6RsForTestSim"	<p>Whether UE trigger IPv6 NDP (RS) procedure to get IPv6 prefix address, when the SIM card inserted is a TEST SIM.</p> <p>Supported values: (0,1)</p> <p>Default value 0.</p> <p>IPv6 NDP (RS) procedure is triggered by default if the inserted SIM card is not for testing.</p>
<CellSearchGuardTimer>	
<PsSoftReset>	
<value>	Value of configuration.

4.2.4 AT\$QCPING Test IP Network Connectivity to a Remote Host

AT\$QCPING Test IP Network Connectivity to a Remote Host

Description	<p>The command sends an ICMP packet to the specified host address. AT\$QCPING initiates the sending of a PING packet with payload size: <size> to the specified address. This will either cause a packet to be returned if the remote system is connected and responding to PING packets or no response will be received. If none of the response packet received within the timeout period <timeout>. It will continue to send PING packet until the <count> number of times.</p>
-------------	--

Test Command AT\$QCPING=?	Response \$QCPING: (list of supported<ipaddr/Url/mode>s),(list of supported<count> s),(list of supported <size>s),(list of supported<timeout>s) OK
Write Command AT\$QCPING=[<ipaddr/Url>/<mode>[,<count>[,<size>[,<timeout>][,rai_enable]]]	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	0 Stop ping
<ipaddr/Url>	String type, IP address or URL
<count>	ping times: 1-255 default value: 4. 255 means all the time Note: default value: 4, 255 means all the time
<size>	Payload size: 1-5000 default value: 32.
<timeout>	UE ping reply timeout after ping request (ms). <timeout> values between 1 to 600000 are supported, and default value: 20000.
<rai_enable>	Integer type, if the value is 1, UE will send the last ping request packet with RAI indication 0-1 Note: default value: 0

NOTE

- When one PING reply received in <timeout>, an unsolicited result code: \$QCPING: SUCC, dest: <dest_ip_addr>, RTT: <rtt_time>ms will sent to TE..
- If no PING reply received in <timeout>, an unsolicited result code: \$QCPING: FAIL, dest: <dest_ip_addr>, time out: <timeout>ms will sent to TE.
- If this is an ERROR meet during PING procedure, an unsolicited result code: \$QCPING: ERROR, Cause: <cause> will send to TE.
- When PING procedure is done, an unsolicited result code: \$QCPING: DONE<CR><LF>\$QCPING:
dest: <dest_ip_addr>, <count> packets transmittted, <reply_count> received, <lost_percent>% packet loss<CR> rtt min/avg/max = <rtt_min> / <rtt_avg> / <rtt_max> ms will send to TE.

4.2.5 AT\$QCFREQ Lock or Unlock Cell

AT\$QCFREQ Lock or Unlock Cell

Description	The command set prefer EARFCN list, lock or unlock cell.
Test Command AT\$QCFREQ=?	Response \$QCFREQ: (list of supported<mode>s) OK
Read Command AT\$QCFREQ?	Response If neither set prefer EARFCN list nor lock EARFCN/cell : OK If set prefer EARFCN list: \$QCFREQ: <1>,<arfcn1>,<arfcn2>,... If lock EARFCN or lock cell: \$QCFREQ: <2>,<arfcn>,<phyCellId> OK If both set prefer EARFCN list and lock EARFCN/cell: \$QCFREQ: <1>,<arfcn1>,<arfcn2>,... \$QCFREQ: <2>,<arfcn>,<phyCellId> OK
Write Command AT\$QCFREQ=<mode> (mode=0) AT\$QCFREQ=<mode>[,<earfcn1>[,<earfcn2> ...]](mode=1) AT\$QCFREQ=<mode>, <earfcn>[,<phyCellId>] (mode2)	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	0 Cancel cell lock 1 Set prefer EARFCN list 2 EARFCN lock, or cell lock
--------	---

	3 Clear prefer EARFCN
<earfcn>	E-UTRA Absolute Radio Frequency Channel Number
<phyCellId>	Physical cell ID

NOTE

AT\$QCFREQ must be restricted to execute in power off or air plane state.

4.2.6 AT\$QCRMFPLMN Remove FPLMN in NVM or SIM

AT\$QCRMFPLMN Remove FPLMN in NVM or SIM

Description	Set command remove FPLMN in NVM or SIM.
Test Command AT\$QCRMFPLMN=?	Response \$QCRMFPLMN: (list of supported<mode>s) OK
Write Command AT\$QCRMFPLMN=<m ode>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	0 Remove FPLMN in NVM file and in SIM card 1 Remove FPLMN in NVM file 2 Remove FPLMN in SIM card
--------	--

4.2.7 AT\$QCATTBEARER Configure the PDN Info Request to Establish

AT\$QCATTBEARER Configure the PDN Info Request to Establish

Description	The set command is used to configure the PDN info request to establish during the attach process, if attach with PDN required.
-------------	--

	<p>The read command is used to obtain the configuration of the PDN info request to establish during the attach process.</p> <p>The test command returns values supported as a compound value.</p>
<p>Test Command</p> <p>AT\$QCATTBEARER=?</p>	<p>Response</p> <p>\$QCATTBEARER: (list of supported<PDP_type>s),(list of supported<eif>s),(list of supported<IPv4AddrAlloc>s),(list of supported<NSLPI>s),(list of supported<IPv4_MTU_discovery>s),(list of supported<NonIP_MTU_discovery>s),(list of supported<auth_proto>s),((userId string),(password string))</p> <p>OK</p>
<p>Read Command</p> <p>AT\$QCATTBEARER?</p>	<p>Response</p> <p>\$QCATTBEARER:<pdnType>,<eif>,<apnStr>,<ipv4allocType>,<NSLPI>,<ipv4Mtu>,<nonIpMtu>,<auth_proto>,<userId>,<password></p> <p>OK</p>
<p>Write Command</p> <p>AT\$QCATTBEARER=<PDP_type>,<eif>[,<apn>,<IPv4AddrAlloc>,<NSLPI>,<IPv4_MTU_discovery>,<NonIP_MTU_discovery>,<auth_proto>,<userId>,<password>]>]]]]]]]</p>	<p>Response</p> <p>OK</p> <p>or</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<PDP_type>	<p>1 IPv4</p> <p>2 IPv6</p> <p><u>3</u> IPv4v6</p> <p>5 NON IP</p>
<eif>	<p>0 Security protected ESM information transfer not required</p> <p><u>1</u> Security protected ESM information transfer required</p>
<apn>	Apn string, the max length is 99 characters;
<IPv4AddrAlloc>	<p><u>0</u> IPv4 address allocate through NAS signaling</p> <p>1 IPv4 address allocate through DHCP (not applicable)</p>
<NSLPI>	<p><u>0</u> indicates that this PDP context is to be activated with the value for the low priority indicator configured in the MT.</p> <p>1 indicates that this PDP context is is to be activated with the value for the low</p>

	priority indicator set to "MS is not configured for NAS signaling low priority".
<IPv4_MTU_discovery>	0 IPv4 MTU size discovery not influenced by \$QCATTBEARER 1 IPv4 MTU size discovery through NAS signaling
<NonIP_MTU_discovery>	0 Non-IP MTU size discovery not influenced by \$QCATTBEARER 1 Non-IP MTU size discovery through NAS signaling
<auth_proto>	0 None. Used to indicate that no authentication protocol is used for this PDP 1 PAP
<userid>	userId string, the max length is 20 characters;
<password>	password string, the max length is 20 characters;

4.2.8 AT\$QCSSENDATA Send Data Via Control Plane or User Plane

AT\$QCSSENDATA Send Data Via Control Plane or User Plane	
Description	The set command could send data via control plane or user plane
Test Command AT\$QCSSENDATA=?	Response \$QCSSENDATA: (range of supported<cid>s),(maximum number of octets of user data indicated by<data_length>),(list of supported<RAI>s),(list of supported<type_of_user_data>s)
Write Command AT\$QCSSENDATA=<cid>,<data_length>,<data>[,<RAI>[,<type_of_user_data>]]	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<cid>	Integer type; specifies a particular PDP context definition.
<data_length>	Integer type. Indicates the number of octets of the <data>information element. The max length is 950.
<data>	String of octets.
<RAI>	0 No information available 1 The MT expects that exchange of data will be completed with the transmission of this UL packet. 2 The MT expects that exchange of data will be completed with the receipt of a DL packet.
<type_of_user_data>	0 Regular data

1 Exception data

NOTE

Difference with AT+CSODCP, AT+CSODCP limit to transmit data over control plane to network, but this AT don't have such limitation.

4.2.9 +RECVNONIP Indicate Downlink NON-IP Data

+RECVNONIP Indicate Downlink NON-IP Data

Description	This is an unsolicited code message used to indicate downlink NON-IP data. +RECVNONIP: <cid>,<data_length>,<data>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<cid>	Integer type; specifies a particular PDP context definition. <cid> values of 1-11 are supported.
<data_length>	Integer type. Indicates the number of octets of the <data> information element.
<data>	string of octets.

4.2.10 AT\$QCPMUCFG Set PMU mode

AT\$QCPMUCFG Set PMU mode

Description	The command set PMU mode. Read command returns the current setup. Test command returns values supported as a compound value.
Test Command AT\$QCPMUCFG=?	Response \$QCPMUCFG: (range of supported<enable>s),(list of supported<mode>s) OK
Read Command	Response

AT\$QCPMUCFG?	\$QCPMUCFG: <enable>[,<mode>]
	OK
Write Command AT\$QCPMUCFG=<enable>[,<mode>]	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<ENABLE>	0 Disable the PMU, <mode> will be ignored and only enter idle 1 Enable the PMU
<MODE>	0 Active 1 Idle 2 Sleep1 3 Sleep2 4 Hibernate

4.2.11 AT\$QCSMSEND Send one SMS

AT\$QCSMSEND Send one SMS	
Description	The command is used to send one SMS. Currently we only support TEXT mode.
Write Command AT\$QCSMSEND=<mode>,<da>[,<toda>,<test_sms>]	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	1 TEXT mode
<da>	destination for TXT mode
<toda>	integer type; Type of destination address

<test_sms>	Message's content for TXT mode
------------	--------------------------------

4.2.12 AT\$QCCGSN Sets the IMEI and SN

AT\$QCCGSN Sets the IMEI and SN

Description	The command is used to send one SMS. Currently we only support TEXT mode.
Test Command AT\$QCCGSN=?	Response \$QCCGSN: (list of supported<type>s),(data) OK
Write Command AT\$QCCGSN=<type>,<sn/imei>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<type>	Can be "IMEI" or "SN"
<sn/imei>	SN(31bytes maximum as visable character)

4.2.13 AT\$QCRFSTAT Shows the Status of RF Calibration

AT\$QCRFSTAT Shows the Status of RF Calibration

Description	The command shows the status of RF calibration.
Read Command AT\$QCRFSTAT?	Response \$QCRFSTAT: calibrate done OK If RF is not calibrated, response: \$QCRFSTAT: not calibrate
Execute Command AT\$QCRFSTAT	Response \$QCRFSTAT: calibrate done

	OK If RF is not calibrated, response: \$QCRFSTAT: not calibrate
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

4.2.14 AT\$QCRST Restart the Chip

AT\$QCRST Restart the Chip	
Description	The command restart the chip.
Execution Command AT\$QCRST	Response OK
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

4.2.15 AT\$QCPSMR Report the Power Saving Mode Status

AT\$QCPSMR Report the Power Saving Mode Status	
Description	The command report the power saving mode status.
Test Command AT\$QCPSMR=?	Response \$QCPSMR: (range of supported<n>s) OK
Read Command AT\$QCPSMR?	Response \$QCPSMR: <n>,<mode> OK or +CME ERROR: <err>
Write Command AT\$QCPSMR=<n>	Response OK or +CME ERROR: <err>

Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<n>	0: disable unsolicited result code 1: enable unsolicited result code +QCPSMR: <mode>
<mode>	0: normal mode 1: power saving mode

4.2.16 AT\$QCPLMNS Used to trigger a PLMN

AT\$QCPLMNS Used to trigger a PLMN	
Description	Set command is used to trigger a PLMN search while UE is out of service, if UE is not out of service, +CME ERROR: <err> is returned. Read command returns the current PLMN search state, and the reset of time of PLMN search timer.
Test Command AT\$QCPLMNS=?	Response OK
Read Command AT\$QCPLMNS?	Response \$QCPLMNS: <state>[,<oosTimeStep>] OK
Execute Command AT\$QCPLMNS	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<state>	0 Deactivated, no PLMN search is ongoing 1 Searching, PLMN search is ongoing 2 Selected, already selected a PLMN 3 OOS, UE is out of service and has started a PLMN search timer
---------	---

<oosTimeStep>	Integer type. The rest of time (in seconds) of OOS PLMN search timer, only present when <state> is 3.
---------------	---

4.2.17 AT\$QCCESQS Controls the Extended Signal Quality Change Event Reporting

AT\$QCCESQS Controls the Extended Signal Quality Change Event Reporting	
Description	The set command controls the extended signal quality change event reporting. If reporting is enabled the MT returns the unsolicited result codes: +CESQ: <rxlev>,<ber>,<rscp>,<ecno>,<rsrq>,<rsrp> , or \$QCCESQ: RSRP,<rsrp>,RSRQ,<rsrq>,SNR,<snr> whenever the extended signal quality is changed. If setting fails in an MT error, +CME ERROR: <err> is returned.
Test Command AT\$QCCESQS=?	Response \$QCCESQS: (list of supported<report level>s)
Read Command AT\$QCCESQS?	Response \$QCCESQS: <report level> OK
Execution Command AT\$QCCESQS=<report level>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<report level>	0 disable unsolicited report. 1 report +CESQ: <rxlev>,<ber>,<rscp>,<ecno>,<rsrq>,<rsrp> 2 report \$QCCESQ: RSRP,<rsrp>,RSRQ,<rsrq>,SNR,<snr>
<rxlev>	99 not known or not detectable
<ber>	99 not known or not detectable
<rscp>	255 not known or not detectable
<ecno>	255 not known or not detectable
<rsrp>	For +CESQ reporting, refer to sub clause 2.2.9 AT+CESQ For \$QCCESQ reporting, the range is -34 dB to 2.5 dB

<rsrq>	For +CESQ reporting, refer to sub clause 2.2.9 AT+CESQ For \$QCCESQ reporting, the range is -34 dB to 2.5 dB
<snr>	The range is -30 dB to 30 dB

4.2.18 AT\$QCSTATUS Returns Some Key Parameter in UE Side

AT\$QCSTATUS Returns Some Key Parameter in UE Side	
Description	This action command returns some key parameter in UE side.
Test Command AT\$QCSTATUS=?	Response \$QCCESQS: (list of supported<report level>s) OK
Execution Command AT\$QCSTATUS	Response \$QCSTATUS: PHY, DLEarfcn:<dLEarfcn>, ULEarfcn:<uLEarfcn>, PCI:<pci>, Band:<band>, RSRP:<rsrp>, RSRQ:<rsrq>, SNR:<snr>, AnchorFreqOfst:<freqOfst>, NonAnchorFreqOfst:<freqOfst>, CeLevel:<ceLevel>, DIBler:<dIBler>, UIBler:<uIBler>, DataInactTimerS:<dataInactTimers>, RetxBSRTimerP:<retxBSRTimerP>, TAValue:<taValue>, TxPower<txPower>, NBMode:<nbMode> \$QCSTATUS: L2, SrbNum:<srbNum>, DrbNum:<drbNum> \$QCSTATUS: RRC, State:<rrcState>, TAC:<tac>, CellId:<cellId> \$QCSTATUS: EMM, EmmState:<emmState>, EmmMode:<emmMode>, PTWMS:<ptwMs>, EDRXPeriodMs:<eDRXPeriodMs>, PsmExt3412TimerS:<psmExt3412TimerS>, T3324TimerS:<T3324TimerS>, T3346RemainTimeS:<T3346RemainTimeS> \$QCSTATUS: PLMN, PlmnState:<plmnState>, PlmnType:<plmnType>, SelectPlmn:<selectPlmn> \$QCSTATUS: ESM, ActBearerNum:<actBearerNum>, APN:<apn>, IPv4:<ipaddr> \$QCSTATUS: CCM, Cfun:<cfun>, IMSI:<imsi> OK
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<dlEarfcn>	Downlink earfcn, value range is 0~262143
<ulEarfcn>	Uplink earfcn, value range is 0~262143
<pci>	Physical cell ID, value range is 0~503,255
<band>	Band, value range is 0~70
<rsrp>	Value in dBm, range is -156dBm ~ -44dBm
<rsrq>	Value in dB, range is -34dB ~ -2.5dB
<snr>	Value in dB, range is -30dB ~ 30dB
<ceLevel>	0 CE level 0 1 CE level 1 2 CE level 2
<dIBler>	Downlink block error, value range is 0~10000
<ulBler>	Uplink block error, value range is 0~10000
<dataInactTimerS>	Data inactive timer in seconds, value range is 0~180
<retxBSRTimerP>	Timer for BSR reporting, value in number of PDCCH periods. Value pp4 corresponds to 4 PDCCH periods, pp16 corresponds to 16 PDCCH periods and so on.
<NBMode>	Value range is "InBand Same PCI","InBand Diff PCI","Guard Band","Stand alone"
<srNum>	Value range is 0~2
<drbNum>	Value range is 0~2
<rrcState>	Value range is "DEACT", "OOS", "IDLE", "SUSPEND IDLE", "CONNECTED", "UNKONWN"
<tac>	Value range is 0~65534
<cellId>	Value range is 0~268435455
<emmState>	Value range is "NULL", "DEREG", "REG INIT", "REG", "DEREG INIT", "TAU INIT", "SR INIT", "UNKNOWN"
<emmMode>	Value range is "IDLE", "PSM", "CONNECTED", "UNKNOWN"
<ptwMs>	eDRX Paging Time Window in milliseconds
<edrxPeriodMs>	eDRX period in milliseconds
<psmExT3412TimerS>	Extended T3412 timer value in seconds
<T3324TimerS>	T3324 timer value in seconds
<T3346RemainTimeS>	If T3346 is running, set to the remaining time, else set to 0
<plmnState>	Value range is "NO PLMN", "SEARCHING", "SELECTED", "UNKNOWN"
<plmnType>	Value range is "HPLMN", "EHPLMN", "VPLMN", "UPLMN", "OPLMN", "UNKNOWN"
<selectPlmn>	Selected PLMN
<actBearerNum>	activated bearer number
<apn>	access point name
<Ipv4Addr	Ipv4/Ipv6 address

ipv6Addr>	
<fun>	0 Minimum functionality 1 Full functionality 4 Turn off RF
<IMSI>	International Mobile Subscriber Identity (string with double quotes)
<AnchorFreqOfst>	Integer type Range is 0 ~ 21, stand for Frequency Offset {Invalid, -10,-9,-8,-7,-6,-5,-4,-3,-2,-1,-0.5,0,1,2,3,4,5,6,7,8,9}
<NonAnchorFreqOfst>	Integer type Range is 0 ~ 21, stand for Frequency Offset {Invalid, -10,-9,-8,-7,-6,-5,-4,-3,-2,-1,-0.5,0,1,2,3,4,5,6,7,8,9}
<taValue>	Integer type Timing advance value. Value range is 0~1282. -1 is invalid value
<txPower>	Integer type Current TX power level in dBm. Value range is -45~23. -128 is invalid value

4.2.19 AT\$QCICCID Causes the TA to Return the ICCID of the UICC

AT\$QCICCID Causes the TA to Return the ICCID of the UICC

Description	Execution command causes the TA to return the ICCID of the UICC.
Test Command AT\$QCICCID=?	Response OK
Execution Command AT\$QCICCID	Response \$QCICCID: <ICCID> OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<ICCID>	Integrated circuit card identification
----------------------	--

4.2.20 AT\$QCBCINFO Return the Basic Serving Cell Information

AT\$QCBCINFO Return the Basic Serving Cell Information	
Description	Execution command to return the basic serving cell information and neighbor cells information, mainly used for location service.
Test Command AT\$QCBCINFO=?	Response \$QCBCINFO: [(list of supported<mode>s)[,(list of supported<timeoutS>s)[,(list of supported<save_for_last>s)[,(list of supported<max_cell_number>s)[,(list of supported<report_mode>s)]]]]] OK
Execution Command AT\$QCBCINFO	Response \$QCBCINFOSC: <earfcn>,<pci>,<rsrp>,<rsrq>,<mcc>,<mnc>,<cellid>[<CR><LF> \$QCBCINFONC: <earfcn>,<pci>,<rsrp>,<rsrq>,<tac>[...]] OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	<p>0 Only search/measure neighbor cell signal quality: RSRP and RSRQ, don't acquire neighbor cell SIB-NB, don't return cell location information. In this mode, neighbor cell information in AT response is: \$QCBCINFONC: <earfcn>,<pci>,<rsrp>,<rsrq></p> <p>Note: default value 0</p> <p>1 Search cell, including measure cell and acquire cell SIB1-NB to get cellID, PLMN and tac info. In this mode, neighbor cell information in AT response is: \$QCBCINFONC: <earfcn>,<pci>,<rsrp>,<rsrq>,<mcc>,<mnc>,<cellid>,<tac></p> <p>2 Read saved cell information, <save_for_later> set to 1 should be called before, and otherwise, no cell information will be returned.</p>
<timeoutS>	<p>Integer type</p> <p>MAX measurement time in unit of seconds, cell information should be acquired/returned in this time period.</p> <p>Note:</p> <ol style="list-style-type: none"> Range: (4-300) Default value: 8
<save_for_later>	Integer type

	<p>Whether need to save cell information, which could be returned in case of AT+QCBCINFO=2 later.</p> <p>Note:</p> <ol style="list-style-type: none"> 1. As the cell information should be saved into flash when enter deep sleep mode: sleep2 and HIB, don't suggest to save it frequently. 2. List value: (0,1) 3. Default value: 0, not save.
<max_cell_number>	<p>Integer type</p> <p>Max number of cells to be measured or searched, including serving cell.</p> <p>Note:</p> <ol style="list-style-type: none"> 1. The more cells needed, the longer measurement time it takes. 2. Range: (1-5) 3. Default value: 5
<report_mode>	<p>Integer type</p> <p>0 Synchronous modes. Report cell info in AT response.</p> <p>Note: Default value: 0</p> <p>1 Asynchronous mode. AT response immediately, measured cell information returned in URC:</p> <p>[<CR><LF>\$QCBCINFOSC: <earfcn>,<pci>,<rsrp>,<rsrq>,<mcc>,<mnc>,<cellid>,<tac>[<CR><LF> [<CR><LF>\$QCBCINFONC: <earfcn>,<pci>,<rsrp>,<rsrq>[,<mcc>,<mnc>,<cellid>,<tac>] [...]]</p>
<earfcn>	Indicate the EARFCN of the cell. Range 0 ~ 262143
<pci>	Indicate the physical cell ID. Range 0 ~ 503
<rsrp>	Indicate the measurement of RSRP value, in unit of dBm. Range -156 ~ -44
<rsrq>	Indicate the measurement of RSRQ value, in unit of dB. Range -34 ~ 25
<mcc>	Indicate the mobile country code
<mnc>	Indicate the mobile network code
<cellid>	Four byte E-UTRAN cell ID in hexadecimal format
<tac>	<p>String type</p> <p>Two byte tracking area code in hexadecimal format</p>

4.2.21 AT+QCDNS Get the IP Address for a Specific URL

AT+QCDNS Get the IP Address for a Specific URL

Description	This command to get the IP address for a specific URL. As a limitation now, only one IP address is returned for a URL
-------------	---

Test Command AT\$QCDNS=?	Response OK
Execution Command AT\$QCDNS=<url>	Response \$QCDNS: <ipaddr> OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<url>	Domain name
<ipaddr>	If IPv4 type, output is dot-notation format, such as: "32.1.13.184" If IPv6 type, output is colon-notation format, such as: "2001:0DB8:0000:CD30:0000:0000:0000:0002"

4.2.22 AT\$QCDNSCFG Set the Default DNS Addresses Configuration

AT\$QCDNSCFG Set the Default DNS Addresses Configuration	
Description	This command to get the IP address for a specific URL. As a limitation now, only one IP address is returned for a URL
Test Command AT\$QCDNSCFG=?	Response OK
Read Command AT\$QCDNSCFG?	Response \$QCDNSCFG: <ipaddr1>[,<ipaddr2>[,<ipaddr3>[,<ipaddr4>]]] OK
Execution Command AT\$QCDNSCFG=<ipaddr1>[,<ipaddr2>[,<ipaddr3>[,<ipaddr4>]]]	Response OK or +CME ERROR: <err>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	

Defined Values

<ipaddr>	<p>If IPv4 type, output is dot-notation format, such as: "32.1.13.184"</p> <p>If IPv6 type, output is colon-notation format, such as: "2001:0DB8:0000:CD30:0000:0000:0000:0002"</p>
-----------------------	---

4.2.23 AT\$QCEMMTIME Report and Get the Emm Time State

AT\$QCEMMTIME Report and Get the Emm Time State	
Description	This command report and get the Emm Time State, include T3346、T3448 and T3412/extend T3412.
Test Command AT\$QCEMMTIME=?	<p>Response</p> <p>\$QCEMMTIME: (range of supported<bitmap>s)</p> <p>OK</p>
Read Command AT\$QCEMMTIME?	<p>Response</p> <p>\$QCEMMTIME:0,<timeState>[,<remainTimeValue>] \$QCEMMTIME:1,<timeState>[,<remainTimeValue>] \$QCEMMTIME:2,<timeState>[,<remainTimeValue>]</p> <p>OK</p>
Write Command AT\$QCEMMTIME=<bit map>	<p>Response</p> <p>OK</p> <p>or</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<bitmap>	<p>bit 0: enable/disable unsolicited result code T3346</p> <p>bit 1: enable/disable unsolicited result code T3448</p> <p>bit 2: enable/disable unsolicited result code T3412/ext T3412</p>
<timeld>	<p>0: Emm Timer: T3346</p> <p>1: Emm Timer: T3448</p> <p>2: Emm Timer: T412/ext T3412</p>
<timeState>	<p>0: Start</p> <p>1: Stop</p> <p>2: Expiry</p>
<remainTimeValue>	Time remain value in seconds, Only include when <timeState> is 0.
<timeValue>	Time value in seconds, Only include when <timeState> is 0.

4.2.24 AT\$QCPCFG Set Plat Configure

AT\$QCPCFG Set Plat Config	
Description	Set command is used to set plat config, if UE is not out of service, +CME ERROR: <err> is returned. Read command returns the current plat config setting.
Test Command AT\$QCPCFG=?	Response \$QCPCFG:<option>,<setting> OK
Read Command AT\$QCPCFG?	Response \$QCPCFG: < option>,< setting>,< option>,< setting>,... OK
Write Command AT\$QCPCFG=<option>,<setting>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	SAVE
Max Response Time	-
Reference	

Defined Values

<option>	faultAction	Set the hardfault action mode
	dumpToATPort	Set show assert dump in AT port or not
<setting>	startWDT	Set watch dog mode
	logCtrl	Set log control mode
	logLevel	Set log print level
	logBaudrate	Set log print baud rate
	slpWaitTime	Set sleep wait time
		For faultAction, the values range is from 0 to 4 0: dump full exception info to flash and EPAT tool then trapped in endless loop 1: print necessary exception info then reset 2: dump full exception info to flash then reset 3: dump full exception info to flash and EPAT tool then reset 4: reset directly. Suggest set to this value when mass production stage. For dumpToATPort, the values range is from 0 to 1 0: not dump to AT port 1: dump to AT port

For startWDT, the values range is from 0 to 1
 0: stop WDT
 1: start WDT. Suggest set to this value when mass production stage.

For logCtrl, the values range is from 0 to 2
 0: unilog is disabled
 1: only sw log is enabled
 2: All log is enabled

For logLevel, the values range is from 0 to 5
 0: debug log level
 1: info log level
 2: value log level
 3: signal log level
 4: warning log level
 5: error log level

For logBaudrate, the values range is from 921600 to 6000000.
 Default value is 3000000.

For slpWaitTime, the values range is from 0 to 0xffff
 Default value is 0.

4.2.25 AT\$QCSLEEP Power Consumption Test

AT\$QCSLEEP Power Consumption Test

Description	This command is used for power consumption test. After executing this command, UE will enter related low power state. And UE could be wake up by wakeup PAD, after wake up, UE will reboot.
Test Command AT\$QCSLEEP=?	Response \$QCSLEEP: <state> OK
Write Command AT\$QCSLEEP=<state>	Response \$QCSLEEP: <mode> OK or +CME ERROR: <err>
Parameter Saving Mode	SAVE
Max Response Time	-
Reference	

Defined Values

<state>	0 HIB2
---------	--------

	1 HIB1 2 SLEEP2 3 SLEEP1
<mode>	HIB2 Hibernate2 status HIB1 Hibernate1 status SLEEP2 Sleep2 status SLEEP1 Sleep1 status

4.2.26 AT\$QCSIMSLEEP Set UE to Allow SIM Card Sleep for Power Consumption

AT\$QCSIMSLEEP Set UE to Allow SIM Card Sleep for Power Consumption	
Description	The command set UE to allow SIM card sleep for power consumption. The read command return current setting of each parameters. The test command returns values supported as a compound value.
Test Command AT\$QCSIMSLEEP=?	Response \$QCSIMSLEEP: <mode>
Write Command AT\$QCSIMSLEEP=<mode>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	0 Not allowed SIM sleep 1 Allowed SIM sleep
--------	--

4.2.27 AT\$QCCGSNLOCK Set Lock Flag for IMEI and SN

AT\$QCCGSNLOCK Set Lock Flag for IMEI and SN	
Description	This command is used to set lock flag for IMEI and SN. If locked, IMEI and SN could not be write via AT\$QCCGSN command. The lock feature maybe required in production stage, to prevent customer's miss operation. If lock is

	set, it could not be cleared via AT command, the only way to clear it is via flash tool (erase related region).
Test Command AT\$QCCGSNLOCK=?	Response \$QCCGSNLOCK: <list of support para> OK
Read Command AT\$QCCGSNLOCK?	Response \$QCCGSNLOCK: <imeistatus,snstatus> OK or +CME ERROR: <err>
Write Command AT\$QCCGSNLOCK=<p para>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	SAVE
Max Response Time	-
Reference	

Defined Values

<para>	"IMEI" "SN"
<imeistatus>	"IMEI LOCKED" "IMEI NOT LOCKED "
<snstatus>	"SN LOCKED" "SN NOT LOCKED "

4.2.28 AT\$QCSAVEFAC Saves Related Regions to Default Reliable Region

AT\$QCSAVEFAC Saves Related Regions to Default Reliable Region

Description	This command is used in production line, which saves related regions to default reliable region.e.g. after IMEI/SN was written or RF calibration was done. Default reliable regions is used to restore factory setting.
Test Command AT\$QCSAVEFAC=?	Response \$QCSAVEFAC: <mode> OK

Write Command AT\$QCSAVEFAC=<mode>	Response \$QCSAVEFAC:OK OK or +CME ERROR: <err>
Parameter Saving Mode	SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	"all" All regions "rfregion" Only RF regions "other" Regions except RF, currently IMEI/SN region
--------	--

4.2.29 AT\$QCTASKINFO Returns All the Task's Information

AT\$QCTASKINFO Returns All the Task's Information	
Description	The execution command returns all the task's name, id, status, priority and stack information. This command is only for debug purpose.
Execution Command AT\$QCTASKINFO	Response <task information> OK
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

4.2.30 AT\$QCTASKHISTINFO Shows Most Recent Tasks' Scheduling History

AT\$QCTASKHISTINFO Shows Most Recent Tasks' Scheduling History	
Description	The execution command shows most recent tasks' scheduling history. This command is only for debug purpose.
Execution Command AT\$QCTASKHISINFO	Response \$QCTASKHISINFO: <task scheduling history> OK
Parameter Saving Mode	NO_SAVE

Max Response Time	-
Reference	

4.2.31 AT\$QCSHOWMEM Shows Current Heap Memory Usage

AT\$QCSHOWMEM Shows Current Heap Memory Usage	
Description	The execution command shows current heap memory usage. This command is only for debug purpose.
Execution Command AT\$QCSHOWMEM	Response curr_free_heap:<curr_free_heap>, min_free_heap:<min_free_heap> OK
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<curr_free_heap>	0—heap size current remained free memory size in heap
<min_free_heap>	0---heap size minimum heap memory size ever remaining in heap

4.2.32 AT\$QCSYSTEST Triggers a Test Feature

AT\$QCSYSTEST Triggers a Test Feature	
Description	This command is only for debug purpose. The test command returns option supported as a compound value. The set command triggers a test feature..
Test Command AT\$QCSYSTEST=?	Response \$QCSYSTEST: <option> OK
Write Command AT\$QCSYSTEST=<option>	Response OK or When <test>="assert" or "fsassert" system assert +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-

Reference

Defined Values

<option>	handshake	Perform handshake with UE
	assert	Trigger a test assert
	testwdt	Trigger watch dog test
	fsassert	Trigger file system assert for test
	hardfault	Trigger a hardfault for test

4.2.33 AT\$QCVOTECHK Analyze the Reason of Sleep Failure

AT\$QCVOTECHK Analyze the Reason of Sleep Failure	
Description	This command shows current vote state, which can help to analyze the reason of sleep failure. This command is only for debug purpose.
Write Command AT\$QCVOTECHK	Response Sleep Vote Info: <vote info detail> OK
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

NOTE

- Vote info detail shows comprehensive information which will affect sleep process in QCX212.
Part1: user set sleep depth limitation.
Part2: QCX212 internal sleep vote result.
Part3: application vote result.
Part4: user registered sleep depth callback.
Part5: driver vote result.
- For more detail information, please refer to slpman_qcx212.h in SDK and QCX212 low power development manual.

4.2.34 AT\$QCURC Close/Open URC Report

AT\$QCURC Close/Open URC Report

Description	The command close/open URC (unsolicited result code) report.
Test Command AT\$QCURC=?	<p>Response</p> <p>\$QCURC: "ALL":(0-1), "CREG":(0-1), "CEREG":(0-1), "CEDRXP":(0-1), "CCIOTOPTI":(0-1), "CSCON":(0-1), "CTZEU":(0-1), "QCCESQ":(0-1), "CGEV":(0-1), "QCPSMR":(0-1), "QCPTWEDRXP":(0-1), "QCPIN":(0-1), "QCPADDR":(0-1), "QCPCFUN":(0-1)</p> <p>OK</p>
Read Command AT\$QCURC?	<p>Response</p> <p>\$QCURC:</p> <p>"ALL":(0-1), "CREG":(0-1), "CEREG":(0-1), "CEDRXP":(0-1), "CCIOTOPTI":(0-1), "CSCON":(0-1), "CTZEU":(0-1), "QCCESQ":(0-1), "CGEV":(0-1), "QCPSMR":(0-1), "QCPTWEDRXP":(0-1), "QCPIN":(0-1), "QCPADDR":(0-1), "QCPCFUN":(0-1)</p> <p>OK</p> <p>or</p> <p>+CME ERROR: <err></p>
Write Command AT\$QCURC=<option>, <value>	<p>Response</p> <p>OK</p> <p>or</p> <p>+CME ERROR: <err></p>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	

Defined Values

<option>	<p>"ALL" All unsolicited result codes included as below</p> <p>"CREG" unsolicited result code +CREG</p> <p>"CEREG" unsolicited result code +CEREG</p> <p>"CEDRXP" unsolicited result code +CEDRXP</p> <p>"CCIOTOPTI" unsolicited result code +CCIOTOPTI</p> <p>"CSCON" unsolicited result code +CSCON</p> <p>"CTZEU" unsolicited result code +CTZEU</p> <p>"QCCESQ" unsolicited result code \$QCCESQ</p> <p>"CGEV" unsolicited result code +CGEV</p> <p>"QCPSMR" unsolicited result code \$QCPSMR</p> <p>"QCPTWEDRXP" unsolicited result code \$QCPTWEDRXP</p> <p>"QCPIN" unsolicited result code \$QCPIN</p>
----------	---

	"QCPADDR" unsolicited result code \$QCPADDR "QCPCFUN" unsolicited result code \$QCPCFUN
<value>	0 disable unsolicited result code report 1 enable unsolicited result code report

NOTE

Set of <value> will save to NVM, and the default value is 0.

4.2.35 AT\$QCPTWEDRXS Control Whether the UE

AT\$QCPTWEDRXS Control Whether the UE	
Description	A special form of the command can be given as AT\$QCPTWEDRXS=3. In this form, paging time window and eDRX will be disabled and data for all parameters in AT\$QCPTWEDRXS command will be removed.
Test Command AT\$QCPTWEDRXS=?	Response \$QCPTWEDRXS: (list of supported<mode>s),(list of supported<AcT-type>s),(list of supported<Requested_Paging_time_window>s),(list of supported<Requested_eDRX_value>s) OK
Read Command AT\$QCPTWEDRXS?	Response \$QCPTWEDRXS: <AcT-type>,<Requested_Paging_time_window>,<Requested_eDRX_value>[,<NW_provided_eDRX_VALUE>[,<Paging_time_window>]] OK
Write Command AT\$QCPTWEDRXS=[<mode>,<AcT-type>,<Requested_Paging_time_window>,<Requested_eDRX_value>]]]	Response OK or +CME ERROR: <err>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	<p>0 Disable the use of requested paging time window and eDRX</p> <p>1 Enable the use of requested paging time window and eDRX</p> <p>2 Enable the use of requested paging time window and eDRX and enable the unsolicited result code:</p> <p>\$QCPTWEDRXP: <AcT-type>[,<Requested_Paging_time_window>[,<Requested_eDRX_value>[,<NWprovided_eDRX_value>[,<Paging_time_window>]]]</p> <p>3 Disable the use of paging time window and eDRX and discard all parameters for pagint time window and eDRX.</p>
<AcT-type>	5 NB IOT
<Requested_Paging_time_window>	String type; half a byte in a 4 bit format. The paging time window refers to bit 8 to 5 of octet 3 of the Extended DRX parameters information element. (e.g. "0000" equals 2.56 seconds)
<Requested_eDRX_value>	String type; half a byte in a 4-bit format. The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element. (e.g. "0010" equals 20.48 seconds)
<NW-provided_eDRX_value>	String type; half a byte in a 4-bit format. The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element. (e.g. "0010" equals 20.48 seconds)
<Paging_time_window>	String type; half a byte in a 4 bit format. The paging time window refers to bit 8 to 5 of octet 3 of the Extended DRX parameters information element. (e.g. "0000" equals 2.56 seconds)

4.2.36 \$QCPIN Indicate SIM PIN State

\$QCPIN Indicate SIM PIN State

Description	<p>This is an unsolicited result code used to indicate SIM PIN state. It's controlled by AT\$QCURC.</p> <p>\$QCPIN: <code></p>
-------------	---

Defined Values

<code>	<p>READY MT is not pending for any password</p> <p>SIM PIN MT is waiting SIM PIN to be given</p> <p>SIM PUK MT is waiting SIM PUK to be given</p> <p>SIM PUK BLOCKED The SIM is locked</p> <p>SIM NOT READY The SIM is not ready.</p>
---------------------	---

4.2.37 \$QCPCFUN Power on status URC report

\$QCPCFUN Power on status URC report

Description	This is an unsolicited result code used to indicate the setting of <fun> as AT+CFUN when the MT powered on. It's controlled by AT\$QCURC.
	\$QCPCFUN: <fun>

Defined Values

<fun>	0 Minimum functionality 1 Full functionality 4 Turn off RF.
-------	---

4.2.38 \$QCPADDR Print PDP Address

\$QCPADDR Print PDP Address

Description	This is an unsolicited result code used to indicate SIM PIN state. It's controlled by AT\$QCURC.
	\$QCPADDR: <cid>[,<PDP_addr_1>[,<PDP_addr_2>]]

Defined Values

<cid>	specifies a particular PDP context definition (see the +CGDCONT commands). <cid> values of 1-11 are supported.
<PDP_addr_1> <PDP_addr_2>	<PDP_addr_1> and <PDP_addr_2>: each is a string type that identifies the MT in the address space applicable to the PDP. Both <PDP_addr_1> and <PDP_addr_2> are omitted if none is available. Both <PDP_addr_1> and <PDP_addr_2> are included when both IPv4 and IPv6 addresses are assigned, with <PDP_addr_1> containing the IPv4 address and <PDP_addr_2> containing the IPv6 address. The string is given as dot-separated numeric (0-255) parameter of the form: a1.a2.a3.a4 for IPv4 and colon-separated hexadecimal parameter of the form:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx for IPv6.

4.2.39 AT\$QCADC Read ADC

AT\$QCADC Read ADC

Description	This command is used to get thermal temperature and VBAT values sampled by ADC.
Test Command AT\$QCADC=?	Response \$QCADC: <option> OK
Write Command AT\$QCADC=<option>	Response \$QCADC: <option>, <value>[,<option> ,<value>] OK
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<option>	Temp Get current thermal temperature in unit of degree centigrade with 1 degree resolution. Vbat Get current VBAT value in unit of mV. All Get current thermal temperature and VBAT value.
<value>	Corresponding value of option

4.2.40 AT\$QCSWC Set the UE Operation SIM Counter

AT\$QCSWC Set the UE Operation SIM Counter

Description	The command set UE to enable, disable, query and reset SIM write counter. The counter record the execution of SIM write command, such as update binary and update record
Test Command AT\$QCSWC=?	Response \$QCSWC: (list of supported <mode>s) OK
Read Command AT\$QCSWC?	Response \$QCSWC: <mode> OK
Write Command AT\$QCSWC=<mode>	Response OK or +CME ERROR: <err>

	When <mode>=2 and command successful: \$QCSWC: <filename>,<counter> \$QCSWC: <filename>,<counter> ... OK
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<mode>	0 Disable the SIM write counter 1 Enable the SIM write counter 2 Query the SIM write counter 3 Reset all SIM write counter as 0
<filename>	SIM EF name, referred to TS31.102, "null" means no file writed.
<counter>	if overflow occurs, restart from 0.

4.2.41 AT\$QCIPR Operate the Baud Rate of UE

AT\$QCIPR Operate the Baud Rate of UE	
Description	Set command sets the UE baud rate to be used. Read command returns the current baud rate. Test command returns baud rates supported by the UE.
Test Command AT\$QCIPR=?	Response \$QCIPR: (list of fixed-only<rate> values) OK
Read Command AT\$QCIPR?	Response \$QCIPR:<rate> OK
Write Command AT\$QCIPR=<rate>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Defined Values

<rate>	Baud rate at which the UE will accept commands.
--------	---

4.2.42 AT\$QCNPICFG Operating NPI

AT\$QCNPICFG Operating NPI	
Description	Set command is used to set NPI config Read command returns the current NPI config setting.
Test Command AT\$QCNPICFG=?	Response \$QCNPICFG: <option>,<value> OK
Read Command AT\$QCNPICFG?	Response \$QCNPICFG: "rfCaliDone":<value>, "rfNSTDone":<value> OK
Write Command AT\$QCNPICFG=<option>,<setting>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	SAVE
Max Response Time	-
Reference	

Defined Values

<option>	rfCaliDone Set RFCALI process status rfNSTDone Set RFNST process status
<setting>	For rfCaliDone , the values range is from 0 to 1 0: RFCALI process is not done 1: RFCALI process is done For rfNSTDone, the values range is from 0 to 1 0: RFNST process is not done 1: RFNST process is done

4.2.43 AT\$QCPRMODE Control NPI production mode

AT\$QCPRMODE Control NPI production mode

Description	Set command is used to control entering NPI production mode. Read command returns the current NPI production mode status.
Test Command AT\$QCPRMODE=?	Response \$QCPRMODE: <status> OK
Read Command AT\$QCPRMODE?	Response \$QCPRMODE: "prodModeEnable":<value1>,"prodModeEnter":<value2> OK
Write Command AT\$QCPRMODE=<setting>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	SAVE
Max Response Time	-
Reference	

Defined Values

<setting>	prodModeEnable Enable production mode prodModeDisable Disable production mode prodModeEnter Enter production mode prodModeExit Exit production mode
<value1>	0: prodMode is disabled 1: prodMode is enabled
<value2>	0: prodMode isn't entered 1: prodMode is entered
<status>	reflects prodMode status

4.2.44 AT\$QCLEDMODE Enable the Netlight Function

AT\$QCLEDMODE Enable the Netlight Function

Description	Set command is used to control entering NPI production mode. Read command returns the current NPI production mode status.
-------------	--

Test Command AT\$QCLEDMODE=?	Response \$QCLEDMODE: (0,1) OK
Read Command AT\$QCLEDMODE?	Response \$QCLEDMODE: <state> OK
Write Command AT\$QCLEDMODE=<state>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	SAVE
Max Response Time	-
Reference	

Defined Values

<state>	0 Netlight function disable 1 Netlight function enable
----------------------	---

NOTE

In QCX212 NB-IoT SDK, Netlight is set to PAD 30 using PWM Instance 5. It can be changed by rewrite NetLightInit function (in bsp_custom.c).

- Netlight function may cause extra power consumption
- All sleep is disabled, until NB enter Idle/PSM
- A pull-down resistor is needed to keep Pad low to avoid unwanted flickerl.
- Netlight Indication Note NB Status

HighLevel 64ms(LED ON)/ LowLevel 800ms(LED OFF) Network searching

HighLevel 64ms(LED ON)/ LowLevel 2000ms(LED OFF) Network connected in NB Connect state

Keep Low Level NB Idle/PSM or other

4.2.45 AT\$QCPOWERCLASS Sets the Band Power Class

AT\$QCPOWERCLASS Sets the Band Power Class

Description	The command sets the band power class. Read command returns the current band and releated power class setting. Test command returns the bands and releated power class supported by the
-------------	---

	UE.
Test Command AT\$QCPOWERCLASS=?	Response \$QCPOWERCLASS: <band1>,(list of supported <power class>s) \$QCPOWERCLASS: <band2>,(list of supported <power class>s) ... OK
Read Command AT\$QCPOWERCLASS?	Response \$QCPOWERCLASS: <band1>,<power class> \$QCPOWERCLASS: <band2>,<power class> ... OK
Write Command AT\$QCPOWERCLASS=<band>,<powerclass>	Response OK or +CME ERROR: <err>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	

Defined Values

<band>	Band in decimal number.All bands supported by RF. 0 is to set power class of all bands.
<power class>	3 UE maximum output power is 23dBm 5 UE maximum output power is 20dBm 6 UE maximum output power is 14dBm

NOTE

AT\$QCEPOWERCLASS must be restricted to execute under power off or air plane state.Parameter <power class> can only be set to 6 when “RelVersion” in AT\$QCCFG is 14.When set parameter <power class> to 6,parameter <band> must be set to 0.

5 AT Commands for Socket

5.1 Overview of AT Commands for Socket

Command	Description
AT\$QCSOCR	Create Socket
AT\$QCSOST	SendTo Command (UDP only)
AT\$QCSOSTF	SendTo Command with flags(UDP only)
AT\$QCQSOS	Query Socket Messages Sent Pending Data List
AT\$QCSORF	Receive Command
AT\$QCSOCO	Connect Command (TCP only)
AT\$QCSOSD	Send Command (TCP only)
AT\$QCSOCL	Close Socket
\$QCSONMI	Socket message arrived indicator (Response Only)
\$QCSOCLI	Socket close indicator (Response Only)
AT\$QCSONMI	Set the Public Max Downlink Buffer Size
AT\$QCSONMIE	Arrived messages of a specified socket

5.2 Detailed Descriptions of Commands

5.2.1 AT\$QCSOCR Create Socket

AT\$QCSOCR Create Socket	
Description	<p>This command creates a socket on the UE. If the port is set, receiving is enabled and unsolicited \$QCSONMI messages will appear for any message that is received on that port. Refer to Chapter 9: Error Values for possible <err> values.</p> <p>If a socket has already been created for a protocol, port combination, \$QCSOCR will fail if requested a second time.</p>
Write Command AT\$QCSOCR=<type>,<protocol>[,<listen port>[,<receive control>[,<af_type>[,<i address>]]]]	Response <socket> OK If failed: +CME ERROR: <err>

Write Command AT\$QCSOCR=?	Response \$QCSOCR: (list of supported <type>s), (list of supported <protocol>s),(list of supported <listen_port>s),(list of supported <receive_control>s),(list of supported <af_type>s),(<ip_addr>) OK
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<type>	Socket Type. DGRAM for UDP, STREAM for TCP
<protocol>	Standard internet protocol definition. For example, UDP is 17.
<listen port>	A number in the range 0-65535. This is the local port that will be included in sent messages and on which messages will be received. If it is 0 or omitted, and used for TCP, LWIP will assign a random <listen port> for this socket.
<socket>	This is a reference to the created socket. It is an integer greater than or equal to 0
<receive control>	Set to 1 if incoming messages should be received, 0 if incoming messages should be ignored. Defaults to 1 (messages will be received)
<af_type>	String type. "AF_INET" IPv4 type "AF_INET6" IPv6 type
<ip address>	The IP address NW assigned to MT.

NOTE

- A maximum of 7 sockets are supported, but other services may reduce this number.
- Only UDP(protocol 17), TCP(protocol 6) supported.
- **<listen port>** value of 20000 for TCP can't be set when bip is enabled.

5.2.2 AT\$QCSOST SendTo Command (UDP only)

AT\$QCSOST SendTo Command (UDP only)

Description	This command sends a UDP datagram to the specified host:port. It will return with the socket and the number of bytes of data to be sent. If the amount of data is larger than the largest datagram that can be sent, the \$QCSOST return value will indicate how much of the data was successfully sent. If <sequence> is not omitted, when datagram is sent by rf or discard, will
-------------	---

<p>Write Command</p> <p>AT\$QCSOST=<socket>,<remote_addr>,<remote_port>,<length>,<data>[,<sequence>],[<segment_id>,<segment_num>]</p>	<p>report the result.</p> <p>Response</p> <p><socket>,<length></p> <p>OK</p> <p>If failed:</p> <p>+CME ERROR: <err></p> <p>If <sequence>is not omitted, when datagram is sent by rf or discard, will report the result.</p> <p>\$QCSOSTR:<socket>,<sequence>,<status></p>
<p>Test Command</p> <p>AT\$QCSOST=?</p>	<p>Response</p> <p>\$QCSOST:(list of supported <socket>s),(list of supported <remote_addr>),(list of supported <remote_port>s),(list of supported <length>s),(list of supported <data>),(list of supported <sequence>s),(list of supported <segment_id>s),(list of supported <segment_num>s)</p> <p>OK</p>
<p>Parameter Saving Mode</p>	<p>-</p>
<p>Max Response Time</p>	<p>-</p>
<p>Reference</p>	<p></p>

Defined Values

<socket>	Socket number returned by \$QCSOCR
<remote addr>	IP address
<remote port>	A number in the range 0-65535. This is the remote port that messages will be received on
<length>	Decimal length of data to be sent.
<data>	Data to be transmitted in hex string format, or quoted string format.
<sequence>	Sequence of data, range 1-255.If omit, will not report data sent status.
<status>	<p>The status of datagram.</p> <p>0 Error</p> <p>1 Sent</p>
<segment_id>	<p>Integer type.</p> <p>1-4 One segment index of a segment message.</p>
< segment_num>	<p>Integer type.</p> <p>2-4 The total number which the messages will fragment.</p>

NOTE

- Maximum data size is 1400 bytes.
- <data> Only hex string format is supported
- IP addresses can be specified in decimal, octal or hexadecimal notation.

- Data can't be transferred if MT don't have address (could use +CGPADDR to get)

5.2.3 AT\$QCSOSTF SendTo Command with Flags(UDP only)

AT\$QCSOSTF SendTo Command with Flags(UDP only)	
Description	This command sends a UDP datagram to the specified host:port. It will return with the socket and the number of bytes of data to be sent. If the amount of data is larger than the largest datagram that can be sent, the \$QCSOSTF return value will indicate how much of the data was successfully sent.
Write Command AT\$QCSOSTF=<socket>,<remote_addr>,<remote_port>,<flag>,<length>,<data>[,<sequence>],[<segment_id>,<segment_num>]	Response <socket>,<length> OK If failed: +CME ERROR: <err> If <sequence> is not omitted, when datagram is sent by rf or discard, will report the result. \$QCSOSTR:<socket>,<sequence>,<status>
Test Command AT\$QCSOSTF=?	Response \$QCSOSTF:(list of supported <socket>s),(<remote_addr>),(list of supported <remote_port>s),(list of supported <flag>s),(list of supported <length>s),(<data>),(list of supported <sequence>s),(list of supported <segment_id>s),(list of supported <segment_num>s) OK
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<socket>	Socket number returned by \$QCSOCR
<remote addr>	IP address
<remote port>	A number in the range 0-65535. This is the remote port that messages will be received on
<flag>	Specifies the type of message transmission. Values of this argument are in hex format and are formed by logically OR'ing zero or more of the following flags: 0x100 Exception Message: Send message with high priority 0x200 Release Indicator: indicate release after next message

	0x400 Release Indicator: indicate release after next message has been replied to If no flags are set, a value of 0 should be provided.
<length>	Decimal length of data to be sent.
<data>	Data to be transmitted in hex string format, or quoted string format.
<sequence>	Sequence of data, range 1-255.If omit, will not report data sent status.
<status>	The status of datagram. 0 Error 1 Sent
<segment_id>	Integer type. 1-4 One segment index of a segment message.
< segment_num>	Integer type. 2-4 The total number which the messages will fragment.

NOTE

- Maximum data size is 1400 bytes.
- <data> Only hex string format is supported
- IP addresses can be specified in decimal, octal or hexadecimal notation.
- Data can't be transferred if MT don't have address (could use +CGPADDR to get)

5.2.4 AT\$QCQSOS Query Socket Messages Sent Pending Data List

AT\$QCQSOS Query Socket Messages Sent Pending Data List	
Description	This command queries the list of the pending upstream message by MT.
Write Command AT\$QCQSOS=<socket>[,<socket>[,<socket>[...]]]	Response [\$QCQSOS:<socket>,<sequence><CR><LF>[\$QCQSOS:<socket>,<sequence>][...]] OK If failed: +CME ERROR: <err>
Test Command AT\$QCQSOS=?	Response \$QCQSOS: (list of supported <socket>s),(list of supported <socket>s),... OK
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<socket>	Socket number.
<sequence>	The sequence of pending up steam message. Range 1-255.

5.2.5 AT\$QCSORF Receive Command

AT\$QCSORF ReceiveCommand	
Description	<p>Reads up to <req length> characters of data from <socket>.</p> <p>Returned length is the actual number of characters returned.</p> <p>Receive data on a socket. When data arrives a +QCSORFI response will be generated that indicates the socket the message was received on and the amount of data. The +QCSORFI command takes a length, which is the maximum amount of data that will be returned.</p> <p>If the requested length is larger than the actual size of the returned data, only the length of returned data is provided, and the remaining length is returned as 0. If the requested length is less than the amount of data returned, only the requested amount of data will be returned, plus an indication of the number of bytes remaining.. Once a message has been fully read, a new +QCSORFI notification will be sent if there is another message to process.</p> <p>Refer to Chapter 9: Error Values for possible <err> values.</p> <p>If messages arrive faster than they are read, and the internal message buffer is full, the most recent message will be discarded.</p>
Write Command AT\$QCSORF=<socket>,<req_length>	<p>Response</p> <p><socket>,<ip_addr>,<port>,<length>,<data>,<remaining_length></p> <p>OK</p> <p>If failed:</p> <p>+CME ERROR: <err></p>
Test Command AT\$QCSORF=?	<p>Response</p> <p>\$QCSORFI: (list of supported <socket>s),(list of supported <req_length>s)</p> <p>OK</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<socket>	Socket number returned by \$QCSORFI
<req_length>	Maximum amount of data to be returned as a decimal byte length.
<remote addr>	Address of system sending the message

<remote port>	A number in the range 0-65535. This is the remote port that messages was sent from
<length>	Amount of data returned as a decimal byte length
<remaining_length>	Amount of data left to read for this message as a decimal byte length
<data>	Data received in hex string format

NOTE

- Maximum data size is 1358 bytes.
- Remaining length is always 0. The remaining data is readable.

5.2.6 AT\$QCSOCO Connect Command (TCP only)

AT\$QCSOCO Connect Command (TCP only)	
Description	<p>This command Connect to a TCP sever to the specified host:port.</p> <p>If the socket connection connect success, it will indicate the success result with the URC "\$QCSOCO". If the socket connection connect fail ite will indicate the fail result with the URC "\$QCSOCLI"</p> <p>Refer to Chapter 9: Error Values for possible <err> values.</p>
Write Command AT\$QCSOCO=<socket>,<remote_addr>,<remote_port>	Response OK If failed: +CME ERROR: <err>
Test Command AT\$QCSOCO=?	\$QCSOCO: (list of supported <socket>s),(list of supported <remote_addr>s),(list of supported <remote_port>s) OK
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<socket>	Socket number returned by \$QCSOCR
<remote_addr>	Address of system sending the message
<remote_port>	A number in the range 0-65535. This is the remote port that connect to.

NOTE

IP addresses can be specified in decimal, octal or hexadecimal notation.

5.2.7 AT\$QCSOSD Send Command (TCP only)

AT\$QCSOSD Send Command (TCP only)	
Description	<p>This command sends a TCP datagram to the TCP server. It will return with the socket that it was sent on, and the number of bytes of data sent. If the amount of data is larger than the largest datagram that can be sent, the \$QCSOSD return value will indicate how much of the data was successfully sent.</p> <p>If <sequence> is not omitted, when datagram is acked by server or discard by UE, will report the result.</p> <p>\$QCSOSTR: <socket>, <sequence>, <status></p> <p>Refer to Chapter 9: Error Values for possible <err> values.</p>
Write Command AT\$QCSOSD=<socket>,<length>,<data>[,<flag>[,<sequence>]]	<p>Response</p> <p>socket, length</p> <p>OK</p> <p>If failed:</p> <p>+CME ERROR: <err></p>
Test Command AT\$QCSOSD=?	<p>Response</p> <p>\$QCSOSD:(list of supported <socket>s),(list of supported <length>s),(list of supported <data>),(list of supported <flag>s),(list of supported <sequence>s)</p> <p>OK</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<socket>	Socket number returned by \$QCSOCR.
<length>	Decimal length of data to be sent.
<data>	Data to be transmitted in hex string format.
<flag>	<p>Specifies the type of message transmission. Values of this argument are in hex format and are formed by logically OR'ing zero or more of the following flags:</p> <p>0x100 Exception Message: Send message with high priority</p> <p>0x200 Release Indicator: indicate release after next message</p> <p>0x400 Release Indicator: indicate release after next message has been replied to</p>

	If no flags are set, a value of 0 should be provided.
<sequence>	Sequence of data, range 1-255.If omit, will not report data sent status.
<status>	The status of datagram. 0 Error 1 Sent

NOTE

- Maximum data size is 1400 bytes.
- <data> Only hex string format is supported
- IP addresses can be specified in decimal, octal or hexadecimal notation.
- <flag> couldn't work now.

5.2.8 AT\$QCSOCL Close Socket

AT\$QCSOCL Close Socket

Description	Close the specified socket. If there are pending messages to be read, they will be dropped. No further unsolicited +QCSOCL notifications will be generated. If the socket has already been closed, or was never created, an error will be returned. Refer to Chapter 9: Error Values for possible <err> values.
Write Command AT\$QCSOCL=<socket>	Response OK If failed: +CME ERROR: <err>
Test Command AT\$QCSOCL=?	Response \$QCSOCL:(list of supported <socket>s) OK
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<socket>	Socket number returned by \$QCSOCL
----------	------------------------------------

5.2.9 \$QCSOCL Socket Message Arrived Indicator (Response Only)

\$QCSOCL Socket Message Arrived Indicator (Response Only)

Description	<p>Unsolicited message to notify that data has been received on a socket and is ready to be read. Returns socket number and number of bytes of data available to read for the first message that is queued. If another message is received on the same socket, it will only be notified when the preceding message has been completely read.</p> <p>Refer to Chapter 9: Error Values for possible <err> values.</p>
	<p>Response</p> <p>\$QCSNMI:<socket>,<length></p>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<socket>	Socket on which data is received. Decimal number returned by \$QCSOCR
<length>	Number of bytes of data in the first message.

NOTE

This message can occur at any point if it is indicating a new message with no messages buffered. If there are buffered messages it will occur in the AT\$QCSORF command before the data is returned.

5.2.10 \$QCSOCLI Socket Close Indicator (Response Only)

\$QCSOCLI Socket Close Indicator (Response Only)	
Description	<p>Unsolicited message to notify that socket has been closed by LWIP internally. Returns socket number.</p> <p>Refer to Chapter 9: Error Values for possible <err> values.</p>
	<p>Response</p> <p>\$QCSOCLI:<socket>,<errno></p>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<socket>	Socket on which is closed. Decimal number returned by \$QCSOCR.
<errno>	<p>Integer type (Posix Errno defines)</p> <p>12 Out of memory error</p> <p>105 No buffer space available</p>

62 Timer expired
113 No route to host
115 Operation now in progress
22 Invalid argument
11 Operation would block
107 Transport endpoint is not connected
103 Software caused connection abort
104 Connection reset by peer

NOTE

Only TCP could report \$QCSOCLI.

5.2.11 AT\$QCSOEMI Set the Public Max Downlink Buffer Size

AT\$QCSOEMI Set the Public Max Downlink Buffer Size

Description	<p>The write command is used to set the unsolicited result code "\$QCSOEMI" to indicate arrived socket messages (the socket were not configure as private socket by AT\$QCSOEMI command):</p> <p>If <mode>=1, the UE will receive an unsolicited result code: "\$QCSOEMI: <socket>,<length>".</p> <p>If <mode>=2, the UE will receive an unsolicited result code: "\$QCSOEMI: <socket>,<remote_ad dr>,<remote_port>,<length>,<data>".</p> <p>If <mode>=3, the UE will receive an unsolicited result code: "\$QCSOEMI: <socket>,<length>,<data>".</p> <p>The read command returns the current setting of the command.</p> <p>The write command is also used to set the public max downlink buffer size and the public max messages number</p>
Write Command AT\$QCSOEMI=<mode> [<max_public_dl_buffer>,<max_public_dl_pkg_num>]	<p>Response</p> <p>OK</p> <p>If there is any error, response:</p> <p>+CME ERROR: <err></p>
Test Command AT\$QCSOEMI=?	<p>Response</p> <p>\$QCSOEMI: (list of supported<mode>s), (list of supported<max_public_dl_buffer>s), (list of supported<max_public_dl_pkg_num>s)</p> <p>OK</p>
Read Command AT\$QCSOEMI?	<p>Response</p> <p>[\$QCSOEMI:<mode>,<max_public_dl_buffer>,<max_public_dl_pkg_n</p>

	um>]
	OK
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<mode>	Control downlink data format. 0 Disable indication messages unsolicited result code. 1 Enable indication messages unsolicited result code for the specified socket: "\$QCSOEMI: <socket>,<length>" 2 Enable indication messages unsolicited result code for the specified socket: "\$QCSOEMI: <socket>,<remote_addr>,<remote_port>,<length>,<data>" 3 Enable indication messages unsolicited result code for the specified socket: "\$QCSOEMI:<socket>,<length>,<data>"
<socket>	Integer type 1-5 Socket Id returned by AT\$QCSOCR.
<length>	Number of bytes of data in the first message.
<remote_addr>	The remote IP address which the message is sent from
<remote_port>	0-65535 The remote port which the message if sent from
<data>	Data received in hex string format. Maximum length of received data is 1358 bytes
<max_private_dl_buffer>	1358-3072 The maximum downlink buffer size for the specified socket. The default value is 2048
<max_private_dl_pkg_num>	8-16 The maximum downlink buffer message number for the specified socket. The default value is 8

5.2.12 AT\$QCSOEMIE Arrived Messages of A Specified Socket

AT\$QCSOEMIE Arrived Messages of A Specified Socket	
Description	<p>The write command is used to set the unsolicited result code "\$QCSOEMI" to indicate arrived messages of a specified socket, the default mode is 3:</p> <p>If <mode>=1, the UE will receive an unsolicited result code: "\$QCSOEMI: <socket>,<length>".</p> <p>If <mode>=2, the UE will receive an unsolicited result code: "\$QCSOEMI: <socket>,<remote_addr>,<remote_port>,<length>,<data>".</p> <p>If <mode>=3, the UE will receive an unsolicited result code: "\$QCSOEMI: <socket>,<length>,<data>".</p> <p>The read command returns the current setting of the command. The write command is also used to set the max downlink buffer size and the max messages number for the specified socket.</p>
Write Command	Response

AT\$QCSOINMIE=<socket>,<mode>[,<max_private_dl_buffer>[,<max_private_dl_pkg_num>]]	<p>OK</p> <p>If there is any error, response:</p> <p>+CME ERROR: <err></p>
Test Command AT\$QCSOINMIE=?	<p>Response</p> <p>\$QCSOINMIE: (list of supported<socket>s),(list of supported<mode>s),(list of supported<max_private_dl_buffer>s),(list of supported<max_private_dl_pkg_num>s)</p>
Read Command AT\$QCSOINMIE?	<p>OK</p> <p>Response</p> <p>[\$QCSOINMIE: <socket>,<mode>,<max_public_dl_buffer>,<max_public_dl_pkg_num>] [...]</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<socket>	Socket on which data is received. Decimal number returned by \$QCSOCR
<mode>	<p>Control downlink data format.</p> <p>0 Disable indication messages unsolicited result code for the specified socket.</p> <p>1 Enable indication messages unsolicited result code for the specified socket: "\$QCSOINMI: <socket>,<length>"</p> <p>2 Enable indication messages unsolicited result code for the specified socket: "\$QCSOINMI: <socket>,<remote_addr>,<remote_port>,<length>,<data>"</p> <p>3 Enable indication messages unsolicited result code for the specified socket: "\$QCSOINMI:<socket>,<length>,<data>"</p> <p>255 reset the mode setting which configure by the command "AT\$QCSOINMI" for the specified socket</p>
<length>	Number of bytes of data in the first message.
<remote_addr>	The remote IP address which the message is sent from
<remote_port>	0-65535 The remote port which the message if sent from
<data>	Data received in hex string format. Maximum length of received data is 1358 bytes
<max_private_dl_buffer>	1358-2048 The maximum downlink buffer size for the specified socket. The default value is 1358
<max_private_dl_pkg_num>	1-8 The maximum downlink buffer message number for the specified socket. The default value is 4

NOTE

This message can occur at any point if it is indicating a new message with no messages buffered. If there are buffered messages it will occur in the AT+QCSORF command before the data is returned.

SIMCom
Confidential

5.2.13 \$QCSOCO Socket Connected Indicator

\$QCSOCLI Socket Connected Indicator	
Description	Unsolicited message to notify that the TCP Connection has connected success.
	Response \$QCSOCO:<socket_id>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<socket_id>	Integer type Socket id returned by AT\$QCSOCR
-------------	--

NOTE

Only TCP could report +QCSOCLI.

6 AT Commands for MQTT

6.1 Overview

Command	Description
AT\$QCMTCFG	Creates a MQTT Client
AT\$QCMTOPEN	Open a Network for MQTT Client.
AT\$QCMTCLOSE	Send MQTT Close Packet.
AT\$QCMTCONN	Send MQTT Subscribe Packet.
AT\$QCMTDISC	Send MQTT Disconnect Packet
AT\$QCMTSUB	Send MQTT Subscribe Packet.
AT\$QCMTUNS	Send MQTT Unsubscribe Packet
AT\$QCMT PUB	Send MQTT Publish Packet
\$QCMTSTAT	Receive Data from MQTT Server
\$QCMTRECV	Receive Data from MQTT Server

6.2 Detailed Descriptions of Commands

6.2.1 AT\$QCMTCFG Creates a MQTT Client

7 AT\$QCMTCFG Creates a MQTT Client	
Description	The command creates a MQTT client.
Test Command AT\$QCMTCFG=?	<p>Response</p> <p>\$QCMTCFG: "echomode",(0),(0,1) "dataformat",(0),(0,1),(0,1) "keepalive",(0),(0-3600), "session",(0),(0,1) "timeout",(0),(1-60),(1-10),(0,1) "will",(0),(0,1),(0-2),(0,1),"will_topic","will_msg" "version",(0),(3,4) "aliauth",(0),"productkey","devicename","devicesecret" "cloud",(0-256),(0-256)</p>

Write Command AT\$QCMTCFG="mode",<value>,[...]	OK Response OK or ERROR
Write Command AT\$QCMTCFG="echo mode",<tcpconnectID>,[<echo_mode>]	Response OK If <echo_mode> is omitted, query the data echo mode: \$QCMTCFG: "echomode",<echo_mode> or ERROR
Write Command AT\$QCMTCFG="dataformat",<tcpconnectID>,[<send_format>,[<recv_format>]]	Response OK If <send_format> and <recv_format> are both omitted, query the format of sent/received data: \$QCMTCFG: "dataformat",<send_format>,<recv_format> OK or ERROR
Write Command AT\$QCMTCFG="keepalive",<tcpconnectID>,[<keep-alive time>]	Response OK If <keep-alive time> is omitted, query the keep-alive time: \$QCMTCFG: "keepalive",<keep-alive time> OK or ERROR
Write Command AT\$QCMTCFG="session",<tcpconnectID>,[<clean_session>]	Response OK If <clean_session> is omitted, query the session type: \$QCMTCFG: "session",<clean_session> OK or ERROR
Write Command AT\$QCMTCFG="timeout",<tcpconnectID>,[<pkt_timeout>,[<retry_times>],[<timeout_notice>]]	Response OK If <pkt_timeout>, <retry_times>, <timeout_notice> are omitted, query the timeout value of message delivery: \$QCMTCFG: "timeout",<pkt_timeout>,<retry_times>,<timeout_notice> OK or ERROR
Write Command AT\$QCMTCFG="will",<tcpconnectID>,[<will_fg>,[<will_qos>,<will_re	Response OK If <will_fg>, <will_qos>, <will_retain>, <will_topic> and <will_msg> are omitted, query the Will information:

tain>,"<will_topic>","<will_msg>"]]	<p>\$QCMTCFG:</p> <p>"will",<will_fg>[,<will_qos>,<will_retain>,<will_topic>,<will_msg>]</p> <p>OK</p> <p>or</p> <p>ERROR</p>
<p>Write Command</p> <p>AT\$QCMTCFG="version",<tcpconnectID>[,<version>]</p>	<p>Response</p> <p>OK</p> <p>If <version> is omitted, query the MQTT protocol version:</p> <p>\$QCMTCFG: "version",<version></p> <p>OK</p> <p>or</p> <p>ERROR</p>
<p>Write Command</p> <p>AT\$QCMTCFG="aliauth",<tcpconnectID>[, "<product_key>","<device_name>","<device_secret>"]]</p>	<p>Response</p> <p>OK</p> <p>If "<product_key>","<device_name>","<device_secret>" are omitted, query the device information:</p> <p>\$QCMTCFG:</p> <p>"aliauth",<product_key>,<device_name>,<device_secret></p> <p>OK</p> <p>or</p> <p>ERROR</p>
<p>Write Command</p> <p>AT\$QCMTCFG="cloud",<tcpconnectID>,<cloudtype>,<data type></p>	<p>Response</p> <p>OK</p> <p>or</p> <p>ERROR</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<tcpconnectID>	MQTT socket identifier, the value is 0
<echo_mode>	0 Do not echo the input data to UART 1 Echo the input data to UART
<send_format>	0 Text mode 1 Hex mode
<recv_format>	0 Text mode 1 Hex mode
<keep-alive time>	The range is 0-3600. The default value is 120. Unit: second. It defines the maximum time interval between messages received from a client. If the server does not receive a message from the client within 1.5 times of the keep-alive time period, it disconnects the client as if the client has sent a DISCONNECT message.
<clean_session>	0 The server must store the subscriptions of the client after it disconnects.

	1 The server must discard any previously maintained information about the
<pkt_timeout>	Timeout of the packet delivery. The range is 1-60. The default value is 10. Unit: second.
<retry_times>	Retry times when packet delivery times out. The range is 1-10. The default value is 3.
<timeout_notice>	0 Not report timeout message when transmitting packet 1 Report timeout message when transmitting packet
<will_fg>	0 Ignore the Will flag configuration 1 Require the Will flag configuration
<will_qos>	0 At most once 1 At least once 2 Exactly once
<will_retain>	0 When a client sends a PUBLISH message to a server, the server will not hold on to the message after it has been delivered to the current subscribers. 1 When a client sends a PUBLISH message to a server, the server should hold on to the message after it has been delivered to the current subscribers.
<will_topic>	Will topic string
<will_msg>	The Will message defines the content of the message that is published to the will topic if the client is unexpectedly disconnected. It can be a zero-length message.
<version>	Version of MQTT protocol, the default is MQTT v3.1.1 3 MQTT v3.1 4 MQTT v3.1.1
<product_key>	Product key issued by AliCloud
<device_name>	Device name issued by AliCloud
<device_secret>	Device secret key issued by AliCloud
<cloud type>	Integer type 0 mosquitto 1 OneNet 2 alibaba 3-255 is reserved for customers
<data type>	Integer type, the range is 0-255 For OneNet cloud 1 OneNet data type1 2 OneNet data type2 3 OneNet data type3 4 OneNet data type4 5 OneNet data type5 6 OneNet data type6 For Ali cloud 1 Json data 2 string data For other, data format insensitive

7.1.1 AT\$QCMTOPEN Open a Network for MQTT Client

AT\$QCMTOPEN Open a Network for MQTT Client

Description	The command is used to open a network for MQTT client.
Test Command AT\$QCMTOPEN=?	Response \$QCMTOPEN: (list of supported<tcpconnectID>s), "<host_name>",(list of supported <port>s) OK
Read Command AT\$QCMTOPEN?	Response OK
Write Command AT\$QCMTOPEN=<tcpconnectID>,"<host_name>",<port>	Response OK \$QCMTOPEN: <tcpconnectID>,<result> or ERROR
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<tcpconnectID>	MQTT socket identifier. The value is 0
<host_name>	The address of the server. It could be an IP address or a domain name. The maximum size is 100 bytes
<port>	The port of the server. The range is 1-65535
<result>	-1 Failed to open network 0 Opened network successfully

7.1.2 AT\$QCMTCLOSE Send MQTT Close Packet

AT\$QCMTCLOSE Send MQTT Close Packet

Description	The command send MQTT close packet.
Test Command AT\$QCMTCLOSE=?	Response \$QCMTCLOSE: (list of <tcpconnectID>s) OK

Write Command AT\$QCMTCLOSE=<tcpconnectID>	Response \$QCMTCLOSE: <tcpconnectID>,<result> or ERROR
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<tcpconnectID>	MQTT socket identifier. The value is 0
<result>	-1 Failed to open network 0 Opened network successfully

7.1.3 AT\$QCMTCONN Send MQTT Subscribe Packet.

AT\$QCMTCONN Send MQTT Subscribe Packet	
Description	The command send MQTT subscribe packet.
Test Command AT\$QCMTCONN=?	Response \$QCMTCONN: (list of supported <tcpconnectID>s), "<clientId>" ["<username>" ["<password>"]] OK
Read Command AT\$QCMTCONN?	Response OK
Write Command AT\$QCMTCONN=<tcpconnectID>,"<clientId>" ["<username>"["<password>"]]	Response OK \$QCMTCONN: <tcpconnectID>,<result>[,<ret_code>] or ERROR
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<tcpconnectID>	MQTT socket identifier. The value is 0
<clientId>	The client identifier
<username>	User name of the client. It can be used for authentication

<password>	Password corresponding to the user name of the client. It can be used for Authentication.
<result>	Integer type 0 send data successfully and received ACK from server 1 send data successfully and received error ACK from server 2 send data fail
<ret_code>	Integer type 0 connect accepted 1 connect refused - incorrect protocol version 2 connect refused -invalid client identifier 3 connect refused - server unavailable 4 connect refused-bad user name or password 5 connect refused -not authorised 6 connect fail

7.1.4 AT\$QCMTDISC Send MQTT Disconnect Packet

AT\$QCMTDISC Send MQTT Disconnect Packet	
Description	The command send MQTT disconnect packet.
Test Command AT\$QCMTDISC=?	Response \$QCMTDISC: (list of supported<tcpconnectID>s) OK
Write Command AT\$QCMTDISC=<tcpconnectID>	Response OK \$QCMTDISC: <tcpconnectID>,<result> or ERROR
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<tcpconnectID>	MQTT socket identifier. The value is 0
<result>	-1 Failed to open network 0 Opened network successfully

7.1.5 AT\$QCMTSUB Send MQTT Subscribe Packet

AT\$QCMTSUB Send MQTT Subscribe Packet	
Description	The command send MQTT subscribe packet.
Test Command AT\$QCMTSUB=?	Response \$QCMTSUB: (list of supported<tcpconnectID>s),(list of supported<msgid>s), "<topic>",(list of supported<qos>s) OK
Write Command AT\$QCMTSUB=<tcpconnectID>,<msgid>,<topic>,<qos>	Response \$QCMTSUB: (list of supported<tcpconnectID>s),(list of supported<msgid>s), "<topic>",(list of supported<qos>s) OK
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<tcpconnectID>	MQTT socket identifier. The value is 0
<msgid>	Message identifier of packet. The range is 1-65535
<topic>	Topic that the client wants to subscribe to or unsubscribe from. The maximum length is 255 bytes
<qos>	Message QoS, can be 0,1 or 2

7.1.6 AT\$QCMTUNS Send MQTT Unsubscribe Packet

AT\$QCMTUNS Send MQTT Unsubscribe Packet	
Description	The command send MQTT unsubscribe packet.
Test Command AT\$QCMTUNS=?	Response \$QCMTUNS: (list of supported<tcpconnectID>s),(list of supported<msgid>s), "<topic>" OK
Write Command AT\$QCMTUNS=<tcpconnectID>,<msgid>,<topic>	Response OK \$QCMTUNS: <tcpconnectID>,<msgid>,<result>

	or ERROR
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<tcpconnectID>	MQTT socket identifier. The value is 0
<msgid>	Message identifier of packet. The range is 1-65535
<topic>	Topic that the client wants to subscribe to or unsubscribe from. The maximum length is 255 bytes
<result>	-1 Failed to open network 0 Opened network successfully

7.1.7 AT\$QCMTPUB Send MQTT Publish Packet

AT\$QCMTPUB Send MQTT Publish Packet	
Description	The command send MQTT publish packet .
Test Command AT\$QCMTPUB=?	Response \$QCMTPUB: (list of supported<tcpconnectID>s),(list of supported<msgid>s),(list of supported <qos>s),(list of supported<retain>s), "<topic>","<msg>"
Write Command AT\$QCMTPUB=<tcpconnectID>,<msgid>,<qos>,<retain>,"<topic>","<payload>"	OK Response OK \$QCMTPUB: <tcpconnectID>,<msgid>,<result> or ERROR
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<tcpconnectID>	MQTT socket identifier. The value is 0
<msgid>	Message identifier of packet. The range is 1-65535.It will be 0 only when <qos>=0

<qos>	Message QoS, can be 0,1 or 2
<retain>	0 Server should not retain the message 1 Server should retain the message
<topic>	Topic that needs to be published. The maximum length is 255 bytes
<payload>	Message that needs to be published. Maximum length is 700 bytes. If in data mode, the maximum length is 1023 bytes
<result>	-1 Failed to open network 0 Opened network successfully

7.1.8 \$QCMTSTAT Receive Data from MQTT Server

\$QCMTSTAT Receive Data from MQTT Server	
Description	This is an unsolicited message to indicate MQTT client receive data from MQTT server.
	\$QCMTSTAT: <tcpconnectID>,<err_code>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<tcpconnectID>	MQTT socket identifier. The value is 0
<err_code>	1 Connection is closed or reset by peer

7.1.9 \$QCMTRECV Receive Data from MQTT Server

\$QCMTRECV Receive Data from MQTT Server	
Description	This is an unsolicited message to indicate MQTT client receive data from MQTT server.
	\$QCMTRECV: <tcpconnectID>,<msgID>,<topic>,<data>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<tcpconnectID>	MQTT socket identifier. The value is 0
-----------------------------	--

<msgID>	The message identifier of packet
<topic>	The topic that received from MQTT server.
<data>	Receive data from server.

SIMCom
Confidential

8 AT Commands for HTTP

8.1 Overview

Command	Description
AT+HTTPCREATE	Create a http client.
AT+HTTPCON	Create a socket and connects with a http server
AT+HTTPDESTROY	Close a socket
AT+HTTPSEND	Send data to the http server
+HTTPRESPH	Represent response header
+HTTPRESPC	Represent response content.
+HTTPERR	Epresent error message

8.2 Detailed Descriptions of Commands

8.2.1 AT+HTTPCREATE Creates a Http Client

AT+HTTPCREATE Create a http client.	
Description	Set command creates a http or https client instance. Configure host, server certification, etc. It can create most 5 instance at one time. Test command returns values supported as a compound value.
Test Command AT+HTTPCREATE=?	Response +HTTPCREATE: (list of supported <flag>s), "<host>", "<authuser>", "<authpasswd>" OK or ERROR
Write Command AT+HTTPCREATE=<flag>,<host>,<authuser>,<authpasswd>	Response if there are more commands need to enter: +HTTP CMD: CONTINUE ENTER CMD If all commands has enter: +HTTPCREATE: <httpclientid> or

	ERROR
Parameter Saving Mode	NO_SAVE
Max Response Time	5S
Reference	

Defined Values

<flag>	Integer type 1 not last part of command 0 last part of command
<host>	string type, http server's host name
<authuser>	string type,Authentication user name
<authpasswd>	string type,Authentication password
<httpclientId>	Integer type,http Client Id ,0-4

NOTE

Only one instance and http was fully verified. https and multiple instances will be test later.

8.2.2 AT+HTTPCON Create a Socket and Connects with a Http Server

AT+HTTPCON Create a socket and connects with a http server

Description	Set command creates a socket and connects with a http server. Then creates a task to receive data come from http server. Test command returns values supported as a compound value.
Test Command AT+HTTPCON=?	Response +HTTPCON: (list of supported<httpclientId>) OK or ERROR
Write Command AT+HTTPCON=<httpclientId>	Response OK or ERROR
Parameter Saving Mode	NO_SAVE
Max Response Time	40S
Reference	

Defined Values

<httpclientId>	Integer type; http client id returned by +HTTPCREATE
----------------	--

8.2.3 AT+HTTPDESTROY Close a Socket

AT+HTTPDESTROY Close a socket

Description	Set command closes a socket, stops receive data from the http server and free the memory that was allocated by the client when creation. Test command returns values supported as a compound value.
Test Command AT+HTTPDESTROY=?	Response +HTTPDESTROY: (list of supported<httpclientId>) OK or ERROR
Write Command AT+HTTPDESTROY=<httpclientId>	Response OK or ERROR
Parameter Saving Mode	NO_SAVE
Max Response Time	40S
Reference	

Defined Values

<httpclientId>	Integer type; http client id returned by +HTTPCREATE
----------------	--

8.2.4 AT+HTTPSEND SendData to the Http Server

AT+HTTPSEND Send data to the http server

Description	Set command closes a socket, stops receive data from the http server and free the memory that was allocated by the client when creation. Test command returns values supported as a compound value.
Test Command AT+HTTPSEND=?	Response +HTTPSEND: (list of supported<httpclientId>),(list of supported<method>),(range of supported<pathlen>),"<path>", (range of supported<customheaderlen>),"<customheader>",(range of supported<contentTypelen>),"<contentType>",(range of

	supported<contentlen>), "<content>"
	OK or ERROR
Write Command AT+HTTPSEND=<httpclientid>,<method>,<pathlen>,<path>,<customheaderlen>,<customheader>,<contentTypelen>,<contentType>,<contentlen>,<content>	Response OK or ERROR
Parameter Saving Mode	NO_SAVE
Max Response Time	5S
Reference	

Defined Values

<httpclientid>	Integer type; http client id returned by +HTTPCREATE
<method>	Integer type; http method 0 GET 1 POST 2 PUT 3 DELETE 4 HEAD
<pathlen>	Integer type, Length of path, 0-260
<path>	string typePath
<customheaderlen>	Integer type, Length of custom header, 0-255
<customheader>	string type, Customheader in hex string
<contentTypelen>	Integer type, Length of content type, 0-64
<contentType>	string type, Content type
<contentlen>	Integer type, Length of content, 0-1024
<content>	String type User data need to send in hex string

8.2.5 +HTTPRESPH Represent response header

+HTTPRESPH Represent response header

Description	This is an unsolicited message to represent response header.
-------------	--

	+HTTPRESPH: <clientId>,<responseCode>,<headerlen>,<header>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<clientId>	Integer type,http client id returned by +HTTPCREATE
<responseCode>	Integer type, http response code
<headerlen>	Integer type, Length of http response header
<header>	Integer type, Header

8.2.6 +HTTPRESPC Represent response content

+HTTPRESPC Represent response content	
Description	This is an unsolicited message to represent response content.
	+HTTPRESPC:<clientId>,<flag>,<contentlength>,<blockcontentlen>,<content>
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<clientId>	Integer type,http client id returned by +HTTPCREATE
<flag>	Integer type, if has more data 0 No more data 1 Has more data
<contentlength>	Integer type, Length of content
<blockcontentlen>	Integer type, Current block length
<content>	string type content

8.2.7 +HTTPERR Indicate of error Message

+HTTPERR Indicate of error message

Description	This is an unsolicited message to represent error message when error happen.
	+HTTPErr: <clientId>,<errorCode>,[<rspcode>]
Parameter Saving Mode	-
Max Response Time	-
Reference	

Defined Values

<clientId>	Integer type,http client id returned by +HTTPCREATE
<errorCode>	Integer type, if has more data 2 URL parse error 3 could not resolve DNS 4 Protocol error 5 HTTP 404 error,NOT FOUND 6 HTTP 403 error,REFUSED 7 HTTP xxx error,with specific rspcode for followed 8 Connection timeout 9 Connection error 10 Connection fatal error 11 Connection closed 13 Buffer overflow error

9 Error Codes and Reset Reasons

9.1 Summary of CME ERROR Codes

Final result code **+CME ERROR: <err>** indicates an error related to mobile equipment or network. The operation is similar to ERROR result code. None of the following commands in the same Command line is executed. Neither ERROR nor OK result code shall be returned.

<err> values used by common messaging commands:

9.1.1 General Errors

Code of <err>	Error Text
1	MT not connection
2	MT link reserved
3	operation not allowed
4	operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	SIM not inserted
11	SIM PIN required
12	SIM PUK required
13	SIM failure
14	SIM busy
15	SIM wrong
16	incorrect password
17	SIM PIN2 required
18	SIM PUK2 required
20	memory full
21	invalid index
22	not found
23	memory failure

24	text string too long
25	invalid characters in text string
26	dial string too long
27	invalid characters in dial string
30	no network service
31	network timeout
23	memory failure
24	text string too long
25	invalid characters in text string
26	dial string too long
27	invalid characters in dial string
30	no network service
31	network timeout
32	network not allowed - emergency call only
40	network personalization PIN required
41	network personalization PUK required
42	network subset personalization PIN required
43	network subset personalization PUK required
44	service provider personalization PIN required
45	service provider personalization PUK required
46	corporate personalization PIN required
47	corporate personalization PUK required
48	hidden key required
49	EAP method not support
50	incorrect Parameters
51	command implemented but currently disabled
52	command aborted by user
53	not attached to network due to MT functionality restrictions
54	modem not allowed - MT restricted to emergency calls only
55	operation not allowed because of MT functionality restrictions
56	fixed dial number only allowed - called number is not a fixed dial number
57	temporarily out of service due to other MT usage
58	language/alphabet not supported
59	unexpected data value
60	system failure
61	data missing
62	call barred
63	message waiting indication subscription failure
100	unknown
103	illegal MS

106	illegal ME
107	GPRS services not allowed
108	GPRS services and non GPRS services not allowed
111	PLMN not allowed
112	location area not allowed
113	roaming not allowed in this location area
114	GPRS services not allowed in this plmn
115	No suitable cells in location area
122	Congestion
126	Insufficient resources
127	Mission or unknown APN
128	SIM PUK required
129	SIM failure
130	SIM busy
131	SIM wrong
132	incorrect password
133	requested service option not subscribed
134	service option temporarily out of order
140	Feature not supported
141	Semantic errors in the TFT operation
142	Syntactical errors in the TFT operation
143	Unknown PDP context
144	Semantic errors in packet filters
145	Syntactical errors in packet filters
146	PDP context without TFT already activated
148	unspecified GPRS error
149	PDP authentication failure
150	invalid mobile class
171	Last PDN disconnection not allowed
172	Semantically incorrect message
173	Mandatory information element error
174	Information element nonexistent or not implemented
175	Conditional ie error
176	Protocol error unspecified
177	Operator determined barring
178	Max number of PDP contexts reached
179	Requested APN not supported in current rat and PLMN combination
180	Request rejected bearer control mode violation
181	Unsupported oci value
182	User data transmission via control plane is congested
301	Internal error base
302	UE busy
303	Not power on

304	PDN not active
305	PDN not valid
306	PDN invalid type
307	PDN no parameter
308	UE fail
309	PDN type and APN duplicate used

9.1.2 Error Code for Socket Command

Code of <err>	Error Text
402	Parameter invalid
403	Too much socket instance
404	Create socket error
405	operation not supported
406	Cannot find the socket
407	Socket Connect fail
408	Socket bind fail
409	Send data fail
410	The socket status is not connected
411	The socket status is already connected
412	The socket status is invalid
413	The socket connect timeout
414	The socket close fail
415	The socket happen fatal error
416	Cannot allocate more memory
417	No more DL buffer resource
418	The socket is connecting
419	UL sequence is invalid
420	Send request fail
421	Unknown error

9.1.3 Error Code for CTM2M

Code of <err>	Error Text
1	Other errors
2	Parameter quantity error
3	Parameter value error
4	command cannot be issued
8	The platform connection parameter is not initialized

14	The Data field length exceeds the limit
15	The Object19 transport channel does not exist
16	Unable to obtain IMSI
17	Data fields are not even in length
33	Operation failed. Logged in
34	Failed to create LWM2M session
950	Engine exception, recovering
951	The connection is unavailable, the network is congested
952	Operation failed, overwrite level 2
953	Engine exception, need to restart
954	Operation failed, not logged in
955	Operation failed, log in
957	The connection is temporarily unavailable
959	The operation is not allowed, only if ON_UQMode=2
960	Operation failed. No authentication encryption string is set
961	Error setting allowed only when IDAuth_Mode=2/3
968	Functionality not supported or otherwise
969	Lifetime exceeds the limit
970	Cache queue overruns
972	Invalid Uri_str

9.2 Summary of CMS ERROR Codes

Final result code **+CMS ERROR: <err>** indicates an error related to message service or network. The operation is similar to ERROR result code. None of the following commands in the same Command line is executed. Neither ERROR nor OK result code shall be returned.

<err> values used by common messaging commands:

Code of <err>	Meaning
300	ME failure
301	SMS service of ME reserved
302	operation not allowed
303	operation not supported
304	invalid PDU mode parameter
305	invalid text mode parameter
310	USIM not inserted
311	USIM PIN required
312	PH-(U)SIM PIN required
313	USIM failure
314	USIM busy
315	USIM wrong

316	USIM PUK required
317	USIM PIN2 required
318	USIM PUK2 required
320	memory failure
321	invalid memory index
322	memory full
330	SMSC address unknown
331	no network service
332	network timeout
340	no +CNMA acknowledgement expected
500	unknown error

9.3 Summary of Unsolicited Result Codes

URC	Description	AT Command
-----	-------------	------------