


# ***Icepap***

Intelligent Controller for Positioning Applications

## ***User Manual***



| <b>Date</b> | <b>Version</b> | <b>Comments</b>       |
|-------------|----------------|-----------------------|
| 10/09/2007  | 0.0a           | Draft in construction |
|             |                |                       |

# CONTENTS

|   |                              |
|---|------------------------------|
| <b>MANUAL ORGANIZATION</b>                          | <b>4</b>                     |
| <b>1. INSTALLATION</b>                              | <b>5</b>                     |
| 1.1. System overview                                | 5                            |
| 1.2. IcePAP components                              | Error! Bookmark not defined. |
| 1.3. Hardware connections and configuration         | 6                            |
| 1.3.1. Rack number                                  | 6                            |
| 1.3.2. Board installation (controllers and drivers) | 6                            |
| 1.3.3. Rack links and termination                   | 6                            |
| 1.3.4. Rack disable                                 | 6                            |
| 1.3.5. Communication links                          | 6                            |
| 1.3.6. Motor and encoder connection                 | 6                            |
| 1.3.7. Ventilation                                  | 6                            |
| 1.4. Installation tips                              | 6                            |
| <b>2. DRIVER CONFIGURATION</b>                      | <b>8</b>                     |
| 2.1. Basic concepts                                 | 8                            |
| 2.1.1. Motor types                                  | 8                            |
| 2.1.2. Axis resolution                              | 8                            |
| 2.2. Configuration parameters                       | 9                            |
| <b>3. OPERATION INSTRUCTIONS</b>                    | <b>11</b>                    |
| 3.1. Command basics                                 | 11                           |
| 3.1.1. System Commands                              | 11                           |
| 3.1.2. Board Commands                               | 11                           |
| 3.2. Moving motors                                  | 11                           |
| 3.3. Usage tips                                     | 11                           |
| <b>4. COMMAND SET</b>                               | <b>12</b>                    |
| 4.1. Command reference                              | 18                           |
| 4.2. Board status registers                         | 58                           |
| 4.3. IcePAP command quick reference                 | 59                           |
| <b>5. COMMUNICATION PROTOCOL</b>                    | <b>12</b>                    |
| 5.1. Communication port                             | Error! Bookmark not defined. |
| A.1.1. Serial line ports                            | Error! Bookmark not defined. |
| A.1.2. GPIB interface                               | Error! Bookmark not defined. |
| 5.2. Syntax conventions                             | 12                           |
| A.1.3. Commands and requests                        | 12                           |
| A.1.4. Addressing                                   | 13                           |
| 5.3. Terminal mode                                  | 14                           |
| 5.4. Binary transfer                                | 14                           |
| A.1.5. Serial port binary blocks                    | 15                           |
| A.1.6. GPIB binary blocks                           | 15                           |

# MANUAL ORGANIZATION

This manual presents ....

Section 1 gives a brief overview of ... The description is made in general terms and specific technical details are minimised.

Section 2 describes .... The connectors and signals functions of both front and rear panels are detailed.

Section 3 is dedicated to ... in a *real world* setup.


Section 4 covers the available commands to communicate with IcePAP systems.

Section 5 is intended to describe the programming aspects of ....

## Related Documentation


- *[IcePAP Hardware Manual](#)*

Presents in detail the components and functionality of the IcePAP system and provides a complete connector description.



- *[IcePAP Configuration and Test Tool](#)*

Describes the GUI tool used for driver configuration and testing.



# 1. INSTALLATION

## 1.1. System overview

IcePAP is a motor control system developed at the ESRF and optimised for high resolution position applications. An IcePAP system may drive up to 128 axes and integrates both control features, like trajectory generation, and the motor power management. Although motor control in IcePAP is axis-oriented, it includes system resources that allow the execution of synchronous multi-axis movements. In addition, all the position information signals are driven through internal multiplexers and can be sent to external devices to properly synchronise data acquisition during motion.

Besides high performance, IcePAP is fully software configurable and provides exhaustive diagnostic capabilities. Most of the functionality relies on programmable components what opens the possibility of adding new features by means of firmware upgrade.

### Components

The IcePAP system is organised in racks. The mechanical support of each rack is provided by a 19" 3U crate that includes the power supply and an interconnection backplane with 9 slots.

The leftmost slot is wider than the other slots and must be always equipped with a controller board. The other slots may be equipped with 1 to 8 driver boards. Each driver board can operate a motorised axis.

The unused slots must be covered with blank front panel plates to avoid accidental access to energised parts.

Figure 1 depicts an IcePAP crate populated with 5 driver boards.




Figure 1: Example of a partially equipped IcePAP rack

Several racks can be connected to form a single multirack IcePAP system.

Each rack must be identified with a different number (0 to 15) that is visualised in a two-digit display at the controller front panel.

In a multirack system one of the controllers is the system master and takes care of communications and system management. The others are slaves.

Two types of controller boards: Master and slaves

If an multirack system includes more than one master board, the board in the rack with the lowest number operates as system master, the other master boards operate as slaves. Slave boards can never be configured or operate as system masters.

A more complete description of the IcePAP system and its hardware resources can be found in the *IcePAP Hardware Manual*.

## **1.2. Hardware connections and configuration**

### **1.2.1. Rack number**

Rotary switch (hexadecimal).

Controller must be extracted and rack power switched off (switch at the back).

Once the rack number is properly set, the controller board can be plugged in the leftmost slot.

### **1.2.2. Board installation (controllers and drivers)**

No hardware configuration required. Driver configuration is implemented by software commands.

### **1.2.3. Rack links and termination**

Multi-axis system needs rack links  
lengths, wiring.

Bus terminator.

### **1.2.4. Rack disable**

Each rack includes a disable connector at the rear panel that allows to disable remotely the motor power of all the driver boards in the rack.

If not used ([what happens?])

### **1.2.5. Communication links**

Ethernet, serial (baudrate, wiring) (USB not implemented yet)

### **1.2.6. Motor and encoder connection**

As described in the Hardware Manual.

Connecting the axis disable line is mandatory

Proper grounding and shielding.

### **1.2.7. Ventilation**

IcePAP racks do not include internal fans of other method for forced ventilation. External ventilation may be necessary .

It is recommended that ...

[At least the case of installation in closed 19" cabinets.]

## **1.3. Installation tips**

- It is always useful to check ....
- Use ...

## **2. DRIVER CONFIGURATION**

By software commands  
Stored in non-volatile memory.  
Use the configuration Tool

Commands: CONFIG, ?CONFIG, CFG, ?CFG, ?CFGINFO

### **2.1. Basic concepts**

#### **2.1.1. Motor types**

Supported types

#### **2.1.2. Axis resolution**

Axis resolution.



## 2.2. Configuration parameters

|           |  |
|-----------|--|
| ACTIVE    | {NO   YES}<br>Axis enable/disable flag                                     |
| PROTLEVEL | <integer><br>Protection level  |
| NAMELOCK  | {NO   YES}<br>Lock axis name   |
| ADDRESS   | <integer><br>Driver address (0 = no check)                                 |
| POWERON   | {NO   YES}<br>Remember motor power state at driver power on                |
| MOTPHASES | {1   2   3}<br>Number of electrical phases (default 2)                     |
| MOTSENSE  | {NORMAL   INVERTED}<br>Sense of motor rotation                             |
| MOTPOLES  | <integer><br>Number of pole pairs  |
| MREGMODE  | {EXT   VOLT   CURR   CURR_VECT   TORQUE}<br>Motor regulation mode          |
| NVOLT     | <float><br>Nominal operation voltage (Volt)                                |
| NCURR     | <float><br>Nominal current (Amp)   |
| BCURR     | <integer><br>Boost/max current increment (%)                               |
| ICURR     | <integer><br>Idle current (%)  |
| MREGP     | <float>  |
| MREGI     | <float>  |
| MREGD     | <float>  |
| MRESFQ    | <integer><br>Resonance frequency (units is tricky), to be removed probably |
| MRESBW    | <integer><br>Resonance bandwidth (units is tricky), to be removed probably |
| ANTURN    | <integer><br>Axis reference number of turns (default: 1)                   |
| ANSTEP    | <integer><br>Axis reference number of steps (default: 400)                 |
| DEFVEL    | <float><br>Default velocity (steps/sec)                                    |
| DEFIVEL   | <float><br>Default initial velocity (steps/sec)                            |
| DEFACCT   | <float><br>Default acceleration time (sec)                                 |
| INDEXER   | {INTERNAL   INPOS   ENCIN}<br>Indexer source                               |
| SHFTENC   | {NONE   INPOS   ENCIN   ABSENC}<br>Shaft encoder                           |
| TGTENC    | {NONE   INPOS   ENCIN   ABSENC}<br>Target encoder                          |
| POSSRC    | {INDEXER   SHFTENC   TGTENC}<br>Axis position source                       |
| CLOOP     | {NONE   SHFTENC   TGTENC}<br>Default closed loop signal                    |
| LPPOL     | {NORMAL   INVERTED}<br>Polarity of the Limit+ signal                       |
| LMPOL     | {NORMAL   INVERTED}<br>Polarity of the Limit- signal                       |
| EINNTURN  | <integer><br>Encln reference number of turns                               |
| EINNSTEP  | <integer><br>Encln reference number of steps                               |
| EINMODE   | {QUAD   PULSE+   PULSE-}<br>Mode of Encln                                  |
| EINSENSE  | {NORMAL   INVERTED}<br>Sense of Encln                                      |

|           |  |
|-----------|--|
| INPNTURN  | <integer><br>InPos reference number of turns   |
| INPNSTEP  | <integer><br>InPos reference number of steps   |
| INPMODE   | {QUAD   PULSE+   PULSE-}<br>Mode of InpPos   |
| INPSENSE  | {NORMAL   INVERTED}<br>Sense of InPos  |
| ABSNTURN  | <integer><br>AbsEnc reference number of turns  |
| ABSNSTEP  | <integer><br>AbsEnc reference number of steps  |
| ABSENSE   | {NORMAL   INVERTED}<br>Sense of AbsEnc is inverted   |
| ABSOFFSET | <integer><br>AbsEnc offset   |
| OUTPSRC   | {AXIS   INDEXER   SHFTENC   TGTENC   INPOS   ENCIN   SYNC}<br>Source signal for OutPos   |
| OUTPMODE  | {QUAD   PULSE+   PULSE-}<br>Mode of InpPos   |
| OUTPPULSE | {200NS   200NS   2US   20US}<br>Pulse width (if mode is set to PULSE+ or PULSE-)   |
| OUTPSENSE | {NORMAL   INVERTED}<br>Sense of InPos  |
| INFASRC   | {LOW   HIGH   LIM+   LIM-   HOME   ENCAUX   INPAUX   SYNCAUX   ENABLE   ALARM  <br>READY   MOVING   BOOST   STEADY}<br>Source signal for InfoA |
| INFAPOL   | {NORMAL   INVERTED}<br>Polarity of InfoA   |
| INFBSRC   | {LOW   HIGH   LIM+   LIM-   HOME   ENCAUX   INPAUX   SYNCAUX   ENABLE   ALARM  <br>READY   MOVING   BOOST   STEADY}<br>Source signal for InfoB |
| INFBPOL   | {NORMAL   INVERTED}<br>Polarity of InfoB   |
| INFCSRC   | {LOW   HIGH   LIM+   LIM-   HOME   ENCAUX   INPAUX   SYNCAUX   ENABLE   ALARM  <br>READY   MOVING   BOOST   STEADY}<br>Source signal for InfoC |
| INFCPOL   | {NORMAL   INVERTED}<br>Polarity of InfoC   |

## 3. OPERATION INSTRUCTIONS

This section deals with ...

### 3.1. Command basics

ASCII commands.

#### 3.1.1. System Commands

...

#### 3.1.2. Board Commands

...

### 3.2. Moving motors

### 3.3. Usage tips

Refer to Section 5.1 for all the commands mentioned below.

- It is quite common to have a situation where one wants to change an incremental encoder direction sign. This can be done easily by using the *INV* keyword in the correspondent channel configuration. Moreover, the *INV* keyword can be also used to change the polarity of the input signals (see the *CHCFG* command).
- It is always useful to check the .... The command allows .

## 4. COMMUNICATION PROTOCOL

### 4.1. Communication basics

This section covers the IcePAP communication protocol. The communication interface is implemented at the system master board.

Communication is achieved by bi-directional byte streams. Normal command and response messages are transferred as lines of printable ASCII characters. The only exception is the transfer of binary data blocks, a special feature described in 4.5.

Commands messages sent to IcePAP must be formatted as sequences of printable characters terminated by a “*carriage return*” (ASCII 0x0D). Any additional control character, like “*line feed*”, is ignored.

Response messages produced by the device consist on lines terminated by a “*carriage return*” + “*line feed*” character sequence (ASCII 0x0D 0x0A).

#### 4.1.1. System commands

Commands that ... These commands are processed by the system master.

#### 4.1.2. Board commands

Commands addressed to specific boards. Both controller and drivers

#### 4.1.3. Local driver interface

Each driver board has an individual communication port for diagnostic purposes. It can also be used for stand alone operation ( no further discussed).

### 4.2. Interfaces

The master boards integrate three communication ports: an Ethernet interface, a serial line and an USB port. The characteristics of the different interfaces are the following:

| <i>Interface</i>            | <i>Type</i>     | <i>Parameters</i>                      |
|-----------------------------|-----------------|--|
| <b>Serial Line</b>          | <b>RS232</b>    | 9600bauds, No parity, 1 stop bit       |
| <b>Ethernet</b>             | <b>100baseT</b> | TCP sockets, port 5000                 |
| <b>Universal Serial Bus</b> | <b>USB 1.0</b>  | Not implemented in the current version |

### 4.3. Syntax conventions

In the most usual case remote control is implemented by an application program running in a host computer that sends commands and requests to the *isgdevice* as sequences of ASCII characters. The syntax rules are described below. See X for practical examples.

#### 4.3.1. Commands and requests

- Command lines consist of a command keyword optionally followed by parameters.
  - The number and type of parameters depend on the particular command.
- Command keywords are not case sensitive.
  - The device converts internally all the characters to uppercase before any syntax checking. (TO BE DISCUSSED)

- Parameters are also converted to uppercase unless they are enclosed between double quotes (" ", ASCII 0x22). (TO BE DISCUSSED)
- Commands may be optionally preceded by the acknowledge character.
  - The acknowledge character is a hash symbol (#, ASCII 0x23) that must appear in the command line immediately before the first character of the command keyword.
- Normal (non query) commands never produce response messages unless the acknowledge character is used.
  - Non query command keywords always start by an alphabetical character (A to Z). Exceptions are binary transfer commands (see XX) that start by an asterisk character (\*, ASCII 0x2A).
  - If the acknowledge character is used, the device produces the response string OK if the command execution was successful.
  - If the acknowledge character is used and the command does not execute successfully, the device produces either the string ERROR or a string containing a human readable error message. The behaviour depends on the current setting of the echo mode (see 4.4).
- Requests are query commands that produce response messages from the device.
  - Requests keywords always start by a question mark character (?, ASCII 0x3F).
  - If the request is successful the content of the response message depends on the particular request.
  - If request fails the device produces either the string ERROR or a string containing a human readable error message. The behaviour depends on the current setting of the echo mode (see 4.4).
  - The acknowledge character has no effect when used with requests.
- Response messages consist of one or more ASCII character lines.
  - The way every line in a response message is terminated depends on the type of communication port (see **Error! Reference source not found.**).
  - A response message may contain either the output of a request, an acknowledgement keyword (OK or ERROR) or a human readable error message.
  - When a response message consists of more than one line, the first and last lines contain a single dollar character (\$, ASCII 0x3F).

#### 4.3.2. Addressing

- Board commands must be sent to the specific controller or drivers boards by using an addressing prefix. An addressing prefix consists of the board address in decimal format followed by a colon character (:, ASCII 0x3A). No spaces are allowed between the last address digit and the colon character.
- An addressing prefix consisting of only the colon character (:) with no address string is interpreted as a broadcast command. In that case the command is forwarded to all the boards in the system. Controller boards ignore broadcasts of driver-only commands as well as driver boards ignore controller-only broadcasts. No queries or acknowledge characters are allowed in broadcasts.

#### 4.4. Terminal mode

When an IcePAP system is accessed through a serial port, two possible communication modes are available that can be selected with the commands `ECHO` and `NOECHO`. The differences between these two modes are described below. These commands can be issued through other interfaces (i.e. Ethernet) but they only have effect on the serial port.

##### Echo mode (terminal mode)

This mode should be used when the IcePAP master board is connected to a dumb terminal. In this case the user types commands on the keyboard and reads the answers and error messages on the terminal screen without computer intervention. This mode is usually not active by default and the user has to send the `ECHO` command every time the device is powered on.

In echo mode all the characters sent to the device are echoed back to the terminal. The device also sends human-readable messages to be printed on the terminal screen whenever an error is detected in commands or requests.

Case conversion takes place before the characters are sent back to the terminal, therefore characters are echoed back as uppercase even if they are typed and sent to the device as lowercase. (TO BE DISCUSSED)

In echo mode the backspace character (ASCII 0x08) has the effect of deleting the last character received by the device. In this way a minimum editing functionality is provided.

##### Noecho mode (host computer)

This is the default mode. In this case no characters are echoed and no error messages are returned by non-query commands unless they are explicitly requested by the acknowledge character. This mode is intended to be used when a program running in a host computer communicates with the controller, sending commands and analysing the answers.

#### 4.5. Binary transfer

Binary transfer is a special mode that extends the standard protocol allowing faster data transfer. Binary blocks have a maximum size of 65535 data bytes (0xFFFF).

Binary transfer commands or requests are initiated by ASCII command lines that follow the same rules than ordinary commands or requests (see 4.3.1). The only difference is that binary transfer command lines must include an asterisk character (\*, ASCII 0x2A) in the command or request keyword. Non-query commands keywords must start by an asterisk character. Request keywords must include the asterisk as the first character after the question mark.

Once the *isgdevice* has received the ASCII command line, the data is transferred as a binary block. In the case of non-query commands, the binary data block is sent from the host computer to the device. In case of binary requests, the device sends the binary block to the host (serial line) or puts it in its output buffer ready to be read by the host (GPIB).

If the device finds an error in a command line containing a binary request, instead of the binary block, it produces the string `ERROR`.

The acknowledge character (#, ASCII 0x23) can be used in the same way that with non-binary commands. If it is included in a non-query command line, the device produces an acknowledgement keyword (`ERROR` or `OK`) to signal if the command line contained errors or not. The acknowledge character has no effect in the case of binary requests.

Although binary transfer is initiated in the same way for both serial line and GPIB communication, the format of the binary data blocks and the management of the end of transfer condition are different in both cases.

#### 4.5.1. Serial port binary blocks

In the case of transfer through a serial port, the binary block contains the binary data and 4 extra bytes. The structure of the block is the following:

| byte Number  | content           |
|--------------|-------------------|
| 0            | 0xFF (signature)  |
| 1            | DataSize (MSB)    |
| 2            | DataSize (LSB)    |
| 3            | data byte (first) |
| ...          | ...               |
| DataSize + 2 | data byte (last)  |
| DataSize + 3 | Checksum          |

The first byte contains always the value 0xFF (255) and can be used the signature of the block. The next two bytes contain the number of data bytes to transfer. The last byte contains the check sum value that is used to verify data integrity.

The checksum value is calculated as the lower 8-bits of the sum of all the bytes in the binary block with exception of the signature byte (and the checksum byte itself).

#### 4.5.2. TCP binary blocks

In the case of transfer by Ethernet, the binary block does not contain any additional control or protocol byte. Only the actual data bytes are transferred. The EOI line is asserted during the transfer of the last data byte to signal the end of the transmission.

## 5. COMMAND SET

### BOARD COMMANDS

| Command  |           | Description                                   | Controller               | Driver                   | Page |
|----------|-----------|---|--------------------------|--------------------------|------|
|          | ?MODE     | Query board mode                              | <input type="checkbox"/> | <input type="checkbox"/> | 39   |
|          | ?STATUS   | Query board status                            | <input type="checkbox"/> | <input type="checkbox"/> | 53   |
| CONFIG   | ?CONFIG   | Manage configuration mode                     |                          | <input type="checkbox"/> | 25   |
| CFG      | ?CFG      | Set/query configuration parameters            |                          | <input type="checkbox"/> | 18   |
|          | ?CFGINFO  | Query configuration parameter info            |                          | <input type="checkbox"/> | 23   |
|          | ?VER      | Query board version information               | <input type="checkbox"/> | <input type="checkbox"/> | 57   |
| NAME     | ?NAME     | Set/query board name                          |                          | <input type="checkbox"/> | 41   |
|          | ?ID       | Query board identification                    | <input type="checkbox"/> | <input type="checkbox"/> | 34   |
|          | ?POST     | Query power-on selftest results               | <input type="checkbox"/> | <input type="checkbox"/> | 45   |
| POWER    | ?POWER    | Set/query motor power state                   |                          | <input type="checkbox"/> | 46   |
| AUXPS    | ?AUXPS    | Set/query auxiliary power supply state        |                          | <input type="checkbox"/> | 21   |
|          | ?MEAS     | Query measured value                          | <input type="checkbox"/> | <input type="checkbox"/> | 38   |
| POS      | ?POS      | Set/query axis position in axis units         | <input type="checkbox"/> | <input type="checkbox"/> | 43   |
| ENC      | ?ENC      | Set/query axis position in encoder steps      | <input type="checkbox"/> | <input type="checkbox"/> | 27   |
| VELOCITY | ?VELOCITY | Set/query programmed axis velocity            | <input type="checkbox"/> | <input type="checkbox"/> | 56   |
| ACCTIME  | ?ACCTIME  | Set/query acceleration time                   | <input type="checkbox"/> | <input type="checkbox"/> | 19   |
| MOVE     |           | Start absolute movement                       | <input type="checkbox"/> | <input type="checkbox"/> | 40   |
| RMOVE    |           | Start relative movement                       | <input type="checkbox"/> | <input type="checkbox"/> | 51   |
| CMOVE    |           | Start relative movement in configuration mode |                          | <input type="checkbox"/> | 24   |
| STOP     |           | Stop movement                                 | <input type="checkbox"/> | <input type="checkbox"/> | 54   |
| ABORT    |           | Abort movement                                | <input type="checkbox"/> | <input type="checkbox"/> | 18   |
| INDEXER  | ?INDEXER  | Set/query indexer signal source               |                          | <input type="checkbox"/> | 35   |
| INFOA    | ?INFOA    | Set/query InfoA signal source and polarity    |                          | <input type="checkbox"/> | 36   |
| INFOB    | ?INFOB    | Set/query InfoB signal source and polarity    |                          | <input type="checkbox"/> | 36   |
| INFOC    | ?INFOC    | Set/query InfoC signal source and polarity    |                          | <input type="checkbox"/> | 36   |
|          | ?HELP     | Query list of available commands              | <input type="checkbox"/> | <input type="checkbox"/> | 33   |
|          | ?ERRMSG   | Query last command error message              | <input type="checkbox"/> | <input type="checkbox"/> | 29   |
|          | ?FERRMSG  | Query first error message                     | <input type="checkbox"/> | <input type="checkbox"/> | 30   |
| ECHO     |           | Select echo mode                              |                          | <input type="checkbox"/> | 26   |
| NOECHO   |           | Cancel echo mode                              |                          | <input type="checkbox"/> | 42   |
|          | ?ADDR     | Query board address                           | <input type="checkbox"/> | <input type="checkbox"/> | 20   |



## SYSTEM COMMANDS

| Command       |           | Description                                       | Page |
|---------------|-----------|---|------|
| MODE          | ?MODE     | Set/query system mode                             | 39   |
|               | ?SYSSTAT  | Query system configuration                        | 55   |
|               | ?STATUS   | Query multiple board status                       | 53   |
|               | ?FSTATUS  | Query multiple board fast status                  | 32   |
| REPORT        | ?REPORT   | Set/query asynchronous report settings            | 48   |
|               | ?VER      | Query system firmware version information         | 57   |
|               | ?RID      | Query rack identification string                  | 50   |
|               | ?RTEMP    | Query rack temperatures                           | 52   |
| *PROG<br>PROG |           | Firmware programming                              | 47   |
| RESET         |           | System or rack reset                              | 49   |
|               |           |   |      |
| POS           | ?POS      | Set/query multiple axis position in axis units    | 43   |
| ENC           | ?ENC      | Set/query multiple axis position in encoder steps | 27   |
|               | ?FPOS     | Query multiple board fast position                | 31   |
| VELOCITY      | ?VELOCITY | Set/query programmed multiple axis velocity       | 56   |
| ACCTIME       | ?ACCTIME  | Set/query acceleration time                       | 19   |
| MOVE          |           | Start multiple axis absolute movement             | 40   |
| RMOVE         |           | Start multiple axis relative movement             | 51   |
| STOP          |           | Stop multiple axis movement                       | 54   |
| ABORT         |           | Abort movement                                    | 18   |
|               |           |   |      |
|               | ?HELP     | Query list of available commands                  | 33   |
|               | ?ERRMSG   | Query last command error message                  | 29   |
| ECHO          |           | Select serial line echo                           | 26   |
| NOECHO        |           | Cancel serial line echo                           | 42   |

## 5.1. Command reference

### ABORT

*Abort movement*

Syntax:

**<board\_addr>:ABORT** (board command)

or

**ABORT [ <axis1> <axis2> ... <axisN>]** (system command)

Description:

The ABORT command ...

---

Examples:

Command: 16:ABORT

Command: ABORT // abort all axes

Command: ABORT 30 33 42

## ACCTIME / ?ACCTIME

*Set/query acceleration time*

Syntax:

**<board\_addr>:ACCTIME [ <accTime> ]** (board command)  
or  
**ACCTIME <axis1> <accTime1> ... <axisN> <accTimeN>** (system command)

Description:

Sets the acceleration time for the corresponding axis to the <accTime> values in seconds. The actual acceleration for each axis is calculated internally based on the current value of the axis velocity (see VELOCITY command).

If no value is specified, the acceleration time is set to the default value.

The acceleration time is internally recalculated every time that the axis velocity changes.

---

Syntax:

**<board\_addr>:?ACCTIME** (board command)  
or  
**?ACCTIME <axis1> <axis2> ... <axisN>** (system command)

Answer:

**<board\_addr>:?ACCTIME <accTime>** (board answer)  
or  
**?ACCTIME <accTime1> <accTime2> ... <accTimeN>** (system answer)

Description:

Returns the current acceleration time in seconds.

---

Examples:

## **?ADDR**

*Query board address*

Syntax:

**<board\_addr>:?ADDR**

Answer:

**<board\_addr>:?ADDR <board\_addr>**

Description:

The ?ADDR command returns the current board address. This command is only useful when the board is accessed through the local serial line interface.

---

Examples:

Command: 16:ABORT

Command: ABORT // abort all axes

Command: ABORT 30 33 42

## **AUXPS / ?AUXPS**

*Set/query axis auxiliary power supply state*

Syntax:

**<driver\_addr>:AUXPS [ {ON | OFF} ]**

Description:

Switches on or off the auxiliary power supply in a driver board. When the auxiliary power supply is switched off, the motor power is also switched off.

---

Syntax:

**<driver\_addr>:?AUXPS**

Answer:

**<driver\_addr>:?AUXPS [ {ON | OFF} ]**

Description:

Returns the state of the auxiliary power supply of the driver board.

---

Examples:

## CFG / ?CFG

*Set/query configuration parameters*

Syntax:

**<driver\_addr>:CFG <configPar> <configVal>**

Description:

The CFG command allows to change the current values of the configuration parameters of a driver board. The driver has to be previously switched into configuration mode (see CONFIG command).

The configuration of driver boards as well as the list of available parameters is detailed in chapter DRIVER CONFIGURATION2.

---

Syntax:

**<driver\_addr>:?CFG [ <configPar> ]**

Answer:

**<driver\_addr>:?CFG <configPar> <configVal>**

**or**

**<driver\_addr>:?CFG \$  
    <configPar1> <configVal1>  
    <configPar2> <configVal2>  
    ...  
    <configParN> <configValN>  
\$**

Description:

The ?CFG query returns the value <configVal> assigned to a particular configuration parameter <configPar>. If no parameter is specified, the query returns a multiline answer with the complete list of configuration parameters and their current values.

---

Examples:

```
Command: 15:?CFG NCURR
Answer:  15:?CFG NCURR 2.4

Command: 23:?CFG
Answer:  23:?CFG $
        ACTIVE YES
        PROTLEVEL 0
        NAMELOCK NO
        ADDRESS 17
        POWERON YES
        MOTPHASES 2
        MOTORSENSE INVERTED
        ...
        INFCPOL NORMAL
        $
```

## ?CFGINFO

Query configuration parameter info

Syntax:

**<driver\_addr>:?CFGINFO [ <configPar> ]**

Answer:

**<driver\_addr>:?CFGINFO <configPar> {INTEGER | FLOAT | *labelList* }**

or

**<driver\_addr>:?CFGINFO \$  
    <configPar1> {INTEGER | FLOAT | *labelList1* }  
    <configPar2> {INTEGER | FLOAT | *labelList2* }  
    ...  
    <configParN> {INTEGER | FLOAT | *labelListN* }  
\$**

Where *labelList* is a list of character strings separated by whitespaces and enclosed in curly braces ({}).

Description:

The ?CFGINFO query returns the type of the configuration parameter <configPar>. Possible types are numeric (*INTEGER* or *FLOAT*) or string. In the case of strings the query returns the list of acceptable values.

If no parameter is specified, the query returns a multiline answer with the complete list of type information for all the driver configuration parameters.

---

Examples:

```
Command: 7:?CFGINFO NCURR
Answer: 7:?CFGINFO FLOAT

Command: 103:?CFGINFO
Answer: 103:?CFGINFO $
ACTIVE {NO YES}
PROTLEVEL INTEGER
NAMELOCK {NO YES}
POWERON {NO YES}
MOTPHASES {1 2 3}
MOTORSENSE {NORMAL INVERTED}
...
INFCPOL {NORMAL INVERTED}
$
```

## **CMOVE**

*Start relative movement in configuration mode*

Syntax:

**<driver\_addr>:CMOVE <absolutePos>**

Description:

Performs a relative movement on the specified driver board. This command can be executed when the driver is in configuration mode. In that case other move commands are not authorised.

---

Examples:

Command:   115:CMOVE -7000



## CONFIG / ?CONFIG

*Manage configuration mode*

Syntax:

**<driver\_addr>:CONFIG [ <confID> ]**

Description:

The CONFIG command allows to switch a driver board into configuration mode. A driver board cannot be switched into configuration mode when the IcePAP system is in *PROG* or *TEST* modes (see MODE command).

When a driver is in configuration mode, the driver configuration parameters can be modified with the CFG command. Once the configuration has been modified, the CONFIG command issued with a non empty <confID> string as parameter validates the current configuration and stores it in the internal non volatile memory of the driver board. The <confID> string is also stored in the driver and can be used to identify the particular set of configuration parameters. The board also switches back to *OPER* mode.

If the driver is in configuration mode and the CONFIG command is issued with no parameters, the driver goes back to OPER mode but the last valid configuration is reloaded and the most recent changes are lost.

---

Syntax:

**<driver\_addr>:?CONFIG**

Answer:

**<driver\_addr>:?CONFIG <confID>**

Description:

The ?CONFIG query returns the identifier of the last valid configuration parameter set.

---

Examples:

```
Command: 32:?CFG ACTIVE
Answer:  32:?CFG NO

Command: ?MODE
Answer:  ?MODE OPER           // System mode is OPER

Command: 32:CONFIG           // Switch axis 32 into CONFIG mode
Command: 32:?MODE
Answer:  32:?MODE CONFIG

Command: 32:CFG ACTIVE YES    // Change configuration parameter
Command: 32:CONFIG CONF001    // Validate driver configuration
Command: 32:?CFG ACTIVE
Answer:  32:?CFG YES
```

## ECHO

*Set echo mode*

Syntax:

**ECHO**

(system command)

or

**<board\_addr>:ECHO**

(board command)

Description:

Switches the echo mode on.

---

Example:

Command: ECHO

Command: 92:ECHO

## ENC / ?ENC

*Set/query axis position in encoder steps*

Syntax:

**<board\_addr>:ENC [ *pos\_sel* ] <posVal>** (board command)  
or  
**ENC [ *pos\_sel* ] <axis1> <posVal1> ... <axisN> <posValN>** (system command)

Description:

Loads the position registers in the specified boards with the <posVal> values. The specific register is selected by the optional parameter *pos\_sel*, that must be one of the following values:

| <i>pos_sel</i> | <i>Position register</i> |
|----------------|--------------------------|
| AXIS           |                          |
| INDEXER        |                          |
| EXTERR         |                          |
| SHFTENC *      |                          |
| TGTENC *       |                          |
| ENCIN *        |                          |
| INPOS *        |                          |
| ABSENC *       |                          |

\* Only valid for driver boards

If position is not specified, the value is loaded as axis position

Syntax:

**<board\_addr>:?ENC [ *pos\_sel* ]** (board query)  
or  
**?ENC [ *pos\_sel* ] <axis1> <axis2> ... <axisN>** (system query)

Answer:

**<board\_addr>:?ENC <posVal>** (board answer)  
or  
**?ENC <posVal1> <posVal2> ... <posValN>** (system answer)

Description:

Returns the current signal source used as axis indexer.

Examples:

Command: 115:ENC AXIS 500  
Command: 115:ENC INDEXER -3000

Command: 115: ?ENC  
Answer: 115: ?ENC 500  
Command: ?ENC INDEXER 5 115  
Answer: ?ENC 13467895 -3000

## **?ERRMSG**

*Query last command error message*

Syntax:

**?ERRMSG** (system query)  
or  
**<board\_addr>:?ERRMSG** (board query)

Answer:

**?ERRMSG [ <errorMessage> ]** (system answer)  
or  
**<board\_addr>:?ERRMSG [ <errorMessage> ]** (board answer)

Description:

If the previous command produced an error, the ?ERRMSG query returns the error message as an ASCII string. If the previous command was successful, the ?ERRMSG query returns an empty string.

[TODO: Explain difference: system errors, board errors].

---

Example:

```
Command:  ?VER
Answer:    ?VER 1.00
Command:   ?ERRMSG
Answer:    ?ERRMSG
Command:   15:VELOCITY 0
Command:   15:?ERRMSG
Answer:    15:?ERRMSG Out of range value
```

## **?FERRMSG**

*Query first error message*

Syntax:

**<board\_addr>:?FERRMSG**

Answer:

**<board\_addr>:?FERRMSG [command <errorMessage> ]**

Description:

Returns the message for the first command error that was produced since the last time the ?FERRMSG query was issued. The query returns the command that produced the error and the error message as an ASCII string.

[TODO: Explain difference: system errors, board errors].

---

Example:

```
Command:  ?VER
Answer:    ?VER 1.00
Command:  ?ERRMSG
Answer:    ?ERRMSG
Command:  15:VELOCITY 0
Command:  15:?ERRMSG
Answer:    15:?ERRMSG Out of range value
```

## ?FPOS

*Set/query multiple board fast position*

Syntax:

**?FPOS [ *pos\_sel* ] <axis1> <axis2> ... <axisN>**

Answer:

**?FPOS <posVal1> <posVal2> ... <posValN>**

Description:

Returns the positions for the specified axes. The specific position is selected by the optional parameter *pos\_sel*, that must be one of the following values:

| <b><i>pos_sel</i></b> | <b><i>Position register</i></b> |
|-----------------------|---------------------------------|
| AXIS                  |                                 |
| INDEXER               |                                 |

If *pos\_sel* is not specified, the values returned are the axis positions

---

Examples:

Command: ?FPOS INDEXER 17 18 19

Answer: ?POS 13467895 0 -3000

Command: ?FPOS 25

Answer: ?POS 5366703

## **?FSTATUS**

*Set/query multiple board fast status*

Syntax:

**?FSTATUS <axis1> <axis2> ... <axisN>**

Answer:

**?FSTATUS <statusReg1> <statusReg2> ... <statusRegN>**

Description:

Returns the value of the status of the selected boards as 32-bit hexadecimal values.

The difference with ?STATUS is ...

---

Example:

Command:    ?FSTATUS 80 83 85

Answer:     ?FSTATUS 0x00000003 0x00000003 0x00000003



## ?HELP

*Query list of available commands*

Syntax:

**<board\_addr>:?HELP**

(board command)

or

**?HELP**

(system command)

Description:

Returns the list of available commands and queries. The list differs between system, controller and driver commands.

---

Examples:

Command: 16 : ?HELP

Answer: \$  
RESET  
?HDWVER  
?STATE  
?RETCODE  
CLEAR  
?LIST  
RUN  
\$

## **?ID**

*Query board identification*

Syntax:

**<board\_addr>:?ID [ { HW | SN } ]**

Answer:

**<board\_addr>:?ID { <hwIDstring> | <serialNumber> }**

Description:

The ?ID query returns either the hardware identification string or the serial number.

---

Examples:

|          |                    |
|----------|--------------------|
| Command: | 16:?ID             |
| Answer:  | ?ID xxxx.xxxx.xxxx |
| Command: | 31:?ID SN          |
| Answer:  | ?ID 0034-44587     |

## INDEXER / ?INDEXER

*Select/query indexer signal source*

Syntax:

**<driver\_addr>:INDEXER [{ INTERNAL | SYNC | INPOS | ENCIN }]**

Description:

Selects the signal source used for the axis indexer.

If no value is specified, the indexer source is set to the default value defined by the configuration parameters (see CFG INDEXER).

Available signal sources:

| Source   | Indexer signal   |
|----------|--|
| INTERNAL | Internally generated indexer is used                       |
| SYNC     | Sync signal distributed through the rack backplane         |
| INPOS    | InPos signal at the front panel connector (Axis Interface) |
| ENCIN    | Encln signal at the rear panel                             |

Syntax:

**<driver\_addr>:?INDEXER**

Answer:

**<driver\_addr>:INDEXER { INTERNAL | SYNC | INPOS | ENCIN }**

Description:

Returns the current signal source used as axis indexer.

Examples:

```
Command: 34: ?CFG INDEXER
Answer:  34: ?CFG INDEXER INTERNAL // the default is INTERNAL
Command: 34: INDEXER SYNC           // change the indexer source
Command: 34: ?INDEXER
Answer:  34: ?INDEXER SYNC
Command: 34: INDEXER                // set the default value back
Command: 34: ?INDEXER
Answer:  34: ?INDEXER INTERNAL
```

**INFOA / ?INFOA**  
**INFOB / ?INFOB**  
**INFOC / ?INFOC**

*Set/query info signal source and polarity*

Syntax:

**<driver\_addr>:INFOx [ *signal\_source* [ {NORMAL | INVERTED} ] ]**

where INFOx is one of INFOA, INFOB or INFOC.

Description:

Configures the Info outputs. If the polarity is not specified it is set to NORMAL.

If *signal\_source* is not specified, the signal is configured to the default value.

Possible values of *signal\_source* are:

| Source  | ...                                    |
|---------|--|
| LOW     | low logic level                        |
| HIGH    | high logic level                       |
| LIM+    | limit- signal                          |
| LIM-    | limit+ signal                          |
| HOME    | home signal                            |
| ENCAUX  | EncAux signal                          |
| INPAUX  | InPosAux signal                        |
| SYNCAUX | SyncAux signal                         |
| ENABLE  | power enable                           |
| ALARM   | alarm condition                        |
| READY   | axis ready                             |
| MOVING  | axis moving                            |
| BOOST   | axis in acceleration phase             |
| STEADY  | axis moving at constant velocity       |
| .MAIN   | internal signals (only for diagnostic) |
| .ISR    |  |

Syntax:

**<driver\_addr>:?INFOx**

where ?INFOx is one of ?INFOA, ?INFOB or ?INFOC

Answer:

**<driver\_addr>:INFOx *signal\_source* {NORMAL | INVERTED}**

where *signal\_source* is one of the possible values presented above.

Description:

Returns the configuration of the corresponding Info output signal.

Examples:

Command: 12:INFOB READY

Command: ?12:INFOB

Answer: ?12:INFOB READY NORMAL

## ?MEAS

*Query measured value*

Syntax:

**<board\_addr>:?MEAS { VCC | VM | IM | IA | IB | IC | T }**

Answer:

**<board\_addr>:?MEAS <measured\_value>**

Description:

Returns the a measured value for the specified axes. The meaning of the possible values is in the following table:

| <i><b>magnitude</b></i> | <i><b>description</b></i> | <i><b>units</b></i> | <i><b>applies to:</b></i> |
|-------------------------|---------------------------|---------------------|---------------------------|
| VCC                     | Main power supply voltage | volts               | only drivers              |
| VM                      | Motor voltage             | volts               | only drivers              |
| I                       | Motor current             | amps                | only drivers              |
| IA                      | Phase A current           | amps                | only drivers              |
| IB                      | Phase B current           | amps                | only drivers              |
| IC                      | Phase C current           | amps                | only drivers              |
| T                       | Board temperature         | ° C                 | controllers and drivers   |
| RT                      | Power supply temperature  | ° C                 | only controllers          |

---

Examples:

Command: 15:?MEAS VCC  
Answer: 15:?MEAS 80.1  
Command: 15:?MEAS T  
Answer: 15:?MEAS 80.1

## MODE / ?MODE

*Set/query board or system mode*

Syntax:

**MODE { OPER | PROG | TEST }**

(system command)

Description:

Changes the mode of the IcePAP system to operation (*OPER*), firmware reprogramming (*PROG*) or factory test (*TEST*) modes.

In normal operation, the system must be always in mode *OPER*.

---

Syntax:

Answer:

**?MODE { OPER | PROG | TEST | FAIL }**

(system answer)

or

**<board\_addr>:?MODE { CONFIG | OPER | PROG | TEST | FAIL }**

(board answer)

Description:

Returns the current mode of the system or the specific mode of one of the boards (controllers or drivers). In normal conditions, all the board should return the same mode than the system.

If a particular driver is switched into configuration mode (see CONFIG command), the returned mode is CONFIG for that driver (note that CONFIG is not a system mode).

If a non recoverable internal hardware error happens in a particular board, that board switches FAIL mode.

---

Examples:

Command: ?MODE

Answer: ?MODE OPER

Command: 25 : ?MODE

Answer: 25 : ?MODE OPER

Command: 25 : CONFIG

Command: 25 : ?MODE

Answer: 25 : ?MODE CONFIG

Command: ?MODE

Answer: ?MODE OPER

## MOVE

*Start absolute movement*

Syntax:

**<board\_addr>:MOVE <absolutePos>** (board command)

or

**MOVE <axis1> <absolutePos1> ... <axisN> <absolutePosN>** (system command)

Description:

Performs an absolute movement on the specified axis or axes.

---

Examples:

Command: 115:MOVE 4000

Command: MOVE 115 4000

Command: MOVE 31 250000 32 -29888 33 250000



## NAME / ?NAME

*Set/query board name*

Syntax:

**<board\_addr>:NAME <boardName>**

Description:

Sets the internal board name to the ASCII string <boardName>. This name is only used for identification purposes and user convenience.

The maximum length is 20 [TODO: CHECK] characters .

If the name is locked cannot be changed.

---

Syntax:

**<board\_addr>:?NAME**

Answer:

**<board\_addr>:?NAME <boardName>**

Description:

Returns the application name field.

---

Examples:

```
Command:  #11:NAME phi
Answer:    11:NAME OK

Command:  12:?NAME
Answer:    12:?NAME th

Command:  #12:NAME tth
Answer:    12:NAME ERROR <.....>
```

## NOECHO

*Cancel echo mode*

Syntax:

**NOECHO**

(system command)

or

**<board\_addr>:NOECHO**

(board command)

Description:

Switches the echo mode off. See the ECHO command for more details. Only applies for serial line communication.

---

Example:

Command: NOECHO

Command: 2:NOECHO

## POS / ?POS

*Set/query axis position in axis units*

Syntax:

**<board\_addr>:POS [ *pos\_sel* ] <posVal>** (board command)  
or  
**POS [ *pos\_sel* ] <axis1> <posVal1> ... <axisN> <posValN>** (system command)

Description:

Loads the position registers in the specified boards with the <posVal> values. The specific register is selected by the optional parameter *pos\_sel*, that must be one of the following values:

| <i>pos_sel</i> | <i>Position register</i> |
|----------------|--------------------------|
| AXIS           |                          |
| INDEXER        |                          |
| EXTERR         |                          |
| SHFTENC *      |                          |
| TGTENC *       |                          |
| ENCIN *        |                          |
| INPOS *        |                          |
| ABSENC *       |                          |

\* Only valid for driver boards

If position is not specified, the value is loaded as axis position

Syntax:

**<board\_addr>:?POS [ *pos\_sel* ]** (board query)  
or  
**?POS [ *pos\_sel* ] <axis1> <axis2> ... <axisN>** (system query)

Answer:

**<board\_addr>:?POS <posVal>** (board answer)  
or  
**<board\_addr>:?POS <posVal1> <posVal2> ... <posValN>** (system answer)

Description:

Returns the current signal source used as axis indexer.

Examples:

Command: 115:POS AXIS 500  
Command: 115:POS INDEXER -3000

Command: 115:?POS  
Answer: 115:?POS 500  
Command: ?POS INDEXER 5 115  
Answer: ?POS 13467895 -3000

## ?POST

*Query power-on selftest results*

Syntax:

**<board\_addr>:?POST**

Answer:

**<board\_addr>:?POST <testresultMask>**

Description:

Returns the result of the power-on self tests as an binary mask <testresultMask>. A bit set to one in the mask indicates that a particular test has failed. If no tests failed during the power-on sequence, this query returns zero.

The meaning of the individual bits in <testresultMask> is summarised in the following table:

| <i>bit</i> | <i>subsystem under test</i> | <i>applies to:</i>      |
|------------|-----------------------------|-------------------------|
| 0x01       | external RAM                | controllers and drivers |
| 0x02       | non volatile FRAM           | controllers and drivers |
| 0x04       | internal 1-wire bus         | controllers and drivers |
| 0x08       | ADC                         | only drivers            |
| 0x10       | FPGA                        | controllers and drivers |
| 0x20       | external 1-wire bus         | only controllers        |
| 0x40       | CANbus                      | only controllers        |

---

Examples:

Command: 115:?POST

Answer: 115:?POST 0

## **POWER / ?POWER**

*Set/query motor power state*

Syntax:

**<driver\_addr>:POWER [ {ON | OFF} ]**

Description:

Switches on or off the motor power in a driver board.

---

Syntax:

**<driver\_addr>:?POWER**

Answer:

**<driver\_addr>:?POWER [ {ON | OFF} ]**

Description:

Returns the power state of the driver board.

---

Examples:

## **\*PROG / PROG**

*Firmware programming*

Syntax:

```
*PROG {NONE | DRIVERS | CONTROLLERS | ALL} [ FORCE ] [ SL ] [ SAVE ]  
PROG {DRIVERS | CONTROLLERS | ALL} [ FORCE ] [ SL ]
```

Description:

The \*PROG command reprograms the components of the IcePAP system by using firmware code that is transferred as a binary data block (see xxx). If the SAVE flag is used, the firmware code is stored in the non volatile FLASH memory of the system master board.

A mandatory parameter specifies the components to program, that can be either the components in driver boards (DRIVERS), in controller boards (CONTROLLERS) or in both (ALL). If the parameter is set to NONE, no components are programmed, but the \*PROG command can be used to store the firmware code in the system if the SAVE flag is used.

If one of the components in the system is already programmed with the same version of firmware, the programming operation for that specific component is skipped. This behaviour changes if the FORCE flag is used. In that case the components in the selected boards are always reprogrammed regardless of their current firmware version.

The SL flag instructs the system to use an alternative channel for firmware programming. The programming operation through the alternative channel is slower but can be used to upload firmware in driver boards that are unresponsive and that do not communicate through the internal bus.

The PROG command works in the same way than \*PROG but uses the firmware code that was previously stored in the non volatile FLASH memory of the system master board by a previous \*PROG SAVE command.

---

Examples:

## REPORT / ?REPORT

*Set/query asynchronous report settings*

Syntax:

**REPORT { ON | OFF } [ <firstRack> <lastRack> [ <maxPeriod> ] ]**

Description:

The REPORT command allows to activate (ON) or deactivate (OFF) the asynchronous reporting feature on the current communication port. When asynchronous reporting is active in a particular port (RS232 serial line or TCP socket), the IcePAP master controller sends binary data blocks containing status and position information through that port to the listening device, usually the host computer. The binary blocks contain status and position information as the values returned by the ?FSTATUS and ?FPOS queries.

The data blocks contain the status as well as the axis and indexer positions for all the boards in the selected racks. The data block is sent whenever the data in the system master board changes or after a time interval of <maxPeriod> seconds.

The block includes data from all the boards in the racks from <firstRack> to <lastRack> that must be numbers from 0 to 15.

The format of the binary blocks is the following:

[TODO: explain block format and structure]

---

Syntax:

**?REPORT**

Answer:

**?REPORT { ON | OFF } <firstRack> <lastRack> <maxPeriod>**

Description:

Returns the status and range of the asynchronous status reporting feature.

---

Examples:



## RESET

*System or rack reset*

Syntax:

**RESET [ <rackNumber> ]**

Description:

With ....

---

Examples:

Command:     RESET

Command:     RESET 8

## **?RID**

*Query rack hardware identification string*

Syntax:

**?RID [ <rackNumber1> <rackNumber2> ... <rackNumberN> ]**

Answer:

**?RID <hwIDstring1> <hwIDstring2> ... <hwIDstringN>**

Description:

The ?RID query returns the hardware identification strings of the racks specified by the list of rack numbers. If the query is issued with no parameters, it returns the identification strings of all the racks present in the system.

---

Examples:

Command:     ?RID

Answer:       ?RID xxxx.xxxx.xxxx yyyy.yyyy.yyyy

Command:     ?RID 5

Answer:       ?RID zzzz.zzzz.zzzz

## RMOVE

*Start relative movement*

Syntax:

**<board\_addr>:RMOVE <absolutePos>** (board command)

or

**RMOVE <axis1> <absolutePos1> ... <axisN> <absolutePosN>** (system command)

Description:

Performs a relative movement on the specified axis or axes.

---

Examples:

Command: 115:RMOVE -7000

Command: RMOVE 115 -7000

Command: RMOVE 31 250000 32 -29888 33 250000

## **?RTEMP**

*Query rack temperatures*

Syntax:

**?RTEMP [ <rackNumber1> <rackNumber2> ... <rackNumberN> ]**

Answer:

**?RTEMP <rackTemp1> <rackTemp2> ... <rackTempN>**

Description:

The ?RTEMP query returns the temperature of the main power supply of the racks specified by the list of rack numbers. If the query is issued with no parameters, it returns the temperatures of all the racks present in the system.

---

Examples:

Command: ?RID

Answer: ?RID xxxx.xxxx.xxxx yyyy.yyyy.yyyy

Command: ?RID 5

Answer: ?RID zzzz.zzzz.zzzz

## ?STATUS

*Query board status*

Syntax:

**<board\_addr>:?STATUS** (board query)

or

**?STATUS <axis1> <axis2> ... <axisN>** (system query)

Answer:

**<board\_addr>:?STATUS <statusReg>** (board answer)

or

**?STATUS <statusReg1> <statusReg2> ... <statusRegN>** (system answer)

Description:

Returns the current state of the boards as 32-bit hexadecimal values

---

Example:

Command: 53:?STATUS

Answer: 53:?STATUS 0x00000003

Command: ?STATUS 80 83 85

Answer: ?STATUS 0x00000003 0x00000003 0x00000003

## STOP

*Stop movement*

Syntax:

**STOP [ <axis1> <axis2> ... <axisN>]**

(system command)

or

**<board\_addr>:STOP**

(board command)

Description:

The STOP command ...

---

Examples:

Command: 10:STOP

Command: STOP

// stop all movements

Command: STOP 51 52 54

// stop selected axes

## **?SYSSTAT**

*Query system configuration*

Syntax:

**?SYSSTAT [ <rackNumber> ]**

Answer:

**?SYSSTAT <rackPresenceMask>**

or

**?SYSSTAT <driverPresenceMask> <driverAliveMask>**

Description:

By default, with no parameter, the SYSSTAT query returns a 16 bit mask that represents the list of racks present in the system. Every bit in the <rackPresenceMask> mask indicates if the corresponding rack (0 to 15) has been found in the system.

If the SYSSTAT command is issued with a valid rack number (0 to 15) as parameter, it returns two 8 bit values that indicates the drivers found in the rack and which of them are responsive. Every bit of each mask correspond to one of the drivers (1 to 8) within the rack. The bits in <driverPresenceMask> that are set to 1, indicate which driver boards are plugged in the rack. The bits in <driverAliveMask> indicates which drivers are responsive and communicate with the system master board.

In normal conditions <driverPresenceMask> and <driverAliveMask> are identical.

---

Example:

```
Command:  ?SYSSTAT
Answer:    0x004F
Command:  ?SYSSTAT 8
Answer:    0x13 0x13
```

## VELOCITY / ?VELOCITY

*Set/query programmed axis velocity*

Syntax:

**<board\_addr>:VELOCITY [ <velocity> ]** (board command)  
or  
**VELOCITY <axis1> <velocity1> ... <axisN> <velocityN>** (system command)

Description:

Sets the velocity for the corresponding axis to the <velocity> values in steps per second. The actual acceleration for each axis is maintained to the previous value, and the acceleration time is internally recalculated (see ?ACCTIME query).  
If no value is specified, the velocity is set to the default value.

---

Syntax:

**<board\_addr>:?VELOCITY** (board command)  
or  
**?VELOCITY <axis1> <axis2> ... <axisN>** (system command)

Answer:

**<board\_addr>:?VELOCITY <velocity>** (board answer)  
or  
**?VELOCITY <velocity1> <velocity2> ... <velocity1>** (system answer)

Description:

Returns the current velocity in steps per second.

---

Examples:



## ?VER

*Query firmware version information*

Syntax:

**?VER [ <verModule> ]** (system command)

or

**<board\_addr>:?VER [ <verModule> ]** (board command)

Answer:

**?VER <verModule> <verNumber>** (system answer)

or

**<board\_addr>:?VER <verModule> <verNumber>** (board answer)

Description:

Returns the version number XX.YY of the firmware.

| <i>module</i> | <i>...</i> | <i>...</i>              |
|---------------|------------|-------------------------|
| SYSTEM        |            | all cases               |
| CONTROLLER    |            | all cases               |
| DRIVER        |            | all cases               |
| DSP           |            | controllers and drivers |
| FPGA          |            | controllers and drivers |
| PCB           |            | controllers and drivers |
| IO            |            | drivers                 |
| INFO          |            | all cases               |

The ?VER INFO query returns a multiline answer with the version numbers of all the modules.

---

Example:

Command: ?VER

Answer: . . .

## 5.2. Board status registers

| DRIVER Status |           |   | CONTROLLER Status  |
|---------------|-----------|---|--|
| Bit #         | name      | value = Description   | value = Description  |
| 0             | PRESENT   | 1 = driver present  | 1 = controller present   |
| 1             | ALIVE     | 1 = board responsive  | 1 = board responsive   |
| 2-3           | MODE      | 0 = OPER<br>1 = PROG<br>2 = TEST<br>3 = CONFIG  | 0 = OPER<br>1 = PROG<br>2 = TEST<br>3 = CONFIG   |
| 4-6           | DISABLE   | 0 = enable<br>1 = axis not active<br>2 = hardware alarm<br>3 = axis disable input<br>4 = local disable switch<br>5 = software disable<br>6 = n/a<br>7 = n/a | 0 = enable<br>1 = n/a<br>2 = hardware alarm<br>3 = rack disable input<br>4 = n/a<br>5 = software disable<br>6 = n/a<br>7 = n/a |
| 7-8           | INDEXER   | 0 = internal indexer<br>1 = in-system indexer<br>2 = external indexer<br>3 = n/a  | 0 = internal indexer<br>1 = n/a<br>2 = n/a (status of multiplexer?)<br>3 = n/a   |
| 9             | READY     | 1 = ready to move   | 1 = ready to move  |
| 10            | MOVING    | 1 = axis moving   | 1 = virtual axis moving  |
| 11            | SETTLING  | 1 = closed loop in settling phase   | n/a  |
| 12            | FOLLOWERR | 1 = follow error  | n/a  |
| 13            | HDWERR    | 1 = hardware error condition  | n/a  |
| 14            | SFTERR    | 1 = software error condition  | 1 = software error condition   |
| 15-17         | STOPCODE  | 0 = end of movement<br>1 = STOP<br>2 = ABORT<br>3 = LIMIT+ reached<br>4 = LIMIT- reached<br>5 = FOLLOWERR<br>6 = DISABLE<br>7 = HDWERROR                    | 0 = end of movement<br>1 = STOP<br>2 = ABORT<br>3 = n/a<br>4 = n/a<br>5 = n/a<br>6 = n/a<br>7 = n/a                            |
| 18            | LIMIT+    | current value of the limit+ signal  | n/a  |
| 19            | LIMIT-    | current value of the limit- signal  | n/a  |
| 20            | HOMEDONE  | 1 = Home switch reached<br>(only in homing modes)   | n/a  |
| 21            | 5VPOWER   | 1 = Aux power supply on   | n/a  |
| 22            | NOCONFIG  | 1 = hardware not configure  |  |
| 23            |           | n/a   | n/a  |
| 24-31         | INFO      | In PROG mode: programming phase<br>In OPER mode: master indexer   | In PROG mode: programming phase  |

## 5.3. IcePAP command quick reference

### BOARD COMMANDS

| BOARD CONFIGURATION and IDENTIFICATION  |                                    |
|---|------------------------------------|
| <board_addr>: ?MODE   | Query board mode                   |
| <board_addr>: ?STATUS   | Query board status                 |
| <driver_addr>: CONFIG [<confID>]<br><driver_addr>: ?CONFIG                      | Manage configuration mode          |
| <driver_addr>: CFG <configPar> <configVal><br><driver_addr>: ?CFG [<configPar>] | Set/query configuration parameters |
| <driver_addr>: ?CFGINFO [<configPar>]   | Query configuration parameter info |
| <board_addr>: ?VER [<verModule>]  | Query board version information    |
| <board_addr>: ?NAME <boardName><br><board_addr>: ?NAME                          | Set/query board name               |
| <board_addr>: ?ID [{HW   SN}]   | Query board identification         |
| <board_addr>: ?POST   | Query power-on selftest results    |

| POWER AND MOTION CONTROL   |   |
|--|---|
| <driver_addr>: POWER [{ON   OFF}]<br><driver_addr>: ?POWER           | Set/query motor power state                   |
| <driver_addr>: AUXPS [{ON   OFF}]<br><driver_addr>: ?AUXPS           | Set/query auxiliary power supply state        |
| <board_addr>: ?MEAS {VCC   VM   IM   IA   IB   IC   T}               | Query measured value                          |
| <board_addr>: POS [pos_sel] <posVal><br><board_addr>: ?POS [pos_sel] | Set/query axis position in axis units         |
| <board_addr>: ENC [pos_sel] <posVal><br><board_addr>: ?ENC [pos_sel] | Set/query axis position in encoder steps      |
| <board_addr>: VELOCITY [<velocity>]<br><board_addr>: ?VELOCITY       | Set/query programmed axis velocity            |
| <board_addr>: ACCTIME [<accTime>]<br><board_addr>: ?ACCTIME          | Set/query acceleration time                   |
| <board_addr>: MOVE <absolutePos>                                     | Start absolute movement                       |
| <board_addr>: RMOVE <absolutePos>                                    | Start relative movement                       |
| <driver_addr>: CMOVE <absolutePos>                                   | Start relative movement in configuration mode |
| <board_addr>: STOP   | Stop movement                                 |
| <board_addr>: ABORT  | Abort movement                                |

| INPUT/OUTPUT  |   |
|---|---|
| <driver_addr>: INDEXER [{INTERNAL   SYNC   INPOS   ENCIN}]<br><driver_addr>: ?INDEXER   | Set/query indexer signal source           |
| <driver_addr>: INFOA [signal_source [{NORMAL   INVERTED}]]<br><driver_addr>: INFOB [signal_source [{NORMAL   INVERTED}]]<br><driver_addr>: INFOC [signal_source [{NORMAL   INVERTED}]]<br><driver_addr>: ?INFOA<br><driver_addr>: ?INFOB<br><driver_addr>: ?INFOC | Set/query Info signal source and polarity |

COMMUNICATION and ERROR MANAGEMENT

|                        |  |
|------------------------|--|
| <board_addr>: ?HELP    | Query list of available board commands |
| <board_addr>: ?ERRMSG  | Query last command error message       |
| <board_addr>: ?FERRMSG | Query first error message              |
| <board_addr>: ECHO     | Select echo mode                       |
| <board_addr>: NOECHO   | Cancel echo mode                       |
| <board_addr>: ?ADDR    | Query board address                    |

## SYSTEM COMMANDS

SYSTEM CONFIGURATION and IDENTIFICATION

|  |   |
|--|---|
| MODE {OPER   PROG   TEST}                                      |   |
| ?MODE  | Set/query system mode                     |
| ?SYSSTAT [<rackNumber>]  | Query system configuration                |
| ?STATUS <axis1> <axis2> ... <axisN>                            | Query multiple board status               |
| ?FSTATUS [<axis1> <axis2> ... <axisN>]                         | Query multiple board fast status          |
| REPORT {ON   OFF} [<firstRack> <lastRack> [<maxPeriod>]]       |   |
| ?REPORT  | Set/query asynchronous report settings    |
| ?VER [<verModule>]   | Query system firmware version information |
| ?RID [<rackNumber1> <rackNumber2> ... <rackNumberN>]           | Query rack identification string          |
| ?RTMP [<rackNumber1> <rackNumber2> ... <rackNumberN>]          | Query rack temperatures                   |
| *PROG {NONE   DRIVERS   CONTROLLERS   ALL} [FORCE] [SL] [SAVE] |   |
| PROG {DRIVERS   CONTROLLERS   ALL} [FORCE] [SL]                | Firmware programming                      |
| RESET [<rackNumber>]   | System or rack reset                      |

MOTION CONTROL

|   |   |
|---|---|
| POS [pos_sel] <axis1> <posVal1> ... <axisN> <posValN>   |   |
| ?POS [pos_sel] <axis1> <axis2> ... <axisN>              | Set/query multiple axis position in axis units    |
| ENC [pos_sel] <axis1> <posVal1> ... <axisN> <posValN>   |   |
| ?ENC [pos_sel] <axis1> <axis2> ... <axisN>              | Set/query multiple axis position in encoder steps |
| ?FPOS [pos_sel] <axis1> <axis2> ... <axisN>             | Query multiple board fast position                |
| ?VELOCITY <axis1> <velocityN> ... <axisN> <velocityN>   |   |
| ?VELOCITY <axis1> <axis2> ... <axisN>                   | Set/query programmed multiple axis velocity       |
| ACCTIME <axis1> <accTime1> ... <axisN> <accTimeN>       |   |
| ?ACCTIME <axis1> <axis2> ... <axisN>                    | Set/query acceleration time                       |
| MOVE <axis1> <absolutePos1> ... <axisN> <absolutePosN>  | Start multiple axis absolute movement             |
| RMOVE <axis1> <absolutePos1> ... <axisN> <absolutePosN> | Start multiple axis relative movement             |
| STOP [<axis1> <axis2> ... <axisN>]                      | Stop multiple axis movement                       |
| ABORT [<axis1> <axis2> ... <axisN>]                     | Abort movement                                    |

COMMUNICATION and ERROR MANAGEMENT

|         |                                  |
|---------|----------------------------------|
| ?HELP   | Query list of available commands |
| ?ERRMSG | Query last command error message |
| ECHO    | Select serial line echo          |
| NOECHO  | Cancel serial line echo          |

