


Bardac Drive Download or Upload Parameter Procedure

1. Check Bardac Drive communication and baud rates:
 - a. RDDRRDRUUU—188) PORT1 FUNCTION: Ensure it is in "**ASCII COMMS**"; If not, use up or down key to change.
 - b. RDDRRRUU —187) PORT1 BAUD RATE: Ensure it is in "**19200**"; If not, use up or down key to change.
2. Calibrate the drive to the motor for Rated Armature Amps and Rated Field Amps.
 - a. Use LLLL-----To get all the way back out.
 - b. RRURR-----2)RATE ARM AMPS: Ensure setpoint for Armature current or adjust by using the up or down key.
 - c. LDDR-----4)RATE FIELD AMPS: Ensure setpoint for field current or adjust by using the up or down key.
 - d. Use LLLL-----To get all the way back out.
 - e. RURU to SAVE all parameter on drive.
3. Connect your laptop to the newly installed Bardac Drive with the Ethernet cable provided.


Open Bardac Drive Icon on the PC




4. Select "Accept"



5. Select PL-series DC drive from "discover on serial port" on menu bar "directory"




6. Make sure "Comms Speed :19.2kb/s " as same drive setting and clips " OK"




7. If communication is OK, it will show as below.




8. Select Import date on the directory to download parameter from PC to Drive




9. Select "file" from local disk




10. Select correct file for motor and click "Open"




11. Select "OK" to progress.



12. Select "Drive Icon" and right clicks to fine parameter




13. Type "2" for Rated Armature Amps and press "OK"




14. Check "Rated Armature Amps". If it doesn't match with spec of motor, please setup parameter on drive directly.



15. Type "4" for Rated Field Amps and press "OK"




16. Check "Rate Field Amps". If it doesn't match with spec of motor, please setup parameter on drive directly.




17. Repeat to check: 5) Base Rated RPM, 6) Desired max RPM, 18) Rated Arm volts, 19) EL1/2/3 rated AC
9) Speed FBK type, 100) Field volts OP%, 11) Encoder lines if possible .


Press right clip on the mouse from drive icon. Select "Save All Parameters to EEPROM" to save all parameter.
Or save them from drive directly.



18. Select "Export Data" to save all parameter from Drive to PC.



19. Type "file name" and click "save"



20. Progress to save file.



- 21 When done, close bardac program