

AL-800 RFID READER

Getting Started Guide for AWS IoT Core



Table of Contents

1	<i>Document Information</i>	<i>3</i>
2	<i>Overview</i>	<i>4</i>
3	<i>Hardware Description.....</i>	<i>5</i>
4	<i>Set up your Development Environment</i>	<i>6</i>
5	<i>Set up your hardware.....</i>	<i>10</i>
6	<i>Setup your AWS account and Permissions.....</i>	<i>18</i>
7	<i>Create Resources in AWS IoT.....</i>	<i>18</i>
8	<i>Connect AL-800 reader to AWS IoT Core</i>	<i>19</i>
9	<i>Debugging and Troubleshooting.....</i>	<i>23</i>

1 Document Information

1.1 Revision History

Version	Modifier	Date	Modify content
1.0	BangYao	2022/11/07	First Draft

2 Overview

A fixed RFID UHF Reader with built-in operation data collection functions and integrated with the cloud. It is a RAIN RFID Reader with built-in Compact Edition Middleware that can customize information collection (TID, EPC), designated cloud service location, etc., does not need to integrate through PC or workstation. Moreover, it could be applied into various industries such as parking lots, the gate or forklifts in the warehouse to do further management or inventory to increase work efficiency.

RFID Solutions

Software	AL-800 has two methods available to develop your own application/software: <ul style="list-style-type: none">● AL-800 Software Development Kit (C#)● AL-800 Utility
Antenna	We provide various antenna patterns, such as near field, far field, and induction field, so as to meet the changeable field environment.
RFID inlay	<ul style="list-style-type: none">● General Inlay● Metal Inlay● Customized Inlay <p>This RFID inlay has a wide frequency range from 860 to 960 MHz; which means you can make your own choices to use NXP, Impinj, or Alien RFID chip, as all of them are compatible with this RFID inlay</p>

3 Hardware Description

3.1 DataSheet

Interface	
Ethernet	Ethernet 10/100 Base-T auto-MDIX Ethernet port
Wi-Fi	USB 2.0 type-B HID port, 2.4GHz
WWAN	LTE(Optional)
USB 2.0 Host	1
USB HID	1
RFID	
Air Interface Protocol	EPC global UHF Class 1 Gen2 / ISO 18000-63
Frequency Range	860~960 MHz
Frequency Resolution	100 KHz
Power Resolution	0.25dB
RX Sensitivity	-74 dBm
Antenna	4
External Storage	
Micro-SD	1
Power	
DC In	+24V / 1A
Operating Environment	
Operating Temperature	-20°C ~55°C
Storage Temperature	-20°C ~85°C
Operating Humidity	5% ~ 95%
Mechanical	
Size	183mm x 222mm x 32mm
Weight	630g
Software Development / Tool	
URC Protocol	1.1
Tool	URC Client Utility
ATB Session	3
SDK	C# .Net
Certification	
Certification	NCC, SRRC

4 Set up your Development Environment

4.1 URC C# SDK

SDK for ARIZON RFID readers with URC protocol


Support	AL-800 RFID Reader
IDE	Visual Studio Code 2022
Environment	.Net Framework 4.8 or .Net Core 7
Programming language	C#

First, you need to add URC_SDK reference to the project. (Example use **Visual Studio 2022**)


Step1. Create a new project (**ASP .NET Core**)




Step2. Name your new project




Step3. Select Framework **.NET 7.0**



Step4. In **Solution Explorer**, right-click the Reference, and then choose **Add Project Reference** from the context menu.



Step5. Click **Browse**. Choose 「URC_SDK.dll」 「System.IO.Ports.dll」, click **Add -> Confirm**



Step6. Use the Ethernet cable (Wired Network) to connect AL-800 to your computer. Run example code.

```
using URC_SDK.Communication.Serial;
using URC_SDK.RFIDReader;

void _device_OnConnectionStateChangedEvent(ConnectionStates state)
{
    if (state == ConnectionStates.Connected)
    {
        Console.WriteLine("Connection Status: Connected");
    }
}

URCDevice _device = new URCDevice("Reader1");
_device.Mode = SerialModes.TCP;
_device.OnConnectionStateChangedEvent += _device_OnConnectionStateChangedEvent;
_device.SerialSetting.TCPSetting.Ip = "192.168.50.1";
_device.SerialSetting.TCPSetting.Port = 1001;
_device.Connect();

var temperatureInfo = _device.GetTemperature();
if (temperatureInfo != null)
{
    double systemTemperature = temperatureInfo.SystemTemperature;
    double RFTemperature = temperatureInfo.RFTemperature;
    double PATemperature = temperatureInfo.PowerAmplifierTemperature;
}

_device.Disconnect();
```


4.2 URC SDK Function


Function	Description
Connect	Connect to reader.
Disconnect	Disconnect to reader.
GetTemperature	Get device temperature. (System, RF, Power Amplifier)
SetATB	Set activity tag broadcast configuration.
GetATB	Get activity tag broadcast configuration.
SetInventoryOperation	Set inventory operation
GetInventoryOperation	Get current inventory operation
SetInventoryConfiguration	Set inventory configuration.
GetInventoryConfiguration	Get inventory configuration
SetAntenna	Set reader antenna power.
GetAntenna	Get reader antenna power.
GetInventoryTag	Get tag object from inventory queue.
SetSelect	Set target tag. (filter by data mask, EPC bank)
GetSelect	Get current select setting.
WriteTag	Write data to target bank.
LockTag	Lock the target tag.
PermalLockTag	Lock the target tag.
KillTag	Kill the target tag.
SetPassword	Set an access password on the target tag. (limit write operation)
SetEndOperation	Stop current operation.
GetOperation	Get current operation.
GetGPIO	Get GPIO status.
SetGPO	Trigger output pin
SetRegion	Set RFID frequency/country.
GetRegion	Get reader RFID frequency/country.

For more details, please refer to the link below:

<https://www.arizontw.com/product-AL-800-AL-800.html>

5 Set up your hardware

5.1 Appearance description



1. **Power indicator**– On indicates power and off indicates no power.
2. **System Status indicator**– Flashing indicates that the system is powering on, and constant light indicates that the power-on is complete.
3. **System Update indicator**– A quick flash indicates a restore to a preset value in progress, and a slow flash indicates an update in progress
(*Warning: Do not turn off the power when this light is blinking!)
4. **RF Status indicator**– Standby mode when blinking slowly and RF signals being emitted when blinking fast.
5. **Receive indicator**– Fast flashing indicates that a UHF tag has been received.
6. **Wi-Fi indicator** – Illuminates to indicate that Wi-Fi is enabled, flashing indicates that communication is in progress, and off indicates that Wi-Fi is disabled.
7. **Antenna 4** – TNC connector with impedance 50Ω.
8. **Antenna 3** – TNC connector with impedance 50Ω.
9. **Antenna 2** – TNC connector with impedance 50Ω.
10. **Antenna 1** – TNC connector with impedance 50Ω.
11. **DC power JACK** – Input voltage 24V / 1.2A power supply.
12. **Reset Button** – Reboot the system on time, press and hold until the system update indicator blinks rapidly and then release to restore the unit to the factory setting.
13. **USB Device**– For RFID function communication, using a HID interface.
14. **USB Host**– Can be connected to USB stickers, VCP, 4G LTE Dongle and more.
15. **RJ-45 Ethernet** – Used to communicate with RFID function and supports 10/100Mbps twisted pair network cables above Cat.5E.
16. **Micro SD** – supports S DHC up to 64GB.
17. **Console** – The internal Linux system can be operated using TTY.
18. **GPIO D-SUB**– Connect to an external GPIO control box for use.
19. **Wi-Fi Antenna** – Connects an SMA specification 2.4GHz antenna.

20. Reserved Antenna.

5.2 Connect to the AL-800

AL-800 default built-in DHCP server, the computer please keep the network adapter settings automatically get DHCP, the following figure is Windows 10 network interface settings.



The default IP address and web login information for the AL-800 are as follows:


URL: <https://192.168.50.1/>

IP Address: 192.168.50.1


User account: root

Password : 123456

The AL-800 web control panel provides network settings, firmware updates, system settings, time and date settings, etc. (please use URC Utility for RFID operations).




5.3 Time Setting



1. Log in to the web control panel.
2. Click the **System** tab in the left menu.
3. Select **System**.
4. For the **general date and time** setting in the **system properties**, you can choose the following two setting methods:
 - 4.1 **Synchronize time with the browser (computer).**
 - 4.2 **Synchronize time with NTP server** (AL-800 requires a connection to the network).
5. Select the **time zone** you want.
6. Press **Save and Apply Settings**.

➤ NTP Setting

NTP (Network Time Protocol) can be used to automatically synchronize time with the server.



1. Log in to the web control panel.
2. Click the **System** tab in the left menu.
3. Select **System**.
4. Click the **Time Synchronization** tab.
5. Tick **Enable NTP Client**. (*To use the local area network automatically, select a **server that uses DHCP advertising**)
6. In **Alternate NTP Server**, enter a list of destination servers that you want to synchronize.
7. Press **Save and Apply Settings**.

5.4 Set the account password

Changing the default account password prevents unauthorized modification of device settings.

The screenshot shows the ARIZON web control panel for 'arizon-rfid'. The left sidebar contains a menu with 'System' expanded, showing 'Administration' as the selected option. The main content area is titled 'Router Password' and includes a subtitle 'Changes the administrator password for accessing the device'. There are two input fields: 'Password' and 'Confirmation', each with a toggle icon. A 'SAVE' button is located at the bottom right. At the very bottom, a footer line reads: 'Powered by LuCI Master (git-21.020.56896-af422b1) / ArLOS Snapshot v1.3.3-20220118 r14808-499924ad0'.

1. Log in to the web control panel.
2. Click the **System** tab in the left menu.
3. Select **Administration**.
4. In Router Password, enter the new password
5. Press **Save** and **Apply Settings**.

5.5 Mount a USB storage device and Micro-SD card

The AL-800 supports connecting external storage space from a USB storage device or Micro-SD slot, and the following explains how to attach storage to an internal archive system.


The screenshot shows the ARIZON web control panel for 'arizon-rfid'. The left sidebar has 'Mount Points' selected under the 'System' tab. The main content area is divided into two sections. The top section, 'Mounted file systems', contains a table with the following data:

Filesystem	Mount Point	Available	Used	Unmount
/dev/root	/rom	0 B / 9.00 MB	100.00% (9.00 MB)	-
tmpfs	/tmp	60.13 MB / 60.37 MB	0.40% (248.00 KB)	-
/dev/mtdblock6	/overlay	4.52 MB / 4.81 MB	6.09% (300.00 KB)	-
overlayfs/overlay	/	4.52 MB / 4.81 MB	6.09% (300.00 KB)	-
tmpfs	/dev	\$12.00 KB / \$12.00 KB	0.00% (0 B)	-

The bottom section, 'Mount Points', has a subtitle 'Mount Points define at which point a memory device will be attached to the filesystem'. It contains a table with headers: 'Enabled', 'Device', 'Mount point', 'Filesystem', 'Mount options', and 'Run filesystem check'. Below the table, it says 'This section contains no values yet' and there is an 'ADD' button. At the bottom, there is a 'SWAP' section with a note about swapping data to a swap-device and a table with headers 'Enabled' and 'Device'.

1. Plug in a USB storage device or Micro-SD memory
2. Log in to the web page background.
3. Click the **System** tab in the left menu.
4. Select **Mount points**.
5. In **Mount Points**, click **Add New**.
6. After the Enable check box is selected, select the corresponding disk area from **the device universal unique identification code UUID**. (MicroSD is usually /dev/mmcblk0p[N], where [N] is the disk number of the memory card, the example in the picture is


mmcblk0p2.)



7. Select Custom at the **mount point**, enter /mnt/[Custom Name], and press **Save**.
8. After pressing **Save** and **Apply**, it takes effect immediately.

5.6 Upgrades the firmware

In order to ensure system stability and introduce new features, new versions of the firmware will be released from time to time.




1. Log in to the web page background.
2. Click the **System** tab in the left menu.
3. Select **Backup/Flash Firmware**.
4. In **Flash new firmware image**, click **Flash Image File**.
5. Press **Browse** to select the image file and click **Upload**.



6. Follow the on-screen instructions to continue with the update, and do not interrupt the power supply during the update, otherwise it will cause damage to the firmware.

5.7 Set Wi-Fi to client mode

The AL-800 supports 802.11 b/g/n wireless networks, the default is access point mode to accept connections from other computers, you can switch the AL-800 to client mode and connect to other networks.



1. Log in to the web control panel.
2. Click on the **Network** tab in the left menu.
3. Select **Wireless**.
4. In the **Wireless Overview**, click **Scan**.
5. Press Join Network in the network you want to connect to.

Join Network: Wireless Scan

Signal	SSID	Channel	Mode	BSSID	Encryption	
-80 dBm	hidden	8	Master	1A:59:C0:44:62:26	WPA2 PSK (CCMP)	JOIN NETWORK
-80 dBm	hidden	8	Master	1E:59:C0:44:62:26	WPA2 PSK (CCMP)	JOIN NETWORK
-83 dBm	hidden	8	Master	02:0C:9D:C1A5:2C	None	JOIN NETWORK
-83 dBm	hidden	9	Master	8A:07:86:C6:26:9D	WPA2 PSK (CCMP)	JOIN NETWORK
-84 dBm	hidden	9	Master	D8:07:86:C6:26:98	WPA2 PSK (CCMP)	JOIN NETWORK
-93 dBm	hidden	8	Master	1E:59:C0:45:B1:51	WPA2 PSK (CCMP)	JOIN NETWORK

6. Enter your **network password** and click Submit.

Joining Network: 1A:59:C0:44:62:26

Replace wireless configuration ☒ Check this option to delete the existing networks from this radio.

Name of the new network The allowed characters are: A-Z, a-z, 0-9 and _

WPA passphrase Specify the secret encryption key here.

Lock to BSSID ☐ Instead of joining any network with a matching SSID, only connect to the BSSID 1A:59:C0:44:62:26.

Create / Assign firewall zone wlan (empty?) Choose the firewall zone you want to assign to this interface. Select unspecified to remove the interface from the associated zone or fill out the custom field to define a new zone and attach the interface to it.

- The details window appears, if you do not need to change other options, please click **Save** directly.

The first screenshot shows the 'Advanced Settings' tab for the wireless interface. It displays the status as 'Mode: Client | SSID: ARIZON ORBI' and 'Wireless is not associated'. There is a 'DISABLE' button for the wireless network. Below this, the 'Operating frequency' is set to 'N' (2462 MHz) with a width of '20 MHz'. There is a checkbox for 'Allow legacy 802.11b rates' which is currently unchecked. The 'Maximum transmit power' is set to 'driver default' with a note that the current power is unknown. A small text block explains that legacy or badly behaving devices may require legacy 802.11b rates to interoperate, but this is not recommended where possible.

The second screenshot shows the 'Interface Configuration' tab. It displays the 'Mode' as 'Client'. The 'ESSID' field is empty. The 'BSSID' field is empty. The 'Network' dropdown is set to 'wwan'. A note at the bottom says 'Choose the network(s) you want to attach to this wireless interface or fill out the custom field to define a new network.'

- After clicking Save and Apply, wait about 80 seconds for it to take effect.

5.8 Set up Ethernet

The AL-800 has a full-duplex 10/100Mbps Ethernet jack, the default IP address is 192.168.50.1 and the DHCP server is enabled, you can change the settings as needed.

The screenshot shows the 'ARIZON arizon-rfid' web interface. The left sidebar has a menu with 'Status', 'System', 'Network', 'Interfaces', 'Wireless', 'Switch', 'DHCP and DNS', 'Hostnames', 'Static Routes', 'Firewall', and 'Diagnostics'. The 'Interfaces' page is selected. It shows two interfaces: 'LAN' and 'WWAN'. The 'LAN' interface is highlighted in green and has a 'RESTART' button. The 'WWAN' interface is highlighted in red and has a 'RESTART' button. Both interfaces have 'STOP', 'EDIT', and 'DELETE' buttons. The 'LAN' interface details include: Protocol: Static address, Uptime: 0h 2m 17s, MAC: 000C43E1762A, RX: 2.38 MB (44252 Pkts.), TX: 121.73 MB (83717 Pkts.), and IPv4: 192.168.50.1/24. The 'WWAN' interface details include: Protocol: DHCP client, Uptime: 0h 2m 3s, MAC: 000C3D06F72A, RX: 123.40 MB (94307 Pkts.), TX: 3.63 MB (44055 Pkts.), and IPv4: 10.35.1.70/24. At the bottom, there is a 'SAVE & APPLY' button, a 'SAVE' button, and a 'RESET' button. A footer note says 'Powered by LuCI Master (git-21.020.56896-af422b1) / ArIOS Snapshot v1.3.9-20220118 r14808-499924ad0'.

Please follow the instructions below to reach this page first:

- Log in to the web page background.
- Click on the **Network** tab in the left menu.
- Select **Interfaces**.

A. Change to automatically obtain the IP location (the DHCP server will be deactivated) :

1. Click **Edit** at **LAN**.
2. In the General Settings tab, change the **protocol** to **DHCP client**.
3. Click **Switch Protocol** to refresh the screen to the corresponding setting parameters.

The screenshot shows the 'Interfaces > LAN' configuration page. The 'General Settings' tab is active. It displays the status of the 'br-lan' device, including its uptime, MAC address, RX/TX statistics, and current IP address (192.168.50.1/24). The 'Protocol' is set to 'DHCP client'. There is a 'Bring up on boot' checkbox which is checked. At the bottom, there is a 'Hostname to send when requesting DHCP' dropdown menu set to 'Send the hostname of this device'. 'DISMISS' and 'SAVE' buttons are at the bottom right.

4. Click **Save**.
5. Click **Save** and **Apply** to make the settings take effect.

B. Change to automatically obtain the IP location (the DHCP server will be deactivated) :

1. Click **Edit** on **LAN**.
2. In the general settings tab, change the **protocol** to **static address**.
3. Click **Switch Protocol** to refresh the screen to the corresponding setting parameters.
4. Please enter the parameters you want to change, such as the IPv4/v6 address, IPv4 gateway, etc.
5. Please click the **DHCP Server** tab.
6. On the **General Settings** tab, select **Ignore Interfaces** and check this interface.
(*This setting will disable the DHCP server, if you want the AL-800 to assign an IP address, please uncheck it)

The screenshot shows the 'Interfaces > LAN' configuration page with the 'DHCP Server' tab selected. Under the 'General Setup' sub-tab, the 'Ignore interface' checkbox is checked. Below this checkbox, it says 'Disable DHCP for this interface.' 'DISMISS' and 'SAVE' buttons are at the bottom right.

7. Click **Save**.
8. Click **Save** and **Apply** to make the settings take effect.

6 Setup your AWS account and Permissions

Refer to the online AWS documentation at [Set up your AWS Account](#). Follow the steps outlined in the sections below to create your account and a user and get started:

- [Sign up for an AWS account](#) and
- [Create a user and grant permissions](#)
- [Open the AWS IoT console](#)

Pay special attention to the Notes.

7 Create Resources in AWS IoT

Refer to the online AWS documentation at [Create AWS IoT Resources](#). Follow the steps outlined in these sections to provision resources for your device:

- [Create an AWS IoT Policy](#)
- [Create a thing object](#)


Pay special attention to the Notes.

8 Connect AL-800 reader to AWS IoT Core


8.1 Connect AL-800 reader to AWS IoT Core

Step1. Use the Ethernet cable (Wired Network) to connect AL-800 to your computer.

Step2. URL: <https://192.168.50.1/cgi-bin/luci/>.



Step3. Sign in with the user name and password. Welcome to the main page.



Step4. Choose page IoT Core → AWS

The screenshot shows the ARIZON IoT Core interface for the 'arizon-rfid' instance. The left sidebar contains a navigation menu with 'AWS' selected. The main content area is titled 'AWS IoT Core' and includes a sub-header '裝置' (Devices). Below this, there are five input fields: '裝置名稱' (Device Name), '資料端點' (Data Endpoint), '裝置憑證' (Device Certificate), '裝置私有金鑰' (Device Private Key), and '根CA憑證' (Root CA Certificate). Each field has a '選擇檔案...' (Choose File...) button. At the bottom of the form is an '操作' (Action) dropdown menu currently set to '停用' (Stop). Below the form is an '事件' (Events) section with a URL 'devices/ /messages/events/tags'.

Step5. Create a thing in AWS IoT Core (Chapter 6, 7). Edit device information, and upload certificate.

- Device name
- Data endpoint
- Device certificate
- Private key file
- Root CA certificate

This screenshot shows the same ARIZON IoT Core interface as the previous one, but with the configuration fields filled out. The '裝置名稱' (Device Name) field is labeled 'a.' and contains 'AL-800'. The '資料端點' (Data Endpoint) field is labeled 'b.' and contains a redacted value. The '裝置憑證' (Device Certificate) field is labeled 'c.' and contains a redacted value. The '裝置私有金鑰' (Device Private Key) field is labeled 'd.' and contains a redacted value. The '根CA憑證' (Root CA Certificate) field is labeled 'e.' and contains a redacted value. The '操作' (Action) dropdown menu is still set to '停用' (Stop). The '事件' (Events) section at the bottom shows the URL 'devices/ AL-800/messages/events/tags'.

- Step6. Edit event configuration. MQTT Topic: **devices/AL-800/messages/events/tags**
- Response interval (second)
 - Tag count

ARIZON arizon-rfid

資料端點 [Redacted]

裝置憑證 [Redacted]

裝置私有金鑰 [Redacted]

根CA憑證 [Redacted]

操作 停用

事件

事件主題 devices/ AL-800/messages/events/tags
MQTT Topic

a. 事件間隔 5

b. 標籤筆數 5

儲存並啟用 儲存 重置

Powered by LuCI Master (git-21.020.56896-af422b1) / ArIoT Snapshot v1.4.8-20221013 r14808-499924adf0

Step7. Set operation **Enable**. Click 「**Save**」 and 「**Save and Apply**」

ARIZON arizon-rfid

資料端點 [Redacted]

裝置憑證 [Redacted]

裝置私有金鑰 [Redacted]

根CA憑證 [Redacted]

操作 停用
啟用

事件

事件主題 devices/ AL-800/messages/events/tags
MQTT Topic

事件間隔 5

標籤筆數 5


a. Save

b. Save and Apply

儲存並啟用 儲存 重置


Powered by LuCI Master (git-21.020.56896-af422b1) / ArIoT Snapshot v1.4.8-20221013 r14808-499924adf0

Step8. Apply configuration.




8.2 Test your AL-800 reader with AWS MQTT test client


Step1. Subscribe to the topic: **iothub/methods/res/#**



Step2. Publish to the topic: **iothub/methods/POST/reader/?\$rid=0**



Step3. AL-800 response device event via MQTT



Tags event topic: **devices/{device name}/messages/events/tags**

9 Debugging and Troubleshooting

The following information might help you troubleshoot common issues in AWS IoT: [Link to Troubleshooting AWS IoT](#).

Also, feel free to contact us if you have any questions. [Contact Us](#)