



Steps to use I2C over HSMC

1. Remove resistor R74
2. Install 3 pin header H1
3. Jumper H1 pin 1 to left pad of R74*
4. Jumper H1 pin 2 to right pad of R74*
5. Jumper H1 pin 3 to pin 158 of J3 (HSMC connector)

For FMC use:

Short pins 1 and 2 of H1

For HSMC use:

Short pins 2 and 3 of H1

*Directions given relative to R74 reference designator