



The ESP32 will enter the serial bootloader when GPIO0 is held low on reset. Otherwise it will run the program in flash.  
<https://github.com/espressif/esptool/wiki/ESP32-Boot-Mode-Selection>

Sheet: /  
 File: esp32 module.sch

**Title:**

Size: A4

Date:

KiCad E.D.A. kicad (5.0.0-rc2-dev-321-g78161b592)

**Rev:**

Id: 1/1