

How To connect Serial Console on Sparky SBC



Can use standard USB TO TTL SERIAL CABLE for connecting Serial console for debugging

Black : Gnd , Green - Rx , White -Tx , Red – No Connect.

Optional UEXT header has to be fixed on SPARKY UEXT pads for connecting serial console. Baud rate 115200, N, 8, 1.

