



## OS Image (.fw) writing in to eMMC card Plugged on SPARKY

### On Windows PC:

- You can download the latest sparky OS zip/tar file from Sparky website and extract to the local folder.
- Download the windows flashing tool IH FW Burning Tool V2.01 from sparky website.
- Run the Flashing tool as administrator, click on {  } to select the extracted image file ( sparky\_os\_version.fw) to flash. Refer Image flashing steps.

### Image flashing steps :

- 1) Run flashing tool and select Image.
- 2) Plug eMMC Card in to Sparky SBC eMMC Connector.
- 3) Connect USB cable between Sparky SBC USB 3.0 port and computer USB port.
- 4) Hold ADFU button and power on sparky -Hold ADFU button for 5-10 seconds minimum during power on to enter the flashing mode.



- 5) Once Sparky SBC gets Powered ON Flashing Tool will show 1 USB Device Detected as Shown in Figure...( figure to be changed) now press Down {  } button and Wait patiently to successfully complete the writing.

