

# **EK-LM3S9D90 Firmware Development Package**

## **USER'S GUIDE**



---

# Copyright

Copyright © 2009-2013 Texas Instruments Incorporated. All rights reserved. Stellaris and StellarisWare are registered trademarks of Texas Instruments. ARM and Thumb are registered trademarks and Cortex is a trademark of ARM Limited. Other names and brands may be claimed as the property of others.

 Please be aware that an important notice concerning availability, standard warranty, and use in critical applications of Texas Instruments semiconductor products and disclaimers thereto appears at the end of this document.

Texas Instruments  
108 Wild Basin, Suite 350  
Austin, TX 78746  
Main: +1-512-279-8800  
Fax: +1-512-279-8879  
<http://www.ti.com/stellaris>



## Revision Information

This is version 10636 of this document, last updated on March 28, 2013.

# Table of Contents

<b>Copyright</b>	<b>2</b>
<b>Revision Information</b>	<b>2</b>
<b>1 Introduction</b>	<b>7</b>
<b>2 Example Applications</b>	<b>9</b>
2.1 Bit-Banding (bitband)	9
2.2 Blinky (blinky)	9
2.3 USB Boot Loader Example (boot_demo_usb)	9
2.4 USB Boot Loader (boot_usb)	10
2.5 Ethernet with lwIP (enet_lwip)	11
2.6 Ethernet with PTP (enet_ptpd)	11
2.7 Ethernet with uIP (enet_uip)	12
2.8 GPIO JTAG Recovery (gpio_jtag)	12
2.9 Hello World (hello)	12
2.10 Interrupts (interrupts)	12
2.11 MPU (mpu_fault)	13
2.12 Quick Start Game (qs-adventure)	13
2.13 SoftUART Echo (softuart_echo)	13
2.14 Timer (timers)	14
2.15 UART Echo (uart_echo)	14
2.16 uDMA (udma_demo)	14
2.17 uDMA with Timer (udma_timer)	14
2.18 uDMA scatter-gather memory/UART transfer (udma_uart_sg)	14
2.19 USB Generic Bulk Device (usb_dev_bulk)	15
2.20 USB composite HID Mouse and CDC serial Device (usb_dev_chidcdc)	15
2.21 USB HID Keyboard Device (usb_dev_keyboard)	16
2.22 USB HID Mouse Device (usb_dev_mouse)	16
2.23 USB Serial Device (usb_dev_serial)	16
2.24 USB HID Keyboard Host (usb_host_keyboard)	16
2.25 USB HID Mouse Host (usb_host_mouse)	17
2.26 USB Mass Storage Class Host (usb_host_msc)	17
2.27 USB Stick Update Demo (usb_stick_demo)	17
2.28 USB Memory Stick Updater (usb_stick_update)	17
2.29 Watchdog (watchdog)	18
<b>3 Development System Utilities</b>	<b>19</b>
<b>4 Command Line Processing Module</b>	<b>27</b>
4.1 Introduction	27
4.2 API Functions	27
4.3 Programming Example	29
<b>5 CPU Usage Module</b>	<b>31</b>
5.1 Introduction	31
5.2 API Functions	31
5.3 Programming Example	32
<b>6 CRC Module</b>	<b>35</b>
6.1 Introduction	35
6.2 API Functions	35
6.3 Programming Example	38
<b>7 Flash Parameter Block Module</b>	<b>41</b>

7.1	Introduction . . . . .	41
7.2	API Functions . . . . .	41
7.3	Programming Example . . . . .	43
<b>8</b>	<b>Integer Square Root Module . . . . .</b>	<b>45</b>
8.1	Introduction . . . . .	45
8.2	API Functions . . . . .	45
8.3	Programming Example . . . . .	46
<b>9</b>	<b>Ethernet Board Locator Module . . . . .</b>	<b>47</b>
9.1	Introduction . . . . .	47
9.2	API Functions . . . . .	47
9.3	Programming Example . . . . .	50
<b>10</b>	<b>lwIP Wrapper Module . . . . .</b>	<b>51</b>
10.1	Introduction . . . . .	51
10.2	API Functions . . . . .	51
10.3	Programming Example . . . . .	54
<b>11</b>	<b>PTPd Wrapper Module . . . . .</b>	<b>55</b>
11.1	Introduction . . . . .	55
11.2	API Functions . . . . .	55
11.3	Programming Example . . . . .	55
<b>12</b>	<b>Ring Buffer Module . . . . .</b>	<b>57</b>
12.1	Introduction . . . . .	57
12.2	API Functions . . . . .	57
12.3	Programming Example . . . . .	63
<b>13</b>	<b>Simple Task Scheduler Module . . . . .</b>	<b>65</b>
13.1	Introduction . . . . .	65
13.2	API Functions . . . . .	65
13.3	Programming Example . . . . .	70
<b>14</b>	<b>Sine Calculation Module . . . . .</b>	<b>73</b>
14.1	Introduction . . . . .	73
14.2	API Functions . . . . .	73
14.3	Programming Example . . . . .	74
<b>15</b>	<b>Software I2C Module . . . . .</b>	<b>75</b>
15.1	Introduction . . . . .	75
15.2	API Functions . . . . .	76
15.3	Programming Example . . . . .	83
<b>16</b>	<b>Software SSI Module . . . . .</b>	<b>87</b>
16.1	Introduction . . . . .	87
16.2	API Functions . . . . .	88
16.3	Programming Example . . . . .	100
<b>17</b>	<b>Software UART Module . . . . .</b>	<b>105</b>
17.1	Introduction . . . . .	105
17.2	API Functions . . . . .	106
17.3	Programming Example . . . . .	122
<b>18</b>	<b>Ethernet Software Update Module . . . . .</b>	<b>127</b>
18.1	Introduction . . . . .	127
18.2	API Functions . . . . .	127
18.3	Programming Example . . . . .	129
<b>19</b>	<b>TFTP Server Module . . . . .</b>	<b>131</b>

19.1	Introduction . . . . .	131
19.2	Usage . . . . .	131
19.3	API Functions . . . . .	134
<b>20</b>	<b>Micro Standard Library Module . . . . .</b>	<b>139</b>
20.1	Introduction . . . . .	139
20.2	API Functions . . . . .	139
20.3	Programming Example . . . . .	148
<b>21</b>	<b>UART Standard IO Module . . . . .</b>	<b>151</b>
21.1	Introduction . . . . .	151
21.2	API Functions . . . . .	152
21.3	Programming Example . . . . .	159
	<b>IMPORTANT NOTICE . . . . .</b>	<b>160</b>



# 1 Introduction

The Texas Instruments® Stellaris® EK-LM3S9D90 evaluation board is a platform that can be used for software development and to prototype a hardware design. It contains a Stellaris ARM® Cortex™-M3-based microcontroller, an Ethernet port, a USB OTG port, a push button, and a LED that can be used to exercise the peripherals on the microcontroller. Additionally, all of the microcontroller's pins are brought to unpopulated stake headers, allowing for easy connection to other hardware for the purposes of prototyping (after the stake headers have been populated by the customer).

This document describes the example applications that are provided for this evaluation board.





## 2 Example Applications

The example applications show how to utilize features of the Cortex-M3 microprocessor, the peripherals on the Stellaris microcontroller, and the drivers provided by the peripheral driver library. These applications are intended for demonstration and as a starting point for new applications.

There is an IAR workspace file (`ek-lm3s9d90.eww`) that contains the peripheral driver library project, USB library project, and all of the board example projects, in a single, easy to use workspace for use with Embedded Workbench version 5.

There is a Keil multi-project workspace file (`ek-lm3s9d90.mpw`) that contains the peripheral driver library project, USB library project, and all of the board example projects, in a single, easy to use workspace for use with uVision.

All of these examples reside in the `boards/ek-lm3s9d90` subdirectory of the firmware development package source distribution.

### 2.1 Bit-Banding (bitband)

This example application demonstrates the use of the bit-banding capabilities of the Cortex-M3 microprocessor. All of SRAM and all of the peripherals reside within bit-band regions, meaning that bit-banding operations can be applied to any of them. In this example, a variable in SRAM is set to a particular value one bit at a time using bit-banding operations (it would be more efficient to do a single non-bit-banded write; this simply demonstrates the operation of bit-banding).

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

### 2.2 Blinky (blinky)

A very simple example that blinks the on-board LED.

### 2.3 USB Boot Loader Example (boot\_demo\_usb)

This example application is used in conjunction with the USB boot loader (`boot_usb`) and turns the evaluation board into a composite device supporting a mouse via the Human Interface Device class and also publishing runtime Device Firmware Upgrade (DFU) capability. Make sure that the USB boot loader is flashed at address 0 and that the binary for this application is placed at 0x1800. When connected to a host system, the application acts as a mouse and moves the pointer in a square pattern for the duration of the time it is plugged in.

Since the device also publishes a DFU interface, host software such as the `dfuprog` tool can determine that the device is capable of receiving software updates over USB. The runtime DFU protocol allows such tools to signal the device to switch into DFU mode and prepare to receive a new software image.

Runtime DFU functionality requires only that the device listen for a particular request (DETACH) from the host and, when this is received, transfer control to the USB boot loader via the normal

means to reenumerate as a pure DFU device capable of uploading and downloading firmware images.

Windows device drivers for both the runtime and DFU mode of operation can be found in C:/StellarisWare/windows\_drivers assuming you installed StellarisWare in the default directory.

To illustrate runtime DFU capability, use the `dfuprog` tool which is part of the Stellaris Windows USB Examples package (SW-USB-win-xxxx.msi). Assuming this package is installed in the default location, the `dfuprog` executable can be found in the C:/Program Files/Texas Instruments/Stellaris/usb\_examples directory.

With the device connected to your PC and the device driver installed, enter the following command to enumerate DFU devices:

```
dfuprog -e
```

This will list all DFU-capable devices found and you should see that you have one device available which is in “Runtime” mode. Entering the following command will switch this device into DFU mode and leave it ready to receive a new firmware image:

```
dfuprog -m
```

After entering this command, you should notice that the device disconnects from the USB bus and reconnects again. Running “`dfuprog -e`” a second time will show that the device is now in DFU mode and ready to receive downloads. At this point, either LM Flash Programmer or `dfuprog` may be used to send a new application binary to the device.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.4 USB Boot Loader (boot\_usb)

The boot loader is a small piece of code that can be programmed at the beginning of flash to act as an application loader as well as an update mechanism for an application running on a Stellaris microcontroller, utilizing either UART0, I2C0, SSI0, Ethernet or USB. The capabilities of the boot loader are configured via the `bl_config.h` include file. For this example, the boot loader uses the USB Device Firmware Upgrade (DFU) class to download an application.

Applications intended for use with this version of the boot loader should be linked to run from address 0x1800 in flash (rather than the default run address of 0). This address is chosen to ensure that boot loader images built with all supported compilers may be used without modifying the application start address. Depending upon the compiler and optimization level you are using, however, you may find that you can reclaim some space by lowering this address and rebuilding both the application and boot loader. To do this, modify the makefile or project you use to build the application to show the new run address and also change the `APP_START_ADDRESS` value defined in `bl_config.h` before rebuilding the boot loader.

The USB boot loader may be demonstrated using the `boot_demo_usb` example application in addition to the `boot_usb` boot loader binary itself. Note that this is the only example application currently configured to run alongside the USB boot loader but making any of the other applications USB boot loader compatible is simply a matter of relinking them with the new start address and adding a mechanism to transfer control to the boot loader when required.

The Windows device driver required to communicate with the USB boot loader can be found on the software and documentation CD from the development kit package. It can also be found in the Windows driver package which can be downloaded via a link from

<http://www.ti.com/stellaris>.

A Windows command-line application, `dfuprog`, is also provided which illustrates how to perform uploads and downloads via the USB DFU protocol. The source for this application can be found in the “C:/StellarisWare/tools” directory and the prebuilt executable is available in the package “Windows-side examples for USB kits” available for download via a link from <http://www.ti.com/stellaris>.

## 2.5 Ethernet with lwIP (enet\_lwip)

This example application demonstrates the operation of the Stellaris Ethernet controller using the lwIP TCP/IP Stack configured to operate as an HTTP (web) server. DHCP is used to obtain an Ethernet address. If DHCP times out without obtaining an address, AutoIP will be used to obtain a link-local address. The address that is selected will be shown on the UART.

Source files for the internal file system image can be found in the “fs” directory. If any of these files are changed, the file system image (`lmi-fsdata.h`) should be rebuilt by running the following command from the `enet_lwip` directory:

```
./../tools/bin/makefsfile -i fs -o lmi-fsdata.h -r -h -q
```

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

For additional details on lwIP, refer to the lwIP web page at: <http://savannah.nongnu.org/projects/lwip/>

## 2.6 Ethernet with PTP (enet\_ptpd)

This example application demonstrates the operation of the Stellaris Ethernet controller using the lwIP TCP/IP Stack. DHCP is used to obtain an Ethernet address. If DHCP times out without obtaining an address, AutoIP will be used to obtain a link-local address. The address that is selected will be output to the UART.

A default set of pages will be served up by an internal file system and the `httpd` server.

The IEEE 1588 (PTP) software has been enabled in this code to synchronize the internal clock to a network master clock source.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

For additional details on lwIP, refer to the lwIP web page at: <http://savannah.nongnu.org/projects/lwip/>

For additional details on the PTPd software, refer to the PTPd web page at: <http://ptpd.sourceforge.net>

## 2.7 Ethernet with uIP (enet\_uip)

This example application demonstrates the operation of the Stellaris Ethernet controller using the uIP TCP/IP Stack. DHCP is used to obtain an Ethernet address. A basic web site is served over the Ethernet port. The web site displays a few lines of text, and a counter that increments each time the page is sent.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

For additional details on uIP, refer to the uIP web page at: <http://www.sics.se/~adam/uip/>

## 2.8 GPIO JTAG Recovery (gpio\_jtag)

This example demonstrates changing the JTAG pins into GPIOs, along with a mechanism to revert them to JTAG pins. When first run, the pins remain in JTAG mode. Pressing the push button will toggle the pins between JTAG mode and GPIO mode. Because there is no debouncing of the push button (either in hardware or software), a button press will occasionally result in more than one mode change.

In this example, four pins (PC0, PC1, PC2, and PC3) are switched.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.9 Hello World (hello)

A very simple “hello world” example. It simply displays “hello world” on the UART and is a starting point for more complicated applications.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.10 Interrupts (interrupts)

This example application demonstrates the interrupt preemption and tail-chaining capabilities of Cortex-M3 microprocessor and NVIC. Nested interrupts are synthesized when the interrupts have the same priority, increasing priorities, and decreasing priorities. With increasing priorities, preemption will occur; in the other two cases tail-chaining will occur. The currently pending interrupts and the currently executing interrupt will be displayed on the UART; GPIO pins B0, B1 and B2 will be asserted upon interrupt handler entry and de-asserted before interrupt handler exit so that the off-to-on time can be observed with a scope or logic analyzer to see the speed of tail-chaining (for the two cases where tail-chaining is occurring).

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.11 MPU (mpu\_fault)

This example application demonstrates the use of the MPU to protect a region of memory from access, and to generate a memory management fault when there is an access violation.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.12 Quick Start Game (qs-adventure)

This game consists of a Z-machine interpreter running a Z-code version of the classic Colossal Cave Adventure game originally created by William Crowther. The Ethernet interface provides a telnet server and the USB interface provides a CDC serial port. Either interface can be used to play the game, though not at the same time.

The LED on the evaluation board will be turned on when the game is being played; further connections will be refused since only one instance of the game can be played at a time. The push button on the evaluation board will restart the game from the beginning; this is equivalent to typing “restart” followed by “yes” in the game itself.

The virtual COM port provided by the ICDI board (which is connected to UART0 on the evaluation board) provides a simple status display. The most important piece of information provided is the IP address of the Ethernet interface, which is selected using AutoIP (which uses DHCP if it is present and a random link-local address otherwise).

The game is played by typing simple English sentences in order to direct the actions of the protagonist, with abbreviations being allowed. For example, “go west”, “west”, and “w” all perform the same action.

Three display modes are available; “verbose” (which displays the full description every time a location is visited), “brief” (which displays the full description the first time a location is visited and only the name every other time), and “superbrief” (which only displays the name). The default display mode is “brief”, and “look” can be used to get the full description at any time (regardless of the display mode).

For a history of the Colossal Cave Adventure game, its creation of the “interactive fiction” gaming genre, and game hints, an Internet search will turn up numerous web sites. A good starting place is [http://en.wikipedia.org/wiki/Colossal\\_Cave\\_Adventure](http://en.wikipedia.org/wiki/Colossal_Cave_Adventure).

## 2.13 SoftUART Echo (softuart\_echo)

This example application utilizes the SoftUART to echo text. The SoftUART is configured to use the same pins as the first UART (connected to the FTDI virtual serial port on the evaluation board), at 115,200 baud, 8-n-1 mode. All characters received on the SoftUART are transmitted back to the SoftUART.

## 2.14 Timer (timers)

This example application demonstrates the use of the timers to generate periodic interrupts. One timer is set up to interrupt once per second and the other to interrupt twice per second; each interrupt handler will toggle its own indicator on the display.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.15 UART Echo (uart\_echo)

This example application utilizes the UART to echo text. The first UART (connected to the FTDI virtual serial port on the evaluation board) will be configured in 115,200 baud, 8-n-1 mode. All characters received on the UART are transmitted back to the UART.

## 2.16 uDMA (udma\_demo)

This example application demonstrates the use of the uDMA controller to transfer data between memory buffers, and to transfer data to and from a UART.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.17 uDMA with Timer (udma\_timer)

This example application demonstrates the use of the timer to trigger periodic DMA transfers. A timer is configured for periodic operation. The uDMA controller channel is configured to perform a transfer when requested from the timer. For the purposes of this demonstration, the data that is transferred is the value of a separate free-running timer. However in a real application the data transferred could be to/from memory or a peripheral.

After a small number of transfers are performed, the captured timer values are compared to make sure the expected duration elapsed between transfers. The results are printed out.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.18 uDMA scatter-gather memory/UART transfer (udma\_uart\_sg)

This example demonstrates using the scatter-gather mode of the uDMA controller to transfer multiple memory buffers to and from a UART. This example uses UART1 in loopback mode.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.19 USB Generic Bulk Device (usb\_dev\_bulk)

This example provides a generic USB device offering simple bulk data transfer to and from the host. The device uses a vendor-specific class ID and supports a single bulk IN endpoint and a single bulk OUT endpoint. Data received from the host is assumed to be ASCII text and it is echoed back with the case of all alphabetic characters swapped.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

A Windows INF file for the device is provided on the installation CD and in the C:/StellarisWare/windows\_drivers directory of StellarisWare releases. This INF contains information required to install the WinUSB subsystem on WindowsXP and Vista PCs. WinUSB is a Windows subsystem allowing user mode applications to access the USB device without the need for a vendor-specific kernel mode driver.

A sample Windows command-line application, usb\_bulk\_example, illustrating how to connect to and communicate with the bulk device is also provided. The application binary is installed as part of the "Windows-side examples for USB kits" package (SW-USB-win) on the installation CD or via download from <http://www.ti.com/stellarisware>. Project files are included to allow the examples to be built using Microsoft VisualStudio 2008. Source code for this application can be found in directory StellarisWare/tools/usb\_bulk\_example.

## 2.20 USB composite HID Mouse and CDC serial Device (usb\_dev\_chidcdc)

This example application turns the evaluation board into a composite USB mouse supporting the Human Interface Device class and a CDC serial device. The mouse pointer will move in a square pattern for the duration of the time it is plugged in. The serial port is used as a command prompt to change the behavior of the board. By default the mouse will simply enumerate and not move. The serial port can then be opened and a command can be issued to start the mouse moving or stop it again.

The commands supported by the UART are the following:

? or help or h - Will display the help message.

led <on|off|toggle|activity> on - Turns on the LED. off - Turns off the LED toggle - Toggle the LED activity - Toggle the LED due to serial activity.

mouse <on|off> on - Starts the mouse moving in a square pattern. off - Stops the mouse moving.

Assuming you installed StellarisWare in the default directory, a driver information (INF) file for use with Windows XP, Windows Vista and Windows7 can be found in C:/StellarisWare/windows\_drivers. For Windows 2000, the required INF file is in C:/StellarisWare/windows\_drivers/win2K.

## 2.21 USB HID Keyboard Device (usb\_dev\_keyboard)

This example application turns the evaluation board into a USB keyboard supporting the Human Interface Device class. When the push button is pressed, a sequence of key presses is simulated to type a string. Care should be taken to ensure that the active window can safely receive the text; enter is not pressed at any point so no actions are attempted by the host if a terminal window is used (for example). The status LED is used to indicate the current Caps Lock state and is updated in response to any other keyboard attached to the same USB host system.

The device implemented by this application also supports USB remote wakeup allowing it to request the host to reactivate a suspended bus. If the bus is suspended (as indicated on the application display), pressing the push button will request a remote wakeup assuming the host has not specifically disabled such requests.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.22 USB HID Mouse Device (usb\_dev\_mouse)

This example application turns the evaluation board into a USB mouse supporting the Human Interface Device class. The mouse pointer will move in a square pattern for the duration of the time it is plugged in.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.23 USB Serial Device (usb\_dev\_serial)

This example application turns the evaluation kit into a virtual serial port when connected to the USB host system. The application supports the USB Communication Device Class, Abstract Control Model to redirect UART0 traffic to and from the USB host system.

Assuming you installed StellarisWare in the default directory, a driver information (INF) file for use with Windows XP, Windows Vista and Windows7 can be found in C:/StellarisWare/windows\_drivers. For Windows 2000, the required INF file is in C:/StellarisWare/windows\_drivers/win2K.

## 2.24 USB HID Keyboard Host (usb\_host\_keyboard)

This application demonstrates the handling of a USB keyboard attached to the evaluation kit. Once attached, text typed on the keyboard will appear on the UART. Any keyboard that supports the USB HID BIOS protocol is supported.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.



## 2.25 USB HID Mouse Host (usb\_host\_mouse)

This application demonstrates the handling of a USB mouse attached to the evaluation kit. Once attached, the position of the mouse pointer and the state of the mouse buttons are output to the UART.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 2.26 USB Mass Storage Class Host (usb\_host\_msc)

This example application demonstrates reading a file system from a USB mass storage class device. It makes use of FatFs, a FAT file system driver. It provides a simple command console via the UART for issuing commands to view and navigate the file system on the mass storage device.

The first UART, which is connected to the FTDI virtual serial port on the evaluation board, is configured for 115,200 bits per second, and 8-N-1 mode. When the program is started a message will be printed to the terminal. Type "help" for command help.

For additional details about FatFs, see the following site:  
[http://elm-chan.org/fsw/ff/00index\\_e.html](http://elm-chan.org/fsw/ff/00index_e.html)

## 2.27 USB Stick Update Demo (usb\_stick\_demo)

An example to demonstrate the use of the flash-based USB stick update program. This example is meant to be loaded into flash memory from a USB memory stick, using the USB stick update program (usb\_stick\_update), running on the microcontroller.

After this program is built, the binary file (usb\_stick\_demo.bin), should be renamed to the filename expected by usb\_stick\_update ("FIRMWARE.BIN" by default) and copied to the root directory of a USB memory stick. Then, when the memory stick is plugged into the eval board that is running the usb\_stick\_update program, this example program will be loaded into flash and then run on the microcontroller.

This program simply displays a message on the screen and prompts the user to press the select button. Once the button is pressed, control is passed back to the usb\_stick\_update program which is still in flash, and it will attempt to load another program from the memory stick. This shows how a user application can force a new firmware update from the memory stick.

## 2.28 USB Memory Stick Updater (usb\_stick\_update)

This example application behaves the same way as a boot loader. It resides at the beginning of flash, and will read a binary file from a USB memory stick and program it into another location in flash. Once the user application has been programmed into flash, this program will always start the user application until requested to load a new application.

When this application starts, if there is a user application already in flash (at **APP\_START\_ADDRESS**), then it will just run the user application. It will attempt to load a

new application from a USB memory stick under the following conditions:

- no user application is present at **APP\_START\_ADDRESS**
- the user application has requested an update by transferring control to the updater
- the user holds down the eval board push button when the board is reset

When this application is attempting to perform an update, it will wait forever for a USB memory stick to be plugged in. Once a USB memory stick is found, it will search the root directory for a specific file name, which is *FIRMWARE.BIN* by default. This file must be a binary image of the program you want to load (the .bin file), linked to run from the correct address, at **APP\_START\_ADDRESS**.

The USB memory stick must be formatted as a FAT16 or FAT32 file system (the normal case), and the binary file must be located in the root directory. Other files can exist on the memory stick but they will be ignored.

## 2.29 Watchdog (watchdog)

This example application demonstrates the use of the watchdog as a simple heartbeat for the system. If the watchdog is not periodically fed, it will reset the system. Each time the watchdog is fed, the LED is inverted so that it is easy to see that it is being fed, which occurs once every second.

UART0, connected to the FTDI virtual COM port and running at 115,200, 8-N-1, is used to display messages from this application.

## 3 Development System Utilities

These are tools that run on the development system, not on the embedded target. They are provided to assist in the development of firmware for Stellaris microcontrollers.

These tools reside in the `tools` subdirectory of the firmware development package source distribution.

### AES Key Expansion Utility

#### Usage:

```
aes_gen_key [OPTIONS] --keysize=[SIZE] --key=[KEYSTRING] [FILE]
```

#### Description:

Generates pre-expanded keys for AES encryption and decryption. It is designed to work in conjunction with the AES library code found in the StellarisWare directory `third_party/aes`. When using an AES key to perform encryption or decryption, the key must first be expanded into a larger table of values before the key can be used. This operation can be performed at run-time but takes time and uses space in RAM.

If the keys are fixed and known in advance, then it is possible to perform the expansion operation at build-time and the pre-expanded table can be built into the code. The advantages of doing this are that it saves time when the keys are used, and the expanded table is stored in non-volatile program memory (flash), which is usually less precious in a typical microcontroller application.

By default, the pre-expanded key is generated as a data array that can be used by reference in the application. It is also possible to generate the pre-expanded key as a code sequence. A function is generated that will copy the pre-expanded key to a caller supplied buffer. This does not save RAM space, but it makes the expanded key more secure. By making the key into pure code (versus data in flash), the Texas Instruments Stellaris OTP feature can be used to make the code execute only (no read). This means that the expanded key cannot be read from flash. It is only loaded into RAM during an encrypt or decrypt operation.

The length of a pre-set key is 44 words for 128-bit keys, 54 words for 192-bit keys, and 68 words for 256-bit keys; instruction-based versions are about two to four times as large in flash and require as much RAM as run-time expansion.

The source code for this utility is contained in `tools/aes_gen_key`, with a pre-built binary contained in `tools/bin`.

#### Arguments:

- a, **--data** generates expanded key as an array of data.
- x, **--code** generates expanded key as executable code.
- e, **--encrypt** generate expanded key for encryption.
- d, **--decrypt** generate expanded key for decryption.
- s, **--keysize** **KEYSIZE** size of the key in bits (128, 192, or 256).
- k, **--key** **KEY** key value in hexadecimal.
- v, **--version** show program version.
- h, **--help** display usage information.

The **--keysize** and **--key** arguments are mandatory. Only one each of **--data** or **--code**, and **--encrypt** or **--decrypt** should be used. If not specified otherwise then the default is **--data --encrypt**.

**FILE** is the name of the file that will be created containing the expanded key. This file will be in the form of a C header file and should be included in your application.

**Example:**

The following will generate an expanded 128-bit key for encryption, encoded as data and create a C header file named `enc_key.h`:

```
aes_gen_key --data --encrypt --keysize=128
            --key=112233445566778899AABBCCDDEEFF00 enc_key.h
```

The following will generate an expanded 128-bit key for decryption, encoded as a code function and create a C header file named `dec_key.h`:

```
aes_gen_key --code --decrypt --keysize=128
            --key=112233445566778899AABBCCDDEEFF00 dec_key.h
```

## USB DFU Programmer

**Usage:**

```
dfuprog [OPTION]...
```

**Description:**

Downloads images to a Texas Instruments Stellaris microcontroller running the USB Device Firmware Upgrade boot loader. Additionally, this utility may be used to read back the existing application image or a subsection of flash and store it either as raw binary data or as a DFU-downloadable image file.

The source code for this utility is contained in `tools/dfuprog`. The binary for this utility is installed as part of the “Windows-side examples for USB kits” package (SW-USB-win) shipped on the release CD and downloadable from [http://www.luminarymicro.com/products/software\\_updates.html](http://www.luminarymicro.com/products/software_updates.html). A Microsoft Visual Studio project file is provided to allow the application to be built.

**Arguments:**

- e** specifies the address of the binary.
- u** specifies that an image is to be uploaded from the board into the target file. If absent, the file will be downloaded to the board.
- c** specifies that a section of flash memory is to be cleared. The address and size of the block may be specified using the **-a** and **-l** parameters. If these are absent, the entire writable area of flash is erased.
- f FILE** specifies the name of the file to download or, if **-u** is given, to upload.
- b** specifies that an uploaded file is to be stored as raw binary data without the DFU file wrapper. This option is only valid if used alongside **-u**.
- d** specifies that the VID and PID in the DFU file wrapper should be ignored for a download operation.
- s** specifies that image verification should be skipped following a download operation.
- a ADDR** specifies the address at which the binary file will be downloaded or from which an uploaded file will be read. If a download operation is taking place and the source file provided is DFU-wrapped, this parameter will be ignored.

- l **SIZE** specifies the number of bytes to be uploaded when used in conjunction with -i or the number of bytes of flash to erase if used in conjunction with -c.
- i **NUM** specifies the zero-based index of the USB DFU device to access if more than one is currently attached to the system. If absent, the first device found is used.
- x specifies that destination file for an upload operation should be overwritten without prompting if it already exists.
- w specifies that the utility should wait for the user to press a key before it exits.
- v displays verbose output during the requested operation.
- h displays this help information.
- ? displays this help information.

**Example:**

The following example writes binary file program.bin to the device flash memory at address 0x1800:

```
dfuprog -f program.bin -a 0x1800
```

The following example writes DFU-wrapped file program.dfu to the flash memory of the second connected USB DFU device at the address found in the DFU file prefix:

```
dfuprog -i 1 -f program.dfu
```

The following example uploads (reads) the current application image into a DFU-formatted file appimage.dfu:

```
dfuprog -u -f appimage.dfu
```

## USB DFU Wrapper

**Usage:**

```
dfuwrap [OPTION]...
```

**Description:**

Prepares binary images for download to a particular position in device flash via the USB device firmware upgrade protocol. A Stellaris-specific prefix and a DFU standard suffix are added to the binary.

The source code for this utility is contained in `tools/dfuwrap`, with a pre-built binary contained in `tools/bin`.

**Arguments:**

- a **ADDR** specifies the address of the binary.
- c specifies that the validity of the DFU wrapper on the input file should be checked.
- d **ID** specifies the USB device ID to place into the DFU wrapper. If not specified, the default of 0x0000 will be used.
- e enables verbose output.
- f specifies that a DFU wrapper should be added to the file even if one already exists.
- h displays usage information.
- i **FILE** specifies the name of the input file.

- o **FILE** specifies the name of the output file. If not specified, the default of image.dfu will be used.
- p **ID** specifies the USB product ID to place into the DFU wrapper. If not specified, the default of 0x00ff will be used.
- q specifies that only error information should be output.
- r specifies that the DFU header should be removed from the input file.
- v **ID** specifies the USB vendor ID to place into the DFU wrapper. if not specified, the default of 0x1cbe will be used.
- x specifies that the output file should be overwritten without prompting.

**Example:**

The following example adds a DFU wrapper which will cause the image to be programmed to address 0x1800:

```
dfuwrap -i program.bin -o program.dfu -a 0x1800
```

## Ethernet Flash Downloader

**Usage:**

```
eflash [OPTION]... [INPUT FILE]
```

**Description:**

Downloads a firmware image to a Stellaris board using an Ethernet connection to the Stellaris Boot Loader. This has the same capabilities as the Ethernet download portion of the Stellaris Flash Programmer.

The source code for this utility is contained in `tools/eflash`, with a pre-built binary contained in `tools/bin`.

**Arguments:**

- help displays usage information.
- h is an alias for --help.
- ip=**IP** specifies the IP address to be provided by the BOOTP server.
- i **IP** is an alias for --ip.
- mac=**MAC** specifies the MAC address
- m **MAC** is an alias for --mac.
- quiet specifies that only error information should be output.
- silent is an alias for --quiet.
- verbose specifies that verbose output should be output.
- version displays the version of the utility and exits.
- INPUT FILE** specifies the name of the firmware image file.

**Example:**

The following will download a firmware image to the board over Ethernet, where the target board has a MAC address of 00:11:22:33:44:55 and is given an IP address of 169.254.19.70:

```
eflash -m 00:11:22:33:44:55 -i 169.254.19.70 image.bin
```

## Finder

**Usage:**

```
finder
```

**Description:**

This program locates Stellaris boards on the local network that are running an lwIP-based application that includes the locator service. It will display the IP address, MAC address, client address, and application description for each board that it finds. This is useful for easily finding the IP address that has been assigned to a board via DHCP or AutoIP without needing to display it from the application (which is difficult on boards that do not have a builtin display).

The source code for this utility is contained in `tools/finder`, with a pre-built binary contained in `tools/bin`.

**Example:**

This utility can be run by clicking on the application in a filesystem browser or by invoking it from the command line as follows:

```
finder
```

## USB DFU Library

**Description:**

LMDFU is a Windows dynamic link library offering a high level interface to the USB Device Firmware Upgrade functionality provided by the Stellaris USB boot loader (`boot_usb`). This DLL is used by the `dfuprog` utility and also by the LMFlash application to allow download and upload of application images to or from a Stellaris-based board via USB.

The source code for this DLL is contained in `tools/lmdfu`. The DLL binary is installed as part of the “Stellaris embedded USB drivers” package (SW-USB-windrivers) shipped on the release CD and downloadable from [http://www.ti.com/software\\_updates.html](http://www.ti.com/software_updates.html). A Microsoft Visual Studio 2008 project file is provided to allow the application to be built.

## USB Dynamic Link Library

**Description:**

LMUSBDLL is a simple Windows dynamic link library offering low level packet read and write functions for some USB-connected Stellaris example applications. The DLL is written above the Microsoft WinUSB interface and is intended solely to ensure that various Windows-side example applications can be built without having to use WinUSB header files. These header files are not included in the Visual Studio tools and are only shipped in the Windows Device Driver Kit (DDK). By providing this simple mapping DLL which links to WinUSB, the user avoids the need for a multi-gigabyte download to build the examples.

The source code for this DLL is contained in `tools/lmusbdll`. The DLL binary is installed as part of the “Stellaris embedded USB drivers” package (SW-USB-windrivers) shipped on the release CD and downloadable from [http://www.ti.com/software\\_updates.html](http://www.ti.com/software_updates.html). A Microsoft Visual Studio 2008 project file is provided to allow the DLL to be built on a PC which has the Windows Device Driver Kit installed.

## Web Filesystem Generator

### Usage:

```
makefsfile [OPTION]...
```

### Description:

Generates a file system image for the lwIP web server. This is loosely based upon the `makefsdata` Perl script that is provided with lwIP, but does not require Perl and has several enhancements. The file system image is produced as a C source file that contains an image of all the files contained within a subtree of the development system's directory structure. This source file is then built into the application and served via HTTP by the lwIP web server.

By default, the file system image embeds the HTTP headers associated with each file in the file system image data itself. This is the default assumption of the lwIP web server implementation and is sensible if using an internal file system image containing a small number of files. If also serving files from a file system which does not embed the headers (for example the FAT file system on a microSD card) dynamic header generation must be used and internal file system images should be built using the `-h` option. In these cases, ensure that `DYNAMIC_HTTP_HEADERS` is also defined in the `lwipopts.h` file to correctly configure the web server.

The `-x` option allows an "exclude file" to be specified. This exclude file contains the names of files and directories within the input directory tree that are to be skipped in the conversion process. If this option is not present, a default set of file excludes is used. This list contains typical source code control metadata directory names (".svn" and "CVS") and system files such as "thumbs.db". To see the default exclude list, run the tool with the `-v` option and look in the output.

Each file or directory name in the exclude file must be on a separate line within the file. The exclude list must contain individual file or directory names and may not include partial paths. For example `images_old` or `.svn` would be acceptable but `images_old/.svn` would not.

In addition to generating multi-file images, the tool can also be used to dump a single file in the form of a C-style array of unsigned characters. This mode of operation is chosen using the `-f` command line option.

The source code for this utility is contained in `tools/makefsfile`, with a pre-built binary contained in `tools/bin`.

### Arguments:

- b** generates a position-independent binary image.
- f** dumps a single file as a C-style hex character array.
- h** excludes HTTP headers from files. By default, HTTP headers are added to each file in the output.
- i NAME** specifies the name of the directory containing the files to be included in the image or the name of the single file to be dumped if `-f` is used.
- o FILE** specifies the name of the output file. If not specified, the default of `fsdata.c` will be used.
- q** enables quiet mode.
- r** overwrites the the output file without prompting.
- v** enables verbose output.
- x FILE** specifies a file containing a list of filenames and directory names to be excluded from the generated image.
- ?** displays usage information.



**Example:**

The following will generate a file system image using all the files in the `html` directory and place the results into `fsdata.h`:

```
makefsfile -i html -o fsdata.h
```

## Serial Flash Downloader

**Usage:**

```
sflash [OPTION]... [INPUT FILE]
```

**Description:**

Downloads a firmware image to a Stellaris board using a UART connection to the Stellaris Serial Flash Loader or the Stellaris Boot Loader. This has the same capabilities as the serial download portion of the Stellaris Flash Programmer.

The source code for this utility is contained in `tools/sflash`, with a pre-built binary contained in `tools/bin`.

**Arguments:**

- b **BAUD** specifies the baud rate. If not specified, the default of 115,200 will be used.
- c **PORT** specifies the COM port. If not specified, the default of COM1 will be used.
- d disables auto-baud.
- h displays usage information.
- l **FILENAME** specifies the name of the boot loader image file.
- p **ADDR** specifies the address at which to program the firmware. If not specified, the default of 0 will be used.
- r **ADDR** specifies the address at which to start processor execution after the firmware has been downloaded. If not specified, the processor will be reset after the firmware has been downloaded.
- s **SIZE** specifies the size of the data packets used to download the firmware data. This must be a multiple of four between 8 and 252, inclusive. If using the Serial Flash Loader, the maximum value that can be used is 76. If using the Boot Loader, the maximum value that can be used is dependent upon the configuration of the Boot Loader. If not specified, the default of 8 will be used.

**INPUT FILE** specifies the name of the firmware image file.

**Example:**

The following will download a firmware image to the board over COM2 without auto-baud support:

```
sflash -c 2 -d image.bin
```

## USB Bulk Data Transfer Example

**Description:**

`usb_bulk_example` is a Windows command line application which communicates with the StellarisWare `usb_dev_bulk` example. The application finds the Stellaris device on the USB bus then, if found, prompts the user to enter strings which are sent to the application running on

the Stellaris board. This application then inverts the case of the alphabetic characters in the string and returns the data back to the USB host where it is displayed.

The source code for this application is contained in `tools/usb_bulk_example`. The binary is installed as part of the “Windows-side examples for USB kits” package (SW-USB-win) shipped on the release CD and downloadable from [http://www.luminarymicro.com/products/software\\_updates.html](http://www.luminarymicro.com/products/software_updates.html). A Microsoft Visual Studio project file is provided to allow the application to be built.

## 4 Command Line Processing Module

Introduction .....	27
API Functions .....	27
Programming Example .....	29

### 4.1 Introduction

The command line processor allows a simple command line interface to be made available in an application, for example via a UART. It takes a buffer containing a string (which must be obtained by the application) and breaks it up into a command and arguments (in traditional C “argc, argv” format). The command is then found in a command table and the corresponding function in the table is called to process the command.

This module is contained in `utils/cmdline.c`, with `utils/cmdline.h` containing the API definitions for use by applications.

### 4.2 API Functions

#### Data Structures

- `tCmdLineEntry`

#### Defines

- `CMDLINE_BAD_CMD`
- `CMDLINE_INVALID_ARG`
- `CMDLINE_TOO_FEW_ARGS`
- `CMDLINE_TOO_MANY_ARGS`

#### Functions

- `int CmdLineProcess (char *pcCmdLine)`

#### Variables

- `tCmdLineEntry g_sCmdTable[]`

## 4.2.1 Data Structure Documentation

### 4.2.1.1 tCmdLineEntry

**Definition:**

```
typedef struct
{
    const char *pcCmd;
    pfnCmdLine pfnCmd;
    const char *pcHelp;
}
tCmdLineEntry
```

**Members:**

**pcCmd** A pointer to a string containing the name of the command.

**pfnCmd** A function pointer to the implementation of the command.

**pcHelp** A pointer to a string of brief help text for the command.

**Description:**

Structure for an entry in the command list table.

## 4.2.2 Define Documentation

### 4.2.2.1 CMDLINE\_BAD\_CMD

**Definition:**

```
#define CMDLINE_BAD_CMD
```

**Description:**

Defines the value that is returned if the command is not found.

### 4.2.2.2 CMDLINE\_INVALID\_ARG

**Definition:**

```
#define CMDLINE_INVALID_ARG
```

**Description:**

Defines the value that is returned if an argument is invalid.

### 4.2.2.3 CMDLINE\_TOO\_FEW\_ARGS

**Definition:**

```
#define CMDLINE_TOO_FEW_ARGS
```

**Description:**

Defines the value that is returned if there are too few arguments.

#### 4.2.2.4 CMDLINE\_TOO\_MANY\_ARGS

**Definition:**

```
#define CMDLINE_TOO_MANY_ARGS
```

**Description:**

Defines the value that is returned if there are too many arguments.

### 4.2.3 Function Documentation

#### 4.2.3.1 CmdLineProcess

Process a command line string into arguments and execute the command.

**Prototype:**

```
int  
CmdLineProcess(char *pcCmdLine)
```

**Parameters:**

**pcCmdLine** points to a string that contains a command line that was obtained by an application by some means.

**Description:**

This function will take the supplied command line string and break it up into individual arguments. The first argument is treated as a command and is searched for in the command table. If the command is found, then the command function is called and all of the command line arguments are passed in the normal argc, argv form.

The command table is contained in an array named `g_sCmdTable` which must be provided by the application.

**Returns:**

Returns **CMDLINE\_BAD\_CMD** if the command is not found, **CMDLINE\_TOO\_MANY\_ARGS** if there are more arguments than can be parsed. Otherwise it returns the code that was returned by the command function.

### 4.2.4 Variable Documentation

#### 4.2.4.1 g\_sCmdTable

**Definition:**

```
tCmdLineEntry g_sCmdTable[ ]
```

**Description:**

This is the command table that must be provided by the application.

## 4.3 Programming Example

The following example shows how to process a command line.

```
//
// Code for the "foo" command.
//
int
ProcessFoo(int argc, char *argv[])
{
    //
    // Do something, using argc and argv if the command takes arguments.
    //
}

//
// Code for the "bar" command.
//
int
ProcessBar(int argc, char *argv[])
{
    //
    // Do something, using argc and argv if the command takes arguments.
    //
}

//
// Code for the "help" command.
//
int
ProcessHelp(int argc, char *argv[])
{
    //
    // Provide help.
    //
}

//
// The table of commands supported by this application.
//
tCmdLineEntry g_sCmdTable[] =
{
    { "foo", ProcessFoo, "The first command." },
    { "bar", ProcessBar, "The second command." },
    { "help", ProcessHelp, "Application help." }
};

//
// Read a process a command.
//
int
Test(void)
{
    unsigned char pucCmd[256];

    //
    // Retrieve a command from the user into pucCmd.
    //
    ...

    //
    // Process the command line.
    //
    return(CmdLineProcess(pucCmd));
}
```

## 5 CPU Usage Module

Introduction .....	31
API Functions .....	31
Programming Example .....	32

### 5.1 Introduction

The CPU utilization module uses one of the system timers and peripheral clock gating to determine the percentage of the time that the processor is being clocked. For the most part, the processor is executing code whenever it is being clocked (exceptions occur when the clocking is being configured, which only happens at startup, and when entering/exiting an interrupt handler, when the processor is performing stacking operations on behalf of the application).

The specified timer is configured to run when the processor is in run mode and to not run when the processor is in sleep mode. Therefore, the timer will only count when the processor is being clocked. Comparing the number of clocks the timer counted during a fixed period to the number of clocks in the fixed period provides the percentage utilization.

In order for this to be effective, the application must put the processor to sleep when it has no work to do (instead of busy waiting). If the processor never goes to sleep (either because of a continual stream of work to do or a busy loop), the processor utilization will be reported as 100%.

Since deep-sleep mode changes the clocking of the system, the computed processor usage may be incorrect if deep-sleep mode is utilized. The number of clocks the processor spends in run mode will be properly counted, but the timing period may not be accurate (unless extraordinary measures are taken to ensure timing period accuracy).

The accuracy of the computed CPU utilization depends upon the regularity with which [CPUUsageTick\(\)](#) is called by the application. If the CPU usage is constant, but [CPUUsageTick\(\)](#) is called sporadically, the reported CPU usage will fluctuate as well despite the fact that the CPU usage is actually constant.

This module is contained in `utils/cpu_usage.c`, with `utils/cpu_usage.h` containing the API definitions for use by applications.

### 5.2 API Functions

#### Functions

- void [CPUUsageInit](#) (unsigned long ulClockRate, unsigned long ulRate, unsigned long ulTimer)
- unsigned long [CPUUsageTick](#) (void)

## 5.2.1 Function Documentation

### 5.2.1.1 CPUUsageInit

Initializes the CPU usage measurement module.

**Prototype:**

```
void
CPUUsageInit(unsigned long ulClockRate,
              unsigned long ulRate,
              unsigned long ulTimer)
```

**Parameters:**

***ulClockRate*** is the rate of the clock supplied to the timer module.

***ulRate*** is the number of times per second that [CPUUsageTick\(\)](#) is called.

***ulTimer*** is the index of the timer module to use.

**Description:**

This function prepares the CPU usage measurement module for measuring the CPU usage of the application.

**Returns:**

None.

### 5.2.1.2 CPUUsageTick

Updates the CPU usage for the new timing period.

**Prototype:**

```
unsigned long
CPUUsageTick(void)
```

**Description:**

This function, when called at the end of a timing period, will update the CPU usage.

**Returns:**

Returns the CPU usage percentage as a 16.16 fixed-point value.

## 5.3 Programming Example

The following example shows how to use the CPU usage module to measure the CPU usage where the foreground simply burns some cycles.

```
//
// The CPU usage for the most recent time period.
//
unsigned long g_ulCPUUsage;

//
// Handles the SysTick interrupt.
```



```
//
void
SysTickIntHandler(void)
{
    //
    // Compute the CPU usage for the last time period.
    //
    g_ulCPUUsage = CPUUsageTick();
}

//
// The main application.
//
int
main(void)
{
    //
    // Initialize the CPU usage module, using timer 0.
    //
    CPUUsageInit(8000000, 100, 0);

    //
    // Initialize SysTick to interrupt at 100 Hz.
    //
    SysTickPeriodSet(8000000 / 100);
    SysTickIntEnable();
    SysTickEnable();

    //
    // Loop forever.
    //
    while(1)
    {
        //
        // Delay for a little bit so that CPU usage is not zero.
        //
        SysCtlDelay(100);

        //
        // Put the processor to sleep.
        //
        SysCtlSleep();
    }
}
```



## 6 CRC Module

Introduction .....	35
API Functions .....	35
Programming Example .....	38

### 6.1 Introduction

The CRC module provides functions to compute the CRC-8-CCITT and CRC-16 of a buffer of data. Support is provided for computing a running CRC, where a partial CRC is computed on one portion of the data, and then continued at a later time on another portion of the data. This is useful when computing the CRC on a stream of data that is coming in via a serial link (for example).

A CRC is useful for detecting errors that occur during the transmission of data over a communications channel or during storage in a memory (such as flash). However, a CRC does not provide protection against an intentional modification or tampering of the data.

This module is contained in `utils/crc.c`, with `utils/crc.h` containing the API definitions for use by applications.

### 6.2 API Functions

#### Functions

- unsigned short [Crc16](#) (unsigned short usCrc, const unsigned char \*pucData, unsigned long ulCount)
- unsigned short [Crc16Array](#) (unsigned long ulWordLen, const unsigned long \*pulData)
- void [Crc16Array3](#) (unsigned long ulWordLen, const unsigned long \*pulData, unsigned short \*pusCrc3)
- unsigned long [Crc32](#) (unsigned long ulCrc, const unsigned char \*pucData, unsigned long ulCount)
- unsigned char [Crc8CCITT](#) (unsigned char ucCrc, const unsigned char \*pucData, unsigned long ulCount)

#### 6.2.1 Function Documentation

##### 6.2.1.1 Crc16

Calculates the CRC-16 of an array of bytes.

**Prototype:**

```
unsigned short
Crc16(unsigned short usCrc,
      const unsigned char *pucData,
      unsigned long ulCount)
```

**Parameters:**

**usCrc** is the starting CRC-16 value.

**pucData** is a pointer to the data buffer.

**ulCount** is the number of bytes in the data buffer.

**Description:**

This function is used to calculate the CRC-16 of the input buffer. The CRC-16 is computed in a running fashion, meaning that the entire data block that is to have its CRC-16 computed does not need to be supplied all at once. If the input buffer contains the entire block of data, then **usCrc** should be set to 0. If, however, the entire block of data is not available, then **usCrc** should be set to 0 for the first portion of the data, and then the returned value should be passed back in as **usCrc** for the next portion of the data.

For example, to compute the CRC-16 of a block that has been split into three pieces, use the following:

```
usCrc = Crc16(0, pucData1, ulLen1);
usCrc = Crc16(usCrc, pucData2, ulLen2);
usCrc = Crc16(usCrc, pucData3, ulLen3);
```

Computing a CRC-16 in a running fashion is useful in cases where the data is arriving via a serial link (for example) and is therefore not all available at one time.

**Returns:**

The CRC-16 of the input data.

### 6.2.1.2 Crc16Array

Calculates the CRC-16 of an array of words.

**Prototype:**

```
unsigned short
Crc16Array(unsigned long ulWordLen,
           const unsigned long *pulData)
```

**Parameters:**

**ulWordLen** is the length of the array in words (the number of bytes divided by 4).

**pulData** is a pointer to the data buffer.

**Description:**

This function is a wrapper around the running CRC-16 function, providing the CRC-16 for a single block of data.

**Returns:**

The CRC-16 of the input data.

### 6.2.1.3 Crc16Array3

Calculates three CRC-16s of an array of words.

**Prototype:**

```
void
Crc16Array3(unsigned long ulWordLen,
            const unsigned long *pulData,
            unsigned short *pusCrc3)
```

**Parameters:**

**ulWordLen** is the length of the array in words (the number of bytes divided by 4).

**pulData** is a pointer to the data buffer.

**pusCrc3** is a pointer to an array in which to place the three CRC-16 values.

**Description:**

This function is used to calculate three CRC-16s of the input buffer; the first uses every byte from the array, the second uses only the even-index bytes from the array (in other words, bytes 0, 2, 4, etc.), and the third uses only the odd-index bytes from the array (in other words, bytes 1, 3, 5, etc.).

**Returns:**

None

#### 6.2.1.4 Crc32

Calculates the CRC-32 of an array of bytes.

**Prototype:**

```
unsigned long
Crc32(unsigned long ulCrc,
      const unsigned char *pucData,
      unsigned long ulCount)
```

**Parameters:**

**ulCrc** is the starting CRC-32 value.

**pucData** is a pointer to the data buffer.

**ulCount** is the number of bytes in the data buffer.

**Description:**

This function is used to calculate the CRC-32 of the input buffer. The CRC-32 is computed in a running fashion, meaning that the entire data block that is to have its CRC-32 computed does not need to be supplied all at once. If the input buffer contains the entire block of data, then **ulCrc** should be set to 0xFFFFFFFF. If, however, the entire block of data is not available, then **ulCrc** should be set to 0xFFFFFFFF for the first portion of the data, and then the returned value should be passed back in as **ulCrc** for the next portion of the data. Once all data has been passed to the function, the final CRC-32 can be obtained by inverting the last returned value.

For example, to compute the CRC-32 of a block that has been split into three pieces, use the following:

```
ulCrc = Crc32(0xFFFFFFFF, pucData1, ulLen1);
ulCrc = Crc32(ulCrc, pucData2, ulLen2);
ulCrc = Crc32(ulCrc, pucData3, ulLen3);
ulCrc ^= 0xFFFFFFFF;
```

Computing a CRC-32 in a running fashion is useful in cases where the data is arriving via a serial link (for example) and is therefore not all available at one time.

**Returns:**

The accumulated CRC-32 of the input data.

### 6.2.1.5 Crc8CCITT

Calculates the CRC-8-CCITT of an array of bytes.

**Prototype:**

```
unsigned char
Crc8CCITT(unsigned char ucCrc,
           const unsigned char *pucData,
           unsigned long ulCount)
```

**Parameters:**

**ucCrc** is the starting CRC-8-CCITT value.

**pucData** is a pointer to the data buffer.

**ulCount** is the number of bytes in the data buffer.

**Description:**

This function is used to calculate the CRC-8-CCITT of the input buffer. The CRC-8-CCITT is computed in a running fashion, meaning that the entire data block that is to have its CRC-8-CCITT computed does not need to be supplied all at once. If the input buffer contains the entire block of data, then **ucCrc** should be set to 0. If, however, the entire block of data is not available, then **ucCrc** should be set to 0 for the first portion of the data, and then the returned value should be passed back in as **ucCrc** for the next portion of the data.

For example, to compute the CRC-8-CCITT of a block that has been split into three pieces, use the following:

```
ucCrc = Crc8CCITT(0, pucData1, ulLen1);
ucCrc = Crc8CCITT(ucCrc, pucData2, ulLen2);
ucCrc = Crc8CCITT(ucCrc, pucData3, ulLen3);
```

Computing a CRC-8-CCITT in a running fashion is useful in cases where the data is arriving via a serial link (for example) and is therefore not all available at one time.

**Returns:**

The CRC-8-CCITT of the input data.

## 6.3 Programming Example

The following example shows how to compute the CRC-16 of a buffer of data.

```
unsigned long ulIdx, ulValue;
unsigned char pucData[256];

//
// Fill pucData with some data.
```

```
//  
for(ulIdx = 0; ulIdx < 256; ulIdx++)  
{  
    pucData[ulIdx] = ulIdx;  
}  
  
//  
// Compute the CRC-16 of the data.  
//  
ulValue = Crc16(0, pucData, 256);
```





# 7 Flash Parameter Block Module

Introduction .....	41
API Functions .....	41
Programming Example .....	43

## 7.1 Introduction

The flash parameter block module provides a simple, fault-tolerant, persistent storage mechanism for storing parameter information for an application.

The [FlashPBlockInit\(\)](#) function is used to initialize a parameter block. The primary conditions for the parameter block are that flash region used to store the parameter blocks must contain at least two erase blocks of flash to ensure fault tolerance, and the size of the parameter block must be an integral divisor of the the size of an erase block. [FlashPBlockGet\(\)](#) and [FlashPBlockSave\(\)](#) are used to read and write parameter block data into the parameter region. The only constraints on the content of the parameter block are that the first two bytes of the block are reserved for use by the read/write functions as a sequence number and checksum, respectively.

This module is contained in `utils/flash_pb.c`, with `utils/flash_pb.h` containing the API definitions for use by applications.

## 7.2 API Functions

### Functions

- unsigned char \* [FlashPBlockGet](#) (void)
- void [FlashPBlockInit](#) (unsigned long ulStart, unsigned long ulEnd, unsigned long ulSize)
- void [FlashPBlockSave](#) (unsigned char \*pucBuffer)

### 7.2.1 Function Documentation

#### 7.2.1.1 FlashPBlockGet

Gets the address of the most recent parameter block.

**Prototype:**

```
unsigned char *  
FlashPBlockGet (void)
```

**Description:**

This function returns the address of the most recent parameter block that is stored in flash.

**Returns:**

Returns the address of the most recent parameter block, or NULL if there are no valid parameter blocks in flash.

### 7.2.1.2 FlashPBlockInit

Initializes the flash parameter block.

**Prototype:**

```
void  
FlashPBlockInit(unsigned long ulStart,  
                unsigned long ulEnd,  
                unsigned long ulSize)
```

**Parameters:**

**ulStart** is the address of the flash memory to be used for storing flash parameter blocks; this must be the start of an erase block in the flash.

**ulEnd** is the address of the end of flash memory to be used for storing flash parameter blocks; this must be the start of an erase block in the flash (the first block that is NOT part of the flash memory to be used), or the address of the first word after the flash array if the last block of flash is to be used.

**ulSize** is the size of the parameter block when stored in flash; this must be a power of two less than or equal to the flash erase block size (typically 1024).

**Description:**

This function initializes a fault-tolerant, persistent storage mechanism for a parameter block for an application. The last several erase blocks of flash (as specified by *ulStart* and *ulEnd*) are used for the storage; more than one erase block is required in order to be fault-tolerant.

A parameter block is an array of bytes that contain the persistent parameters for the application. The only special requirement for the parameter block is that the first byte is a sequence number (explained in [FlashPBlockSave\(\)](#)) and the second byte is a checksum used to validate the correctness of the data (the checksum byte is the byte such that the sum of all bytes in the parameter block is zero).

The portion of flash for parameter block storage is split into N equal-sized regions, where each region is the size of a parameter block (*ulSize*). Each region is scanned to find the most recent valid parameter block. The region that has a valid checksum and has the highest sequence number (with special consideration given to wrapping back to zero) is considered to be the current parameter block.

In order to make this efficient and effective, three conditions must be met. The first is *ulStart* and *ulEnd* must be specified such that at least two erase blocks of flash are dedicated to parameter block storage. If not, fault tolerance can not be guaranteed since an erase of a single block will leave a window where there are no valid parameter blocks in flash. The second condition is that the size (*ulSize*) of the parameter block must be an integral divisor of the size of an erase block of flash. If not, a parameter block will end up spanning between two erase blocks of flash, making it more difficult to manage. The final condition is that the size of the flash dedicated to parameter blocks (*ulEnd* - *ulStart*) divided by the parameter block size (*ulSize*) must be less than or equal to 128. If not, it will not be possible in all cases to determine which parameter block is the most recent (specifically when dealing with the sequence number wrapping back to zero).

When the microcontroller is initially programmed, the flash blocks used for parameter block storage are left in an erased state.

This function must be called before any other flash parameter block functions are called.

**Returns:**

None.

### 7.2.1.3 FlashPBSave

Writes a new parameter block to flash.

**Prototype:**

```
void  
FlashPBSave(unsigned char *pucBuffer)
```

**Parameters:**

***pucBuffer*** is the address of the parameter block to be written to flash.

**Description:**

This function will write a parameter block to flash. Saving the new parameter blocks involves three steps:

- Setting the sequence number such that it is one greater than the sequence number of the latest parameter block in flash.
- Computing the checksum of the parameter block.
- Writing the parameter block into the storage immediately following the latest parameter block in flash; if that storage is at the start of an erase block, that block is erased first.

By this process, there is always a valid parameter block in flash. If power is lost while writing a new parameter block, the checksum will not match and the partially written parameter block will be ignored. This is what makes this fault-tolerant.

Another benefit of this scheme is that it provides wear leveling on the flash. Since multiple parameter blocks fit into each erase block of flash, and multiple erase blocks are used for parameter block storage, it takes quite a few parameter block saves before flash is re-written.

**Returns:**

None.

## 7.3 Programming Example

The following example shows how to use the flash parameter block module to read the contents of a flash parameter block.

```
unsigned char pucBuffer[16], *pucPB;  
  
//  
// Initialize the flash parameter block module, using the last two pages of  
// a 64 KB device as the parameter block.  
//  
FlashPBInit(0xf800, 0x10000, 16);  
  
//  
// Read the current parameter block.  
//  
pucPB = FlashPBGet();  
if(pucPB)  
{  
    memcpy(pucBuffer, pucPB);  
}
```



## 8 Integer Square Root Module

Introduction .....	45
API Functions .....	45
Programming Example .....	46

### 8.1 Introduction

The integer square root module provides an integer version of the square root operation that can be used instead of the floating point version provided in the C library. The algorithm used is a derivative of the manual pencil-and-paper method that used to be taught in school, and is closely related to the pencil-and-paper division method that is likely still taught in school.

For full details of the algorithm, see the article by Jack W. Crenshaw in the February 1998 issue of Embedded System Programming. It can be found online at <http://www.embedded.com/98/9802fe2.htm>.

This module is contained in `utils/isqrt.c`, with `utils/isqrt.h` containing the API definitions for use by applications.

### 8.2 API Functions

#### Functions

- unsigned long `isqrt` (unsigned long `ulValue`)

#### 8.2.1 Function Documentation

##### 8.2.1.1 `isqrt`

Compute the integer square root of an integer.

**Prototype:**

```
unsigned long  
isqrt(unsigned long ulValue)
```

**Parameters:**

***ulValue*** is the value whose square root is desired.

**Description:**

This function will compute the integer square root of the given input value. Since the value returned is also an integer, it is actually better defined as the largest integer whose square is less than or equal to the input value.

**Returns:**

Returns the square root of the input value.

## 8.3 Programming Example

The following example shows how to compute the square root of a number.

```
unsigned long ulValue;  
  
//  
// Get the square root of 52378. The result returned will be 228, which is  
// the largest integer less than or equal to the square root of 52378.  
//  
ulValue = isqrt(52378);
```

## 9 Ethernet Board Locator Module

Introduction .....	47
API Functions .....	47
Programming Example .....	50

### 9.1 Introduction

The locator module offers a simple way to add Ethernet board locator capability to an application which is using the lwIP TCP/IP stack. Applications running the locator service will be detected by the `finder` application which can be found in the `tools` directory of the StellarisWare installation.

APIs offered by the locator module allow an application to set various fields which are communicated to the `finder` application when it enumerates Stellaris boards on the network. These fields include an application-specified name, the MAC address of the board, the board ID and the client IP address.

This module is contained in `utils/locator.c`, with `utils/locator.h` containing the API definitions for use by applications.

### 9.2 API Functions

#### Functions

- void [LocatorAppTitleSet](#) (const char \*pcAppTitle)
- void [LocatorBoardIDSet](#) (unsigned long ulID)
- void [LocatorBoardTypeSet](#) (unsigned long ulType)
- void [LocatorClientIPSet](#) (unsigned long ulIP)
- void [LocatorInit](#) (void)
- void [LocatorMACAddrSet](#) (unsigned char \*pucMACArray)
- void [LocatorVersionSet](#) (unsigned long ulVersion)

#### 9.2.1 Function Documentation

##### 9.2.1.1 LocatorAppTitleSet

Sets the application title in the locator response packet.

**Prototype:**

```
void  
LocatorAppTitleSet(const char *pcAppTitle)
```

**Parameters:**

***pcAppTitle*** is a pointer to the application title string.

**Description:**

This function sets the application title in the locator response packet. The string is truncated at 64 characters if it is longer (without a terminating 0), and is zero-filled to 64 characters if it is shorter.

**Returns:**

None.

### 9.2.1.2 LocatorBoardIDSet

Sets the board ID in the locator response packet.

**Prototype:**

```
void  
LocatorBoardIDSet(unsigned long ulID)
```

**Parameters:**

***ulID*** is the ID of the board.

**Description:**

This function sets the board ID field in the locator response packet.

**Returns:**

None.

### 9.2.1.3 LocatorBoardTypeSet

Sets the board type in the locator response packet.

**Prototype:**

```
void  
LocatorBoardTypeSet(unsigned long ulType)
```

**Parameters:**

***ulType*** is the type of the board.

**Description:**

This function sets the board type field in the locator response packet.

**Returns:**

None.

### 9.2.1.4 LocatorClientIPSet

Sets the client IP address in the locator response packet.

**Prototype:**

```
void  
LocatorClientIPSet(unsigned long ulIP)
```



**Parameters:**

***uIP*** is the IP address of the currently connected client.

**Description:**

This function sets the IP address of the currently connected client in the locator response packet. The IP should be set to 0.0.0.0 if there is no client connected. It should never be set for devices that do not have a strict one-to-one mapping of client to server (for example, a web server).

**Returns:**

None.

### 9.2.1.5 LocatorInit

Initializes the locator service.

**Prototype:**

```
void  
LocatorInit(void)
```

**Description:**

This function prepares the locator service to handle device discovery requests. A UDP server is created and the locator response data is initialized to all empty.

**Returns:**

None.

### 9.2.1.6 LocatorMACAddrSet

Sets the MAC address in the locator response packet.

**Prototype:**

```
void  
LocatorMACAddrSet(unsigned char *pucMACArray)
```

**Parameters:**

***pucMACArray*** is the MAC address of the network interface.

**Description:**

This function sets the MAC address of the network interface in the locator response packet.

**Returns:**

None.

### 9.2.1.7 LocatorVersionSet

Sets the firmware version in the locator response packet.

**Prototype:**

```
void  
LocatorVersionSet(unsigned long ulVersion)
```

**Parameters:**

***ulVersion*** is the version number of the device firmware.

**Description:**

This function sets the version number of the device firmware in the locator response packet.

**Returns:**

None.

## 9.3 Programming Example

The following example shows how to set up the board locator service in an application which uses Ethernet and the lwIP TCP/IP stack.

```
//  
// Initialize the lwIP TCP/IP stack.  
//  
lwIPInit(pucMACAddr, 0, 0, 0, IPADDR_USE_DHCP);  
  
//  
// Setup the device locator service.  
//  
LocatorInit();  
LocatorMACAddrSet(pucMACAddr);  
LocatorAppTitleSet("Your application name");
```

## 10 lwIP Wrapper Module

Introduction .....	51
API Functions .....	51
Programming Example .....	54

### 10.1 Introduction

The lwIP wrapper module provides a simple abstraction layer for the lwIP version 1.3.2 TCP/IP stack. The configuration of the TCP/IP stack is based on the options defined in the `lwipopts.h` file provided by the application.

The `lwIPInit()` function is used to initialize the lwIP TCP/IP stack. The `lwIPEthernetIntHandler()` is the interrupt handler function for use with the lwIP TCP/IP stack. This handler will process transmit and receive packets. If no RTOS is being used, the interrupt handler will also service the lwIP timers. The `lwIPTimer()` function is to be called periodically to support the TCP, ARP, DHCP and other timers used by the lwIP TCP/IP stack. If no RTOS is being used, this timer function will simply trigger an Ethernet interrupt to allow the interrupt handler to service the timers.

This module is contained in `utils/lwiplib.c`, with `utils/lwiplib.h` containing the API definitions for use by applications.

### 10.2 API Functions

#### Functions

- void `lwIPEthernetIntHandler` (void)
- void `lwIPInit` (const unsigned char \*pucMAC, unsigned long ulIPAddr, unsigned long ulNetMask, unsigned long ulGWAddr, unsigned long ulIPMode)
- unsigned long `lwIPLocalGWAddrGet` (void)
- unsigned long `lwIPLocalIPAddrGet` (void)
- void `lwIPLocalMACGet` (unsigned char \*pucMAC)
- unsigned long `lwIPLocalNetMaskGet` (void)
- void `lwIPNetworkConfigChange` (unsigned long ulIPAddr, unsigned long ulNetMask, unsigned long ulGWAddr, unsigned long ulIPMode)

#### 10.2.1 Function Documentation

##### 10.2.1.1 lwIPEthernetIntHandler

Handles Ethernet interrupts for the lwIP TCP/IP stack.

**Prototype:**

```
void  
lwIPEthernetIntHandler(void)
```

**Description:**

This function handles Ethernet interrupts for the lwIP TCP/IP stack. At the lowest level, all receive packets are placed into a packet queue for processing at a higher level. Also, the transmit packet queue is checked and packets are drained and transmitted through the Ethernet MAC as needed. If the system is configured without an RTOS, additional processing is performed at the interrupt level. The packet queues are processed by the lwIP TCP/IP code, and lwIP periodic timers are serviced (as needed).

**Returns:**

None.

### 10.2.1.2 lwIPInit

Initializes the lwIP TCP/IP stack.

**Prototype:**

```
void  
lwIPInit(const unsigned char *pucMAC,  
          unsigned long ulIPAddr,  
          unsigned long ulNetMask,  
          unsigned long ulGWAddr,  
          unsigned long ulIPMode)
```

**Parameters:**

**pucMAC** is a pointer to a six byte array containing the MAC address to be used for the interface.

**ulIPAddr** is the IP address to be used (static).

**ulNetMask** is the network mask to be used (static).

**ulGWAddr** is the Gateway address to be used (static).

**ulIPMode** is the IP Address Mode. **IPADDR\_USE\_STATIC** will force static IP addressing to be used, **IPADDR\_USE\_DHCP** will force DHCP with fallback to Link Local (Auto IP), while **IPADDR\_USE\_AUTOIP** will force Link Local only.

**Description:**

This function performs initialization of the lwIP TCP/IP stack for the Stellaris Ethernet MAC, including DHCP and/or AutoIP, as configured.

**Returns:**

None.

### 10.2.1.3 lwIPLocalGWAddrGet

Returns the gateway address for this interface.

**Prototype:**

```
unsigned long  
lwIPLocalGWAddrGet(void)
```

**Description:**

This function will read and return the currently assigned gateway address for the Stellaris Ethernet interface.

**Returns:**

the assigned gateway address for this interface.

#### 10.2.1.4 lwIPLocalIPAddrGet

Returns the IP address for this interface.

**Prototype:**

```
unsigned long  
lwIPLocalIPAddrGet(void)
```

**Description:**

This function will read and return the currently assigned IP address for the Stellaris Ethernet interface.

**Returns:**

Returns the assigned IP address for this interface.

#### 10.2.1.5 lwIPLocalMACGet

Returns the local MAC/HW address for this interface.

**Prototype:**

```
void  
lwIPLocalMACGet(unsigned char *pucMAC)
```

**Parameters:**

***pucMAC*** is a pointer to an array of bytes used to store the MAC address.

**Description:**

This function will read the currently assigned MAC address into the array passed in *pucMAC*.

**Returns:**

None.

#### 10.2.1.6 lwIPLocalNetMaskGet

Returns the network mask for this interface.

**Prototype:**

```
unsigned long  
lwIPLocalNetMaskGet(void)
```

**Description:**

This function will read and return the currently assigned network mask for the Stellaris Ethernet interface.

**Returns:**

the assigned network mask for this interface.

### 10.2.1.7 lwIPNetworkConfigChange

Change the configuration of the lwIP network interface.

**Prototype:**

```
void  
lwIPNetworkConfigChange(unsigned long ulIPAddr,  
                        unsigned long ulNetMask,  
                        unsigned long ulGWAddr,  
                        unsigned long ulIPMode)
```

**Parameters:**

**ulIPAddr** is the new IP address to be used (static).

**ulNetMask** is the new network mask to be used (static).

**ulGWAddr** is the new Gateway address to be used (static).

**ulIPMode** is the IP Address Mode. **IPADDR\_USE\_STATIC** 0 will force static IP addressing to be used, **IPADDR\_USE\_DHCP** will force DHCP with fallback to Link Local (Auto IP), while **IPADDR\_USE\_AUTOIP** will force Link Local only.

**Description:**

This function will evaluate the new configuration data. If necessary, the interface will be brought down, reconfigured, and then brought back up with the new configuration.

**Returns:**

None.

## 10.3 Programming Example

The following example shows how to use the lwIP wrapper module to initialize the lwIP stack.

```
unsigned char pucMACArray[6];  
  
//  
// Fill in the MAC array and initialize the lwIP library using DHCP.  
//  
lwIPInit(pucMACArray, 0, 0, 0, IPADDR_USE_DHCP);  
  
//  
// Periodically call the lwIP timer tick. In a real application, this  
// would use a timer interrupt instead of an endless loop.  
//  
while(1)  
{  
    SysCtlDelay(1000);  
    lwIPTimer(1);  
}
```

# 11 PTPd Wrapper Module

Introduction .....	55
API Functions .....	55
Programming Example .....	55

## 11.1 Introduction

The PTPd wrapper module provides a simple way to include the open-source PTPd library in an application. Because the PTPd library has compile-time options that may vary from one application to the next, it is not practical to provide this library in object format. By including the `ptpdlib.c` module in your application's project and/or make file, the library can be included at compile-time with a single reference.

The PTPd library provides IEEE Precision Time Protocol (1588) ported to the Stellaris family of Ethernet-enabled devices. This port uses lwIP as the underlying TCP/IP stack. Refer to the `enet_ptpd` sample application for the EK-6965 and EK-8962 Evaluation Kits for additional details.

This module is contained in `utils/ptpdlib.c`, with `utils/ptpdlib.h` containing the API definitions for use by applications.

## 11.2 API Functions

## 11.3 Programming Example

```
//
// Clear out all of the run time options and protocol stack options.
//
memset(&g_sRtOpts, 0, sizeof(g_sRtOpts));
memset(&g_sPTPClock, 0, sizeof(g_sPTPClock));

//
// Initialize all PTPd Run Time and Clock Options.
// Note: This code will be specific to your application
//
...

//
// Run the protocol engine for the first time to initialize the state
// machines.
//
protocol_first(&g_sRtOpts, &g_sPTPClock);

...

//
// Main Loop
//
while(1)
{
    ...
}
```

```
    //  
    // Run the protocol engine for each pass through the main process loop.  
    //  
    protocol_loop(&g_sRtOpts, &g_sPTPClock);  
  
    ...  
}
```



## 12 Ring Buffer Module

Introduction .....	57
API Functions .....	57
Programming Example .....	63

### 12.1 Introduction

The ring buffer module provides a set of functions allowing management of a block of memory as a ring buffer. This is typically used in buffering transmit or receive data for a communication channel but has many other uses including implementing queues and FIFOs.

This module is contained in `utils/ringbuf.c`, with `utils/ringbuf.h` containing the API definitions for use by applications.

### 12.2 API Functions

#### Functions

- void [RingBufAdvanceRead](#) (tRingBufObject \*ptRingBuf, unsigned long ulNumBytes)
- void [RingBufAdvanceWrite](#) (tRingBufObject \*ptRingBuf, unsigned long ulNumBytes)
- unsigned long [RingBufContigFree](#) (tRingBufObject \*ptRingBuf)
- unsigned long [RingBufContigUsed](#) (tRingBufObject \*ptRingBuf)
- tBoolean [RingBufEmpty](#) (tRingBufObject \*ptRingBuf)
- void [RingBufFlush](#) (tRingBufObject \*ptRingBuf)
- unsigned long [RingBufFree](#) (tRingBufObject \*ptRingBuf)
- tBoolean [RingBufFull](#) (tRingBufObject \*ptRingBuf)
- void [RingBufInit](#) (tRingBufObject \*ptRingBuf, unsigned char \*pucBuf, unsigned long ulSize)
- void [RingBufRead](#) (tRingBufObject \*ptRingBuf, unsigned char \*pucData, unsigned long ulLength)
- unsigned char [RingBufReadOne](#) (tRingBufObject \*ptRingBuf)
- unsigned long [RingBufSize](#) (tRingBufObject \*ptRingBuf)
- unsigned long [RingBufUsed](#) (tRingBufObject \*ptRingBuf)
- void [RingBufWrite](#) (tRingBufObject \*ptRingBuf, unsigned char \*pucData, unsigned long ulLength)
- void [RingBufWriteOne](#) (tRingBufObject \*ptRingBuf, unsigned char ucData)

#### 12.2.1 Function Documentation

##### 12.2.1.1 RingBufAdvanceRead

Remove bytes from the ring buffer by advancing the read index.

**Prototype:**

```
void  
RingBufAdvanceRead(tRingBufObject *ptRingBuf,  
                  unsigned long ulNumBytes)
```

**Parameters:**

***ptRingBuf*** points to the ring buffer from which bytes are to be removed.  
***ulNumBytes*** is the number of bytes to be removed from the buffer.

**Description:**

This function advances the ring buffer read index by a given number of bytes, removing that number of bytes of data from the buffer. If *ulNumBytes* is larger than the number of bytes currently in the buffer, the buffer is emptied.

**Returns:**

None.

### 12.2.1.2 RingBufAdvanceWrite

Add bytes to the ring buffer by advancing the write index.

**Prototype:**

```
void  
RingBufAdvanceWrite(tRingBufObject *ptRingBuf,  
                   unsigned long ulNumBytes)
```

**Parameters:**

***ptRingBuf*** points to the ring buffer to which bytes have been added.  
***ulNumBytes*** is the number of bytes added to the buffer.

**Description:**

This function should be used by clients who wish to add data to the buffer directly rather than via calls to [RingBufWrite\(\)](#) or [RingBufWriteOne\(\)](#). It advances the write index by a given number of bytes. If the *ulNumBytes* parameter is larger than the amount of free space in the buffer, the read pointer will be advanced to cater for the addition. Note that this will result in some of the oldest data in the buffer being discarded.

**Returns:**

None.

### 12.2.1.3 RingBufContigFree

Returns number of contiguous free bytes available in a ring buffer.

**Prototype:**

```
unsigned long  
RingBufContigFree(tRingBufObject *ptRingBuf)
```

**Parameters:**

***ptRingBuf*** is the ring buffer object to check.

**Description:**

This function returns the number of contiguous free bytes ahead of the current write pointer in the ring buffer.

**Returns:**

Returns the number of contiguous bytes available in the ring buffer.

#### 12.2.1.4 RingBufContigUsed

Returns number of contiguous bytes of data stored in ring buffer ahead of the current read pointer.

**Prototype:**

```
unsigned long  
RingBufContigUsed(tRingBufObject *ptRingBuf)
```

**Parameters:**

**ptRingBuf** is the ring buffer object to check.

**Description:**

This function returns the number of contiguous bytes of data available in the ring buffer ahead of the current read pointer. This represents the largest block of data which does not straddle the buffer wrap.

**Returns:**

Returns the number of contiguous bytes available.

#### 12.2.1.5 RingBufEmpty

Determines whether the ring buffer whose pointers and size are provided is empty or not.

**Prototype:**

```
tBoolean  
RingBufEmpty(tRingBufObject *ptRingBuf)
```

**Parameters:**

**ptRingBuf** is the ring buffer object to empty.

**Description:**

This function is used to determine whether or not a given ring buffer is empty. The structure is specifically to ensure that we do not see warnings from the compiler related to the order of volatile accesses being undefined.

**Returns:**

Returns **true** if the buffer is empty or **false** otherwise.

#### 12.2.1.6 RingBufFlush

Empties the ring buffer.

**Prototype:**

```
void  
RingBufFlush(tRingBufObject *ptRingBuf)
```

**Parameters:**

***ptRingBuf*** is the ring buffer object to empty.

**Description:**

Discards all data from the ring buffer.

**Returns:**

None.

### 12.2.1.7 RingBufFree

Returns number of bytes available in a ring buffer.

**Prototype:**

```
unsigned long  
RingBufFree(tRingBufObject *ptRingBuf)
```

**Parameters:**

***ptRingBuf*** is the ring buffer object to check.

**Description:**

This function returns the number of bytes available in the ring buffer.

**Returns:**

Returns the number of bytes available in the ring buffer.

### 12.2.1.8 RingBufFull

Determines whether the ring buffer whose pointers and size are provided is full or not.

**Prototype:**

```
tBoolean  
RingBufFull(tRingBufObject *ptRingBuf)
```

**Parameters:**

***ptRingBuf*** is the ring buffer object to empty.

**Description:**

This function is used to determine whether or not a given ring buffer is full. The structure is specifically to ensure that we do not see warnings from the compiler related to the order of volatile accesses being undefined.

**Returns:**

Returns **true** if the buffer is full or **false** otherwise.

### 12.2.1.9 RingBufInit

Initialize a ring buffer object.

**Prototype:**

```
void  
RingBufInit (tRingBufObject *ptRingBuf,  
             unsigned char *pucBuf,  
             unsigned long ulSize)
```

**Parameters:**

***ptRingBuf*** points to the ring buffer to be initialized.  
***pucBuf*** points to the data buffer to be used for the ring buffer.  
***ulSize*** is the size of the buffer in bytes.

**Description:**

This function initializes a ring buffer object, preparing it to store data.

**Returns:**

None.

### 12.2.1.10 RingBufRead

Reads data from a ring buffer.

**Prototype:**

```
void  
RingBufRead (tRingBufObject *ptRingBuf,  
             unsigned char *pucData,  
             unsigned long ulLength)
```

**Parameters:**

***ptRingBuf*** points to the ring buffer to be read from.  
***pucData*** points to where the data should be stored.  
***ulLength*** is the number of bytes to be read.

**Description:**

This function reads a sequence of bytes from a ring buffer.

**Returns:**

None.

### 12.2.1.11 RingBufReadOne

Reads a single byte of data from a ring buffer.

**Prototype:**

```
unsigned char  
RingBufReadOne (tRingBufObject *ptRingBuf)
```

**Parameters:**

***ptRingBuf*** points to the ring buffer to be written to.

**Description:**

This function reads a single byte of data from a ring buffer.

**Returns:**

The byte read from the ring buffer.

### 12.2.1.12 RingBufSize

Return size in bytes of a ring buffer.

**Prototype:**

```
unsigned long  
RingBufSize(tRingBufObject *ptRingBuf)
```

**Parameters:**

***ptRingBuf*** is the ring buffer object to check.

**Description:**

This function returns the size of the ring buffer.

**Returns:**

Returns the size in bytes of the ring buffer.

### 12.2.1.13 RingBufUsed

Returns number of bytes stored in ring buffer.

**Prototype:**

```
unsigned long  
RingBufUsed(tRingBufObject *ptRingBuf)
```

**Parameters:**

***ptRingBuf*** is the ring buffer object to check.

**Description:**

This function returns the number of bytes stored in the ring buffer.

**Returns:**

Returns the number of bytes stored in the ring buffer.

### 12.2.1.14 RingBufWrite

Writes data to a ring buffer.

**Prototype:**

```
void  
RingBufWrite(tRingBufObject *ptRingBuf,  
             unsigned char *pucData,  
             unsigned long ulLength)
```

**Parameters:**

***ptRingBuf*** points to the ring buffer to be written to.  
***pucData*** points to the data to be written.  
***ulLength*** is the number of bytes to be written.

**Description:**

This function write a sequence of bytes into a ring buffer.

**Returns:**

None.

### 12.2.1.15 RingBufWriteOne

Writes a single byte of data to a ring buffer.

**Prototype:**

```
void  
RingBufWriteOne(tRingBufObject *ptRingBuf,  
               unsigned char ucData)
```

**Parameters:**

***ptRingBuf*** points to the ring buffer to be written to.  
***ucData*** is the byte to be written.

**Description:**

This function writes a single byte of data into a ring buffer.

**Returns:**

None.

## 12.3 Programming Example

The following example shows how to pass data through the ring buffer.

```
char pcBuffer[128], pcData[16];  
tRingBufObject sRingBuf;  
  
//  
// Initialize the ring buffer.  
//  
RingBufInit(&sRingBuf, pcBuffer, sizeof(pcBuffer));  
  
//  
// Write some data into the ring buffer.  
//  
RingBufWrite(&sRingBuf, "Hello World", 11);
```

```
//  
// Read the data out of the ring buffer.  
//  
RingBufRead(&sRingBuf, pData, 11);
```



## 13 Simple Task Scheduler Module

Introduction .....	65
API Functions .....	65
Programming Example .....	70

### 13.1 Introduction

The simple task scheduler module offers an easy way to implement applications which rely upon a group of functions being called at regular time intervals. The module makes use of an application-defined task table listing functions to be called. Each task is defined by a function pointer, a parameter that will be passed to that function, the period between consecutive calls to the function and a flag indicating whether that particular task is enabled.

The scheduler makes use of the SysTick counter and interrupt to track time and calls enabled functions when the appropriate period has elapsed since the last call to that function.

In addition to providing the task table `g_psSchedulerTable[]` to the module, the application must also define a global variable `g_ulSchedulerNumTasks` containing the number of task entries in the table. The module also requires exclusive access to the SysTick hardware and the application must hook the scheduler's SysTick interrupt handler to the appropriate interrupt vector. Although the scheduler owns SysTick, functions are provided to allow the current system time to be queried and to calculate elapsed time between two system time values or between an earlier time value and the present time.

All times passed to the scheduler or returned from it are expressed in terms of system ticks. The basic system tick rate is set by the application when it initializes the scheduler module.

This module is contained in `utils/scheduler.c`, with `utils/scheduler.h` containing the API definitions for use by applications.

### 13.2 API Functions

#### Data Structures

- [tSchedulerTask](#)

#### Functions

- unsigned long [SchedulerElapsedTicksCalc](#) (unsigned long ulTickStart, unsigned long ulTickEnd)
- unsigned long [SchedulerElapsedTicksGet](#) (unsigned long ulTickCount)
- void [SchedulerInit](#) (unsigned long ulTicksPerSecond)
- void [SchedulerRun](#) (void)
- void [SchedulerSysTickIntHandler](#) (void)
- void [SchedulerTaskDisable](#) (unsigned long ulIndex)
- void [SchedulerTaskEnable](#) (unsigned long ulIndex, tBoolean bRunNow)

- unsigned long [SchedulerTickCountGet](#) (void)

## Variables

- [tSchedulerTask](#) [g\\_psSchedulerTable](#)[]
- unsigned long [g\\_ulSchedulerNumTasks](#)

## 13.2.1 Data Structure Documentation

### 13.2.1.1 tSchedulerTask

#### Definition:

```
typedef struct
{
    void (*pfnFunction) (void *);
    void *pvParam;
    unsigned long ulFrequencyTicks;
    unsigned long ulLastCall;
    tBoolean bActive;
}
tSchedulerTask
```

#### Members:

**pfnFunction** A pointer to the function which is to be called periodically by the scheduler.

**pvParam** The parameter which is to be passed to this function when it is called.

**ulFrequencyTicks** The frequency the function is to be called expressed in terms of system ticks. If this value is 0, the function will be called on every call to SchedulerRun.

**ulLastCall** Tick count when this function was last called. This field is updated by the scheduler.

**bActive** A flag indicating whether or not this task is active. If true, the function will be called periodically. If false, the function is disabled and will not be called.

#### Description:

The structure defining a function which the scheduler will call periodically.

## 13.2.2 Function Documentation

### 13.2.2.1 SchedulerElapsedTicksCalc

Returns the number of ticks elapsed between two times.

#### Prototype:

```
unsigned long
SchedulerElapsedTicksCalc(unsigned long ulTickStart,
                          unsigned long ulTickEnd)
```

#### Parameters:

**ulTickStart** is the system tick count for the start of the period.

**ulTickEnd** is the system tick count for the end of the period.

**Description:**

This function may be called by a client to determine the number of ticks which have elapsed between provided starting and ending tick counts. The function takes into account wrapping cases where the end tick count is lower than the starting count assuming that the ending tick count always represents a later time than the starting count.

**Returns:**

The number of ticks elapsed between the provided start and end counts.

### 13.2.2.2 SchedulerElapsedTicksGet

Returns the number of ticks elapsed since the provided tick count.

**Prototype:**

```
unsigned long  
SchedulerElapsedTicksGet(unsigned long ulTickCount)
```

**Parameters:**

***ulTickCount*** is the tick count from which to determine the elapsed time.

**Description:**

This function may be called by a client to determine how much time has passed since a particular tick count provided in the *ulTickCount* parameter. This function takes into account wrapping of the global tick counter and assumes that the provided tick count always represents a time in the past. The returned value will, of course, be wrong if the tick counter has wrapped more than once since the passed *ulTickCount*. As a result, please do not use this function if you are dealing with timeouts of 497 days or longer (assuming you use a 10mS tick period).

**Returns:**

The number of ticks elapsed since the provided tick count.

### 13.2.2.3 SchedulerInit

Initializes the task scheduler.

**Prototype:**

```
void  
SchedulerInit(unsigned long ulTicksPerSecond)
```

**Parameters:**

***ulTicksPerSecond*** sets the basic frequency of the SysTick interrupt used by the scheduler to determine when to run the various task functions.

**Description:**

This function must be called during application startup to configure the SysTick timer. This is used by the scheduler module to determine when each of the functions provided in the `g_psSchedulerTable` array is called.

The caller is responsible for ensuring that [SchedulerSysTickIntHandler\(\)](#) has previously been installed in the SYSTICK vector in the vector table and must also ensure that interrupts are enabled at the CPU level.

Note that this call does not start the scheduler calling the configured functions. All function calls are made in the context of later calls to [SchedulerRun\(\)](#). This call merely configures the SysTick interrupt that is used by the scheduler to determine what the current system time is.

**Returns:**

None.

#### 13.2.2.4 SchedulerRun

Instructs the scheduler to update its task table and make calls to functions needing called.

**Prototype:**

```
void  
SchedulerRun(void)
```

**Description:**

This function must be called periodically by the client to allow the scheduler to make calls to any configured task functions if it is their time to be called. The call must be made at least as frequently as the most frequent task configured in the `g_psSchedulerTable` array.

Although the scheduler makes use of the SysTick interrupt, all calls to functions configured in `g_psSchedulerTable` are made in the context of [SchedulerRun\(\)](#).

**Returns:**

None.

#### 13.2.2.5 SchedulerSysTickIntHandler

Handles the SysTick interrupt on behalf of the scheduler module.

**Prototype:**

```
void  
SchedulerSysTickIntHandler(void)
```

**Description:**

Applications using the scheduler module must ensure that this function is hooked to the SysTick interrupt vector.

**Returns:**

None.

#### 13.2.2.6 SchedulerTaskDisable

Disables a task and prevents the scheduler from calling it.

**Prototype:**

```
void  
SchedulerTaskDisable(unsigned long ulIndex)
```

**Parameters:**

**ulIndex** is the index of the task which is to be disabled in the global *g\_psSchedulerTable* array.

**Description:**

This function marks one of the configured tasks as inactive and prevents [SchedulerRun\(\)](#) from calling it. The task may be reenabled by calling [SchedulerTaskEnable\(\)](#).

**Returns:**

None.

### 13.2.2.7 SchedulerTaskEnable

Enables a task and allows the scheduler to call it periodically.

**Prototype:**

```
void  
SchedulerTaskEnable(unsigned long ulIndex,  
                    tBoolean bRunNow)
```

**Parameters:**

**ulIndex** is the index of the task which is to be enabled in the global *g\_psSchedulerTable* array.

**bRunNow** is **true** if the task is to be run on the next call to [SchedulerRun\(\)](#) or **false** if one whole period is to elapse before the task is run.

**Description:**

This function marks one of the configured tasks as enabled and causes [SchedulerRun\(\)](#) to call that task periodically. The caller may choose to have the enabled task run for the first time on the next call to [SchedulerRun\(\)](#) or to wait one full task period before making the first call.

**Returns:**

None.

### 13.2.2.8 SchedulerTickCountGet

Returns the current system time in ticks since power on.

**Prototype:**

```
unsigned long  
SchedulerTickCountGet(void)
```

**Description:**

This function may be called by a client to retrieve the current system time. The value returned is a count of ticks elapsed since the system last booted.

**Returns:**

Tick count since last boot.

## 13.2.3 Variable Documentation

### 13.2.3.1 g\_psSchedulerTable

**Definition:**

```
tSchedulerTask g_psSchedulerTable[ ]
```

**Description:**

This global table must be populated by the client and contains information on each function that the scheduler is to call.

### 13.2.3.2 g\_ulSchedulerNumTasks

**Definition:**

```
unsigned long g_ulSchedulerNumTasks
```

**Description:**

This global variable must be exported by the client. It must contain the number of entries in the g\_psSchedulerTable array.

## 13.3 Programming Example

The following example shows how to use the task scheduler module. This code illustrates a simple application which toggles two LEDs at different rates and updates a scrolling text string on the display.

```
//*****  
//  
// Definition of the system tick rate. This results in a tick period of 10mS.  
//  
//*****  
#define TICKS_PER_SECOND 100  
  
//*****  
//  
// Prototypes of functions which will be called by the scheduler.  
//  
//*****  
static void ScrollTextBanner(void *pvParam);  
static void ToggleLED(void *pvParam);  
  
//*****  
//  
// This table defines all the tasks that the scheduler is to run, the periods  
// between calls to those tasks, and the parameter to pass to the task.  
//  
//*****  
tSchedulerTask g_psSchedulerTable[] =  
{  
    //  
    // Scroll the text banner 1 character to the left. This function is called  
    // every 20 ticks (5 times per second).  
    //  
    { ScrollTextBanner, (void *)0, 20, 0, true},  
}
```

```

//
// Toggle LED number 0 every 50 ticks (twice per second).
//
{ ToggleLED, (void *)0, 50, 0, true},

//
// Toggle LED number 1 every 100 ticks (once per second).
//
{ ToggleLED, (void *)1, 100, 0, true},
};

//*****
//
// The number of entries in the global scheduler task table.
//
//*****
unsigned long g_ulSchedulerNumTasks = (sizeof(g_psSchedulerTable) /
                                       sizeof(tSchedulerTask));

//*****
//
// This function is called by the scheduler to toggle one of two LEDs
//
//*****
static void
ToggleLED(void *pvParam)
{
    long lState;

    ulState = GPIOPinRead(LED_GPIO_BASE
                          (pvParam ? LED1_GPIO_PIN : LED0_GPIO_PIN));
    GPIOPinWrite(LED_GPIO_BASE, (pvParam ? LED1_GPIO_PIN : LED0_GPIO_PIN),
                 ~lState);
}

//*****
//
// This function is called by the scheduler to scroll a line of text on the
// display.
//
//*****
static void
ScrollTextBanner(void *pvParam)
{
    //
    // Left as an exercise for the reader.
    //
}

//*****
//
// Application main task.
//
//*****
int
main(void)
{
    //
    // Initialize system clock and any peripherals that are to be used.
    //
    SystemInit();

    //
    // Initialize the task scheduler and configure the SysTick to interrupt
    // 100 times per second.

```

```
//
SchedulerInit(TICKS_PER_SECOND);

//
// Turn on interrupts at the CPU level.
//
IntMasterEnable();

//
// Drop into the main loop.
//
while(1)
{
    //
    // Tell the scheduler to call any periodic tasks that are due to be
    // called.
    //
    SchedulerRun();
}
}
```



## 14 Sine Calculation Module

Introduction .....	73
API Functions .....	73
Programming Example .....	74

### 14.1 Introduction

This module provides a fixed-point sine function. The input angle is a 0.32 fixed-point value that is the percentage of 360 degrees. This has two benefits; the sine function does not have to handle angles that are outside the range of 0 degrees through 360 degrees (in fact, 360 degrees can not be represented since it would wrap to 0 degrees), and the computation of the angle can be simplified since it does not have to deal with wrapping at values that are not natural for binary arithmetic (such as 360 degrees or  $2\pi$  radians).

A sine table is used to find the approximate value for a given input angle. The table contains 128 entries that range from 0 degrees through 90 degrees and the symmetry of the sine function is used to determine the value between 90 degrees and 360 degrees. The maximum error caused by this table-based approach is 0.00618, which occurs near 0 and 180 degrees.

This module is contained in `utils/sine.c`, with `utils/sine.h` containing the API definitions for use by applications.

### 14.2 API Functions

#### Defines

- `cosine`(ulAngle)

#### Functions

- long `sine` (unsigned long ulAngle)

#### 14.2.1 Define Documentation

##### 14.2.1.1 cosine

Computes an approximation of the cosine of the input angle.

**Definition:**

```
#define cosine(ulAngle)
```

**Parameters:**

**ulAngle** is an angle expressed as a 0.32 fixed-point value that is the percentage of the way around a circle.

**Description:**

This function computes the cosine for the given input angle. The angle is specified in 0.32 fixed point format, and is therefore always between 0 and 360 degrees, inclusive of 0 and exclusive of 360.

**Returns:**

Returns the cosine of the angle, in 16.16 fixed point format.

## 14.2.2 Function Documentation

### 14.2.2.1 sine

Computes an approximation of the sine of the input angle.

**Prototype:**

```
long  
sine(unsigned long ulAngle)
```

**Parameters:**

***ulAngle*** is an angle expressed as a 0.32 fixed-point value that is the percentage of the way around a circle.

**Description:**

This function computes the sine for the given input angle. The angle is specified in 0.32 fixed point format, and is therefore always between 0 and 360 degrees, inclusive of 0 and exclusive of 360.

**Returns:**

Returns the sine of the angle, in 16.16 fixed point format.

## 14.3 Programming Example

The following example shows how to produce a sine wave with 7 degrees between successive values.

```
unsigned long ulValue;  
  
//  
// Produce a sine wave with each step being 7 degrees advanced from the  
// previous.  
//  
for(ulValue = 0; ; ulValue += 0x04FA4FA4)  
{  
    //  
    // Compute the sine at this angle and do something with the result.  
    //  
    sine(ulValue);  
}
```

# 15 Software I2C Module

Introduction .....	75
API Functions .....	76
Programming Example .....	83

## 15.1 Introduction

The software I2C module uses a timer and two GPIO pins to create a slow-speed software I2C peripheral. Multiple software I2C modules can be in use simultaneously, limited only by the availability of resources (RAM for the per-instance data structure, pins for the interface, timers if unique clock rates are required, and processor cycles to execute the code). The software I2C module supports master mode only; multi-master support is not provided. A callback mechanism is used to simulate the interrupts that would be provided by a hardware I2C module.

The API for the software I2C module has been constructed to be as close as possible to the API provided in the Stellaris Peripheral Driver Library for the hardware I2C module. The two notable differences are the function prefix being “SoftI2C” instead of “I2CMaster”, and the first argument of each API is a pointer to the [tSoftI2C](#) data structure instead of the base address of the hardware module.

Timing for the software I2C module is provided by the application. The [SoftI2CTimerTick\(\)](#) function must be called on a periodic basis to provide the timing for the software I2C module. The timer tick function must be called at four times the desired I2C clock rate; for example, to operate the software I2C interface at 10 KHz, the tick function must be called at a 40 KHz rate. By having the application providing the timing, the timer resource can be flexible and multiple software I2C modules can be driven from a single timer resource. Alternatively, if the software I2C module is only needed for brief periods of time and processor usage is not a concern, the timer tick function can simply be called in a loop until the entire I2C transaction has completed (maximizing both I2C clock speed and processor usage, but not requiring a timer).

The software I2C module requires two GPIO pins; one for SCL and one for SDA. The per-instance data structure is approximately 20 bytes in length (the actual length depends on how the structure is packed by the compiler).

As a point of reference, the following are some rough measurements of the processor usage of the software I2C module at various I2C clock speeds with the processor running at 50 MHz. Actual processor usage may vary, depending on how the application uses the software I2C module, processor clock speed, interrupt priority, and compiler.

I2C Clock	% Of Processor	Million Cycles Per Second
5 KHz	4.53	2.26
10 KHz	9.05	4.52
15 KHz	13.53	6.76
20 KHz	18.03	9.01
25 KHz	22.51	11.25
30 KHz	27.05	13.52
35 KHz	31.52	15.76
40 KHz	36.06	18.03
45 KHz	40.54	20.27
50 KHz	44.96	22.48

This module is contained in `utils/softi2c.c`, with `utils/softi2c.h` containing the API definitions for use by applications.

## 15.2 API Functions

### Data Structures

- [tSoftI2C](#)

### Functions

- tBoolean [SoftI2CBusy](#) (tSoftI2C \*pl2C)
- void [SoftI2CCallbackSet](#) (tSoftI2C \*pl2C, void (\*pfnCallback)(void))
- void [SoftI2CControl](#) (tSoftI2C \*pl2C, unsigned long ulCmd)
- unsigned long [SoftI2CDataGet](#) (tSoftI2C \*pl2C)
- void [SoftI2CDataPut](#) (tSoftI2C \*pl2C, unsigned char ucData)
- unsigned long [SoftI2CErr](#) (tSoftI2C \*pl2C)
- void [SoftI2CInit](#) (tSoftI2C \*pl2C)
- void [SoftI2CIntClear](#) (tSoftI2C \*pl2C)
- void [SoftI2CIntDisable](#) (tSoftI2C \*pl2C)
- void [SoftI2CIntEnable](#) (tSoftI2C \*pl2C)
- tBoolean [SoftI2CIntStatus](#) (tSoftI2C \*pl2C, tBoolean bMasked)
- void [SoftI2CSCLGPIOSet](#) (tSoftI2C \*pl2C, unsigned long ulBase, unsigned char ucPin)
- void [SoftI2CSDAGPIOSet](#) (tSoftI2C \*pl2C, unsigned long ulBase, unsigned char ucPin)
- void [SoftI2CSlaveAddrSet](#) (tSoftI2C \*pl2C, unsigned char ucSlaveAddr, tBoolean bReceive)
- void [SoftI2CTimerTick](#) (tSoftI2C \*pl2C)

### 15.2.1 Data Structure Documentation

#### 15.2.1.1 tSoftI2C

**Definition:**

```
typedef struct
{
    void (*pfnIntCallback) (void);
    unsigned long ulSCLGPIO;
    unsigned long ulSDAGPIO;
    unsigned char ucFlags;
    unsigned char ucSlaveAddr;
    unsigned char ucData;
    unsigned char ucState;
    unsigned char ucCurrentBit;
    unsigned char ucIntMask;
    unsigned char ucIntStatus;
}
tSoftI2C
```

**Members:**

***pfnIntCallback*** The address of the callback function that is called to simulate the interrupts that would be produced by a hardware I2C implementation. This address can be set via a direct structure access or using the `SoftI2CCallbackSet` function.

***uiSCLGPIO*** The address of the GPIO pin to be used for the SCL signal. This member can be set via a direct structure access or using the `SoftI2CSCLGPIOSet` function.

***uiSDAGPIO*** The address of the GPIO pin to be used for the SDA signal. This member can be set via a direct structure access or using the `SoftI2CSDAGPIOSet` function.

***ucFlags*** The flags that control the operation of the SoftI2C module. This member should not be accessed or modified by the application.

***ucSlaveAddr*** The slave address that is currently being accessed. This member should not be accessed or modified by the application.

***ucData*** The data that is currently being transmitted or received. This member should not be accessed or modified by the application.

***ucState*** The current state of the SoftI2C state machine. This member should not be accessed or modified by the application.

***ucCurrentBit*** The number of bits that have been transmitted and received in the current frame. This member should not be accessed or modified by the application.

***ucIntMask*** The set of virtual interrupts that should be sent to the callback function. This member should not be accessed or modified by the application.

***ucIntStatus*** The set of virtual interrupts that are currently asserted. This member should not be accessed or modified by the application.

**Description:**

This structure contains the state of a single instance of a SoftI2C module.

## 15.2.2 Function Documentation

### 15.2.2.1 SoftI2CBusy

Indicates whether or not the SoftI2C module is busy.

**Prototype:**

```
tBoolean  
SoftI2CBusy(tSoftI2C *pI2C)
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

**Description:**

This function returns an indication of whether or not the SoftI2C module is busy transmitting or receiving data.

**Returns:**

Returns **true** if the SoftI2C module is busy; otherwise, returns **false**.

### 15.2.2.2 SoftI2CCallbackSet

Sets the callback used by the SoftI2C module.

**Prototype:**

```
void  
SoftI2CCallbackSet(tSoftI2C *pI2C,  
                  void (*pfnCallback)(void))
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

***pfnCallback*** is a pointer to the callback function.

**Description:**

This function sets the address of the callback function that is called when there is an “interrupt” produced by the SoftI2C module.

**Returns:**

None.

### 15.2.2.3 SoftI2CControl

Controls the state of the SoftI2C module.

**Prototype:**

```
void  
SoftI2CControl(tSoftI2C *pI2C,  
              unsigned long ulCmd)
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

***ulCmd*** command to be issued to the SoftI2C module.

**Description:**

This function is used to control the state of the SoftI2C module send and receive operations. The *ucCmd* parameter can be one of the following values:

- **SOFTI2C\_CMD\_SINGLE\_SEND**
- **SOFTI2C\_CMD\_SINGLE\_RECEIVE**
- **SOFTI2C\_CMD\_BURST\_SEND\_START**
- **SOFTI2C\_CMD\_BURST\_SEND\_CONT**
- **SOFTI2C\_CMD\_BURST\_SEND\_FINISH**
- **SOFTI2C\_CMD\_BURST\_SEND\_ERROR\_STOP**
- **SOFTI2C\_CMD\_BURST\_RECEIVE\_START**
- **SOFTI2C\_CMD\_BURST\_RECEIVE\_CONT**
- **SOFTI2C\_CMD\_BURST\_RECEIVE\_FINISH**
- **SOFTI2C\_CMD\_BURST\_RECEIVE\_ERROR\_STOP**

**Returns:**

None.

#### 15.2.2.4 SoftI2CDataGet

Receives a byte that has been sent to the SoftI2C module.

**Prototype:**

```
unsigned long  
SoftI2CDataGet (tSoftI2C *pI2C)
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

**Description:**

This function reads a byte of data from the SoftI2C module that was received as a result of an appropriate call to [SoftI2CControl\(\)](#).

**Returns:**

Returns the byte received by the SoftI2C module, cast as an unsigned long.

#### 15.2.2.5 SoftI2CDataPut

Transmits a byte from the SoftI2C module.

**Prototype:**

```
void  
SoftI2CDataPut (tSoftI2C *pI2C,  
                unsigned char ucData)
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

***ucData*** data to be transmitted from the SoftI2C module.

**Description:**

This function places the supplied data into SoftI2C module in preparation for being transmitted via an appropriate call to [SoftI2CControl\(\)](#).

**Returns:**

None.

#### 15.2.2.6 SoftI2CErr

Gets the error status of the SoftI2C module.

**Prototype:**

```
unsigned long  
SoftI2CErr (tSoftI2C *pI2C)
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

**Description:**

This function is used to obtain the error status of the SoftI2C module send and receive operations.

**Returns:**

Returns the error status, as one of **SOFTI2C\_ERR\_NONE**, **SOFTI2C\_ERR\_ADDR\_ACK**, or **SOFTI2C\_ERR\_DATA\_ACK**.

### 15.2.2.7 SoftI2CInit

Initializes the SoftI2C module.

**Prototype:**

```
void  
SoftI2CInit (tSoftI2C *pI2C)
```

**Parameters:**

**pI2C** specifies the SoftI2C data structure.

**Description:**

This function initializes operation of the SoftI2C module. After successful initialization of the SoftI2C module, the software I2C bus is in the idle state.

**Returns:**

None.

### 15.2.2.8 SoftI2CIntClear

Clears the SoftI2C “interrupt”.

**Prototype:**

```
void  
SoftI2CIntClear (tSoftI2C *pI2C)
```

**Parameters:**

**pI2C** specifies the SoftI2C data structure.

**Description:**

The SoftI2C “interrupt” source is cleared, so that it no longer asserts. This function must be called in the “interrupt” handler to keep it from being called again immediately on exit.

**Returns:**

None.

### 15.2.2.9 SoftI2CIntDisable

Disables the SoftI2C “interrupt”.

**Prototype:**

```
void  
SoftI2CIntDisable (tSoftI2C *pI2C)
```

**Parameters:**

**pI2C** specifies the SoftI2C data structure.



**Description:**

Disables the SoftI2C “interrupt” source.

**Returns:**

None.

#### 15.2.2.10 SoftI2CIntEnable

Enables the SoftI2C “interrupt”.

**Prototype:**

```
void  
SoftI2CIntEnable (tSoftI2C *pI2C)
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

**Description:**

Enables the SoftI2C “interrupt” source.

**Returns:**

None.

#### 15.2.2.11 SoftI2CIntStatus

Gets the current SoftI2C “interrupt” status.

**Prototype:**

```
tBoolean  
SoftI2CIntStatus (tSoftI2C *pI2C,  
                 tBoolean bMasked)
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

***bMasked*** is **false** if the raw “interrupt” status is requested and **true** if the masked “interrupt” status is requested.

**Description:**

This returns the “interrupt” status for the SoftI2C module. Either the raw “interrupt” status or the status of “interrupts” that are allowed to reflect to the processor can be returned.

**Returns:**

The current interrupt status, returned as **true** if active or **false** if not active.

#### 15.2.2.12 SoftI2CSCLogPIOSet

Sets the GPIO pin to be used as the SoftI2C SCL signal.

**Prototype:**

```
void  
SoftI2CSCLGPIOSet (tSoftI2C *pI2C,  
                   unsigned long ulBase,  
                   unsigned char ucPin)
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

***ulBase*** is the base address of the GPIO module.

***ucPin*** is the bit-packed representation of the pin to use.

**Description:**

This function sets the GPIO pin that is used for the SoftI2C SCL signal.

The pin is specified using a bit-packed byte, where bit 0 of the byte represents GPIO port pin 0, bit 1 represents GPIO port pin 1, and so on.

**Returns:**

None.

#### 15.2.2.13 SoftI2CSDAGPIOSet

Sets the GPIO pin to be used as the SoftI2C SDA signal.

**Prototype:**

```
void  
SoftI2CSDAGPIOSet (tSoftI2C *pI2C,  
                   unsigned long ulBase,  
                   unsigned char ucPin)
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

***ulBase*** is the base address of the GPIO module.

***ucPin*** is the bit-packed representation of the pin to use.

**Description:**

This function sets the GPIO pin that is used for the SoftI2C SDA signal.

The pin is specified using a bit-packed byte, where bit 0 of the byte represents GPIO port pin 0, bit 1 represents GPIO port pin 1, and so on.

**Returns:**

None.

#### 15.2.2.14 SoftI2CSlaveAddrSet

Sets the address that the SoftI2C module places on the bus.

**Prototype:**

```
void  
SoftI2CSlaveAddrSet (tSoftI2C *pI2C,
```

```
unsigned char ucSlaveAddr,  
tBoolean bReceive)
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

***ucSlaveAddr*** 7-bit slave address

***bReceive*** flag indicating the type of communication with the slave.

**Description:**

This function sets the address that the SoftI2C module places on the bus when initiating a transaction. When the *bReceive* parameter is set to **true**, the address indicates that the SoftI2C module is initiating a read from the slave; otherwise the address indicates that the SoftI2C module is initiating a write to the slave.

**Returns:**

None.

### 15.2.2.15 SoftI2CTimerTick

Performs the periodic update of the SoftI2C module.

**Prototype:**

```
void  
SoftI2CTimerTick(tSoftI2C *pI2C)
```

**Parameters:**

***pI2C*** specifies the SoftI2C data structure.

**Description:**

This function performs the periodic, time-based updates to the SoftI2C module. The transmission and reception of data over the SoftI2C link is performed by the state machine in this function.

This function must be called at four times the desired SoftI2C clock rate. For example, to run the SoftI2C clock at 10 KHz, this function must be called at a 40 KHz rate.

**Returns:**

None.

## 15.3 Programming Example

The following example shows how to configure the software I2C module and transmit some data to an external peripheral. This example uses Timer 0 as the timing source.

```
//  
// The instance data for the software I2C.  
//  
tSoftI2C g_sI2C;  
  
//  
// The timer tick function.
```

```
//
void
Timer0AIntHandler(void)
{
    //
    // Clear the timer interrupt.
    //
    TimerIntClear(TIMER0_BASE, TIMER_TIMA_TIMEOUT);

    //
    // Call the software I2C timer tick function.
    //
    SoftI2CTimerTick(&g_sI2C);
}

//
// The callback function for the software I2C. This function is equivalent
// to the interrupt handler for a hardware I2C.
//
void
I2CCallback(void)
{
    //
    // Clear the interrupt.
    //
    SoftI2CIntClear(&g_sI2C);

    //
    // Handle the interrupt.
    //
    ...
}

//
// Setup the software I2C and send some data.
//
void
TestSoftI2C(void)
{
    //
    // Clear the software I2C instance data.
    //
    memset(&g_sI2C, 0, sizeof(g_sI2C));

    //
    // Set the callback function used for this software I2C.
    //
    SoftI2CCallbackSet(&g_sI2C, I2CCallback);

    //
    // Configure the pins used for the software I2C. This example uses
    // pins PD0 and PE1.
    //
    SoftI2CSCLGPIOSet(&g_sI2C, GPIO_PORTD_BASE, GPIO_PIN_0);
    SoftI2CSDAGPIOSet(&g_sI2C, GPIO_PORTE_BASE, GPIO_PIN_1);

    //
    // Enable the GPIO modules that contains the GPIO pins to be used by
    // the software I2C.
    //
    SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOD);
    SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOE);

    //
    // Initialize the software I2C module.
    //
}
```

```

SoftI2CInit(&g_sI2C);

//
// Configure the timer used to generate the timing for the software
// I2C. The interface will be run at 10 KHz, requiring a timer tick
// at 40 KHz.
//
SysCtlPeripheralEnable(SYSCTL_PERIPH_TIMER0);
TimerConfigure(TIMER0_BASE, TIMER_CFG_32_BIT_PER);
TimerLoadSet(TIMER0_BASE, TIMER_A, SysCtlClockGet() / 40000);
TimerIntEnable(TIMER0_BASE, TIMER_TIMA_TIMEOUT);
IntEnable(INT_TIMER0A);
TimerEnable(TIMER0_BASE, TIMER_A);

//
// Enable the software I2C interrupt.
//
SoftI2CIntEnable(&g_sI2C);

//
// Send a single byte to the slave device.
//
SoftI2CSlaveAddrSet(&g_sI2C, 0x55, 0);
SoftI2CDataPut(&g_sI2C, 0xaa);
SoftI2CControl(&g_sI2C, SOFTI2C_CMD_SINGLE_SEND);

//
// Wait until the software I2C is idle. The completion interrupt will
// be sent to the callback function prior to exiting this loop.
//
while(SoftI2CBusy(&g_sI2C))
{
}
}

```

As a comparison, the following is the equivalent code using the hardware I2C module and the Stellaris Peripheral Driver Library.

```

//
// The interrupt handler for the hardware I2C.
//
void
I2C0IntHandler(void)
{
    //
    // Clear the asserted interrupt sources.
    //
    I2CMasterIntClear(I2C0_MASTER_BASE);

    //
    // Handle the interrupt.
    //
    ...
}

//
// Setup the hardware I2C and send some data.
//
void
TestI2C(void)
{
    //
    // Enable the GPIO module that contains the GPIO pins to be used by
    // the I2C, as well as the I2C module.
    //

```

```
SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOB);
SysCtlPeripheralEnable(SYSCTL_PERIPH_I2C0);

//
// Configure the GPIO pins for use by the I2C module.
//
GPIOPinTypeI2C(GPIO_PORTB_BASE, GPIO_PIN_2 | GPIO_PIN_3);

//
// Initialize the hardware I2C module.
//
I2CMasterInitExpClk(I2C0_MASTER_BASE, SysCtlClockGet(), false);

//
// Enable the hardware I2C.
//
I2CMasterEnable(I2C0_MASTER_BASE);

//
// Enable the interrupt in the hardware I2C.
//
I2CMasterIntEnable(I2C0_MASTER_BASE);
IntEnable(INT_I2C0);

//
// Write some data into the hardware I2C transmit FIFO.
//
I2CMasterSlaveAddrSet(I2C0_MASTER_BASE, 0x55, 0);
I2CMasterDataPut(I2C0_MASTER_BASE, 0xaa);
I2CMasterControl(I2C0_MASTER_BASE, I2C_MASTER_CMD_SINGLE_SEND);

//
// Wait until the hardware I2C is idle. The interrupt will be sent to
// the interrupt handler prior to exiting this loop.
//
while(I2CBusy(I2C0_MASTER_BASE))
{
}
```

## 16 Software SSI Module

Introduction .....	87
API Functions .....	88
Programming Example .....	100

### 16.1 Introduction

The software SSI module uses a timer and a few GPIO pins to create a slow-speed software SSI peripheral. Multiple software SSI modules can be in use simultaneously, limited only by the availability of resources (RAM for the per-instance data structure, pins for the interface, timers if unique clock rates are required, and processor cycles to execute the code). The software SSI module supports the Motorola® SPI™ formats with 4 to 16 data bits. A callback mechanism is used to simulate the interrupts that would be provided by a hardware SSI module.

The API for the software SSI module has been constructed to be as close as possible to the API provided in the Stellaris Peripheral Driver Library for the hardware SSI module. The two notable difference are the function prefix being “SoftSSI” instead of “SSI”, and the first argument of each API is a pointer to the [tSoftSSI](#) data structure instead of the base address of the hardware module.

Timing for the software SSI module is provided by the application. The [SoftSSITimerTick\(\)](#) function must be called on a periodic basis to provide the timing for the software SSI module. The timer tick function must be called at twice the desired SSI clock rate; for example, to operate the software SSI interface at 10 KHz, the tick function must be called at a 20 KHz rate. By having the application providing the timing, the timer resource to be used is flexible and multiple software SSI modules can be driven from a single timer resource. Alternatively, if the software SSI module is only needed for brief periods of time and processor usage is not a concern, the timer tick function can simply be called in a loop until the entire SSI transaction has completed (maximizing both SSI clock speed and processor usage, but not requiring a timer).

The software SSI module requires a few as two and as many as four GPIO pins. The following table shows the possible pin usages for the software SSI module:

Fss	Clk	Tx	Rx	Pins	Description
	yes	yes		2	transmit only
yes	yes	yes		3	
	yes		yes	2	receive only
yes	yes		yes	3	
	yes	yes	yes	3	transmit and receive
yes	yes	yes	yes	4	

For the cases where Fss is not used, it is up to the application to control that signal (either via a separately-controlled GPIO, or by being tied to ground in the hardware).

The per-instance data structure is approximately 52 bytes in length (the actual length will depend upon how the structure is packed by the compiler in use).

As a point of reference, the following are some rough measurements of the processor usage of the software SSI module at various SSI clock speeds with the processor running at 50 MHz. Actual processor usage may vary, depending upon how the application uses the software SSI module, processor clock speed, interrupt priority, and compiler in use.

SSI Clock	% Of Processor	Million Cycles Per Second
10 KHz	5.26	2.63
20 KHz	10.48	5.24
30 KHz	15.68	7.84
40 KHz	20.90	10.45
50 KHz	26.10	13.05
60 KHz	31.38	15.69
70 KHz	36.54	18.27
80 KHz	41.79	20.89
90 KHz	47.06	23.53
100 KHz	52.17	26.08

This module is contained in `utils/softssi.c`, with `utils/softssi.h` containing the API definitions for use by applications.

## 16.2 API Functions

### Data Structures

- [tSoftSSI](#)

### Functions

- `tBoolean` [SoftSSIBusy](#) (`tSoftSSI *pSSI`)
- `void` [SoftSSICallbackSet](#) (`tSoftSSI *pSSI`, `void (*pfnCallback)(void)`)
- `void` [SoftSSIClkGPIOSet](#) (`tSoftSSI *pSSI`, `unsigned long ulBase`, `unsigned char ucPin`)
- `void` [SoftSSIConfigSet](#) (`tSoftSSI *pSSI`, `unsigned char ucProtocol`, `unsigned char ucBits`)
- `tBoolean` [SoftSSIDataAvail](#) (`tSoftSSI *pSSI`)
- `void` [SoftSSIDataGet](#) (`tSoftSSI *pSSI`, `unsigned long *pulData`)
- `long` [SoftSSIDataGetNonBlocking](#) (`tSoftSSI *pSSI`, `unsigned long *pulData`)
- `void` [SoftSSIDataPut](#) (`tSoftSSI *pSSI`, `unsigned long ulData`)
- `long` [SoftSSIDataPutNonBlocking](#) (`tSoftSSI *pSSI`, `unsigned long ulData`)
- `void` [SoftSSIDisable](#) (`tSoftSSI *pSSI`)
- `void` [SoftSSIEnable](#) (`tSoftSSI *pSSI`)
- `void` [SoftSSIFssGPIOSet](#) (`tSoftSSI *pSSI`, `unsigned long ulBase`, `unsigned char ucPin`)
- `void` [SoftSSIIntClear](#) (`tSoftSSI *pSSI`, `unsigned long ulIntFlags`)
- `void` [SoftSSIIntDisable](#) (`tSoftSSI *pSSI`, `unsigned long ulIntFlags`)
- `void` [SoftSSIIntEnable](#) (`tSoftSSI *pSSI`, `unsigned long ulIntFlags`)
- `unsigned long` [SoftSSIIntStatus](#) (`tSoftSSI *pSSI`, `tBoolean bMasked`)
- `void` [SoftSSIRxBufferSet](#) (`tSoftSSI *pSSI`, `unsigned short *pusRxBuffer`, `unsigned short usLen`)
- `void` [SoftSSIRxGPIOSet](#) (`tSoftSSI *pSSI`, `unsigned long ulBase`, `unsigned char ucPin`)
- `tBoolean` [SoftSSISpaceAvail](#) (`tSoftSSI *pSSI`)
- `void` [SoftSSITimerTick](#) (`tSoftSSI *pSSI`)
- `void` [SoftSSITxBufferSet](#) (`tSoftSSI *pSSI`, `unsigned short *pusTxBuffer`, `unsigned short usLen`)
- `void` [SoftSSITxGPIOSet](#) (`tSoftSSI *pSSI`, `unsigned long ulBase`, `unsigned char ucPin`)



## 16.2.1 Data Structure Documentation

### 16.2.1.1 tSoftSSI

**Definition:**

```
typedef struct
{
    void (*pfnIntCallback)(void);
    unsigned long ulFssGPIO;
    unsigned long ulClkGPIO;
    unsigned long ulTxGPIO;
    unsigned long ulRxGPIO;
    unsigned short *pusTxBuffer;
    unsigned short *pusRxBuffer;
    unsigned short usTxBufferLen;
    unsigned short usTxBufferRead;
    unsigned short usTxBufferWrite;
    unsigned short usRxBufferLen;
    unsigned short usRxBufferRead;
    unsigned short usRxBufferWrite;
    unsigned short usTxData;
    unsigned short usRxData;
    unsigned char ucFlags;
    unsigned char ucBits;
    unsigned char ucState;
    unsigned char ucCurrentBit;
    unsigned char ucIntMask;
    unsigned char ucIntStatus;
    unsigned char ucIdleCount;
}
tSoftSSI
```

**Members:**

***pfnIntCallback*** The address of the callback function that is called to simulate the interrupts that would be produced by a hardware SSI implementation. This address can be set via a direct structure access or using the SoftSSICallbackSet function.

***ulFssGPIO*** The address of the GPIO pin to be used for the Fss signal. If this member is zero, the Fss signal is not generated. This member can be set via a direct structure access or using the SoftSSIFssGPIOSet function.

***ulClkGPIO*** The address of the GPIO pin to be used for the Clk signal. This member can be set via a direct structure access or using the SoftSSIClkGPIOSet function.

***ulTxGPIO*** The address of the GPIO pin to be used for the Tx signal. This member can be set via a direct structure access or using the SoftSSITxGPIOSet function.

***ulRxGPIO*** The address of the GPIO pin to be used for the Rx signal. If this member is zero, the Rx signal is not read. This member can be set via a direct structure access or using the SoftSSIRxGPIOSet function.

***pusTxBuffer*** The address of the data buffer used for the transmit FIFO. This member can be set via a direct structure access or using the SoftSSITxBufferSet function.

***pusRxBuffer*** The address of the data buffer used for the receive FIFO. This member can be set via a direct structure access or using the SoftSSIRxBufferSet function.

***usTxBufferLen*** The length of the transmit FIFO. This member can be set via a direct structure access or using the SoftSSITxBufferSet function.

- usTxBufferRead** The index into the transmit FIFO of the next word to be transmitted. This member should be initialized to zero, but should not be accessed or modified by the application.
- usTxBufferWrite** The index into the transmit FIFO of the next location to store data into the FIFO. This member should be initialized to zero, but should not be accessed or modified by the application.
- usRxBufferLen** The length of the receive FIFO. This member can be set via a direct structure access or using the `SoftSSIRxBufferSet` function.
- usRxBufferRead** The index into the receive FIFO of the next word to be read from the FIFO. This member should be initialized to zero, but should not be accessed or modified by the application.
- usRxBufferWrite** The index into the receive FIFO of the location to store the next word received. This member should be initialized to zero, but should not be accessed or modified by the application.
- usTxData** The word that is currently being transmitted. This member should not be accessed or modified by the application.
- usRxData** The word that is currently being received. This member should not be accessed or modified by the application.
- ucFlags** The flags that control the operation of the SoftSSI module. This member should not be accessed or modified by the application.
- ucBits** The number of data bits in each SoftSSI frame, which also specifies the width of each data item in the transmit and receive FIFOs. This member can be set via a direct structure access or using the `SoftSSIConfigSet` function.
- ucState** The current state of the SoftSSI state machine. This member should not be accessed or modified by the application.
- ucCurrentBit** The number of bits that have been transmitted and received in the current frame. This member should not be accessed or modified by the application.
- ucIntMask** The set of virtual interrupts that should be sent to the callback function. This member should not be accessed or modified by the application.
- ucIntStatus** The set of virtual interrupts that are currently asserted. This member should not be accessed or modified by the application.
- ucIdleCount** The number of tick counts that the SoftSSI module has been idle with data stored in the receive FIFO, which is used to generate the receive timeout interrupt. This member should not be accessed or modified by the application.

**Description:**

This structure contains the state of a single instance of a SoftSSI module.

## 16.2.2 Function Documentation

### 16.2.2.1 SoftSSIBusy

Determines whether the SoftSSI transmitter is busy or not.

**Prototype:**

```
tBoolean  
SoftSSIBusy(tSoftSSI *pSSI)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**Description:**

Allows the caller to determine whether all transmitted bytes have cleared the transmitter. If **false** is returned, then the transmit FIFO is empty and all bits of the last transmitted word have left the shift register.

**Returns:**

Returns **true** if the SoftSSI is transmitting or **false** if all transmissions are complete.

### 16.2.2.2 SoftSSICallbackSet

Sets the callback used by the SoftSSI module.

**Prototype:**

```
void  
SoftSSICallbackSet (tSoftSSI *pSSI,  
                   void (*pfnCallback) (void))
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**pfnCallback** is a pointer to the callback function.

**Description:**

This function sets the address of the callback function that is called when there is an “interrupt” produced by the SoftSSI module.

**Returns:**

None.

### 16.2.2.3 SoftSSIClkGPIOSet

Sets the GPIO pin to be used as the SoftSSI Clk signal.

**Prototype:**

```
void  
SoftSSIClkGPIOSet (tSoftSSI *pSSI,  
                  unsigned long ulBase,  
                  unsigned char ucPin)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**ulBase** is the base address of the GPIO module.

**ucPin** is the bit-packed representation of the pin to use.

**Description:**

This function sets the GPIO pin that is used for the SoftSSI Clk signal.

The pin is specified using a bit-packed byte, where bit 0 of the byte represents GPIO port pin 0, bit 1 represents GPIO port pin 1, and so on.

**Returns:**

None.

#### 16.2.2.4 SoftSSISetConfig

Sets the configuration of a SoftSSI module.

**Prototype:**

```
void  
SoftSSISetConfig(tSoftSSI *pSSI,  
                 unsigned char ucProtocol,  
                 unsigned char ucBits)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**ucProtocol** specifies the data transfer protocol.

**ucBits** specifies the number of bits transferred per frame.

**Description:**

This function configures the data format of a SoftSSI module. The *ucProtocol* parameter can be one of the following values: **SOFTSSI\_FRF\_MOTO\_MODE\_0**, **SOFTSSI\_FRF\_MOTO\_MODE\_1**, **SOFTSSI\_FRF\_MOTO\_MODE\_2**, or **SOFTSSI\_FRF\_MOTO\_MODE\_3**. These frame formats imply the following polarity and phase configurations:

Polarity	Phase	Mode
0	0	SOFTSSI_FRF_MOTO_MODE_0
0	1	SOFTSSI_FRF_MOTO_MODE_1
1	0	SOFTSSI_FRF_MOTO_MODE_2
1	1	SOFTSSI_FRF_MOTO_MODE_3

The *ucBits* parameter defines the width of the data transfers, and can be a value between 4 and 16, inclusive.

**Returns:**

None.

#### 16.2.2.5 SoftSSIDataAvail

Determines if there is any data in the receive FIFO.

**Prototype:**

```
tBoolean  
SoftSSIDataAvail(tSoftSSI *pSSI)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**Description:**

This function determines if there is any data available to be read from the receive FIFO.

**Returns:**

Returns **true** if there is data in the receive FIFO or **false** if there is no data in the receive FIFO.

### 16.2.2.6 SoftSSIDataGet

Gets a data element from the SoftSSI receive FIFO.

**Prototype:**

```
void  
SoftSSIDataGet (tSoftSSI *pSSI,  
                unsigned long *pulData)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**pulData** is a pointer to a storage location for data that was received over the SoftSSI interface.

**Description:**

This function gets received data from the receive FIFO of the specified SoftSSI module and places that data into the location specified by the *pulData* parameter.

**Note:**

Only the lower N bits of the value written to *pulData* contain valid data, where N is the data width as configured by [SoftSSIConfigSet\(\)](#). For example, if the interface is configured for 8-bit data width, only the lower 8 bits of the value written to *pulData* contain valid data.

**Returns:**

None.

### 16.2.2.7 SoftSSIDataGetNonBlocking

Gets a data element from the SoftSSI receive FIFO.

**Prototype:**

```
long  
SoftSSIDataGetNonBlocking (tSoftSSI *pSSI,  
                            unsigned long *pulData)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**pulData** is a pointer to a storage location for data that was received over the SoftSSI interface.

**Description:**

This function gets received data from the receive FIFO of the specified SoftSSI module and places that data into the location specified by the *ulData* parameter. If there is no data in the FIFO, then this function returns a zero.

**Note:**

Only the lower N bits of the value written to *pulData* contain valid data, where N is the data width as configured by [SoftSSIConfigSet\(\)](#). For example, if the interface is configured for 8-bit data width, only the lower 8 bits of the value written to *pulData* contain valid data.

**Returns:**

Returns the number of elements read from the SoftSSI receive FIFO.

### 16.2.2.8 SoftSSIDataPut

Puts a data element into the SoftSSI transmit FIFO.

**Prototype:**

```
void  
SoftSSIDataPut (tSoftSSI *pSSI,  
               unsigned long ulData)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**ulData** is the data to be transmitted over the SoftSSI interface.

**Description:**

This function places the supplied data into the transmit FIFO of the specified SoftSSI module.

**Note:**

The upper 32 - N bits of the *ulData* are discarded, where N is the data width as configured by [SoftSSIConfigSet\(\)](#). For example, if the interface is configured for 8-bit data width, the upper 24 bits of *ulData* are discarded.

**Returns:**

None.

### 16.2.2.9 SoftSSIDataPutNonBlocking

Puts a data element into the SoftSSI transmit FIFO.

**Prototype:**

```
long  
SoftSSIDataPutNonBlocking (tSoftSSI *pSSI,  
                           unsigned long ulData)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**ulData** is the data to be transmitted over the SoftSSI interface.

**Description:**

This function places the supplied data into the transmit FIFO of the specified SoftSSI module. If there is no space in the FIFO, then this function returns a zero.

**Note:**

The upper 32 - N bits of the *ulData* are discarded, where N is the data width as configured by [SoftSSIConfigSet\(\)](#). For example, if the interface is configured for 8-bit data width, the upper 24 bits of *ulData* are discarded.

**Returns:**

Returns the number of elements written to the SSI transmit FIFO.

### 16.2.2.10 SoftSSIDisable

Disables the SoftSSI module.

**Prototype:**

```
void  
SoftSSIDisable (tSoftSSI *pSSI)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**Description:**

This function disables operation of the SoftSSI module. If a data transfer is in progress, it is finished before the module is fully disabled.

**Returns:**

None.

### 16.2.2.11 SoftSSIEnable

Enables the SoftSSI module.

**Prototype:**

```
void  
SoftSSIEnable (tSoftSSI *pSSI)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**Description:**

This function enables operation of the SoftSSI module. The SoftSSI module must be configured before it is enabled.

**Returns:**

None.

### 16.2.2.12 SoftSSIFssGPIOSet

Sets the GPIO pin to be used as the SoftSSI Fss signal.

**Prototype:**

```
void  
SoftSSIFssGPIOSet (tSoftSSI *pSSI,  
                   unsigned long ulBase,  
                   unsigned char ucPin)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**ulBase** is the base address of the GPIO module.

**ucPin** is the bit-packed representation of the pin to use.

**Description:**

This function sets the GPIO pin that is used for the SoftSSI Fss signal. If there is not a GPIO pin allocated for Fss, the SoftSSI module does not assert/deassert the Fss signal, leaving it to the application either to do manually or to not do at all if the slave device has Fss tied to ground.

The pin is specified using a bit-packed byte, where bit 0 of the byte represents GPIO port pin 0, bit 1 represents GPIO port pin 1, and so on.

**Returns:**

None.

### 16.2.2.13 SoftSSIIntClear

Clears SoftSSI “interrupt” sources.

**Prototype:**

```
void  
SoftSSIIntClear(tSoftSSI *pSSI,  
               unsigned long ulIntFlags)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**ulIntFlags** is a bit mask of the “interrupt” sources to be cleared.

**Description:**

The specified SoftSSI “interrupt” sources are cleared so that they no longer assert. This function must be called in the “interrupt” handler to keep the “interrupt” from being recognized again immediately upon exit. The *ulIntFlags* parameter is the logical OR of any of the **SOFTSSI\_TXEOT**, **SOFTSSI\_RXTO**, and **SOFTSSI\_RXOR** values.

**Returns:**

None.

### 16.2.2.14 SoftSSIIntDisable

Disables individual SoftSSI “interrupt” sources.

**Prototype:**

```
void  
SoftSSIIntDisable(tSoftSSI *pSSI,  
                 unsigned long ulIntFlags)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**ulIntFlags** is a bit mask of the “interrupt” sources to be disabled.

**Description:**

Disables the indicated SoftSSI “interrupt” sources. The *ulIntFlags* parameter can be any of the **SOFTSSI\_TXEOT**, **SOFTSSI\_TXFF**, **SOFTSSI\_RXFF**, **SOFTSSI\_RXTO**, or **SOFTSSI\_RXOR** values.



**Returns:**

None.

### 16.2.2.15 SoftSSIIntEnable

Enables individual SoftSSI “interrupt” sources.

**Prototype:**

```
void  
SoftSSIIntEnable(tSoftSSI *pSSI,  
                unsigned long ulIntFlags)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**ulIntFlags** is a bit mask of the “interrupt” sources to be enabled.

**Description:**

Enables the indicated SoftSSI “interrupt” sources. Only the sources that are enabled can be reflected to the callback function; disabled sources do not result in a callback. The *ulIntFlags* parameter can be any of the **SOFTSSI\_TXEOT**, **SOFTSSI\_TXFF**, **SOFTSSI\_RXFF**, **SOFTSSI\_RXTO**, or **SOFTSSI\_RXOR** values.

**Returns:**

None.

### 16.2.2.16 SoftSSIIntStatus

Gets the current “interrupt” status.

**Prototype:**

```
unsigned long  
SoftSSIIntStatus(tSoftSSI *pSSI,  
                tBoolean bMasked)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**bMasked** is **false** if the raw “interrupt” status is required or **true** if the masked “interrupt” status is required.

**Description:**

This function returns the “interrupt” status for the SoftSSI module. Either the raw “interrupt” status or the status of “interrupts” that are allowed to reflect to the callback can be returned.

**Returns:**

The current “interrupt” status, enumerated as a bit field of **SOFTSSI\_TXEOT**, **SOFTSSI\_TXFF**, **SOFTSSI\_RXFF**, **SOFTSSI\_RXTO**, and **SOFTSSI\_RXOR**.

### 16.2.2.17 SoftSSIRxBufferSet

Sets the receive FIFO buffer for a SoftSSI module.

**Prototype:**

```
void  
SoftSSIRxBufferSet (tSoftSSI *pSSI,  
                    unsigned short *pusRxBuffer,  
                    unsigned short usLen)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**pusRxBuffer** is the address of the receive FIFO buffer.

**usLen** is the size, in 16-bit half-words, of the receive FIFO buffer.

**Description:**

This function sets the address and size of the receive FIFO buffer and also resets the read and write pointers, marking the receive FIFO as empty. When the buffer pointer and length are configured as zero, all data received from the slave device is discarded. This capability is useful when there is no GPIO pin allocated for the Rx signal.

**Returns:**

None.

### 16.2.2.18 SoftSSIRxGPIOSet

Sets the GPIO pin to be used as the SoftSSI Rx signal.

**Prototype:**

```
void  
SoftSSIRxGPIOSet (tSoftSSI *pSSI,  
                  unsigned long ulBase,  
                  unsigned char ucPin)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**ulBase** is the base address of the GPIO module.

**ucPin** is the bit-packed representation of the pin to use.

**Description:**

This function sets the GPIO pin that is used for the SoftSSI Rx signal. If there is not a GPIO pin allocated for Rx, the SoftSSI module does not read data from the slave device.

The pin is specified using a bit-packed byte, where bit 0 of the byte represents GPIO port pin 0, bit 1 represents GPIO port pin 1, and so on.

**Returns:**

None.

### 16.2.2.19 SoftSSISpaceAvail

Determines if there is any space in the transmit FIFO.

**Prototype:**

```
tBoolean  
SoftSSISpaceAvail (tSoftSSI *pSSI)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**Description:**

This function determines if there is space available in the transmit FIFO.

**Returns:**

Returns **true** if there is space available in the transmit FIFO or **false** if there is no space available in the transmit FIFO.

### 16.2.2.20 SoftSSITimerTick

Performs the periodic update of the SoftSSI module.

**Prototype:**

```
void  
SoftSSITimerTick (tSoftSSI *pSSI)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

**Description:**

This function performs the periodic, time-based updates to the SoftSSI module. The transmission and reception of data over the SoftSSI link is performed by the state machine in this function.

This function must be called at twice the desired SoftSSI clock rate. For example, to run the SoftSSI clock at 10 KHz, this function must be called at a 20 KHz rate.

**Returns:**

None.

### 16.2.2.21 SoftSSITxBufferSet

Sets the transmit FIFO buffer for a SoftSSI module.

**Prototype:**

```
void  
SoftSSITxBufferSet (tSoftSSI *pSSI,  
                    unsigned short *pusTxBuffer,  
                    unsigned short usLen)
```

**Parameters:**

**pSSI** specifies the SoftSSI data structure.

***pusTxBuffer*** is the address of the transmit FIFO buffer.

***usLen*** is the size, in 16-bit half-words, of the transmit FIFO buffer.

**Description:**

This function sets the address and size of the transmit FIFO buffer and also resets the read and write pointers, marking the transmit FIFO as empty.

**Returns:**

None.

### 16.2.2.22 SoftSSITxGPIOSet

Sets the GPIO pin to be used as the SoftSSI Tx signal.

**Prototype:**

```
void  
SoftSSITxGPIOSet (tSoftSSI *pSSI,  
                  unsigned long ulBase,  
                  unsigned char ucPin)
```

**Parameters:**

***pSSI*** specifies the SoftSSI data structure.

***ulBase*** is the base address of the GPIO module.

***ucPin*** is the bit-packed representation of the pin to use.

**Description:**

This function sets the GPIO pin that is used for the SoftSSI Tx signal.

The pin is specified using a bit-packed byte, where bit 0 of the byte represents GPIO port pin 0, bit 1 represents GPIO port pin 1, and so on.

**Returns:**

None.

## 16.3 Programming Example

The following example shows how to configure the software SSI module and transmit some data to an external peripheral. This example uses Timer 0 as the timing source.

```
//  
// The instance data for the software SSI.  
//  
tSoftSSI g_sSSI;  
  
//  
// The buffer used to hold the transmit data.  
//  
unsigned short g_pusTxBuffer[8];  
  
//  
// The timer tick function.  
//
```

```
void
Timer0AIntHandler(void)
{
    //
    // Clear the timer interrupt.
    //
    TimerIntClear(TIMER0_BASE, TIMER_TIMA_TIMEOUT);

    //
    // Call the software SSI timer tick function.
    //
    SoftSSITimerTick(&g_sSSI);
}

//
// The callback function for the software SSI. This function is equivalent
// to the interrupt handler for a hardware SSI.
//
void
SSICallback(void)
{
    unsigned long ulInts;

    //
    // Read the asserted interrupt sources.
    //
    ulInts = SoftSSIIntStatus(&g_sSSI, true);

    //
    // Clear the asserted interrupt sources.
    //
    SoftSSIIntClear(&g_sSSI, ulInts);

    //
    // Handle the asserted interrupts.
    //
    ...
}

//
// Setup the software SSI and send some data.
//
void
TestSoftSSI(void)
{
    //
    // Clear the software SSI instance data.
    //
    memset(&g_sSSI, 0, sizeof(g_sSSI));

    //
    // Set the callback function used for this software SSI.
    //
    SoftSSICallbackSet(&g_sSSI, SSICallback);

    //
    // Configure the pins used for the software SSI. This example uses
    // pins PD0, PE1, and PF2.
    //
    SoftSSIFssGPIOSet(&g_sSSI, GPIO_PORTD_BASE, GPIO_PIN_0);
    SoftSSIClkGPIOSet(&g_sSSI, GPIO_PORTE_BASE, GPIO_PIN_1);
    SoftSSITxGPIOSet(&g_sSSI, GPIO_PORTF_BASE, GPIO_PIN_2);

    //
    // Configure the data buffer used as the transmit FIFO.
    //
}
```

```
SoftSSITxBufferSet(&g_sSSI, g_pusTxBuffer, 8);

//
// Enable the GPIO modules that contains the GPIO pins to be used by
// the software SSI.
//
SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOD);
SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOE);
SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);

//
// Initialize the software SSI module, using mode 3 and 8 data bits.
//
SoftSSIConfigSet(&g_sSSI, SOFTSSI_FRF_MOTO_MODE_3, 8);

//
// Enable the software SSI.
//
SoftSSIEnable(&g_sSSI);

//
// Configure the timer used to generate the timing for the software
// SSI. The interface will be run at 10 KHz, requiring a timer tick
// at 20 KHz.
//
SysCtlPeripheralEnable(SYSCTL_PERIPH_TIMER0);
TimerConfigure(TIMER0_BASE, TIMER_CFG_32_BIT_PER);
TimerLoadSet(TIMER0_BASE, TIMER_A, SysCtlClockGet() / 20000);
TimerIntEnable(TIMER0_BASE, TIMER_TIMA_TIMEOUT);
IntEnable(INT_TIMER0A);
TimerEnable(TIMER0_BASE, TIMER_A);

//
// Enable the transmit FIFO half full interrupt in the software SSI.
//
SoftSSIIntEnable(&g_sSSI, SOFTSSI_TXFF);

//
// Write some data into the software SSI transmit FIFO.
//
SoftSSIDataPut(&g_sSSI, 0x55);
SoftSSIDataPut(&g_sSSI, 0xaa);
SoftSSIDataPut(&g_sSSI, 0x55);
SoftSSIDataPut(&g_sSSI, 0xaa);
SoftSSIDataPut(&g_sSSI, 0x55);
SoftSSIDataPut(&g_sSSI, 0xaa);

//
// Wait until the software SSI is idle. The transmit FIFO half full
// interrupt will be sent to the callback function prior to exiting
// this loop.
//
while(SoftSSIBusy(&g_sSSI))
{
}
}
```

As a comparison, the following is the equivalent code using the hardware SSI module and the Stellaris Peripheral Driver Library.

```
//
// The interrupt handler for the hardware SSI.
//
void
SSI0IntHandler(void)
```

```
{
    unsigned long ulInts;

    //
    // Read the asserted interrupt sources.
    //
    ulInts = SSIIntStatus(SSIO_BASE, true);

    //
    // Clear the asserted interrupt sources.
    //
    SSIIntClear(SSIO_BASE, ulInts);

    //
    // Handle the asserted interrupts.
    //
    ...
}

//
// Setup the hardware SSI and send some data.
//
void
TestSSI(void)
{
    //
    // Enable the GPIO module that contains the GPIO pins to be used by
    // the SSI, as well as the SSI module.
    //
    SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOA);
    SysCtlPeripheralEnable(SYSCTL_PERIPH_SSI0);

    //
    // Configure the GPIO pins for use by the SSI module.
    //
    GPIOPinTypeSSI(GPIO_PORTA_BASE, (GPIO_PIN_2 | GPIO_PIN_3 |
                                     GPIO_PIN_4 | GPIO_PIN_5));

    //
    // Initialize the hardware SSI module, using mode 3 and 8 data bits.
    //
    SSIConfigSetExpClk(SSIO_BASE, SysCtlClockGet(), SSI_FRF_MOTO_MODE_3,
                      SSI_MODE_MASTER, 10000, 8);

    //
    // Enable the hardware SSI.
    //
    SSIEnable(SSIO_BASE);

    //
    // Enable the transmit FIFO half full interrupt in the hardware SSI.
    //
    SSIIntEnable(SSIO_BASE, SSI_TXFF);
    IntEnable(INT_SSI0);

    //
    // Write some data into the hardware SSI transmit FIFO.
    //
    SSIDataPut(SSIO_BASE, 0x55);
    SSIDataPut(SSIO_BASE, 0xaa);
    SSIDataPut(SSIO_BASE, 0x55);
    SSIDataPut(SSIO_BASE, 0xaa);
    SSIDataPut(SSIO_BASE, 0x55);
    SSIDataPut(SSIO_BASE, 0xaa);

    //

```

```
// Wait until the hardware SSI is idle. The transmit FIFO half full
// interrupt will be sent to the interrupt handler prior to exiting
// this loop.
//
while(SSIBusy(SSIO_BASE))
{
}
```



## 17 Software UART Module

Introduction .....	105
API Functions .....	106
Programming Example .....	122

### 17.1 Introduction

The software UART module uses two timers and a two GPIO pins to create a software UART peripheral. Multiple software UART modules can be in use simultaneously, limited only by the availability of resources (RAM for the per-instance data structure, pins for the interface, timers, and processor cycles to execute the code). The software UART module supports five through eight data bits, a variety of parity modes (odd, even, one, zero, and none), and one or two stop bits. A callback mechanism is used to simulate the interrupts that would be provided by a hardware UART module.

The API for the software UART module has been constructed to be as close as possible to the API provided in the Stellaris Peripheral Driver Library for the hardware UART module. The two notable difference are the function prefix being “SoftUART” instead of “UART”, and the first argument of each API is a pointer to the [tSoftUART](#) data structure instead of the base address of the hardware module.

The software UART transmitter and receiver are handled independently (because of the asynchronous nature of the two). As a result, there are separate timers for each, and if only one is required then the other does not need to be utilized.

Timing for the software UART transmitter is provided by the application. The [SoftUARTTx-TimerTick\(\)](#) function must be called on a periodic basis to provide the timing for the software UART transmitter. The timer tick function must be called at the desired UART baud rate; for example, to operate the software UART transmitter at 38,400 baud, the tick function must be called at a 38,400 Hz rate. Because the application provides the timing, the timer resource can be flexible and multiple software UART transmitters can be driven from a single timer resource.

Timing for the software UART receiver is also provided by the application. Initially, the Rx pin is configured by the software UART module for a GPIO edge interrupt. The GPIO edge interrupt handler must be provided by the application (so that it can be shared with other possible GPIO interrupts on that port). When the interrupt occurs, a timer must be started at the desired baud rate (i.e. for 38,400 baud, it must run at 38,400 Hz) and the [SoftUARTRxTick\(\)](#) function must be called. Then, whenever the timer interrupt occurs, the [SoftUARTRxTick\(\)](#) function must be called. The timer is disabled whenever [SoftUARTRxTick\(\)](#) indicates that it is no longer needed. Because the application provides the timing, the timer resource can be flexible. However, each software UART receiver must have its own timer resource.

The software UART module requires one or two GPIO pins. The following table shows the possible pin usages for the software UART module:

Tx	Rx	Pins	Description
yes		1	transmit only
	yes	1	receive only
yes	yes	2	transmit and receive

The per-instance data structure is approximately 52 bytes in length (the actual length depends on how the structure is packed by the compiler in use).

The following table shows some approximate measurements of the processor usage of the software UART module at various baud rates with the processor running at 50 MHz. Actual processor usage may vary, depending on how the application uses the software UART module, processor clock speed, interrupt priority, and compiler in use.

UART Baud Rate	% Of Processor	Million Cycles Per Second
9600	5.32	2.66
14400	7.99	3.99
19200	10.65	5.32
28800	15.96	7.98
38400	21.28	10.64
57600	32.00	16.00
115200	64.04	32.02

This module is contained in `utils/softuart.c`, with `utils/softuart.h` containing the API definitions for use by applications.

## 17.2 API Functions

### Data Structures

- [tSoftUART](#)

### Functions

- void [SoftUARTBreakCtl](#) ([tSoftUART](#) \*pUART, tBoolean bBreakState)
- tBoolean [SoftUARTBusy](#) ([tSoftUART](#) \*pUART)
- void [SoftUARTCallbackSet](#) ([tSoftUART](#) \*pUART, void (\*pfnCallback)(void))
- long [SoftUARTCharGet](#) ([tSoftUART](#) \*pUART)
- long [SoftUARTCharGetNonBlocking](#) ([tSoftUART](#) \*pUART)
- void [SoftUARTCharPut](#) ([tSoftUART](#) \*pUART, unsigned char ucData)
- tBoolean [SoftUARTCharPutNonBlocking](#) ([tSoftUART](#) \*pUART, unsigned char ucData)
- tBoolean [SoftUARTCharsAvail](#) ([tSoftUART](#) \*pUART)
- void [SoftUARTConfigGet](#) ([tSoftUART](#) \*pUART, unsigned long \*pulConfig)
- void [SoftUARTConfigSet](#) ([tSoftUART](#) \*pUART, unsigned long ulConfig)
- void [SoftUARTDisable](#) ([tSoftUART](#) \*pUART)
- void [SoftUARTEnable](#) ([tSoftUART](#) \*pUART)
- void [SoftUARTFIFOLevelGet](#) ([tSoftUART](#) \*pUART, unsigned long \*pulTxLevel, unsigned long \*pulRxLevel)
- void [SoftUARTFIFOLevelSet](#) ([tSoftUART](#) \*pUART, unsigned long ulTxLevel, unsigned long ulRxLevel)
- void [SoftUARTInit](#) ([tSoftUART](#) \*pUART)
- void [SoftUARTIntClear](#) ([tSoftUART](#) \*pUART, unsigned long ulIntFlags)
- void [SoftUARTIntDisable](#) ([tSoftUART](#) \*pUART, unsigned long ulIntFlags)
- void [SoftUARTIntEnable](#) ([tSoftUART](#) \*pUART, unsigned long ulIntFlags)

- unsigned long [SoftUARTIntStatus](#) (tSoftUART \*pUART, tBoolean bMasked)
- unsigned long [SoftUARTParityModeGet](#) (tSoftUART \*pUART)
- void [SoftUARTParityModeSet](#) (tSoftUART \*pUART, unsigned long ulParity)
- void [SoftUARTRxBufferSet](#) (tSoftUART \*pUART, unsigned short \*pusRxBuffer, unsigned short usLen)
- void [SoftUARTRxErrorClear](#) (tSoftUART \*pUART)
- unsigned long [SoftUARTRxErrorGet](#) (tSoftUART \*pUART)
- void [SoftUARTRxGPIOSet](#) (tSoftUART \*pUART, unsigned long ulBase, unsigned char ucPin)
- unsigned long [SoftUARTRxTick](#) (tSoftUART \*pUART, tBoolean bEdgeInt)
- tBoolean [SoftUARTSpaceAvail](#) (tSoftUART \*pUART)
- void [SoftUARTTxBufferSet](#) (tSoftUART \*pUART, unsigned char \*pucTxBuffer, unsigned short usLen)
- void [SoftUARTTxGPIOSet](#) (tSoftUART \*pUART, unsigned long ulBase, unsigned char ucPin)
- void [SoftUARTTxTimerTick](#) (tSoftUART \*pUART)

## 17.2.1 Data Structure Documentation

### 17.2.1.1 tSoftUART

**Definition:**

```
typedef struct
{
    void (*pfnIntCallback) (void);
    unsigned long ulTxGPIO;
    unsigned long ulRxGPIOPort;
    unsigned char *pucTxBuffer;
    unsigned short *pusRxBuffer;
    unsigned short usTxBufferLen;
    unsigned short usTxBufferRead;
    unsigned short usTxBufferWrite;
    unsigned short usTxBufferLevel;
    unsigned short usRxBufferLen;
    unsigned short usRxBufferRead;
    unsigned short usRxBufferWrite;
    unsigned short usRxBufferLevel;
    unsigned short usIntStatus;
    unsigned short usIntMask;
    unsigned short usConfig;
    unsigned char ucFlags;
    unsigned char ucTxState;
    unsigned char ucTxNext;
    unsigned char ucTxData;
    unsigned char ucRxPin;
    unsigned char ucRxState;
    unsigned char ucRxData;
    unsigned char ucRxFlags;
    unsigned char ucRxStatus;
}
tSoftUART
```

**Members:**

- pfnIntCallback*** The address of the callback function that is called to simulate the interrupts that would be produced by a hardware UART implementation. This address can be set via a direct structure access or using the `SoftUARTCallbackSet` function.
- uiTxGPIO*** The address of the GPIO pin to be used for the Tx signal. This member can be set via a direct structure access or using the `SoftUARTTxGPIOSet` function.
- uiRxGPIOPort*** The address of the GPIO port to be used for the Rx signal. This member can be set via a direct structure access or using the `SoftUARTRxGPIOSet` function.
- pucTxBuffer*** The address of the data buffer used for the transmit buffer. This member can be set via a direct structure access or using the `SoftUARTTxBufferSet` function.
- pusRxBuffer*** The address of the data buffer used for the receive buffer. This member can be set via a direct structure access or using the `SoftUARTRxBufferSet` function.
- usTxBufferLen*** The length of the transmit buffer. This member can be set via a direct structure access or using the `SoftUARTTxBufferSet` function.
- usTxBufferRead*** The index into the transmit buffer of the next character to be transmitted. This member should not be accessed or modified by the application.
- usTxBufferWrite*** The index into the transmit buffer of the next location to store a character into the buffer. This member should not be accessed or modified by the application.
- usTxBufferLevel*** The transmit buffer level at which the transmit interrupt is asserted. This member should not be accessed or modified by the application.
- usRxBufferLen*** The length of the receive buffer. This member can be set via a direct structure access or using the `SoftUARTRxBufferSet` function.
- usRxBufferRead*** The index into the receive buffer of the next character to be read from the buffer. This member should not be accessed or modified by the application.
- usRxBufferWrite*** The index into the receive buffer of the location to store the next character received. This member should not be accessed or modified by the application.
- usRxBufferLevel*** The receive buffer level at which the receive interrupt is asserted. This member should not be accessed or modified by the application.
- usIntStatus*** The set of virtual interrupts that are currently asserted. This member should not be accessed or modified by the application.
- usIntMask*** The set of virtual interrupts that should be sent to the callback function. This member should not be accessed or modified by the application.
- usConfig*** The configuration of the SoftUART module. This member can be set via the `SoftUARTConfigSet` and `SoftUARTFIFOLevelSet` functions.
- ucFlags*** The flags that control the operation of the SoftUART module. This member should not be accessed or modified by the application.
- ucTxState*** The current state of the SoftUART transmit state machine. This member should not be accessed or modified by the application.
- ucTxNext*** The value that is written to the Tx pin at the start of the next transmit timer tick. This member should not be accessed or modified by the application.
- ucTxData*** The character that is currently be sent via the Tx pin. This member should not be accessed or modified by the application.
- ucRxPin*** The GPIO pin to be used for the Rx signal. This member can be set via a direct structure access or using the `SoftUARTRxGPIOSet` function.
- ucRxState*** The current state of the SoftUART receive state machine. This member should not be accessed or modified by the application.
- ucRxData*** The character that is currently being received via the Rx pin. This member should not be accessed or modified by the application.

***ucRxFlags*** The flags that indicate any errors that have occurred during the reception of the current character via the Rx pin. This member should not be accessed or modified by the application.

***ucRxStatus*** The receive error status. This member should only be accessed via the SoftUARTRxErrorGet and SoftUARTRxErrorClear functions.

**Description:**

This structure contains the state of a single instance of a SoftUART module.

## 17.2.2 Function Documentation

### 17.2.2.1 SoftUARTBreakCtl

Causes a BREAK to be sent.

**Prototype:**

```
void  
SoftUARTBreakCtl (tSoftUART *pUART,  
                  tBoolean bBreakState)
```

**Parameters:**

***pUART*** specifies the SoftUART data structure.

***bBreakState*** controls the output level.

**Description:**

Calling this function with *bBreakState* set to **true** asserts a break condition on the SoftUART. Calling this function with *bBreakState* set to **false** removes the break condition. For proper transmission of a break command, the break must be asserted for at least two complete frames.

**Returns:**

None.

### 17.2.2.2 SoftUARTBusy

Determines whether the UART transmitter is busy or not.

**Prototype:**

```
tBoolean  
SoftUARTBusy (tSoftUART *pUART)
```

**Parameters:**

***pUART*** specifies the SoftUART data structure.

**Description:**

Allows the caller to determine whether all transmitted bytes have cleared the transmitter hardware. If **false** is returned, the transmit buffer is empty and all bits of the last transmitted character, including all stop bits, have left the hardware shift register.

**Returns:**

Returns **true** if the UART is transmitting or **false** if all transmissions are complete.

### 17.2.2.3 SoftUARTCallbackSet

Sets the callback used by the SoftUART module.

**Prototype:**

```
void  
SoftUARTCallbackSet (tSoftUART *pUART,  
                     void (*pfnCallback) (void))
```

**Parameters:**

**pUART** specifies the SoftUART data structure.  
**pfnCallback** is a pointer to the callback function.

**Description:**

This function sets the address of the callback function that is called when there is an “interrupt” produced by the SoftUART module.

**Returns:**

None.

### 17.2.2.4 SoftUARTCharGet

Waits for a character from the specified port.

**Prototype:**

```
long  
SoftUARTCharGet (tSoftUART *pUART)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**Description:**

Gets a character from the receive buffer for the specified port. If there are no characters available, this function waits until a character is received before returning.

**Returns:**

Returns the character read from the specified port, cast as a *long*.

### 17.2.2.5 SoftUARTCharGetNonBlocking

Receives a character from the specified port.

**Prototype:**

```
long  
SoftUARTCharGetNonBlocking (tSoftUART *pUART)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**Description:**

Gets a character from the receive buffer for the specified port.

**Returns:**

Returns the character read from the specified port, cast as a *long*. A **-1** is returned if there are no characters present in the receive buffer. The [SoftUARTCharsAvail\(\)](#) function should be called before attempting to call this function.

### 17.2.2.6 SoftUARTCharPut

Waits to send a character from the specified port.

**Prototype:**

```
void  
SoftUARTCharPut (tSoftUART *pUART,  
                 unsigned char ucData)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**ucData** is the character to be transmitted.

**Description:**

Sends the character *ucData* to the transmit buffer for the specified port. If there is no space available in the transmit buffer, this function waits until there is space available before returning.

**Returns:**

None.

### 17.2.2.7 SoftUARTCharPutNonBlocking

Sends a character to the specified port.

**Prototype:**

```
tBoolean  
SoftUARTCharPutNonBlocking (tSoftUART *pUART,  
                            unsigned char ucData)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**ucData** is the character to be transmitted.

**Description:**

Writes the character *ucData* to the transmit buffer for the specified port. This function does not block, so if there is no space available, then a **false** is returned, and the application must retry the function later.

**Returns:**

Returns **true** if the character was successfully placed in the transmit buffer or **false** if there was no space available in the transmit buffer.

### 17.2.2.8 SoftUARTCharsAvail

Determines if there are any characters in the receive buffer.

**Prototype:**

```
tBoolean  
SoftUARTCharsAvail (tSoftUART *pUART)
```

**Parameters:**

***pUART*** specifies the SoftUART data structure.

**Description:**

This function returns a flag indicating whether or not there is data available in the receive buffer.

**Returns:**

Returns **true** if there is data in the receive buffer or **false** if there is no data in the receive buffer.

### 17.2.2.9 SoftUARTConfigGet

Gets the current configuration of a UART.

**Prototype:**

```
void  
SoftUARTConfigGet (tSoftUART *pUART,  
                   unsigned long *pulConfig)
```

**Parameters:**

***pUART*** specifies the SoftUART data structure.

***pulConfig*** is a pointer to storage for the data format.

**Description:**

Returns the data format of the SoftUART. The data format returned in *pulConfig* is enumerated the same as the *ulConfig* parameter of [SoftUARTConfigSet\(\)](#).

**Returns:**

None.

### 17.2.2.10 SoftUARTConfigSet

Sets the configuration of a SoftUART module.

**Prototype:**

```
void  
SoftUARTConfigSet (tSoftUART *pUART,  
                   unsigned long ulConfig)
```

**Parameters:**

***pUART*** specifies the SoftUART data structure.

***ulConfig*** is the data format for the port (number of data bits, number of stop bits, and parity).



**Description:**

This function configures the SoftUART for operation in the specified data format, as specified in the *ulConfig* parameter.

The *ulConfig* parameter is the logical OR of three values: the number of data bits, the number of stop bits, and the parity. **SOFTUART\_CONFIG\_WLEN\_8**, **SOFTUART\_CONFIG\_WLEN\_7**, **SOFTUART\_CONFIG\_WLEN\_6**, and **SOFTUART\_CONFIG\_WLEN\_5** select from eight to five data bits per byte (respectively). **SOFTUART\_CONFIG\_STOP\_ONE** and **SOFTUART\_CONFIG\_STOP\_TWO** select one or two stop bits (respectively). **SOFTUART\_CONFIG\_PAR\_NONE**, **SOFTUART\_CONFIG\_PAR\_EVEN**, **SOFTUART\_CONFIG\_PAR\_ODD**, **SOFTUART\_CONFIG\_PAR\_ONE**, and **SOFTUART\_CONFIG\_PAR\_ZERO** select the parity mode (no parity bit, even parity bit, odd parity bit, parity bit always one, and parity bit always zero, respectively).

**Returns:**

None.

#### 17.2.2.11 SoftUARTDisable

Disables the SoftUART.

**Prototype:**

```
void  
SoftUARTDisable(tSoftUART *pUART)
```

**Parameters:**

***pUART*** specifies the SoftUART data structure.

**Description:**

This function disables the SoftUART after waiting for it to become idle.

**Returns:**

None.

#### 17.2.2.12 SoftUARTEnable

Enables the SoftUART.

**Prototype:**

```
void  
SoftUARTEnable(tSoftUART *pUART)
```

**Parameters:**

***pUART*** specifies the SoftUART data structure.

**Description:**

This function enables the SoftUART, allowing data to be transmitted and received.

**Returns:**

None.

### 17.2.2.13 SoftUARTFIFOLevelGet

Gets the buffer level at which “interrupts” are generated.

**Prototype:**

```
void  
SoftUARTFIFOLevelGet (tSoftUART *pUART,  
                      unsigned long *pulTxLevel,  
                      unsigned long *pulRxLevel)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**pulTxLevel** is a pointer to storage for the transmit buffer level, returned as one of **UART\_FIFO\_TX1\_8**, **UART\_FIFO\_TX2\_8**, **UART\_FIFO\_TX4\_8**, **UART\_FIFO\_TX6\_8**, or **UART\_FIFO\_TX7\_8**.

**pulRxLevel** is a pointer to storage for the receive buffer level, returned as one of **UART\_FIFO\_RX1\_8**, **UART\_FIFO\_RX2\_8**, **UART\_FIFO\_RX4\_8**, **UART\_FIFO\_RX6\_8**, or **UART\_FIFO\_RX7\_8**.

**Description:**

This function gets the buffer level at which transmit and receive “interrupts” are generated.

**Returns:**

None.

### 17.2.2.14 SoftUARTFIFOLevelSet

Sets the buffer level at which “interrupts” are generated.

**Prototype:**

```
void  
SoftUARTFIFOLevelSet (tSoftUART *pUART,  
                      unsigned long ulTxLevel,  
                      unsigned long ulRxLevel)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**ulTxLevel** is the transmit buffer “interrupt” level, specified as one of **UART\_FIFO\_TX1\_8**, **UART\_FIFO\_TX2\_8**, **UART\_FIFO\_TX4\_8**, **UART\_FIFO\_TX6\_8**, or **UART\_FIFO\_TX7\_8**.

**ulRxLevel** is the receive buffer “interrupt” level, specified as one of **UART\_FIFO\_RX1\_8**, **UART\_FIFO\_RX2\_8**, **UART\_FIFO\_RX4\_8**, **UART\_FIFO\_RX6\_8**, or **UART\_FIFO\_RX7\_8**.

**Description:**

This function sets the buffer level at which transmit and receive “interrupts” are generated.

**Returns:**

None.

### 17.2.2.15 SoftUARTInit

Initializes the SoftUART module.

**Prototype:**

```
void  
SoftUARTInit (tSoftUART *pUART)
```

**Parameters:**

**pUART** specifies the soft UART data structure.

**Description:**

This function initializes the data structure for the SoftUART module, putting it into the default configuration.

**Returns:**

None.

### 17.2.2.16 SoftUARTIntClear

Clears SoftUART “interrupt” sources.

**Prototype:**

```
void  
SoftUARTIntClear (tSoftUART *pUART,  
                  unsigned long ulIntFlags)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**ulIntFlags** is a bit mask of the “interrupt” sources to be cleared.

**Description:**

The specified SoftUART “interrupt” sources are cleared, so that they no longer assert. This function must be called in the callback function to keep the “interrupt” from being recognized again immediately upon exit.

The *ulIntFlags* parameter has the same definition as the *ulIntFlags* parameter to [SoftUARTIntEnable\(\)](#).

**Returns:**

None.

### 17.2.2.17 SoftUARTIntDisable

Disables individual SoftUART “interrupt” sources.

**Prototype:**

```
void  
SoftUARTIntDisable (tSoftUART *pUART,  
                    unsigned long ulIntFlags)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**ulIntFlags** is the bit mask of the “interrupt” sources to be disabled.

**Description:**

Disables the indicated SoftUART “interrupt” sources. Only the sources that are enabled can be reflected to the SoftUART callback.

The *ulIntFlags* parameter has the same definition as the *ulIntFlags* parameter to [SoftUARTIntEnable\(\)](#).

**Returns:**

None.

### 17.2.2.18 SoftUARTIntEnable

Enables individual SoftUART “interrupt” sources.

**Prototype:**

```
void  
SoftUARTIntEnable(tSoftUART *pUART,  
                  unsigned long ulIntFlags)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**ulIntFlags** is the bit mask of the “interrupt” sources to be enabled.

**Description:**

Enables the indicated SoftUART “interrupt” sources. Only the sources that are enabled can be reflected to the SoftUART callback.

The *ulIntFlags* parameter is the logical OR of any of the following:

- **SOFTUART\_INT\_OE** - Overrun Error “interrupt”
- **SOFTUART\_INT\_BE** - Break Error “interrupt”
- **SOFTUART\_INT\_PE** - Parity Error “interrupt”
- **SOFTUART\_INT\_FE** - Framing Error “interrupt”
- **SOFTUART\_INT\_RT** - Receive Timeout “interrupt”
- **SOFTUART\_INT\_TX** - Transmit “interrupt”
- **SOFTUART\_INT\_RX** - Receive “interrupt”

**Returns:**

None.

### 17.2.2.19 SoftUARTIntStatus

Gets the current SoftUART “interrupt” status.

**Prototype:**

```
unsigned long  
SoftUARTIntStatus(tSoftUART *pUART,  
                  tBoolean bMasked)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**bMasked** is **false** if the raw “interrupt” status is required and **true** if the masked “interrupt” status is required.

**Description:**

This returns the “interrupt” status for the SoftUART. Either the raw “interrupt” status or the status of “interrupts” that are allowed to reflect to the SoftUART callback can be returned.

**Returns:**

Returns the current “interrupt” status, enumerated as a bit field of values described in [SoftUARTIntEnable\(\)](#).

### 17.2.2.20 SoftUARTParityModeGet

Gets the type of parity currently being used.

**Prototype:**

```
unsigned long  
SoftUARTParityModeGet (tSoftUART *pUART)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**Description:**

This function gets the type of parity used for transmitting data and expected when receiving data.

**Returns:**

Returns the current parity settings, specified as one of **SOFTUART\_CONFIG\_PAR\_NONE**, **SOFTUART\_CONFIG\_PAR\_EVEN**, **SOFTUART\_CONFIG\_PAR\_ODD**, **SOFTUART\_CONFIG\_PAR\_ONE**, or **SOFTUART\_CONFIG\_PAR\_ZERO**.

### 17.2.2.21 SoftUARTParityModeSet

Sets the type of parity.

**Prototype:**

```
void  
SoftUARTParityModeSet (tSoftUART *pUART,  
                        unsigned long ulParity)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**ulParity** specifies the type of parity to use.

**Description:**

Sets the type of parity to use for transmitting and expect when receiving. The *ulParity* parameter must be one of **SOFTUART\_CONFIG\_PAR\_NONE**, **SOFTUART\_CONFIG\_PAR\_EVEN**, **SOFTUART\_CONFIG\_PAR\_ODD**, **SOFTUART\_CONFIG\_PAR\_ONE**, or **SOFTUART\_CONFIG\_PAR\_ZERO**. The last two allow direct control of the parity bit; it is always either one or zero based on the mode.

**Returns:**  
None.

#### 17.2.2.22 SoftUARTRxBufferSet

Sets the receive buffer for a SoftUART module.

**Prototype:**

```
void  
SoftUARTRxBufferSet (tSoftUART *pUART,  
                     unsigned short *pusRxBuffer,  
                     unsigned short usLen)
```

**Parameters:**  
***pUART*** specifies the SoftUART data structure.  
***pusRxBuffer*** is the address of the receive buffer.  
***usLen*** is the size, in 16-bit half-words, of the receive buffer.

**Description:**  
This function sets the address and size of the receive buffer. It also resets the read and write pointers, marking the receive buffer as empty.

**Returns:**  
None.

#### 17.2.2.23 SoftUARTRxErrorClear

Clears all reported receiver errors.

**Prototype:**

```
void  
SoftUARTRxErrorClear (tSoftUART *pUART)
```

**Parameters:**  
***pUART*** specifies the SoftUART data structure.

**Description:**  
This function is used to clear all receiver error conditions reported via [SoftUARTRxErrorGet\(\)](#). If using the overrun, framing error, parity error or break interrupts, this function must be called after clearing the interrupt to ensure that later errors of the same type trigger another interrupt.

**Returns:**  
None.

#### 17.2.2.24 SoftUARTRxErrorGet

Gets current receiver errors.

**Prototype:**

```
unsigned long  
SoftUARTRxErrorGet (tSoftUART *pUART)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**Description:**

This function returns the current state of each of the 4 receiver error sources. The returned errors are equivalent to the four error bits returned via the previous call to [SoftUARTCharGet\(\)](#) or [SoftUARTCharGetNonBlocking\(\)](#) with the exception that the overrun error is set immediately when the overrun occurs rather than when a character is next read.

**Returns:**

Returns a logical OR combination of the receiver error flags, **SOFTUART\_RXERROR\_FRAMING**, **SOFTUART\_RXERROR\_PARITY**, **SOFTUART\_RXERROR\_BREAK** and **SOFTUART\_RXERROR\_OVERRUN**.

### 17.2.2.25 SoftUARTRxGPIOSet

Sets the GPIO pin to be used as the SoftUART Rx signal.

**Prototype:**

```
void  
SoftUARTRxGPIOSet (tSoftUART *pUART,  
                   unsigned long ulBase,  
                   unsigned char ucPin)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.  
**ulBase** is the base address of the GPIO module.  
**ucPin** is the bit-packed representation of the pin to use.

**Description:**

This function sets the GPIO pin that is used when the SoftUART must sample the Rx signal. If there is not a GPIO pin allocated for Rx, the SoftUART module will not read data from the slave device.

The pin is specified using a bit-packed byte, where bit 0 of the byte represents GPIO port pin 0, bit 1 represents GPIO port pin 1, and so on.

**Returns:**

None.

### 17.2.2.26 SoftUARTRxTick

Performs the periodic update of the SoftUART receiver.

**Prototype:**

```
unsigned long  
SoftUARTRxTick (tSoftUART *pUART,  
                tBoolean bEdgeInt)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**bEdgeInt** should be **true** if this function is being called because of a GPIO edge interrupt and **false** if it is being called because of a timer interrupt.

**Description:**

This function performs the periodic, time-based updates to the SoftUART receiver. The reception of data to the SoftUART is performed by the state machine in this function.

This function must be called by the GPIO interrupt handler, and then periodically at the desired SoftUART baud rate. For example, to run the SoftUART at 115,200 baud, this function must be called at a 115,200 Hz rate.

**Returns:**

Returns **SOFTUART\_RXTIMER\_NOP** if the receive timer should continue to operate or **SOFTUART\_RXTIMER\_END** if it should be stopped.

### 17.2.2.27 SoftUARTSpaceAvail

Determines if there is any space in the transmit buffer.

**Prototype:**

```
tBoolean  
SoftUARTSpaceAvail (tSoftUART *pUART)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**Description:**

This function returns a flag indicating whether or not there is space available in the transmit buffer.

**Returns:**

Returns **true** if there is space available in the transmit buffer or **false** if there is no space available in the transmit buffer.

### 17.2.2.28 SoftUARTTxBufferSet

Sets the transmit buffer for a SoftUART module.

**Prototype:**

```
void  
SoftUARTTxBufferSet (tSoftUART *pUART,  
                     unsigned char *pucTxBuffer,  
                     unsigned short usLen)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**pucTxBuffer** is the address of the transmit buffer.

**usLen** is the size, in 8-bit bytes, of the transmit buffer.



**Description:**

This function sets the address and size of the transmit buffer. It also resets the read and write pointers, marking the transmit buffer as empty.

**Returns:**

None.

### 17.2.2.29 SoftUARTTxGPIOSet

Sets the GPIO pin to be used as the SoftUART Tx signal.

**Prototype:**

```
void  
SoftUARTTxGPIOSet (tSoftUART *pUART,  
                   unsigned long ulBase,  
                   unsigned char ucPin)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**ulBase** is the base address of the GPIO module.

**ucPin** is the bit-packed representation of the pin to use.

**Description:**

This function sets the GPIO pin that is used when the SoftUART must assert the Tx signal.

The pin is specified using a bit-packed byte, where bit 0 of the byte represents GPIO port pin 0, bit 1 represents GPIO port pin 1, and so on.

**Returns:**

None.

### 17.2.2.30 SoftUARTTxTimerTick

Performs the periodic update of the SoftUART transmitter.

**Prototype:**

```
void  
SoftUARTTxTimerTick (tSoftUART *pUART)
```

**Parameters:**

**pUART** specifies the SoftUART data structure.

**Description:**

This function performs the periodic, time-based updates to the SoftUART transmitter. The transmission of data from the SoftUART is performed by the state machine in this function.

This function must be called at the desired SoftUART baud rate. For example, to run the SoftUART at 115,200 baud, this function must be called at a 115,200 Hz rate.

**Returns:**

None.

## 17.3 Programming Example

The following example shows how to configure the software UART module and transmit some data to an external peripheral. This example uses Timer 0 as the timing source.

```
//
// The instance data for the software UART.
//
tSoftUART g_sUART;

//
// The buffer used to hold the transmit data.
//
unsigned char g_pucTxBuffer[16];

//
// The buffer used to hold the receive data.
//
unsigned short g_pusRxBuffer[16];

//
// The number of processor clocks in the time period of a single bit on the
// software UART interface.
//
unsigned long g_ulBitTime;

//
// The transmit timer tick function.
//
void
Timer0AIntHandler(void)
{
    //
    // Clear the timer interrupt.
    //
    TimerIntClear(TIMER0_BASE, TIMER_TIMA_TIMEOUT);

    //
    // Call the software UART transmit timer tick function.
    //
    SoftUARTTxTimerTick(&g_sUART);
}

//
// The receive timer tick function.
//
void
Timer0BIntHandler(void)
{
    //
    // Clear the timer interrupt.
    //
    TimerIntClear(TIMER0_BASE, TIMER_TIMA_TIMEOUT);

    //
    // Call the software UART receive timer tick function, and see if the
    // timer should be disabled.
    //
    if(SoftUARTRxTick(&g_sUART, false) == SOFTUART_RXTIMER_END)
    {
        //
        // Disable the timer interrupt since the software UART doesn't need
        // it any longer.
        //
    }
}
```

```
        TimerDisable(TIMER0_BASE, TIMER_B);
    }
}

//
// The interrupt handler for the software UART GPIO edge interrupt.
//
void
GPIOIntHandler(void)
{
    //
    // Configure the software UART receive timer so that it samples at the
    // mid-bit time of this character.
    //
    TimerDisable(TIMER0_BASE, TIMER_B);
    TimerLoadSet(TIMER0_BASE, TIMER_B, g_ulBitTime);
    TimerIntClear(TIMER0_BASE, TIMER_TIMB_TIMEOUT);
    TimerEnable(TIMER0_BASE, TIMER_B);

    //
    // Call the software UART receive timer tick function.
    //
    SoftUARTRxTick(&g_sUART, true);
}

//
// The callback function for the software UART. This function is
// equivalent to the interrupt handler for a hardware UART.
//
void
UARTCallback(void)
{
    unsigned long ulInts;

    //
    // Read the asserted interrupt sources.
    //
    ulInts = SoftUARTIntStatus(&g_sUART, true);

    //
    // Clear the asserted interrupt sources.
    //
    SoftUARTIntClear(&g_sUART, ulInts);

    //
    // Handle the asserted interrupts.
    //
    ...
}

//
// Setup the software UART and send some data.
//
void
TestSoftUART(void)
{
    //
    // Initialize the software UART instance data.
    //
    SoftUARTInit(&g_sUART);

    //
    // Set the callback function used for this software UART.
    //
    SoftUARTCallbackSet(&g_sUART, UARTCallback);
}
```

```
//
// Configure the pins used for the software UART. This example uses
// pins PD0 and PE1.
//
SoftUARTTxGPIOSet(&g_sUART, GPIO_PORTD_BASE, GPIO_PIN_0);
SoftUARTRxGPIOSet(&g_sUART, GPIO_PORTE_BASE, GPIO_PIN_1);

//
// Configure the data buffers used as the transmit and receive buffers.
//
SoftUARTTxBufferSet(&g_sUART, g_pucTxBuffer, 16);
SoftUARTRxBufferSet(&g_sUART, g_pusRxBuffer, 16);

//
// Enable the GPIO modules that contains the GPIO pins to be used by
// the software UART.
//
SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOD);
SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOE);

//
// Configure the software UART module: 8 data bits, no parity, and one
// stop bit.
//
SoftUARTConfigSet(&g_sUART,
                  (SOFTUART_CONFIG_WLEN_8 | SOFTUART_CONFIG_PAR_NONE |
                   SOFTUART_CONFIG_STOP_ONE));

//
// Compute the bit time for 38,400 baud.
//
g_ulBitTime = (SysCtlClockGet() / 38400) - 1;

//
// Configure the timers used to generate the timing for the software
// UART. The interface in this example is run at 38,400 baud,
// requiring a timer tick at 38,400 Hz.
//
SysCtlPeripheralEnable(SYSCTL_PERIPH_TIMER0);
TimerConfigure(TIMER0_BASE,
               (TIMER_CFG_16_BIT_PAIR | TIMER_CFG_A_PERIODIC |
                TIMER_CFG_B_PERIODIC));
TimerLoadSet(TIMER0_BASE, TIMER_A, g_ulBitTime);
TimerIntEnable(TIMER0_BASE, TIMER_TIMA_TIMEOUT | TIMER_TIMB_TIMEOUT);
TimerEnable(TIMER0_BASE, TIMER_A);

//
// Set the priorities of the interrupts associated with the software
// UART. The receiver is higher priority than the transmitter, and the
// receiver edge interrupt is higher priority than the receiver timer
// interrupt.
//
IntPrioritySet(INT_GPIOE, 0x00);
IntPrioritySet(INT_TIMER0B, 0x40);
IntPrioritySet(INT_TIMER0A, 0x80);

//
// Enable the interrupts associated with the software UART.
//
IntEnable(INT_GPIOE);
IntEnable(INT_TIMER0A);
IntEnable(INT_TIMER0B);

//
// Enable the transmit FIFO half full interrupt in the software UART.
//
```

```
SoftUARTIntEnable(&g_sUART, SOFTUART_INT_TX);

//
// Write some data into the software UART transmit FIFO.
//
SoftUARTCharPut(&g_sUART, 0x55);
SoftUARTCharPut(&g_sUART, 0xaa);
SoftUARTCharPut(&g_sUART, 0x55);
SoftUARTCharPut(&g_sUART, 0xaa);
SoftUARTCharPut(&g_sUART, 0x55);
SoftUARTCharPut(&g_sUART, 0xaa);
SoftUARTCharPut(&g_sUART, 0x55);
SoftUARTCharPut(&g_sUART, 0xaa);
SoftUARTCharPut(&g_sUART, 0x55);
SoftUARTCharPut(&g_sUART, 0xaa);
SoftUARTCharPut(&g_sUART, 0x55);
SoftUARTCharPut(&g_sUART, 0xaa);

//
// Wait until the software UART is idle. The transmit FIFO half full
// interrupt is sent to the callback function prior to exiting this
// loop.
//
while(SoftUARTBusy(&g_sUART))
{
}
}
```

As a comparison, the following is the equivalent code using the hardware UART module and the Stellaris Peripheral Driver Library.

```
//
// The interrupt handler for the hardware UART.
//
void
UART0IntHandler(void)
{
    unsigned long ulInts;

    //
    // Read the asserted interrupt sources.
    //
    ulInts = UARTIntStatus(UART0_BASE, true);

    //
    // Clear the asserted interrupt sources.
    //
    UARTIntClear(UART0_BASE, ulInts);

    //
    // Handle the asserted interrupts.
    //
    ...
}

//
// Setup the hardware UART and send some data.
//
void
TestUART(void)
{
    //
    // Enable the GPIO module that contains the GPIO pins to be used by
    // the UART, as well as the UART module.
    //
}
```

```
SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOA);
SysCtlPeripheralEnable(SYSCTL_PERIPH_UART0);

//
// Configure the GPIO pins for use by the UART module.
//
GPIOPinTypeUART(GPIO_PORTA_BASE, GPIO_PIN_0 | GPIO_PIN_1);

//
// Initialize the hardware UART module: 8 data bits, no parity, one stop
// bit, and 38,400 baud rate.
//
UARTConfigSetExpClk(UART0_BASE, SysCtlClockGet(), 38400,
                    (UART_CONFIG_WLEN_8 | UART_CONFIG_PAR_NONE |
                     UART_CONFIG_STOP_ONE));

//
// Enable the transmit FIFO half full interrupt in the hardware UART.
//
UARTIntEnable(UART0_BASE, UART_INT_TX);
IntEnable(INT_UART0);

//
// Write some data into the hardware UART transmit FIFO.
//
UARTCharPut(UART0_BASE, 0x55);
UARTCharPut(UART0_BASE, 0xaa);
UARTCharPut(UART0_BASE, 0x55);
UARTCharPut(UART0_BASE, 0xaa);
UARTCharPut(UART0_BASE, 0x55);
UARTCharPut(UART0_BASE, 0xaa);
UARTCharPut(UART0_BASE, 0x55);
UARTCharPut(UART0_BASE, 0xaa);
UARTCharPut(UART0_BASE, 0x55);
UARTCharPut(UART0_BASE, 0xaa);
UARTCharPut(UART0_BASE, 0x55);
UARTCharPut(UART0_BASE, 0xaa);

//
// Wait until the hardware UART is idle. The transmit FIFO half full
// interrupt is sent to the interrupt handler prior to exiting this
// loop.
//
while(UARTBusy(UART0_BASE))
{
}
}
```

# 18 Ethernet Software Update Module

Introduction .....	127
API Functions .....	127
Programming Example .....	129

## 18.1 Introduction

The Ethernet software update module provides a convenient method of registering a callback which will be notified when a user attempts to initiate a firmware update over Ethernet using the LM Flash Programmer application. In addition to providing notification of an update request, the module also provides a function that can be called to initiate an update using the Ethernet boot loader.

To make use of this module, an application must include the lwIP TCP/IP stack and must be run on a system configured to use the Ethernet boot loader.

This module is contained in `utils/swupdate.c`, with `utils/swupdate.h` containing the API definitions for use by applications.

## 18.2 API Functions

### Functions

- void [SoftwareUpdateBegin](#) (void)
- void [SoftwareUpdateInit](#) (tSoftwareUpdateRequested pfnCallback)

### 18.2.1 Function Documentation

#### 18.2.1.1 SoftwareUpdateBegin

Passes control to the bootloader and initiates a remote software update over Ethernet.

##### Prototype:

```
void  
SoftwareUpdateBegin(void)
```

##### Description:

This function passes control to the bootloader and initiates an update of the main application firmware image via BOOTP across Ethernet. This function may only be used on parts supporting Ethernet and in cases where the Ethernet boot loader is in use alongside the main application image. It must not be called in interrupt context.

Applications wishing to make use of this function must be built to operate with the bootloader. If this function is called on a system which does not include the bootloader, the results are unpredictable.

**Note:**

It is not safe to call this function from within the callback provided on the initial call to [SoftwareUpdateInit\(\)](#). The application must use the callback to signal a pending update (assuming the update is to be permitted) to some other code running in a non-interrupt context.

**Returns:**

Never returns.

### 18.2.1.2 SoftwareUpdateInit

Initializes the remote Ethernet software update notification feature.

**Prototype:**

```
void  
SoftwareUpdateInit(tSoftwareUpdateRequested pfnCallback)
```

**Parameters:**

***pfnCallback*** is a pointer to a function which will be called whenever a remote firmware update request is received. If the application wishes to allow the update to go ahead, it must call [SoftwareUpdateBegin\(\)](#) from non-interrupt context after the callback is received. Note that the callback will most likely be made in interrupt context so it is not safe to call [SoftwareUpdateBegin\(\)](#) from within the callback itself.

**Description:**

This function may be used on Ethernet-enabled parts to support remotely-signaled firmware updates over Ethernet. The LM Flash Programmer (LMFlash.exe) application sends a magic packet to UDP port 9 whenever the user requests an Ethernet-based firmware update. This packet consists of 6 bytes of 0xAA followed by the target MAC address repeated 4 times. This function starts listening on UDP port 9 and, if a magic packet matching the MAC address of this board is received, makes a call to the provided callback function to indicate that an update has been requested.

The callback function provided here will typically be called in the context of the lwIP Ethernet interrupt handler. It is not safe to call [SoftwareUpdateBegin\(\)](#) in this context so the application should use the callback to signal code running in a non-interrupt context to perform the update if it is to be allowed.

UDP port 9 is chosen for this function since this is the well-known port associated with “discard” operation. In other words, any other system receiving the magic packet will simply ignore it. The actual magic packet used is modeled on Wake-On-LAN which uses a similar structure (6 bytes of 0xFF followed by 16 repetitions of the target MAC address). Some Wake-On-LAN implementations also use UDP port 9 for their signaling.

**Note:**

Applications using this function must initialize the lwIP stack prior to making this call and must ensure that the `lwIPTimer()` function is called periodically. lwIP UDP must be enabled in `lwipopts.h` to ensure that the magic packets can be received.

**Returns:**

None.



## 18.3 Programming Example

The following example shows how to use the software update module.

```
//*****
//
// A flag used to indicate that an Ethernet remote firmware update request
// has been received.
//
//*****
volatile tBoolean g_bFirmwareUpdate = false;

//*****
//
// This function is called by the software update module whenever a remote
// host requests to update the firmware on this board. We set a flag that
// will cause the bootloader to be entered the next time the user enters a
// command on the console.
//
//*****
void
SoftwareUpdateRequestCallback(void)
{
    g_bFirmwareUpdate = true;
}

//*****
//
// The main entry point for the application. This function contains all
// hardware initialization code and also the main loop for the application.
//
//*****
int
main(void)
{
    unsigned char pucMACAddr[6];

    //
    // System clock initialization and reading of the MAC address into array
    // pucMACAddr occurs here. This code is omitted for clarity.
    //

    //
    // Initialize the lwIP TCP/IP stack.
    //
    lwIPInit(pucMACAddr, 0, 0, 0, IPADDR_USE_DHCP);

    //
    // Start the remote software update module.
    //
    SoftwareUpdateInit(SoftwareUpdateRequestCallback);

    //
    // Do whatever other setup things the application needs.
    //

    //
    // Loop until someone requests a remote firmware update.
    //
    while(!g_bFirmwareUpdate)
    {
        //
        // Perform your main loop functions here.
        //
    }
}
```

```
    }  
  
    //  
    // If we drop out, a remote firmware update request has been received.  
    // Transfer control to the bootloader which will perform the update.  
    //  
    SoftwareUpdateBegin();  
}
```

## 19 TFTP Server Module

Introduction .....	131
Usage .....	131
API Functions .....	134

### 19.1 Introduction

The TFTP (tiny file transfer protocol) server module provides a simple way of transferring files to and from a system over an Ethernet connection. The general-purpose server module implements all the basic TFTP protocol and interacts with applications via a number of application-provided callback functions which are called when:

- A new file transfer request is received from a client.
- Another block of file data is required to satisfy an ongoing GET (read) request.
- A new block of data is received during an ongoing PUT (write) request.
- A file transfer has completed.

To make use of this module, an application must include the lwIP TCP/IP stack with UDP enabled in the `lwipopts.h` header file.

This module is contained in `utils/tftp.c`, with `utils/tftp.h` containing the API definitions for use by applications.

### 19.2 Usage

The TFTP server module handles the TFTP protocol on behalf of an application but the application using it is responsible for all file system interaction - reading and writing files in response to callbacks from the TFTP server. To make use of the module, an application must provide the following callback functions to the server.

**pfnRequest** (type `tTFTPRequest`) This function pointer is provided to the server as a parameter to the `TFTPInit()` function. It will be called whenever a new incoming TFTP request is received by the server and allows the application to determine whether the connection should be accepted or rejected.

**pfnGetData** (type `{tTFTPTransfer}`) This function is called to read each block of file data during an ongoing GET request. It must copy the requested number of bytes from a given position in the file into a supplied buffer. The application writes a pointer to this function into the `tTFTPConnection` instance data structure during processing of the `pfnRequest` callback if a GET request is to be accepted.

**pfnPutData** (type `tTFTPTransfer`) This function is called to write each block of file data during an ongoing PUT request. It must write the provided block of data into the target file. The application writes a pointer to this function into the `tTFTPConnection` instance data structure during processing of the `pfnRequest` callback if a PUT request is to be accepted.

**pfnClose** (type `tTFTPClose`) This function is called when a TFTP connection ends and allows the application to perform any cleanup required - freeing workspace memory and closing files, for example. The application writes a pointer to this function into the `tTFTPConnection` instance data structure during processing of the `pfnRequest` callback if the request is to be accepted.

### 19.2.0.3 pfnRequest

Application callback function called whenever a new TFTP request is received by the server.

**Prototype:**

```
tTFTPError  
pfnRequest(struct _tTFTPConnection *psTFTP, tBoolean bGet, char  
*pucFileName, tTFTPMode eMode)
```

**Parameters:**

**psTFTP** points to the TFTP connection instance data for the new request.

**bGet** is `true` if the incoming request is a GET (read) request or `false` if it is a PUT (write) request.

**pucFileName** points to the first character of the name of the local file which is to be read (on a GET request) or written (on a PUT request).

**eMode** indicates the requested transfer mode, `TFTP_MODE_NETASCII` (text) or `TFTP_MODE_OCTET` (binary).

**Description:**

This function, whose pointer is passed to the server as a parameter to function `TFTPInit()`, is called whenever a new TFTP request is received. It passes information about the request to the application allowing it to accept or reject it. The request type, GET or PUT, is determined from the `bGet` parameter and the target file name is provided in `pucFileName`.

If the application wishes to reject the request, it should set the `pcErrorString` field in the `psTFTP` structure and return an error code other than **TFTP\_OK**.

To accept an incoming connection and start the file transfer, the application should return **TFTP\_OK** after completing various fields in the `psTFTP` structure. For a GET request, fill in the `pfnGetData` and `pfnClose` function pointers and set `ulDataRemaining` to the size of the file which is being requested. For a PUT request, fill in the `pfnPutData` and `pfnClose` function pointers.

During processing of `pfnRequest`, the application may use the `pucUser` field as an anchor for any additional instance data required to process the request - a file handle, for example. This field will be accessible on all future callbacks related to this connection since the `psTFTP` structure is passed as a parameter in each case. Any resources allocated during `pfnRequest` can be freed during the later call to `pfnClose`.

**Returns:**

Returns **TFTP\_OK** if the request is to be handled or any other TFTP error code if it is to be rejected.

### 19.2.0.4 pfnGetData

Application callback function called whenever the TFTP server needs another block of data read from the source file.

**Prototype:**

```
tTFTPError  
pfnGetData(struct _tTFTPConnection *psTFTP)
```

**Parameters:**

**psTFTP** points to the TFTP connection instance data for the existing GET request.

**Description:**

This function, whose pointer was passed to the server in the `psTFTP` structure when the TFTP connection was accepted in `pfnRequest`, is called whenever the server needs a new block of file data to send back to the remote client. The application must copy a block of `psTFTP->ulDataLength` bytes of data from the source file to the buffer pointed to by `psTFTP->pucData`.

Typically, GET requests will read data sequentially from the file but, in some error recovery cases, data previously read may be requested again. The application must, therefore, ensure that the correct block of data is being returned by checking `psTFTP->ulBlockNum` and setting the source file offset correctly based on its value. The required read offset is `(psTFTP->ulBlockNum * TFTP_BLOCK_SIZE)` bytes from the start of the file.

If an error is detected while reading the file, field `psTFTP->pcErrorString` should be set and a value other than **TFTP\_OK** returned.

**Returns:**

Returns **TFTP\_OK** if the data was read successfully or any other TFTP error code if an error occurred.

### 19.2.0.5 pfnPutData

Application callback function called whenever the TFTP server has received data to be written to the destination file.

**Prototype:**

```
tTFTPError  
pfnPutData(struct _tTFTPConnection *psTFTP)
```

**Parameters:**

**psTFTP** points to the TFTP connection instance data for the existing PUT request.

**Description:**

This function, whose pointer was passed to the server in the `psTFTP` structure when the TFTP connection was accepted in `pfnRequest`, is called whenever the server receives a block of data. The application must write a block of `psTFTP->ulDataLength` bytes of data from address `psTFTP->pucData` to the destination file.

Typically, PUT requests will write data sequentially to the file but, in some error recovery cases, data previously written may be received again. The application must, therefore, ensure that the received data is written at the correct position within the file. This position is determined from the fields `psTFTP->ulBlockNum` and `psTFTP->ulDataRemaining`. The byte offset relative

to the start of the file that the data must be written to is given by `((psTFTP->ulBlockNum - 1) * TFTP_BLOCK_SIZE) + psTFTP->ulDataRemaining`.

If an error is detected while writing the file, field `psTFTP->pcErrorString` should be set and a value other than **TFTP\_OK** returned.

**Returns:**

Returns **TFTP\_OK** if the data was written successfully or any other TFTP error code if an error occurred.

### 19.2.0.6 pfnClose

Application callback function called whenever the TFTP connection is being closed.

**Prototype:**

```
void  
pfnClose(struct _tTFTPConnection *psTFTP)
```

**Parameters:**

**psTFTP** points to the TFTP instance data block for the connection which is being closed.

**Description:**

This function, whose pointer was passed to the server in the `psTFTP` structure when the TFTP connection was accepted in `pfnRequest`, is called whenever the server is about to close the TFTP connection. An application may use it to free any resources allocated to service the connection (file handles, for example).

**Returns:**

None.

## 19.3 API Functions

### Data Structures

- [\\_tTFTPConnection](#)

### Defines

- [TFTP\\_BLOCK\\_SIZE](#)

### Enumerations

- [tTFTPError](#)

### Functions

- void [TFTPInit](#) (tTFTPRequest pfnRequest)

## 19.3.1 Data Structure Documentation

### 19.3.1.1 `_tTFTPConnection`

**Definition:**

```
typedef struct
{
    unsigned char *pucData;
    unsigned long ulDataLength;
    unsigned long ulDataRemaining;
    tTFTPTransfer pfnGetData;
    tTFTPTransfer pfnPutData;
    tTFTPClose pfnClose;
    unsigned char *pucUser;
    char *pcErrorString;
    udp_pcb *pPCB;
    unsigned long ulBlockNum;
}
_tTFTPConnection
```

**Members:**

***pucData*** Pointer to the start of the buffer into which GET data should be copied or from which PUT data should be read.

***ulDataLength*** The length of the data requested in response to a single pfnGetData callback or the size of the received data for a pfnPutData callback.

***ulDataRemaining*** Count of remaining bytes to send during a GET request or the byte offset within a block during a PUT request. The application must set this field to the size of the requested file during the tTFTPRequest

***pfnGetData*** Application function which is called whenever more data is required to satisfy a GET request. The function must copy ulDataLength bytes into the buffer pointed to by pucData.

***pfnPutData*** Application function which is called whenever a packet of file data is received during a PUT request. The function must save the data to the target file using ulBlockNum and ulDataRemaining to indicate the position of the data in the file, and return an appropriate error code. Note that several calls to this function may be made for a given received TFTP block since the underlying networking stack may have split the TFTP packet between several packets and a callback is made for each of these. This avoids the need for a 512 byte buffer. The ulDataRemaining is used in these cases to indicate the offset of the data within the current block.

***pfnClose*** Application function which is called when the TFTP connection is to be closed. The function should tidy up and free any resources associated with the connection prior to returning.

***pucUser*** This field may be used by the client to store an application-specific pointer that will be accessible on all callbacks from the TFTP module relating to this connection.

***pcErrorString*** Pointer to an error string which the client must fill in if reporting an error. This string will be sent to the TFTP client in any case where pfnPutData or pfnGetData return a value other than TFTP\_OK.

***pPCB*** A pointer to the underlying UDP connection. Applications must not modify this field.

***ulBlockNum*** The current block number for an ongoing TFTP transfer. Applications may read this value to determine which data to return on a pfnGetData callback or where to write incoming data on a pfnPutData callback but must not modify it.

**Description:**

The TFTP connection control structure. This is passed to a client on all callbacks relating to a given TFTP connection. Depending upon the callback, the client may need to fill in values to various fields or use field values to determine where to transfer data from or to.

## 19.3.2 Define Documentation

### 19.3.2.1 TFTP\_BLOCK\_SIZE

**Definition:**

```
#define TFTP_BLOCK_SIZE
```

**Description:**

Data transfer under TFTP is performed using fixed-size blocks. This label defines the size of a block of TFTP data.

## 19.3.3 Typedef Documentation

### 19.3.3.1 tTFTPConnection

**Definition:**

```
typedef struct _tTFTPConnection tTFTPConnection
```

**Description:**

The TFTP connection control structure. This is passed to a client on all callbacks relating to a given TFTP connection. Depending upon the callback, the client may need to fill in values to various fields or use field values to determine where to transfer data from or to.

## 19.3.4 Enumeration Documentation

### 19.3.4.1 tTFTPError

**Description:**

TFTP error codes. Note that this enum is mapped so that all positive values match the TFTP protocol-defined error codes.

### 19.3.4.2 enum tTFTPMode

TFTP file transfer modes. This enum contains members defining ASCII text transfer mode (TFTP\_MODE\_NETASCII), binary transfer mode (TFTP\_MODE\_OCTET) and a marker for an invalid mode (TFTP\_MODE\_INVALID).



## 19.3.5 Function Documentation

### 19.3.5.1 void TFTPInit (tTFTPRequest *pfnRequest*)

Initializes the TFTP server module.

**Parameters:**

***pfnRequest*** - A pointer to the function which the server will call whenever a new incoming TFTP request is received. This function must determine whether the request can be handled and return a value telling the server whether to continue processing the request or ignore it.

This function initializes the lwIP TFTP server and starts listening for incoming requests from clients. It must be called after the network stack is initialized using a call to [lwIPInit\(\)](#).

**Returns:**

None.



## 20 Micro Standard Library Module

Introduction .....	139
API Functions .....	139
Programming Example .....	148

### 20.1 Introduction

The micro standard library module provides a set of small implementations of functions normally found in the C library. These functions provide reduced or greatly reduced functionality in order to remain small while still being useful for most embedded applications.

The following functions are provided, along with the C library equivalent:

Function	C library equivalent
<code>usprintf</code>	<code>sprintf</code>
<code>usnprintf</code>	<code>snprintf</code>
<code>uvsnprintf</code>	<code>vsnprintf</code>
<code>ustrnicmp</code>	<code>strnicmp</code>
<code>ustrtoul</code>	<code>strtoul</code>
<code>ustrstr</code>	<code>strstr</code>
<code>ulocaltime</code>	<code>localtime</code>

This module is contained in `utils/ustdlib.c`, with `utils/ustdlib.h` containing the API definitions for use by applications.

### 20.2 API Functions

#### Data Structures

- [tTime](#)

#### Functions

- void [ulocaltime](#) (unsigned long ulTime, [tTime](#) \*psTime)
- unsigned long [umktime](#) ([tTime](#) \*psTime)
- int [urand](#) (void)
- int [usnprintf](#) (char \*pcBuf, unsigned long ulSize, const char \*pcString,...)
- int [usprintf](#) (char \*pcBuf, const char \*pcString,...)
- void [usrand](#) (unsigned long ulSeed)
- int [ustrcasecmp](#) (const char \*pcStr1, const char \*pcStr2)
- int [ustrcmp](#) (const char \*pcStr1, const char \*pcStr2)
- int [ustrlen](#) (const char \*pcStr)
- int [ustrncmp](#) (const char \*pcStr1, const char \*pcStr2, int iCount)

- char \* [ustrncpy](#) (char \*pcDst, const char \*pcSrc, int iNum)
- int [ustrnicmp](#) (const char \*pcStr1, const char \*pcStr2, int iCount)
- char \* [ustrstr](#) (const char \*pcHaystack, const char \*pcNeedle)
- unsigned long [ustrtoul](#) (const char \*pcStr, const char \*\*ppcStrRet, int iBase)
- int [uvsnprintf](#) (char \*pcBuf, unsigned long ulSize, const char \*pcString, va\_list vaArgP)

## 20.2.1 Data Structure Documentation

### 20.2.1.1 tTime

**Definition:**

```
typedef struct
{
    unsigned short usYear;
    unsigned char ucMon;
    unsigned char ucMday;
    unsigned char ucWday;
    unsigned char ucHour;
    unsigned char ucMin;
    unsigned char ucSec;
}
tTime
```

**Members:**

- usYear** The number of years since 0 AD.
- ucMon** The month, where January is 0 and December is 11.
- ucMday** The day of the month.
- ucWday** The day of the week, where Sunday is 0 and Saturday is 6.
- ucHour** The number of hours.
- ucMin** The number of minutes.
- ucSec** The number of seconds.

**Description:**

A structure that contains the broken down date and time.

## 20.2.2 Function Documentation

### 20.2.2.1 ulocaltime

Converts from seconds to calendar date and time.

**Prototype:**

```
void
ulocaltime(unsigned long ulTime,
            tTime *psTime)
```

**Parameters:**

- ulTime** is the number of seconds.
- psTime** is a pointer to the time structure that is filled in with the broken down date and time.

**Description:**

This function converts a number of seconds since midnight GMT on January 1, 1970 (traditional Unix epoch) into the equivalent month, day, year, hours, minutes, and seconds representation.

**Returns:**

None.

### 20.2.2.2 umktime

Converts calendar date and time to seconds.

**Prototype:**

```
unsigned long  
umktime(tTime *psTime)
```

**Parameters:**

*psTime* is a pointer to the time structure that is filled in with the broken down date and time.

**Description:**

This function converts the date and time represented by the *psTime* structure pointer to the number of seconds since midnight GMT on January 1, 1970 (traditional Unix epoch).

**Returns:**

Returns the calendar time and date as seconds. If the conversion was not possible then the function returns (unsigned long)(-1).

### 20.2.2.3 urand

Generate a new (pseudo) random number

**Prototype:**

```
int  
urand(void)
```

**Description:**

This function is very similar to the C library `rand()` function. It will generate a pseudo-random number sequence based on the seed value.

**Returns:**

A pseudo-random number will be returned.

### 20.2.2.4 usnprintf

A simple `snprintf` function supporting %c, %d, %p, %s, %u, %x, and %X.

**Prototype:**

```
int  
usnprintf(char *pcBuf,  
          unsigned long ulSize,  
          const char *pcString,  
          ...)
```

**Parameters:**

***pcBuf*** is the buffer where the converted string is stored.

***ulSize*** is the size of the buffer.

***pcString*** is the format string.

... are the optional arguments, which depend on the contents of the format string.

**Description:**

This function is very similar to the C library `sprintf()` function. Only the following formatting characters are supported:

- `%c` to print a character
- `%d` or `%i` to print a decimal value
- `%s` to print a string
- `%u` to print an unsigned decimal value
- `%x` to print a hexadecimal value using lower case letters
- `%X` to print a hexadecimal value using upper case letters (not lower case letters as would typically be used)
- `%p` to print a pointer as a hexadecimal value
- `%%` to print out a `%` character

For `%d`, `%i`, `%p`, `%s`, `%u`, `%x`, and `%X`, an optional number may reside between the `%` and the format character, which specifies the minimum number of characters to use for that value; if preceded by a 0 then the extra characters will be filled with zeros instead of spaces. For example, `"%8d"` will use eight characters to print the decimal value with spaces added to reach eight; `"%08d"` will use eight characters as well but will add zeros instead of spaces.

The type of the arguments after *pcString* must match the requirements of the format string. For example, if an integer was passed where a string was expected, an error of some kind will most likely occur.

The function will copy at most *ulSize* - 1 characters into the buffer *pcBuf*. One space is reserved in the buffer for the null termination character.

The function will return the number of characters that would be converted as if there were no limit on the buffer size. Therefore it is possible for the function to return a count that is greater than the specified buffer size. If this happens, it means that the output was truncated.

**Returns:**

Returns the number of characters that were to be stored, not including the NULL termination character, regardless of space in the buffer.

### 20.2.2.5 `usprintf`

A simple `sprintf` function supporting `%c`, `%d`, `%p`, `%s`, `%u`, `%x`, and `%X`.

**Prototype:**

```
int
usprintf(char *pcBuf,
         const char *pcString,
         ...)
```

**Parameters:**

***pcBuf*** is the buffer where the converted string is stored.

***pcString*** is the format string.

... are the optional arguments, which depend on the contents of the format string.

**Description:**

This function is very similar to the C library `sprintf()` function. Only the following formatting characters are supported:

- `%c` to print a character
- `%d` or `%i` to print a decimal value
- `%s` to print a string
- `%u` to print an unsigned decimal value
- `%x` to print a hexadecimal value using lower case letters
- `%X` to print a hexadecimal value using upper case letters (not lower case letters as would typically be used)
- `%p` to print a pointer as a hexadecimal value
- `%%` to print out a `%` character

For `%d`, `%i`, `%p`, `%s`, `%u`, `%x`, and `%X`, an optional number may reside between the `%` and the format character, which specifies the minimum number of characters to use for that value; if preceded by a 0 then the extra characters will be filled with zeros instead of spaces. For example, `"%8d"` will use eight characters to print the decimal value with spaces added to reach eight; `"%08d"` will use eight characters as well but will add zeros instead of spaces.

The type of the arguments after *pcString* must match the requirements of the format string. For example, if an integer was passed where a string was expected, an error of some kind will most likely occur.

The caller must ensure that the buffer *pcBuf* is large enough to hold the entire converted string, including the null termination character.

**Returns:**

Returns the count of characters that were written to the output buffer, not including the NULL termination character.

## 20.2.2.6 `usrand`

Set the random number generator seed.

**Prototype:**

```
void  
usrand(unsigned long ulSeed)
```

**Parameters:**

***ulSeed*** is the new seed value to use for the random number generator.

**Description:**

This function is very similar to the C library `srand()` function. It will set the seed value used in the `urand()` function.

**Returns:**

None

### 20.2.2.7 `ustrcasecmp`

Compares two strings without regard to case.

**Prototype:**

```
int
ustrcasecmp(const char *pcStr1,
             const char *pcStr2)
```

**Parameters:**

***pcStr1*** points to the first string to be compared.

***pcStr2*** points to the second string to be compared.

**Description:**

This function is very similar to the C library `strcasecmp()` function. It compares two strings without regard to case. The comparison ends if a terminating NULL character is found in either string. In this case, the shorter string is deemed the lesser.

**Returns:**

Returns 0 if the two strings are equal, -1 if *pcStr1* is less than *pcStr2* and 1 if *pcStr1* is greater than *pcStr2*.

### 20.2.2.8 `ustrcmp`

Compares two strings.

**Prototype:**

```
int
ustrcmp(const char *pcStr1,
         const char *pcStr2)
```

**Parameters:**

***pcStr1*** points to the first string to be compared.

***pcStr2*** points to the second string to be compared.

**Description:**

This function is very similar to the C library `strcmp()` function. It compares two strings, taking case into account. The comparison ends if a terminating NULL character is found in either string. In this case, the shorter string is deemed the lesser.

**Returns:**

Returns 0 if the two strings are equal, -1 if *pcStr1* is less than *pcStr2* and 1 if *pcStr1* is greater than *pcStr2*.

### 20.2.2.9 `ustrlen`

Retruns the length of a null-terminated string.

**Prototype:**

```
int
ustrlen(const char *pcStr)
```



**Parameters:**

***pcStr*** is a pointer to the string whose length is to be found.

**Description:**

This function is very similar to the C library `strlen()` function. It determines the length of the null-terminated string passed and returns this to the caller.

This implementation assumes that single byte character strings are passed and will return incorrect values if passed some UTF-8 strings.

**Returns:**

Returns the length of the string pointed to by *pcStr*.

### 20.2.2.10 `ustrncmp`

Compares two strings.

**Prototype:**

```
int
ustrncmp(const char *pcStr1,
         const char *pcStr2,
         int iCount)
```

**Parameters:**

***pcStr1*** points to the first string to be compared.

***pcStr2*** points to the second string to be compared.

***iCount*** is the maximum number of characters to compare.

**Description:**

This function is very similar to the C library `strncmp()` function. It compares at most *iCount* characters of two strings taking case into account. The comparison ends if a terminating NULL character is found in either string before *iCount* characters are compared. In this case, the shorter string is deemed the lesser.

**Returns:**

Returns 0 if the two strings are equal, -1 if *pcStr1* is less than *pcStr2* and 1 if *pcStr1* is greater than *pcStr2*.

### 20.2.2.11 `ustrncpy`

Copies a certain number of characters from one string to another.

**Prototype:**

```
char *
ustrncpy(char *pcDst,
         const char *pcSrc,
         int iNum)
```

**Parameters:**

***pcDst*** is a pointer to the destination buffer into which characters are to be copied.

***pcSrc*** is a pointer to the string from which characters are to be copied.

***iNum*** is the number of characters to copy to the destination buffer.

**Description:**

This function copies at most *iNum* characters from the string pointed to by *pcSrc* into the buffer pointed to by *pcDst*. If the end of *pcSrc* is found before *iNum* characters have been copied, remaining characters in *pcDst* will be padded with zeroes until *iNum* characters have been written. Note that the destination string will only be NULL terminated if the number of characters to be copied is greater than the length of *pcSrc*.

**Returns:**

Returns *pcDst*.

### 20.2.2.12 ustrnicmp

Compares two strings without regard to case.

**Prototype:**

```
int
ustrnicmp(const char *pcStr1,
          const char *pcStr2,
          int iCount)
```

**Parameters:**

***pcStr1*** points to the first string to be compared.

***pcStr2*** points to the second string to be compared.

***iCount*** is the maximum number of characters to compare.

**Description:**

This function is very similar to the C library `strnicmp()` function. It compares at most *iCount* characters of two strings without regard to case. The comparison ends if a terminating NULL character is found in either string before *iCount* characters are compared. In this case, the shorter string is deemed the lesser.

**Returns:**

Returns 0 if the two strings are equal, -1 if *pcStr1* is less than *pcStr2* and 1 if *pcStr1* is greater than *pcStr2*.

### 20.2.2.13 ustrstr

Finds a substring within a string.

**Prototype:**

```
char *
ustrstr(const char *pcHaystack,
        const char *pcNeedle)
```

**Parameters:**

***pcHaystack*** is a pointer to the string that will be searched.

***pcNeedle*** is a pointer to the substring that is to be found within *pcHaystack*.

**Description:**

This function is very similar to the C library `strstr()` function. It scans a string for the first instance of a given substring and returns a pointer to that substring. If the substring cannot be found, a NULL pointer is returned.

**Returns:**

Returns a pointer to the first occurrence of *pcNeedle* within *pcHaystack* or NULL if no match is found.

### 20.2.2.14 strtoul

Converts a string into its numeric equivalent.

**Prototype:**

```
unsigned long
strtoul(const char *pcStr,
        const char **ppcStrRet,
        int iBase)
```

**Parameters:**

**pcStr** is a pointer to the string containing the integer.

**ppcStrRet** is a pointer that will be set to the first character past the integer in the string.

**iBase** is the radix to use for the conversion; can be zero to auto-select the radix or between 2 and 16 to explicitly specify the radix.

**Description:**

This function is very similar to the C library `strtoul()` function. It scans a string for the first token (that is, non-white space) and converts the value at that location in the string into an integer value.

**Returns:**

Returns the result of the conversion.

### 20.2.2.15 uvsnprintf

A simple `vsnprintf` function supporting %c, %d, %p, %s, %u, %x, and %X.

**Prototype:**

```
int
uvsnprintf(char *pcBuf,
            unsigned long ulSize,
            const char *pcString,
            va_list vaArgP)
```

**Parameters:**

**pcBuf** points to the buffer where the converted string is stored.

**ulSize** is the size of the buffer.

**pcString** is the format string.

**vaArgP** is the list of optional arguments, which depend on the contents of the format string.

**Description:**

This function is very similar to the C library `vsnprintf()` function. Only the following formatting characters are supported:

- `%c` to print a character
- `%d` or `%i` to print a decimal value
- `%s` to print a string
- `%u` to print an unsigned decimal value
- `%x` to print a hexadecimal value using lower case letters
- `%X` to print a hexadecimal value using upper case letters (not lower case letters as would typically be used)
- `%p` to print a pointer as a hexadecimal value
- `%%` to print out a `%` character

For `%d`, `%i`, `%p`, `%s`, `%u`, `%x`, and `%X`, an optional number may reside between the `%` and the format character, which specifies the minimum number of characters to use for that value; if preceded by a 0 then the extra characters will be filled with zeros instead of spaces. For example, `"%8d"` will use eight characters to print the decimal value with spaces added to reach eight; `"%08d"` will use eight characters as well but will add zeroes instead of spaces.

The type of the arguments after *pcString* must match the requirements of the format string. For example, if an integer was passed where a string was expected, an error of some kind will most likely occur.

The *ulSize* parameter limits the number of characters that will be stored in the buffer pointed to by *pcBuf* to prevent the possibility of a buffer overflow. The buffer size should be large enough to hold the expected converted output string, including the null termination character.

The function will return the number of characters that would be converted as if there were no limit on the buffer size. Therefore it is possible for the function to return a count that is greater than the specified buffer size. If this happens, it means that the output was truncated.

**Returns:**

Returns the number of characters that were to be stored, not including the NULL termination character, regardless of space in the buffer.

## 20.3 Programming Example

The following example shows how to use some of the micro standard library functions.

```
unsigned long ulValue;
char pcBuffer[32];
tTime sTime;

//
// Convert the number in pcBuffer (previous read from somewhere) into an
// integer. Note that this supports converting decimal values (such as
// 4583), octal values (such as 036583), and hexadecimal values (such as
// 0x3425).
//
ulValue = strtoul(pcBuffer, 0, 0);

//
// Convert that integer from a number of seconds into a broken down date.
```

```
//
ulocaltime(ulValue, &sTime);

//
// Print out the corresponding time of day in military format.
//
usprintf(pcBuffer, "%02d:%02d", sTime.ucHour, sTime.ucMin);
```



## 21 UART Standard IO Module

Introduction .....	151
API Functions .....	152
Programming Example .....	159

### 21.1 Introduction

The UART standard IO module provides a simple interface to a UART that is similar to the standard IO package available in the C library. Only a very small subset of the normal functions are provided; [UARTprintf\(\)](#) is an equivalent to the C library `printf()` function and [UARTgets\(\)](#) is an equivalent to the C library `fgets()` function.

This module is contained in `utils/uartstdio.c`, with `utils/uartstdio.h` containing the API definitions for use by applications.

#### 21.1.1 Unbuffered Operation

Unbuffered operation is selected by not defining **UART\_BUFFERED** when building the UART standard IO module. In unbuffered mode, calls to the module will not return until the operation has been completed. So, for example, a call to [UARTprintf\(\)](#) will not return until the entire string has been placed into the UART's FIFO. If it is not possible for the function to complete its operation immediately, it will busy wait.

#### 21.1.2 Buffered Operation

Buffered operation is selected by defining **UART\_BUFFERED** when building the UART standard IO module. In buffered mode, there is a larger UART data FIFO in SRAM that extends the size of the hardware FIFO. Interrupts from the UART are used to transfer data between the SRAM buffer and the hardware FIFO. It is the responsibility of the application to ensure that [UARTStdioIntHandler\(\)](#) is called when the UART interrupt occurs; typically this is accomplished by placing it in the vector table in the startup code for the application.

In addition providing a larger UART buffer, the behavior of [UARTprintf\(\)](#) is slightly modified. If the output buffer is full, [UARTprintf\(\)](#) will discard the remaining characters from the string instead of waiting until space becomes available in the buffer. If this behavior is not desired, [UARTFlushTx\(\)](#) may be called to ensure that the transmit buffer is emptied prior to adding new data via [UARTprintf\(\)](#) (though this will not work if the string to be printed is larger than the buffer).

[UARTPeek\(\)](#) can be used to determine whether a line end is present prior to calling [UARTgets\(\)](#) if non-blocking operation is required. In cases where the buffer supplied on [UARTgets\(\)](#) fills before a line termination character is received, the call will return with a full buffer.

## 21.2 API Functions

### Functions

- void [UARTEchoSet](#) (tBoolean bEnable)
- void [UARTFlushRx](#) (void)
- void [UARTFlushTx](#) (tBoolean bDiscard)
- unsigned char [UARTgetc](#) (void)
- int [UARTgets](#) (char \*pcBuf, unsigned long ulLen)
- int [UARTPeek](#) (unsigned char ucChar)
- void [UARTprintf](#) (const char \*pcString,...)
- int [UARTRxBytesAvail](#) (void)
- void [UARTStdioConfig](#) (unsigned long ulPortNum, unsigned long ulBaud, unsigned long ulSrcClock)
- void [UARTStdioInit](#) (unsigned long ulPortNum)
- void [UARTStdioInitExpClk](#) (unsigned long ulPortNum, unsigned long ulBaud)
- void [UARTStdioIntHandler](#) (void)
- int [UARTTxBytesFree](#) (void)
- int [UARTwrite](#) (const char \*pcBuf, unsigned long ulLen)

### 21.2.1 Function Documentation

#### 21.2.1.1 UARTEchoSet

Enables or disables echoing of received characters to the transmitter.

**Prototype:**

```
void
UARTEchoSet (tBoolean bEnable)
```

**Parameters:**

**bEnable** must be set to **true** to enable echo or **false** to disable it.

**Description:**

This function, available only when the module is built to operate in buffered mode using **UART\_BUFFERED**, may be used to control whether or not received characters are automatically echoed back to the transmitter. By default, echo is enabled and this is typically the desired behavior if the module is being used to support a serial command line. In applications where this module is being used to provide a convenient, buffered serial interface over which application-specific binary protocols are being run, however, echo may be undesirable and this function can be used to disable it.

**Returns:**

None.



### 21.2.1.2 UARTFlushRx

Flushes the receive buffer.

**Prototype:**

```
void  
UARTFlushRx(void)
```

**Description:**

This function, available only when the module is built to operate in buffered mode using **UART\_BUFFERED**, may be used to discard any data received from the UART but not yet read using [UARTgets\(\)](#).

**Returns:**

None.

### 21.2.1.3 UARTFlushTx

Flushes the transmit buffer.

**Prototype:**

```
void  
UARTFlushTx(tBoolean bDiscard)
```

**Parameters:**

**bDiscard** indicates whether any remaining data in the buffer should be discarded (**true**) or transmitted (**false**).

**Description:**

This function, available only when the module is built to operate in buffered mode using **UART\_BUFFERED**, may be used to flush the transmit buffer, either discarding or transmitting any data received via calls to [UARTprintf\(\)](#) that is waiting to be transmitted. On return, the transmit buffer will be empty.

**Returns:**

None.

### 21.2.1.4 UARTgetc

Read a single character from the UART, blocking if necessary.

**Prototype:**

```
unsigned char  
UARTgetc(void)
```

**Description:**

This function will receive a single character from the UART and store it at the supplied address.

In both buffered and unbuffered modes, this function will block until a character is received. If non-blocking operation is required in buffered mode, a call to [UARTRxAvail\(\)](#) may be made to determine whether any characters are currently available for reading.

**Returns:**

Returns the character read.

### 21.2.1.5 UARTgets

A simple UART based get string function, with some line processing.

**Prototype:**

```
int
UARTgets(char *pcBuf,
          unsigned long ulLen)
```

**Parameters:**

**pcBuf** points to a buffer for the incoming string from the UART.

**ulLen** is the length of the buffer for storage of the string, including the trailing 0.

**Description:**

This function will receive a string from the UART input and store the characters in the buffer pointed to by *pcBuf*. The characters will continue to be stored until a termination character is received. The termination characters are CR, LF, or ESC. A CRLF pair is treated as a single termination character. The termination characters are not stored in the string. The string will be terminated with a 0 and the function will return.

In both buffered and unbuffered modes, this function will block until a termination character is received. If non-blocking operation is required in buffered mode, a call to [UARTPeek\(\)](#) may be made to determine whether a termination character already exists in the receive buffer prior to calling [UARTgets\(\)](#).

Since the string will be null terminated, the user must ensure that the buffer is sized to allow for the additional null character.

**Returns:**

Returns the count of characters that were stored, not including the trailing 0.

### 21.2.1.6 UARTPeek

Looks ahead in the receive buffer for a particular character.

**Prototype:**

```
int
UARTPeek(unsigned char ucChar)
```

**Parameters:**

**ucChar** is the character that is to be searched for.

**Description:**

This function, available only when the module is built to operate in buffered mode using **UART\_BUFFERED**, may be used to look ahead in the receive buffer for a particular character and report its position if found. It is typically used to determine whether a complete line of user input is available, in which case ucChar should be set to CR ('\r') which is used as the line end marker in the receive buffer.

**Returns:**

Returns -1 to indicate that the requested character does not exist in the receive buffer. Returns a non-negative number if the character was found in which case the value represents the position of the first instance of *ucChar* relative to the receive buffer read pointer.

### 21.2.1.7 UARTprintf

A simple UART based printf function supporting %c, %d, %p, %s, %u, %x, and %X.

**Prototype:**

```
void
UARTprintf(const char *pcString,
           ...)
```

**Parameters:**

***pcString*** is the format string.

... are the optional arguments, which depend on the contents of the format string.

**Description:**

This function is very similar to the C library `fprintf()` function. All of its output will be sent to the UART. Only the following formatting characters are supported:

- %c to print a character
- %d or %i to print a decimal value
- %s to print a string
- %u to print an unsigned decimal value
- %x to print a hexadecimal value using lower case letters
- %X to print a hexadecimal value using upper case letters (not lower case letters as would typically be used)
- %p to print a pointer as a hexadecimal value
- %% to print out a % character

For %s, %d, %i, %u, %p, %x, and %X, an optional number may reside between the % and the format character, which specifies the minimum number of characters to use for that value; if preceded by a 0 then the extra characters will be filled with zeros instead of spaces. For example, "%8d" will use eight characters to print the decimal value with spaces added to reach eight; "%08d" will use eight characters as well but will add zeroes instead of spaces.

The type of the arguments after *pcString* must match the requirements of the format string. For example, if an integer was passed where a string was expected, an error of some kind will most likely occur.

**Returns:**

None.

### 21.2.1.8 UARTRxBytesAvail

Returns the number of bytes available in the receive buffer.

**Prototype:**

```
int
UARTRxBytesAvail(void)
```

**Description:**

This function, available only when the module is built to operate in buffered mode using **UART\_BUFFERED**, may be used to determine the number of bytes of data currently available in the receive buffer.

**Returns:**

Returns the number of available bytes.

### 21.2.1.9 UARTStdioConfig

Configures the UART console.

**Prototype:**

```
void
UARTStdioConfig(unsigned long ulPortNum,
                 unsigned long ulBaud,
                 unsigned long ulSrcClock)
```

**Parameters:**

***ulPortNum*** is the number of UART port to use for the serial console (0-2)

***ulBaud*** is the bit rate that the UART is to be configured to use.

***ulSrcClock*** is the frequency of the source clock for the UART module.

**Description:**

This function will configure the specified serial port to be used as a serial console. The serial parameters are set to the baud rate specified by the *ulBaud* parameter and use 8 bit, no parity, and 1 stop bit.

This function must be called prior to using any of the other UART console functions: [UART-printf\(\)](#) or [UARTgets\(\)](#). This function assumes that the caller has previously configured the relevant UART pins for operation as a UART rather than as GPIOs.

**Returns:**

None.

### 21.2.1.10 UARTStdioInit

Initializes the UART console.

**Prototype:**

```
void
UARTStdioInit(unsigned long ulPortNum)
```

**Parameters:**

***ulPortNum*** is the number of UART port to use for the serial console (0-2)

**Description:**

This function will initialize the specified serial port to be used as a serial console. The serial parameters will be set to 115200, 8-N-1. An application wishing to use a different baud rate may call [UARTStdioInitExpClk\(\)](#) instead of this function.

This function or [UARTStdioInitExpClk\(\)](#) must be called prior to using any of the other UART console functions: [UARTprintf\(\)](#) or [UARTgets\(\)](#). In order for this function to work correctly, [SysCtlClockSet\(\)](#) must be called prior to calling this function.

It is assumed that the caller has previously configured the relevant UART pins for operation as a UART rather than as GPIOs.

**Returns:**

None.

### 21.2.1.11 UARTStdioInitExpClk

Initializes the UART console and allows the baud rate to be selected.

**Prototype:**

```
void
UARTStdioInitExpClk(unsigned long ulPortNum,
                    unsigned long ulBaud)
```

**Parameters:**

***ulPortNum*** is the number of UART port to use for the serial console (0-2)

***ulBaud*** is the bit rate that the UART is to be configured to use.

**Description:**

This function will initialize the specified serial port to be used as a serial console. The serial parameters will be set to 8-N-1 and the bit rate set according to the value of the *ulBaud* parameter.

This function or [UARTStdioInit\(\)](#) must be called prior to using any of the other UART console functions: [UARTprintf\(\)](#) or [UARTgets\(\)](#). In order for this function to work correctly, [SysCtlClockSet\(\)](#) must be called prior to calling this function. An application wishing to use 115,200 baud may call [UARTStdioInit\(\)](#) instead of this function but should not call both functions.

It is assumed that the caller has previously configured the relevant UART pins for operation as a UART rather than as GPIOs.

**Returns:**

None.

### 21.2.1.12 UARTStdioIntHandler

Handles UART interrupts.

**Prototype:**

```
void
UARTStdioIntHandler(void)
```

**Description:**

This function handles interrupts from the UART. It will copy data from the transmit buffer to the UART transmit FIFO if space is available, and it will copy data from the UART receive FIFO to the receive buffer if data is available.

**Returns:**

None.

### 21.2.1.13 UARTTxBytesFree

Returns the number of bytes free in the transmit buffer.

**Prototype:**

```
int
UARTTxBytesFree(void)
```

**Description:**

This function, available only when the module is built to operate in buffered mode using **UART\_BUFFERED**, may be used to determine the amount of space currently available in the transmit buffer.

**Returns:**

Returns the number of free bytes.

### 21.2.1.14 UARTwrite

Writes a string of characters to the UART output.

**Prototype:**

```
int
UARTwrite(const char *pcBuf,
          unsigned long ulLen)
```

**Parameters:**

**pcBuf** points to a buffer containing the string to transmit.

**ulLen** is the length of the string to transmit.

**Description:**

This function will transmit the string to the UART output. The number of characters transmitted is determined by the *ulLen* parameter. This function does no interpretation or translation of any characters. Since the output is sent to a UART, any LF (/n) characters encountered will be replaced with a CRLF pair.

Besides using the *ulLen* parameter to stop transmitting the string, if a null character (0) is encountered, then no more characters will be transmitted and the function will return.

In non-buffered mode, this function is blocking and will not return until all the characters have been written to the output FIFO. In buffered mode, the characters are written to the UART transmit buffer and the call returns immediately. If insufficient space remains in the transmit buffer, additional characters are discarded.

**Returns:**

Returns the count of characters written.

## 21.3 Programming Example

The following example shows how to use the UART standard IO module to write a string to the UART “console”.

```
//  
// Configure the appropriate pins as UART pins; in this case, PA0/PA1 are  
// used for UART0.  
//  
SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOA);  
GPIOPinTypeUART(GPIO_PORTA_BASE, GPIO_PIN_0 | GPIO_PIN_1);  
  
//  
// Initialize the UART standard IO module.  
//  
UARTStdioInit(0);  
  
//  
// Print a string.  
//  
UARTprintf("Hello world!\n");
```

---

# IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

## Products

Audio	<a href="http://www.ti.com/audio">www.ti.com/audio</a>
Amplifiers	<a href="http://amplifier.ti.com">amplifier.ti.com</a>
Data Converters	<a href="http://dataconverter.ti.com">dataconverter.ti.com</a>
DLP® Products	<a href="http://www.dlp.com">www.dlp.com</a>
DSP	<a href="http://dsp.ti.com">dsp.ti.com</a>
Clocks and Timers	<a href="http://www.ti.com/clocks">www.ti.com/clocks</a>
Interface	<a href="http://interface.ti.com">interface.ti.com</a>
Logic	<a href="http://logic.ti.com">logic.ti.com</a>
Power Mgmt	<a href="http://power.ti.com">power.ti.com</a>
Microcontrollers	<a href="http://microcontroller.ti.com">microcontroller.ti.com</a>
RFID	<a href="http://www.ti-rfid.com">www.ti-rfid.com</a>
OMAP Mobile Processors	<a href="http://www.ti.com/omap">www.ti.com/omap</a>
Wireless Connectivity	<a href="http://www.ti.com/wirelessconnectivity">www.ti.com/wirelessconnectivity</a>

## Applications

Automotive and Transportation	<a href="http://www.ti.com/automotive">www.ti.com/automotive</a>
Communications and Telecom	<a href="http://www.ti.com/communications">www.ti.com/communications</a>
Computers and Peripherals	<a href="http://www.ti.com/computers">www.ti.com/computers</a>
Consumer Electronics	<a href="http://www.ti.com/consumer-apps">www.ti.com/consumer-apps</a>
Energy and Lighting	<a href="http://www.ti.com/energy">www.ti.com/energy</a>
Industrial	<a href="http://www.ti.com/industrial">www.ti.com/industrial</a>
Medical	<a href="http://www.ti.com/medical">www.ti.com/medical</a>
Security	<a href="http://www.ti.com/security">www.ti.com/security</a>
Space, Avionics and Defense	<a href="http://www.ti.com/space-avionics-defense">www.ti.com/space-avionics-defense</a>
Video and Imaging	<a href="http://www.ti.com/video">www.ti.com/video</a>

**TI E2E Community Home Page**

[e2e.ti.com](http://e2e.ti.com)

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2009-2013, Texas Instruments Incorporated