

Function		Transmitted	Recognized	Remarks
Basic Channel	Default	3 (Synth), 16 (Program Change) 1–16	3 (Synth), 16 (Program Change) 1–16	Memorized
	Changed			
Mode	Default	Mode 3 x x	Mode 3 x x	
	Messages Altered			
Note Number	: True Voice	0–127	0–127	
Velocity	Note On	o	o	
	Note Off	x	x	
After Touch	Key's	x	x	
	Channel's	x	x	
Pitch Bend		x	o	
Control Change	1	x	o	For details, refer to “Control change list”.
	3	o	o	
	5	o	o	
	10	x	o	
	11	x	o	
	12–31	o	o	
	64, 65	x	o	
	71–76	o	o	
	77	x	o	
	78–83	o	o	
	85–87	o	o	
	89–93	o	o	
	102–107	o	o	
Program Change		o	o	
	: True Number	0–63	0–63	
System Exclusive		x	x	
System Common	: Song Position	x	x	
	: Song Select	x	x	
	: Tune Request	x	x	
System Real Time	: Clock	o	o	
	: Start	o	o	
	: Continue	x	x	
	: Stop	o	o	
Aux Message	: All Sound Off	o	o	Transmitted: MIDI OFFLINE
	: Reset All Controllers	x	o	
	: All Notes Off	x	o	
	: Omni Mode Off	x	x	
	: Omni Mode On	x	x	
	: Mono Mode On	x	x	
	: Poly Mode On	x	x	
	: Active Sensing	o	o	
	: System Reset	x	x	