


# WIPER AND WASHER

## WINDSHIELD WIPER LINK REMOVAL/INSTALLATION

X5U919W05

1. Remove the windshield wiper arm and blade.  
(Refer to 09-19 WINDSHIELD WIPER ARM AND BLADE REMOVAL/INSTALLATION, Windshield Wiper Arm Installation Note.)
2. Remove the cowl grille.
3. Pry off the connection between the windshield wiper motor and the windshield wiper link.
4. Remove in the order indicated in the table.
5. Install in the reverse order of removal.
6. Adjust the windshield wiper arm and blade. (Refer to 09-19 WINDSHIELD WIPER ARM AND BLADE ADJUSTMENT.)



1	Nut
2	Windshield wiper link



## WINDSHIELD WIPER MOTOR REMOVAL/INSTALLATION

X5U919W01

1. Disconnect the negative battery cable.
2. Pry off the connection between the windshield wiper motor and windshield wiper link.
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.

### Windshield Wiper Motor Removal Note

- Rotate the windshield wiper motor counterclockwise and then remove it.




1	Windshield wiper motor connector
2	Bolt
3	Windshield wiper motor ☞ Removal Note

## WINDSHIELD WIPER MOTOR INSPECTION

X5U919W02

1. Disconnect the windshield wiper motor connector.
2. Apply battery positive voltage and inspect the operation of the windshield wiper motor as indicated below.

Terminal	Operation
A	High
C	Low



3. Connect the windshield wiper motor connector.


## WIPER AND WASHER

- Turn the ignition switch to ON and turn the windshield wiper switch on.
- Turn the ignition switch to LOCK while the windshield wipers are operating.
- Verify that the windshield wipers do not stop in the park position.
- Disconnect the windshield wiper motor connector.
- Inspect for continuity between the windshield wiper motor terminals by using an ohmmeter.

○—○ : Continuity

Windshield wiper motor position	Terminal				Body GND
	C	A	B	D	
Except park position			○—○		
Park position	○—○	○—○			○—○

X5U919WA1



X5U919WA2


- Connect the windshield wiper motor connector.

- Turn the ignition switch to ON and turn the windshield wiper switch on.
- Turn the windshield wiper switch off while the windshield wipers are operating.
- Verify that the windshield wipers stop in the park position.
- Disconnect the windshield wiper motor connector.
- Inspect for continuity between the windshield wiper motor terminals by using an ohmmeter.

○—○ : Continuity

Windshield wiper motor position	Terminal			Body GND
	A	B	C	
Park position	○—○	○—○	○—○	○—○

X5U919WA3




X5U919WA4

- If not as specified, replace the windshield wiper motor.


## WINDSHIELD WASHER TANK REMOVAL/INSTALLATION

- Disconnect the negative battery cable.
- Remove in the order indicated in the table.
- Install in the reverse order of removal.


### EXCEPT CANADA: WITH ABS



### EXCEPT CANADA: WITHOUT ABS



### CANADA



1	Windshield washer motor connector
2	Windshield washer pipe
3	Bolt
4	Windshield washer tank


# WIPER AND WASHER

## WINDSHIELD WASHER MOTOR REMOVAL/INSTALLATION


X5U919W07

1. Disconnect the negative battery cable.
2. Remove the windshield washer tank.
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.

**EXCEPT CANADA: WITH ABS**  
**CANADA**



**EXCEPT CANADA: WITHOUT ABS**





1	Windshield washer motor
2	Grommet

## WINDSHIELD WASHER MOTOR INSPECTION

X5U919W08


1. Disconnect the windshield washer motor connector.
2. Connect battery positive voltage to the terminal B and ground to the terminal A of the motor.
3. Verify that the windshield washer motor operates.

**EXCEPT CANADA: WITH ABS**  
**CANADA**



X5U919WAF

**EXCEPT CANADA: WITHOUT ABS**



4. If the motor does not operate, replace the windshield washer motor.




# WIPER AND WASHER

## WINDSHIELD WASHER PIPE REMOVAL/INSTALLATION

X5U919W\*2


1. Remove in the order indicated in the table.
2. Install in the reverse order of removal.

**EXCEPT CANADA: WITH ABS**  
**CANADA**



X5U919WAK

**EXCEPT CANADA: WITHOUT ABS**



X5U919WAK

1	Clip
2	Joint pipe
3	Windshield washer pipe

# 09-20 ENTERTAINMENT

## DOOR SPEAKER

REMOVAL/INSTALLATION ..... 09-20-1

DOOR SPEAKER INSPECTION ..... 09-20-1

## TWEETER SPEAKER

REMOVAL/INSTALLATION ..... 09-20-2

TWEETER SPEAKER INSPECTION ... 09-20-2

## MANUAL ANTENNA

REMOVAL/INSTALLATION ..... 09-20-3

Mounting Nut Removal Note ..... 09-20-3

MANUAL ANTENNA INSPECTION .... 09-20-3

## POWER ANTENNA

REMOVAL/INSTALLATION ..... 09-20-4

Mounting Nut Removal Note ..... 09-20-4

## POWER ANTENNA

DISASSEMBLY/ASSEMBLY ..... 09-20-4

POWER ANTENNA INSPECTION ..... 09-20-5

ANTENNA MAST REMOVAL ..... 09-20-5

ANTENNA MAST INSTALLATION ..... 09-20-5

## FRONT ANTENNA FEEDER

REMOVAL/INSTALLATION ..... 09-20-6

## FRONT ANTENNA FEEDER

INSPECTION ..... 09-20-6

## REAR ANTENNA FEEDER

REMOVAL/INSTALLATION ..... 09-20-7

## REAR ANTENNA FEEDER

INSPECTION ..... 09-20-7

## AUDIO UNIT REMOVAL

INSPECTION ..... 09-20-8

## AUDIO UNIT INSTALLATION

INSPECTION ..... 09-20-8

## AUDIO AMPLIFIER

REMOVAL/INSTALLATION ..... 09-20-9

## AUDIO RELAY

REMOVAL/INSTALLATION ..... 09-20-9

AUDIO RELAY INSPECTION ..... 09-20-10

## CIGARETTE LIGHTER

REMOVAL/INSTALLATION ..... 09-20-10

Socket Removal Note ..... 09-20-10

CIGARETTE LIGHTER INSPECTION .. 09-20-10


## DOOR SPEAKER REMOVAL/INSTALLATION

X5U920W01

### Caution

- When removing or installing a door speaker, touching the radio cone paper could cause poor sound quality. When removing or installing a door speaker, hold the speaker's bracket and handle with care.

1. Disconnect the negative battery cable.
2. Remove the door trim. (Refer to 09-17 DOOR TRIM REMOVAL/INSTALLATION.)
3. Remove the screws.
4. Disconnect the door speaker connector and remove the door speaker.



X5U920WA0

5. Position the door speaker so that the terminals face downward and install in the reverse order of removal.

## DOOR SPEAKER INSPECTION

X5U920W02


1. Remove the door speaker. (Refer to 09-20 DOOR SPEAKER REMOVAL/INSTALLATION.)
2. Inspect for resistance between the door speaker terminals by using an ohmmeter.

○—○ : Resistance

Door speaker	Terminal	
	A	B
Standard type	○—○	R <sub>1</sub>
BOSE type	○—○	R <sub>2</sub>

R<sub>1</sub>: 4 Ω R<sub>2</sub>: 0.5 Ω

X5U920WA1



X5U920WA2

3. Touch the leads of an ohmmeter to the door speaker terminals and verify that the speaker clicks.

### Range

×1 Ω

4. If not as specified, replace the door speaker.


## TWEETER SPEAKER REMOVAL/INSTALLATION

X5U920WC3

### Caution

- When removing or installing a tweeter speaker, touching the radio cone paper could cause poor sound quality. When removing or installing a tweeter speaker, hold the speaker's bracket and handle with care.

1. Disconnect the negative battery cable.
2. Remove the door trim. (Refer to 09-17 DOOR TRIM REMOVAL/INSTALLATION.)
3. Remove the screws and remove the tweeter speaker.



4. Install in the reverse order of removal.

## TWEETER SPEAKER INSPECTION

X5U920CW04

1. Remove the tweeter speaker. (Refer to 09-20 TWEETER SPEAKER REMOVAL/INSTALLATION.)
2. Inspect for resistance between the tweeter speaker terminals by using an ohmmeter.

OW-O : Resistance

Test condition	Terminal	
	A	B
Constant		


R: 4 Ω

X5U920WA4

3. Touch the leads of an ohmmeter to the tweeter speaker terminals and verify that the speaker clicks.

**Range**  
× 1 Ω

4. If not as specified, replace the tweeter speaker.




X5U920WA5

## MANUAL ANTENNA REMOVAL/INSTALLATION

X5U920W09


1. Disconnect the negative battery cable.
2. Remove the trunk side trim (LH). (Refer to 09-17 TRUNK SIDE TRIM REMOVAL/INSTALLATION.)
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.



1	Rear antenna feeder
2	Mounting nut ☐ Removal Note
3	Spacer
4	Nut
5	Manual antenna

### Mounting Nut Removal Note

- Use a snap-ring pliers to remove the mounting nut.



X5U920WAD

## MANUAL ANTENNA INSPECTION


X5U920W10

1. Remove the trunk side trim (LH). (Refer to 09-17 TRUNK SIDE TRIM REMOVAL/INSTALLATION.)
2. Disconnect the connection between the rear antenna feeder and the manual antenna.
3. Verify that there is no continuity between manual antenna terminals A and B by using an ohmmeter.
4. Inspect for continuity between the manual antenna terminals by using an ohmmeter.

○—○ : Continuity

Step	Terminal			
	A	B	C	D
1	○—○		○—○	
2		○—○		○—○

X5U920WAE



X5U920WAF


5. If not as specified, replace the manual antenna.



## POWER ANTENNA REMOVAL/INSTALLATION


XEJ920W11

1. Disconnect the negative battery cable.
2. Remove the trunk side trim (LH). (Refer to 09-17 TRUNK SIDE TRIM REMOVAL/INSTALLATION.)
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.



### Mounting Nut Removal Note

- Use a snap-ring pliers to remove the mounting nut.




X5U920WAH

1	Rear antenna feeder
2	Power antenna connector
3	Drain hose
4	Mounting nut ☐ Removal Note
5	Spacer
6	Nut
7	Power antenna

## POWER ANTENNA DISASSEMBLY/ASSEMBLY

X5U920W12

1. Disassemble in the order indicated in the table.
2. Assemble in the reverse order of disassembly.




1	Drain hose
2	Screw
3	Bracket
4	Rod insulator
5	O-ring
6	Motor

## POWER ANTENNA INSPECTION

X5U92CW13

1. Remove the trunk side trim (LH). (Refer to 09-17 TRUNK SIDE TRIM REMOVAL/INSTALLATION.)
2. Disconnect the power antenna connector.
3. Connect ground to terminal H of the power antenna.
4. Connect battery positive voltage to the following terminals of the power antenna. Verify that the power antenna operated as indicated below.

Terminal		Power antenna operation
B	D	
B+	—	Down
B+	B+	Up



X5U920WAK

5. If not as specified, replace the necessary part.


## ANTENNA MAST REMOVAL

X5U920W14

### Caution

- Always remove the antenna mast with the power antenna installed in the vehicle. Removing the antenna mast from the removed power antenna may damage the power antenna or the antenna mast.

1. Use a snap-ring pliers to remove the mounting nut.



X5U920WAL

2. Turn the ignition switch to ON or ACC.
3. Audio power switch is ON.
4. To turn on the radio, press AM/FM button.
5. Pull out the antenna mast after it fully extends.

## ANTENNA MAST INSTALLATION

X5U920W15


1. Turn the ignition switch to ON or ACC.
2. Straighten the warp of rack end.
3. Audio power switch is ON.
4. To turn on the radio, press AM/FM button.
5. To turn off the radio, audio power switch is off, then immediately insert the rack into the power antenna.

6. After the antenna mast is fully retracted, tighten the mounting nut to the specification.

### Tightening torque

1.5—2.9 N·m {15—30 kgf·cm, 14—26 in·lbf}

7. Verify that the power antenna operates smoothly when the audio unit radio on.




X5U920WAM

## FRONT ANTENNA FEEDER REMOVAL/INSTALLATION

X5U920W06

1. Disconnect the negative battery cable.
2. Remove the audio unit. (Refer to 09-20 AUDIO UNIT REMOVAL.) (Refer to 09-20 AUDIO UNIT INSTALLATION.)
3. Remove the console. (Refer to 09-17 CONSOLE REMOVAL/INSTALLATION.)
4. Disconnect the connection between the front antenna feeder and the rear antenna feeder.
5. Remove in the order indicated in the table.
6. Install in the reverse order of removal.




X5U920WA8

1	Clip
2	Front antenna feeder

## FRONT ANTENNA FEEDER INSPECTION

X5U920W05

1. Disconnect the negative battery cable.
2. Remove the audio unit. (Refer to 09-20 AUDIO UNIT REMOVAL.)
3. Remove the console. (Refer to 09-17 CONSOLE REMOVAL/INSTALLATION.)
4. Disconnect the connection between front antenna feeder and the rear antenna feeder.
5. Verify that there is no continuity between front antenna feeder terminals A and B by using an ohmmeter.
6. Inspect for continuity between the front antenna feeder terminals by using an ohmmeter.



X5U920WA7

7. If not as specified, replace the front antenna feeder.

○—○ : Continuity


Step	Terminal			
	A	B	C	D
1	○—○		○—○	
2		○—○		○—○

X5U920WA6

## REAR ANTENNA FEEDER REMOVAL/INSTALLATION

X5U920W07

1. Disconnect the negative battery cable.
2. Remove the trunk side trim (LH). (Refer to 09-17 TRUNK SIDE TRIM REMOVAL/INSTALLATION.)
3. Disconnect the connection between the rear antenna feeder and the power antenna. (With manual antenna: manual antenna)
4. Remove the rear package trim. (Refer to 09-17 REAR PACKAGE TRIM REMOVAL/INSTALLATION.)
5. Turn over the floor covering from the right side. (Refer to 09-17 FLOOR COVERING REMOVAL/INSTALLATION.)
6. Disconnect the connection between the front antenna feeder and the rear antenna feeder.
7. Remove in the order indicated in the table.
8. Install in the reverse order of removal.



X5U920WA9

1	Clip
2	Fastener

3	Rear antenna feeder
---	---------------------


## REAR ANTENNA FEEDER INSPECTION

1. Remove the console. (Refer to 09-17 CONSOLE REMOVAL/INSTALLATION.)
2. Disconnect the connection between the front antenna feeder and the rear antenna feeder.
3. Remove the trunk side trim (LH). (Refer to 09-17 TRUNK SIDE TRIM REMOVAL/INSTALLATION.)
4. Disconnect the connection between the rear antenna feeder and the power antenna. (With manual antenna: manual antenna)
5. Verify that there is no continuity between rear antenna feeder terminals A and B by using an ohmmeter.
6. Inspect for continuity between the rear antenna feeder terminals by using an ohmmeter.

○—○ : Continuity

Step	Terminal			
	A	B	C	D
1	○—		○—	
2		○—		○—

X5U920WAA



X5U920W05


X5U920WAB

7. If not as specified, replace the rear antenna feeder.

## AUDIO UNIT REMOVAL


X5U920W17

1. Disconnect the negative battery cable.
2. Remove the service hole covers by inserting a small tape-wrapped flathead screwdriver into the slot and carefully pry them off without scratching the center panel. Pry up and pull off the service hole covers carefully to prevent the posts from breaking off.



3. With the beveled parts of the **SST** (Removing tool) facing inward, insert them into the unit.
4. Pull the **SST** (Removing tool) outward and forward to slide out the unit.

49 UN01 050



5. Disconnect the connectors and antenna jack.

## AUDIO UNIT INSTALLATION

X5U920W18

### Caution

- Make certain that the wiring harness and antenna feeder are not caught between the unit and dashboard. If the harness or the antenna feeder is caught between the unit and dashboard, it may become the cause of trouble or malfunctions.
- To install the audio unit, be sure to push the service hole cover areas on both sides of the audio unit. If the switches are pressed instead, it may become the cause of trouble or malfunctions.


1. Connect the connectors and antenna jack.
2. Insert the unit until each clip clicks.
3. Install the service hole covers.
4. Connect the negative battery cable.

## AUDIO AMPLIFIER REMOVAL/INSTALLATION

X5U920W16

1. Disconnect the negative battery cable.
2. Remove the dashboard. (Refer to 09-17 DASHBOARD REMOVAL/INSTALLATION.)
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.

1	Audio amplifier connector
2	Nut
3	Audio amplifier




X5U920WAN

## AUDIO RELAY REMOVAL/INSTALLATION

X5U920W19

1. Disconnect the negative battery cable.
2. Remove the center lower panel. (Refer to 09-17 CENTER LOWER PANEL REMOVAL/INSTALLATION.)
3. Disconnect the audio relay connector.
4. Remove the audio relay.

5. Install in the reverse order of removal.



X5U920WAR

## AUDIO RELAY INSPECTION



X5U920W20

1. Remove the audio relay. (Refer to 09-20 AUDIO RELAY REMOVAL/INSTALLATION.)
2. Inspect for continuity between the audio relay terminals by using an ohmmeter.

○—○ : Continuity

Step	Terminal			
	A	B	C	D
1	○—○			
2	B+	GND	○—○	○—○

X5U920WAS




X5U920WAT

3. If not as specified, replace the audio relay.

## CIGARETTE LIGHTER REMOVAL/INSTALLATION

X5U920W22


1. Disconnect the negative battery cable.
2. Remove the center panel. (Refer to 09-17 CENTER PANEL REMOVAL/INSTALLATION.)
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.



X5U920WAV

### Socket Removal Note

1. Pry up the stopper with the tape-wrapped flathead screwdriver.
2. Pull the socket while prying up the stopper.



X5U920WAW

1	Cigarette lighter plug
2	Socket ☞ Removal Note


## CIGARETTE LIGHTER INSPECTION

X5U920W21

### Note



- Verify that the cigarette lighter plug will move normally within **20—30 seconds**, after pressing the plug into the socket. If the fuse does not move, perform the following procedures.

1. Remove the socket. (Refer to 09-20 CIGARETTE LIGHTER REMOVAL/INSTALLATION.)
2. Verify the bimetals in the socket are not warped.
3. Inspect if the backs of the bimetals can be seen from the inside or outside.



NORMAL

DEFECTIVE



BIMETAL BACK


X5U920WAU

## ENTERTAINMENT

---

4. If the back of the bimetal can be seen from the inside, replace the socket.
5. If the fuse has been burnt, replace the socket.

6. If the bimetal and the socket are normal, replace the cigarette lighter plug.



X5U920WAX

---



## 09-21 POWER SYSTEMS

FUSE SERVICE CAUTION .....	09-21-1
MAIN FUSE REMOVAL/INSTALLATION .....	09-21-1
ROOM FUSE INSTALLATION .....	09-21-2
IGNITION SWITCH REMOVAL/INSTALLATION .....	09-21-2

IGNITION SWITCH INSPECTION .....	09-21-2
KEY REMINDER SWITCH INSPECTION .....	09-21-3

### FUSE SERVICE CAUTION

X5U921W01


#### Caution

- Determine and correct the cause of the burnt fuse before replacing it. If the fuse is replaced before doing this, it may burn again.

### MAIN FUSE REMOVAL/INSTALLATION

X5U921W02

1. Disconnect the negative battery cable.
2. Remove in the order indicated in the table.
3. Install in the reverse order of removal.



X5U921WA0

1	Main fuse block cover
2	Nut
3	Bolt
4	Main fuse


## ROOM FUSE INSTALLATION

X5U921W03

### Note

- When the ROOM fuse is burnt or removed, the malfunction indicator lamp illuminates. If the ROOM fuse is replaced or installed with the ignition switch at ON, the malfunction indicator lamp will continue to illuminate.

- Turn the ignition switch to LOCK.
- Install the ROOM fuse.




X5U921WA1

## IGNITION SWITCH REMOVAL/INSTALLATION

X5U921W04

- Disconnect the negative battery cable.
- Remove the column cover. (Refer to 09-17 COLUMN COVER REMOVAL/INSTALLATION.)
- Remove in the order indicated in the table.
- Install in the reverse order of removal.



X5U921WA2

1	Screw
2	Ignition switch connector
3	Ignition switch

## IGNITION SWITCH INSPECTION

X5U921W05


- Remove the column cover. (Refer to 09-17 COLUMN COVER REMOVAL/INSTALLATION.)
- Disconnect the ignition switch connector.
- Inspect for continuity between the ignition switch terminals by using an ohmmeter.

○—○ : Continuity

Key position	Terminal					
	A	B	C	D	E	F
LOCK						
ACC			○	—	—	○
ON	○	○	○	—	—	○
START		○	○	○	○	

X5U921WA3

4. If not as specified, replace the ignition switch.




X5U921WA4

## KEY REMINDER SWITCH INSPECTION

X5U921W06

1. Remove the column cover. (Refer to 09-17 COLUMN COVER REMOVAL/INSTALLATION.)
2. Disconnect the key reminder switch connector.

KEY REMINDER  
SWITCH CONNECTOR




X5U921WA5

3. Inspect for continuity between the key reminder switch terminals by using an ohmmeter.

○—○ : Continuity

Key condition	Terminal	
	A	B
Key inserted	○—○	○—○
Key removed		

X5U921WA6



X5U921WA7

4. If not as specified, replace the steering lock. (Refer to 06-10 STEERING WHEEL AND COLUMN REMOVAL/INSTALLATION.)

## 09-22 INSTRUMENTATION/DRIVER INFO.

### INSTRUMENT CLUSTER

REMOVAL/INSTALLATION ..... 09-22-1

### INSTRUMENT CLUSTER

DISASSEMBLY/ASSEMBLY ..... 09-22-1

INSTRUMENT CLUSTER INSPECTION , 09-22-2

Speedometer ..... 09-22-2

Tachometer ..... 09-22-2

Fuel Gauge ..... 09-22-2

Water Temperature Gauge ..... 09-22-2

Oil Pressure Gauge ..... 09-22-3

### INSTRUMENT CLUSTER INPUT/OUTPUT

CHECK MODE ..... 09-22-4

Diagnostic Trouble Code Chart ..... 09-22-4

Operating Order ..... 09-22-4

Checking Order ..... 09-22-4

Check Code 00—14 ..... 09-22-4

Check Code 31 ..... 09-22-4

Cancel Order ..... 09-22-4

Inspection of Diagnostic Trouble

Codes ..... 09-22-5

### WARNING AND INDICATOR LIGHT BULB

REMOVAL/INSTALLATION ..... 09-22-6

### FUEL GAUGE SENDER UNIT

INSPECTION ..... 09-22-7

OIL PRESSURE SWITCH INSPECTION 09-22-7

HORN REMOVAL/INSTALLATION ..... 09-22-7


HORN RELAY INSPECTION ..... 09-22-7

### INSTRUMENT CLUSTER REMOVAL/INSTALLATION

X5U922W01

1. Disconnect the negative battery cable.
2. Remove the meter hood. (Refer to 09-17 METER HOOD REMOVAL/INSTALLATION.)
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.

1	Screw
2	Instrument cluster connector
3	Instrument cluster



X5U922WA0


### INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY

X5U922W02

#### Caution

- If the instrument cluster is dropped or damaged, the system will not operate properly and it may become the cause of trouble or malfunction.

1. Disassemble in the order indicated in the table.
2. Assemble in the reverse order of disassembly.



X5U922WA1

1	Front glass
2	Window plate
3	Screw
4	Bulb
5	Print plate
6	Tachometer
7	Speedometer
8	Fuel gauge
9	Water temperature gauge
10	Oil pressure gauge
11	Odometer/tripmeter
12	Warning plate
13	Case

## INSTRUMENT CLUSTER INSPECTION

X5U922W03

### Speedometer


1. Remove the speedometer. (Refer to 09-22 INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY.)
2. Measure the resistance between the speedometer terminals by using an ohmmeter.

○—W—○ : Resistance

Step	Terminal			
	A	B	C	D
1	○—W—○			: R
2			○—W—○	: R

R: 136—184 Ω

X5U922WA2



X5U922WA3

3. If not as specified, replace the speedometer. (Refer to 09-22 INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY.)

### Tachometer


1. Remove the tachometer. (Refer to 09-22 INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY.)
2. Measure the resistance between the tachometer terminals by using an ohmmeter.

○—W—○ : Resistance

Step	Terminal			
	A	B	C	D
1	○—W—○			: R
2			○—W—○	: R

R: 136—184 Ω

X5U922WA4



X5U922WA5

3. If not as specified, replace the tachometer. (Refer to 09-22 INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY.)

### Fuel Gauge

1. Remove the fuel gauge. (Refer to 09-22 INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY.)
2. Measure the resistance between the fuel gauge terminals by using an ohmmeter.

○—W—○ : Resistance


Step	Terminal		
	A	B	C
1	○—W—○		: R <sub>1</sub>
2		○—W—○	: R <sub>2</sub>
3	○—W—○		: R <sub>3</sub>

R<sub>1</sub>: 110.7—135.3 Ω

R<sub>2</sub>: 89.1—108.9 Ω

R<sub>3</sub>: 199.8—244.2 Ω

X5U922WA6



X5U922WA7

3. If not as specified, replace the fuel gauge. (Refer to 09-22 INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY.)

### Water Temperature Gauge

1. Remove the water temperature gauge. (Refer to 09-22 INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY.)
2. Measure the resistance between the water temperature gauge terminals by using an ohmmeter.

○—W—○ : Resistance


Step	Terminal		
	A	B	C
1	○—W—○		: R <sub>1</sub>
2		○—W—○	: R <sub>2</sub>
3	○—W—○		: R <sub>3</sub>

R<sub>1</sub>: 85.5—94.5 Ω

R<sub>2</sub>: 247.5—302.5 Ω

R<sub>3</sub>: 193.5—236.5 Ω

X5U922WA8



X5U922WA9

3. If not as specified, replace the water temperature gauge. (Refer to 09-22 INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY.)

## Oil Pressure Gauge

1. Remove the oil pressure gauge. (Refer to 09-22 INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY.)
2. Measure the resistance between the oil pressure gauge terminals by using an ohmmeter.


○—○ : Resistance

Step	Terminal		
	A	B	C
1	○—○		: R <sub>1</sub>
2		○—○	: R <sub>2</sub>
3	○—○		: R <sub>3</sub>

R<sub>1</sub>: 89.1—108.9 Ω R<sub>2</sub>: 228.6—279.4 Ω

R<sub>3</sub>: 139.5—170.5 Ω

X5U922WAA



X5U922WAB

3. If not as specified, replace the oil pressure gauge. (Refer to 09-22 INSTRUMENT CLUSTER DISASSEMBLY/ASSEMBLY.)

## INSTRUMENT CLUSTER INPUT/OUTPUT CHECK MODE

X5U922W09

### Note

- In this mode, it is possible to check the item in the following chart.

### Diagnostic Trouble Code Chart

DTC	Checking item
00	Transmission range switch
01	Seat belt switch
04	Door switch
08	TNS relay
14	Buzzer
31	Key reminder switch

### Note


- Diagnostic trouble code which are not listed may be indicated, but they cannot be inspected.

### Operating Order

#### Note

- Connect the negative battery cable after **30 seconds or more** have passed after disconnecting the cable, then operate the input/output check mode again after terminating the input/output check mode.

- Close the all doors.
- Disconnect the negative battery cable.
- Open the driver's side door.
- Connect the negative battery cable.
- Perform the following procedures within **30 seconds**, after connecting the negative battery cable.
  - Turn the ignition switch to ON.
  - Push the door switch 3 times.
  - Push the odometer/tripmeter switch 3 times.



ODOMETER/TRIPMETER SWITCH

X5U922WAH

### Checking Order

#### Note

- The diagnostic trouble codes are displayed in numerical order. (While performing the inspection, if you want to inspect a diagnostic trouble code of which the number is smaller than the code number you are currently inspecting, terminate the check mode then repeat the inspection from the beginning.)
- If rotate the wheels, cancel the input/output check mode.

### Check Code 00—14

#### Note

- The diagnostic trouble codes can be fast forward by pushing and holding the odometer/tripmeter switch for **1 second or more**.

- Push the odometer/tripmeter switch and select the diagnostic trouble code.
- Inspect each diagnostic trouble code by following the related inspection procedures. (Refer to Inspection of Diagnostic Trouble Codes.)

### Check Code 31

- Turn the ignition switch to ACC.
- Push the odometer/tripmeter switch and select the diagnostic trouble code.
- Inspect each diagnostic trouble code by following the related inspection procedures. (Refer to Inspection of Diagnostic Trouble Codes.)

### Cancel Order

- Cancel the input/output check mode by turning the ignition switch to LOCK then back to ON.

#### Note

- Cancel the input/output check mode by leaving the instrument cluster in check mode for **approximately 45 minutes**.

# INSTRUMENTATION/DRIVER INFO.

## Inspection of Diagnostic Trouble Codes

DTC 00 Transmission range switch (R range) signal			
STEP	INSPECTION	INDICATION	ACTION
1	Set the selector lever to R range.	on X5U922WAL	Go to next step.
		off X5U922WAK	<ul style="list-style-type: none"> <li>Check the transmission range switch.</li> <li>Check the wiring harness. (Battery — transmission range switch — instrument cluster)</li> </ul>
2	Set the selector lever to another range except R range.	on X5U922WAL	<ul style="list-style-type: none"> <li>Check the transmission range switch.</li> <li>Check the wiring harness. (Battery — transmission range switch — instrument cluster)</li> </ul>
		off X5U922WAM	Input signal to instrument cluster is okay.

DTC 01 Seat belt switch on/off signal			
STEP	INSPECTION	INDICATION	ACTION
1	Pull the driver's side seat belt.	on X5U922WAN	<ul style="list-style-type: none"> <li>Check the seat belt switch.</li> <li>Check the wiring harness. (Instrument cluster — seat belt switch)</li> </ul>
		off X5U922WAP	Go to next step.
2	Release the driver's side seat belt.	on X5U922WAQ	Input signal to instrument cluster is okay.
		off X5U922WAR	<ul style="list-style-type: none"> <li>Check the seat belt switch.</li> <li>Check the wiring harness. (Instrument cluster — seat belt switch)</li> </ul>

DTC 04 Door switch on/off signal			
STEP	INSPECTION	INDICATION	ACTION
1	Open the driver's side door.	on X5U922WAS	Close the driver's side door, then go to next step.
		off X5U922WAT	<ul style="list-style-type: none"> <li>Check the door switch.</li> <li>Check the wiring harness. (Instrument cluster — door switch)</li> </ul>
2	Open the passenger's side door.	on X5U922WAU	Close the passenger's side door, then go to next step.
		off X5U922WAV	<ul style="list-style-type: none"> <li>Check the door switch.</li> <li>Check the wiring harness. (Instrument cluster — door switch)</li> </ul>
3	Close all doors.	on X5U922WAW	<ul style="list-style-type: none"> <li>Check the door switch.</li> <li>Check the wiring harness. (Instrument cluster — door switch)</li> </ul>
		off X5U922WAX	Input signal to instrument cluster is okay.



## INSTRUMENTION/DRIVER INFO.

DTC 08 TNS relay on/off signal			
STEP	INSPECTION	INDICATION	ACTION
1	Turn the headlight switch to TNS position.	ON X5U922WAY	Go to next step.
		OFF X5U922WAZ	<ul style="list-style-type: none"> <li>Check the TNS relay.</li> <li>Check the wiring harness. (Battery — TNS relay — instrument cluster)</li> </ul>
2	Turn the headlight switch to OFF.	ON X5U922WB0	<ul style="list-style-type: none"> <li>Check the TNS relay.</li> <li>Check the wiring harness. (Battery — TNS relay — instrument cluster)</li> </ul>
		OFF X5U922WB1	Input signal to instrument cluster is okay.


DTC 14	Operation signal to buzzer			
INSPECTION		INDICATION	SITUATION	ACTION
Wait for <b>2 seconds</b> after selecting DTC 14.		(No indication)	Buzzer continuously sounds.	Buzzer is okay.
			Buzzer does not continuously sound.	Replace the odometer/tripmeter.

DTC 31 Key reminder switch on/off signal			
STEP	INSPECTION	INDICATION	ACTION
1	Insert the key into steering lock.	ON X5U922WB2	Go to next step.
		OFF X5U922WB3	<ul style="list-style-type: none"> <li>Check the key reminder switch.</li> <li>Check the wiring harness. (Battery — key reminder switch — instrument cluster)</li> </ul>
2	Remove the key from steering lock.	ON X5U922WB4	<ul style="list-style-type: none"> <li>Check the key reminder switch.</li> <li>Check the wiring harness. (Battery — key reminder switch — instrument cluster)</li> </ul>
		OFF X5U922WB5	Input signal to instrument cluster is okay.

### WARNING AND INDICATOR LIGHT BULB REMOVAL/INSTALLATION

X5U922W04

1. Disconnect the negative battery cable.
2. Remove the instrument cluster. (Refer to 09-22 INSTRUMENT CLUSTER REMOVAL/INSTALLATION.)
3. Turn the socket counterclockwise to remove the bulb as shown in the figure.




X5U922WAC

4. Install in the reverse order of removal.

## FUEL GAUGE SENDER UNIT INSPECTION

1. Remove the fuel pump. (Refer to 01-14 FUEL PUMP REMOVAL/INSTALLATION.)
2. Using an ohmmeter, measure and verify the resistance between the fuel gauge sender unit terminals as shown in the following chart while slowly moving the unit arm from empty to full.

Measuring point	Resistance ( $\Omega$ )
Full	6.4—7.6
1/2	31.8—33.2
Empty	93—97




3. If not as specified, replace the fuel gauge sender unit. (Refer to 01-14 FUEL PUMP REMOVAL/INSTALLATION.)

## OIL PRESSURE SWITCH INSPECTION

1. Verify that the oil pressure gauge needle moves to H when the engine is started.
2. Verify that the oil pressure gauge needle moves to L when the engine is stopped.
3. If the oil pressure gauge needle does not move, inspect the oil pressure gauge and related wiring harness.
4. If the oil pressure gauge and related wiring harness are normal, inspect the oil pressure. (Refer to 01-11 OIL PRESSURE INSPECTION.)
5. If the oil pressure is normal, replace the oil pressure switch. (Refer to 01-11 OIL PRESSURE INSPECTION.)

## HORN REMOVAL/INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the upper seal board.
3. Disconnect the horn connector.
4. Remove the bolt.
5. Remove the horn.



6. Install in the reverse order of removal.


## HORN RELAY INSPECTION

1. Remove the horn relay.
2. Inspect for continuity between the horn relay terminals by using an ohmmeter.

○—○ : Continuity

Step	Terminal			
	B	D	A	C
1	○—○	○—○		
2	B+	GND	○—○	

X5U922WAF



3. If not as specified, replace the horn relay.

# 09-50 TECHNICAL DATA

09 BODY & ACCESSORIES ..... 09-50-1

## 09 BODY & ACCESSORIES

X5U96CW01




Item		Specification
<b>LIGHTING SYSTEMS</b>		
Exterior light bulb capacity (W)	Headlight	60/55
	Front turn light/parking light	27/8
	Front side marker light	3.8
	Rear turn light	21
	Brake light/taillight	21/5
	Back-up light	21
	High-mount brake light	21
	License plate light	5
Interior light bulb capacity (W)	Interior light	8
	Instrument cluster illumination	3.4, 1.4
<b>INSTRUMENTATION/DRIVER INFO.</b>		
Warning and indicator light bulb capacity (W)	ABS warning light	1.4
	Air bag system warning light	1.4
	Brake system warning light	1.4
	Cruise set indicator light	1.4
	Generator warning light	1.4
	High beam indicator light	1.4
	HOLD indicator light	1.4
	Malfunction indicator lamp	1.4
	O/D OFF indicator light	1.4
	Seat belt warning light	1.4
	Turn indicator light	1.4

## 09-60 SERVICE TOOLS

09 BODY & ACCESSORIES SST ..... 09-60-1

### 09 BODY & ACCESSORIES SST

X5U960WC1

<p>49 0305 870A</p> <p>Window Tool Set</p>  <p>T0305870A</p>	<p>49 G050 1A0</p> <p>Sealant Remover</p>  <p>TG0501A0X</p>	<p>49 UN01 050</p> <p>Removing tool</p>  <p>TUN01050X</p>
---	---	--

# ALPHABETICAL INDEX

**AI**  
SECTION

## A

A-PILLAR TRIM  
REMOVAL/INSTALLATION ..... 09-17-8  
A/C COMPRESSOR  
REMOVAL/INSTALLATION ..... 07-11-6  
A/C RELAY AND CONDENSER  
FAN RELAY INSPECTION ..... 07-40-10  
A/C RELAY AND CONDENSER FAN  
RELAY REMOVAL/INSTALLATION ..... 07-40-9  
ABBREVIATIONS ..... 00-00-19  
ABS CONTROL MODULE  
REMOVAL/INSTALLATION ..... 04-13-4  
ABS HARNESS AND INPUT SIGNAL  
INSPECTION ..... 04-13-5  
ABS HYDRAULIC UNIT INSPECTION ..... 04-13-1  
ABS HYDRAULIC UNIT  
REMOVAL/INSTALLATION ..... 04-13-3  
ABS RELAY INSPECTION ..... 04-13-7  
ABS RELAY REMOVAL/INSTALLATION ... 04-13-7  
ACCELERATOR CABLE  
INSPECTION/ADJUSTMENT ..... 01-13-7  
ACCELERATOR PEDAL  
REMOVAL/INSTALLATION ..... 01-13-7  
ACTUATOR CABLE ADJUSTMENT ..... 01-20-5  
ACTUATOR CABLE  
REMOVAL/INSTALLATION ..... 01-20-5  
AFTER REPAIR PROCEDURE ..... 01-14-2  
AIR BAG DEACTIVATION (PAD) SWITCH  
ILLUMINATION BULB  
REMOVAL/INSTALLATION ..... 08-10-7  
AIR BAG MODULE DEPLOYMENT  
AUTHORIZATION PROCEDURES ..... 08-10-8  
AIR BAG MODULE DEPLOYMENT  
PROCEDURES ..... 08-10-9  
AIR BAG MODULE DISPOSAL  
PROCEDURES ..... 08-10-12  
AIR BAG SYSTEM ON-BOARD  
DIAGNOSIS ..... 08-01-1  
AIR BAG SYSTEM SERVICE WARNINGS . 08-10-1  
AIR BAG SYSTEM SYMPTOM  
TROUBLESHOOTING ..... 08-01-8  
AIR BLEEDING ..... 04-11-1  
AIR BLEEDING ..... 06-12-1  
AIR FILTER INSPECTION ..... 01-16-5  
ANTENNA MAST INSTALLATION ..... 09-20-5  
ANTENNA MAST REMOVAL ..... 09-20-5  
ANTILOCK BRAKE SYSTEM ON-BOARD  
DIAGNOSIS ..... 04-01-2  
ANTILOCK BRAKE SYSTEM SYMPTOM  
TROUBLESHOOTING ..... 04-01-9

AUDIO AMPLIFIER  
REMOVAL/INSTALLATION ..... 09-20-9  
AUDIO RELAY INSPECTION ..... 09-20-10  
AUDIO RELAY  
REMOVAL/INSTALLATION ..... 09-20-9  
AUDIO UNIT INSTALLATION ..... 09-20-8  
AUDIO UNIT REMOVAL ..... 09-20-8  
AUTOMATIC TRANSMISSION BASIC  
INSPECTION ..... 05-01-16  
AUTOMATIC TRANSMISSION FLUID (ATF)  
INSPECTION ..... 05-13-6  
AUTOMATIC TRANSMISSION FLUID (ATF)  
REPLACEMENT ..... 05-13-7  
AUTOMATIC TRANSMISSION ON-BOARD  
DIAGNOSTIC ..... 05-01-2  
AUTOMATIC TRANSMISSION  
REMOVAL/INSTALLATION ..... 05-13-20  
AUTOMATIC TRANSMISSION SYMPTOM  
TROUBLESHOOTING ..... 05-01-17

## B

BACK-UP LIGHT SWITCH INSPECTION .. 09-18-5  
BACK-UP LIGHT SWITCH  
REMOVAL/INSTALLATION ..... 09-18-4  
BASE INSTALLATION ..... 09-12-24  
BASE REMOVAL ..... 09-12-24  
BASIC SYSTEM STRUCTURAL VIEW .... 07-11-1  
BATTERY REMOVAL/INSTALLATION ..... 01-17-1  
BEFORE REPAIR PROCEDURE ..... 01-14-1  
BELTLINE MOLDING  
REMOVAL/INSTALLATION ..... 09-16-1  
BLOWER MOTOR INSPECTION ..... 07-40-5  
BLOWER MOTOR  
REMOVAL/INSTALLATION ..... 07-40-5  
BLOWER RELAY INSPECTION ..... 07-40-10  
BLOWER RELAY  
REMOVAL/INSTALLATION ..... 07-40-10  
BLOWER UNIT  
DISASSEMBLY/ASSEMBLY ..... 07-11-2  
BLOWER UNIT  
REMOVAL/INSTALLATION ..... 07-11-2  
BRAKE FLUID LEVEL SENSOR  
INSPECTION ..... 04-11-8  
BRAKE PEDAL ADJUSTMENT ..... 04-11-3  
BRAKE PEDAL INSPECTION ..... 04-11-2  
BRAKE PEDAL  
REMOVAL/INSTALLATION ..... 04-11-4  
BRAKE SWITCH INSPECTION ..... 04-11-5  
BUCKLE REMOVAL/INSTALLATION ..... 08-11-2  
Battery inspection ..... 01-17-1  
Battery recharging ..... 01-17-2

**AI**

# ALPHABETICAL INDEX

## C

CALIPER (FRONT)  
DISASSEMBLY/ASSEMBLY ..... 04-11-16  
CALIPER (REAR)  
DISASSEMBLY/ASSEMBLY ..... 04-11-20  
CAMSHAFT POSITION SENSOR  
INSPECTION ..... 01-40-15  
CAMSHAFT POSITION SENSOR  
REMOVAL/INSTALLATION ..... 01-40-17  
CANISTER DRAIN CUT VALVE (CDCV)  
INSPECTION ..... 01-16-7  
CANISTER DRAIN CUT VALVE (CDCV)  
REMOVAL/INSTALLATION ..... 01-16-7  
CATCH TANK INSPECTION ..... 01-16-8  
CENTER PANEL  
REMOVAL/INSTALLATION ..... 09-17-4  
CHARCOAL CANISTER INSPECTION ..... 01-16-7  
CIGARETTE LIGHTER INSPECTION ..... 09-20-10  
CIGARETTE LIGHTER  
REMOVAL/INSTALLATION ..... 09-20-10  
CLOCK SPRING ADJUSTMENT ..... 08-10-5  
CLOCK SPRING INSPECTION ..... 08-10-6  
CLOCK SPRING  
REMOVAL/INSTALLATION ..... 08-10-5  
CLUTCH COVER INSPECTION ..... 05-10-12  
CLUTCH DISC INSPECTION ..... 05-10-12  
CLUTCH FLUID AIR BLEEDING ..... 05-10-2  
CLUTCH FLUID INSPECTION ..... 05-10-1  
CLUTCH FLUID REPLACEMENT ..... 05-10-2  
CLUTCH MASTER CYLINDER  
DISASSEMBLY/ASSEMBLY ..... 05-10-7  
CLUTCH MASTER CYLINDER  
REMOVAL/INSTALLATION ..... 05-10-6  
CLUTCH PEDAL ADJUSTMENT ..... 05-10-4  
CLUTCH PEDAL INSPECTION ..... 05-10-3  
CLUTCH PEDAL  
REMOVAL/INSTALLATION ..... 05-10-5  
CLUTCH RELEASE COLLAR  
INSPECTION ..... 05-10-13  
CLUTCH RELEASE CYLINDER  
DISASSEMBLY/ASSEMBLY ..... 05-10-9  
CLUTCH RELEASE CYLINDER  
REMOVAL/INSTALLATION ..... 05-10-8  
CLUTCH SWITCH INSPECTION ..... 01-40-20  
CLUTCH UNIT  
REMOVAL/INSTALLATION ..... 05-10-10  
COLUMN COVER  
REMOVAL/INSTALLATION ..... 09-17-4  
COMBINATION SWITCH  
DISASSEMBLY/ASSEMBLY ..... 09-18-6  
COMBINATION SWITCH INSPECTION ..... 09-18-6  
COMBINATION SWITCH  
REMOVAL/INSTALLATION ..... 09-18-5  
COMPRESSION INSPECTION ..... 01-10-5  
CONDENSER FAN INSPECTION ..... 07-40-4  
CONDENSER FAN  
REMOVAL/INSTALLATION ..... 07-40-4  
CONDENSER INSPECTION ..... 07-11-7  
CONDENSER REMOVAL/INSTALLATION .. 07-11-7  
CONSOLE DISASSEMBLY/ASSEMBLY .... 09-17-5  
CONSOLE REMOVAL/INSTALLATION ..... 09-17-5  
CONTROL SYSTEM COMPONENT  
LOCATION ..... 01-40-2  
CONTROL SYSTEM STRUCTURAL VIEW . 07-40-1

CONTROL VALVE BODY  
REMOVAL/INSTALLATION ..... 05-13-25  
CONVERTIBLE TOP ADJUSTMENT ..... 09-16-6  
CONVERTIBLE TOP  
DISASSEMBLY/ASSEMBLY ..... 09-16-8  
CONVERTIBLE TOP  
REMOVAL/INSTALLATION ..... 09-16-7  
COOLING FAN MOTOR INSPECTION ..... 01-12-6  
COOLING FAN MOTOR  
REMOVAL/INSTALLATION ..... 01-12-7  
COOLING FAN RELAY INSPECTION ..... 01-12-7  
COOLING SYSTEM SERVICE  
WARNINGS ..... 01-12-1  
COOLING UNIT  
DISASSEMBLY/ASSEMBLY ..... 07-11-4  
COOLING UNIT  
REMOVAL/INSTALLATION ..... 07-11-3  
COWL GRILLE  
REMOVAL/INSTALLATION ..... 09-16-1  
CRANKSHAFT POSITION SENSOR  
ADJUSTMENT ..... 01-40-14  
CRANKSHAFT POSITION SENSOR  
INSPECTION ..... 01-40-13  
CRANKSHAFT POSITION SENSOR  
REMOVAL/INSTALLATION ..... 01-40-14  
CRUISE ACTUATOR INSPECTION ..... 01-20-4  
CRUISE ACTUATOR  
REMOVAL/INSTALLATION ..... 01-20-3  
CRUISE CONTROL MAIN SWITCH  
INSPECTION ..... 01-20-6  
CRUISE CONTROL MAIN SWITCH  
REMOVAL/INSTALLATION ..... 01-20-6  
CRUISE CONTROL MODULE  
INSPECTION ..... 01-20-1  
CRUISE CONTROL MODULE  
REMOVAL/INSTALLATION ..... 01-20-1  
CRUISE CONTROL SWITCH  
INSPECTION ..... 01-20-7  
CRUISE CONTROL SWITCH  
REMOVAL/INSTALLATION ..... 01-20-6  
CRUISE CONTROL SYSTEM ON-BOARD  
DIAGNOSIS ..... 01-01C-1  
CYLINDER HEAD GASKET  
REPLACEMENT ..... 01-10-10

## D

DASHBOARD  
DISASSEMBLY/ASSEMBLY ..... 09-17-3  
DASHBOARD  
REMOVAL/INSTALLATION ..... 09-17-2  
DETACHABLE HARDTOP  
ADJUSTMENT ..... 09-16-17  
DETACHABLE HARDTOP  
DISASSEMBLY/ASSEMBLY ..... 09-16-18  
DIFFERENTIAL  
DISASSEMBLY/ASSEMBLY ..... 03-14-5  
DIFFERENTIAL OIL INSPECTION ..... 03-14-1  
DIFFERENTIAL OIL REPLACEMENT ..... 03-14-1  
DIFFERENTIAL  
REMOVAL/INSTALLATION ..... 03-14-3  
DISC PAD (FRONT) REPLACEMENT ..... 04-11-15  
DISC PAD (REAR) REPLACEMENT ..... 04-11-19  
DOOR ADJUSTMENT ..... 09-11-1  
DOOR DISASSEMBLY/ASSEMBLY ..... 09-11-3

# ALPHABETICAL INDEX

DOOR GLASS ADJUSTMENT .....	09-12-1
DOOR GLASS AND GUIDE	
REMOVAL/INSTALLATION .....	09-12-5
DOOR LOCK ACTUATOR INSPECTION ...	09-14-1
DOOR LOCK AND OPENER	
REMOVAL/INSTALLATION .....	09-14-1
DOOR LOCK CONTROL MODULE	
INSPECTION .....	09-14-3
DOOR LOCK CONTROL MODULE	
REMOVAL/INSTALLATION .....	09-14-4
DOOR LOCK STRIKER	
REMOVAL/INSTALLATION .....	09-14-2
DOOR LOCK-LINK SWITCH	
INSPECTION .....	09-14-2
DOOR REMOVAL/INSTALLATION .....	09-11-2
DOOR SPEAKER INSPECTION .....	09-20-1
DOOR SPEAKER	
REMOVAL/INSTALLATION .....	09-20-1
DOOR SWITCH INSPECTION .....	09-18-13
DOOR SWITCH	
REMOVAL/INSTALLATION .....	09-18-13
DOOR TRIM REMOVAL/INSTALLATION ...	09-17-7
DRIVE BELT ADJUSTMENT .....	01-10-2
DRIVE BELT INSPECTION .....	01-10-1
DRIVE PLATE	
REMOVAL/INSTALLATION .....	05-13-28
DRIVE SHAFT	
DISASSEMBLY/ASSEMBLY .....	03-13-3
DRIVE SHAFT PREINSPECTION .....	03-13-1
DRIVE SHAFT REMOVAL/INSTALLATION .	03-13-2
DRIVER-SIDE AIR BAG MODULE	
REMOVAL/INSTALLATION .....	08-10-3
DRL CONTROL MODULE INSPECTION ..	09-18-11
DRL CONTROL MODULE	
REMOVAL/INSTALLATION .....	09-18-11

## E

EGR BOOST SENSOR INSPECTION ....	01-40-20
EGR BOOST SENSOR SOLENOID VALVE	
INSPECTION .....	01-16-11
EGR VALVE INSPECTION .....	01-16-10
EGR VALVE REMOVAL/INSTALLATION ..	01-16-10
ELECTRICAL system .....	00-00-14
EMERGENCY OVERRIDE BUTTON	
INSPECTION .....	05-14-1
EMISSION SYSTEM (ENGINE COMPARTMENT	
SIDE) COMPONENT LOCATION .....	01-16-4
ENGINE COOLANT LEAKAGE	
INSPECTION .....	01-12-3
ENGINE COOLANT LEVEL INSPECTION ..	01-12-1
ENGINE COOLANT REPLACEMENT .....	01-12-2
ENGINE COOLANT TEMPERATURE	
SENSOR INSPECTION .....	01-40-12
ENGINE DIAGNOSTIC INSPECTION ..	01-01A-142
ENGINE DISASSEMBLY/ASSEMBLY .....	01-10-16
ENGINE OIL LEVEL INSPECTION .....	01-11-1
ENGINE OIL REPLACEMENT .....	01-11-1
ENGINE ON-BOARD DIAGNOSIS .....	01-01A-2
ENGINE REMOVAL/INSTALLATION .....	01-10-15
ENGINE SYMPTOM	
TROUBLESHOOTING .....	01-01A-97
ENGINE SYSTEM INSPECTION .....	01-01A-149
ENGINE TUNE-UP .....	01-10-17
EVAPORATIVE CHAMBER INSPECTION ..	01-16-9

EVAPORATIVE EMISSION CONTROL SYSTEM	
COMPONENTS LOCATION .....	01-16-2
EVAPORATOR INSPECTION .....	07-11-4
EXHAUST SYSTEM INSPECTION .....	01-15-1
EXHAUST SYSTEM	
REMOVAL/INSTALLATION .....	01-15-2
EXTENSION HOUSING	
REMOVAL/INSTALLATION .....	05-13-23

## F

FILAMENT INSPECTION .....	09-12-16
FILAMENT REPAIR .....	09-12-17
FLASHER CONTROL MODULE	
INSPECTION .....	09-18-10
FLASHER CONTROL MODULE	
REMOVAL/INSTALLATION .....	09-18-10
FLOOR COVERING	
REMOVAL/INSTALLATION .....	09-17-11
FLYWHEEL INSPECTION .....	05-10-13
FOREWARD .....	04-01-1
FOREWORD .....	01-01A-2
FOREWORD .....	05-01-1
FOREWORD .....	07-01-1
FRONT ABS WHEEL-SPEED SENSOR	
INSPECTION .....	04-13-10
FRONT ABS WHEEL-SPEED SENSOR	
REMOVAL/INSTALLATION .....	04-13-9
FRONT ANTENNA FEEDER	
INSPECTION .....	09-20-6
FRONT ANTENNA FEEDER	
REMOVAL/INSTALLATION .....	09-20-6
FRONT BELTLINE MOLDING	
REMOVAL/INSTALLATION .....	09-16-2
FRONT BRAKE (DISC) INSPECTION ....	04-11-13
FRONT BRAKE (DISC)	
REMOVAL/INSTALLATION .....	04-11-14
FRONT BUMPER	
REMOVAL/INSTALLATION .....	09-10-5
FRONT COMBINATION LIGHT	
REMOVAL/INSTALLATION .....	09-18-2
FRONT CROSSMEMBER	
REMOVAL/INSTALLATION .....	02-13-11
FRONT FENDER PANEL	
REMOVAL/INSTALLATION .....	09-10-7
FRONT HEADER TRIM	
REMOVAL/INSTALLATION .....	09-17-8
FRONT LOWER ARM INSPECTION .....	02-13-7
FRONT LOWER ARM	
REMOVAL/INSTALLATION .....	02-13-5
FRONT OIL SEAL REPLACEMENT .....	01-10-13
FRONT SHOCK ABSORBER AND COIL	
SPRING REMOVAL/INSTALLATION .....	02-13-1
FRONT SHOCK ABSORBER DISPOSAL ..	02-13-4
FRONT SHOCK ABSORBER	
INSPECTION .....	02-13-4
FRONT SIDE MARKER LIGHT	
REMOVAL/INSTALLATION .....	09-18-3
FRONT SIDE TRIM	
REMOVAL/INSTALLATION .....	09-17-9
FRONT STABILIZER	
REMOVAL/INSTALLATION .....	02-13-9
FRONT UPPER ARM INSPECTION .....	02-13-9
FRONT UPPER ARM	
REMOVAL/INSTALLATION .....	02-13-7

# ALPHABETICAL INDEX

FRONT WHEEL ALIGNMENT .....	02-11-1
FUEL FILTER (HIGH-PRESSURE)	
REMOVAL/INSTALLATION .....	01-14-11
FUEL GAUGE SENDER UNIT	
INSPECTION .....	09-22-7
FUEL INJECTOR INSPECTION .....	01-14-14
FUEL INJECTOR	
REMOVAL/INSTALLATION .....	01-14-13
FUEL PUMP DISASSEMBLY/ASSEMBLY ..	01-14-7
FUEL PUMP INSPECTION .....	01-14-8
FUEL PUMP RELAY INSPECTION .....	01-14-19
FUEL PUMP REMOVAL/INSTALLATION ...	01-14-6
FUEL TANK PRESSURE SENSOR	
INSPECTION .....	01-40-22
FUEL TANK REMOVAL/INSTALLATION ...	01-14-3
FUEL-FILLER LID ADJUSTMENT .....	09-10-1
FUEL-FILLER LID OPENER	
REMOVAL/INSTALLATION .....	09-14-5
FUEL-FILLER LID	
REMOVAL/INSTALLATION .....	09-10-2
FUNDAMENTAL PROCEDURES .....	00-00-11
FUSE SERVICE CAUTION .....	09-21-1

## G

GENERAL PROCEDURES (CLUTCH) .....	05-10-1
GENERATOR INSPECTION .....	01-17-3
GENERATOR REMOVAL/INSTALLATION ..	01-17-3
GLOVE COMPARTMENT	
REMOVAL/INSTALLATION .....	09-17-6

## H

HAZARD WARNING SWITCH	
INSPECTION .....	09-18-8
HAZARD WARNING SWITCH	
REMOVAL/INSTALLATION .....	09-18-7
HEADLIGHT ADJUSTMENT .....	09-18-1
HEADLIGHT BULB	
REMOVAL/INSTALLATION .....	09-18-2
HEADLIGHT RELAY INSPECTION .....	09-18-9
HEADLIGHT RELAY	
REMOVAL/INSTALLATION .....	09-18-8
HEATED OXYGEN SENSOR HEATER	
INSPECTION .....	01-40-19
HEATED OXYGEN SENSOR	
INSPECTION .....	01-40-18
HEATER CONTROL UNIT	
DISASSEMBLY/ASSEMBLY .....	07-40-8
HEATER CONTROL UNIT INSPECTION ...	07-40-8
HEATER CONTROL UNIT INSTALLATION ...	07-40-7
HEATER CONTROL UNIT REMOVAL .....	07-40-7
HEATER CONTROL UNIT	
WIRE ADJUSTMENT .....	07-40-9
HEATER CORE INSPECTION .....	07-11-6
HEATER UNIT	
DISASSEMBLY/ASSEMBLY .....	07-11-5
HEATER UNIT	
REMOVAL/INSTALLATION .....	07-11-5
HIGH-MOUNT BRAKE LIGHT	
REMOVAL/INSTALLATION .....	09-18-3
HIGH-TENSION LEAD INSPECTION .....	01-18-2
HIGH-TENSION LEAD	
REMOVAL/INSTALLATION .....	01-18-2
HOOD ADJUSTMENT .....	09-10-2

HOOD LOCK AND OPENER	
REMOVAL/INSTALLATION .....	09-14-6
HOOD REMOVAL/INSTALLATION .....	09-10-3
HORN RELAY INSPECTION .....	09-22-7
HORN REMOVAL/INSTALLATION .....	09-22-7
HOW TO USE THIS MANUAL .....	00-00-2

## I

IDENTIFICATION NUMBER	
LOCATIONS .....	00-00-18
IDLE AIR CONTROL VALVE	
INSPECTION .....	01-13-3
IDLE AIR CONTROL VALVE	
REMOVAL/INSTALLATION .....	01-13-3
IGNITION COIL INSPECTION .....	01-18-1
IGNITION COIL	
REMOVAL/INSTALLATION .....	01-18-1
IGNITION SWITCH INSPECTION .....	09-21-2
IGNITION SWITCH	
REMOVAL/INSTALLATION .....	09-21-2
INPUT/TURBINE SPEED SENSOR	
INSPECTION .....	05-13-14
INPUT/TURBINE SPEED SENSOR	
REMOVAL/INSTALLATION .....	05-13-14
INSPECTION OF SST	
(DEPLOYMENT TOOL) .....	08-10-13
INSTALLATION OF RADIO SYSTEM .....	00-00-13
INSTRUMENT CLUSTER	
DISASSEMBLY/ASSEMBLY .....	09-22-1
INSTRUMENT CLUSTER INPUT/OUTPUT	
CHECK MODE .....	09-22-4
INSTRUMENT CLUSTER INSPECTION ...	09-22-2
INSTRUMENT CLUSTER	
REMOVAL/INSTALLATION .....	09-22-1
INTAKE AIR TEMPERATURE SENSOR	
INSPECTION .....	01-40-9
INTAKE-AIR SYSTEM	
REMOVAL/INSTALLATION .....	01-13-2
INTERIOR LIGHT INSPECTION .....	09-18-13
INTERIOR LIGHT	
REMOVAL/INSTALLATION .....	09-18-12

## J

JACKING POSITIONS .....	00-00-17
-------------------------	----------

## K

KEY INTERLOCK SOLENOID	
INSPECTION .....	05-14-1
KEY INTERLOCK SOLENOID	
REMOVAL/INSTALLATION .....	05-14-2
KEY INTERLOCK UNIT INSPECTION .....	05-14-2
KEY INTERLOCK UNIT	
REMOVAL/INSTALLATION .....	05-14-3
KEY REMINDER SWITCH INSPECTION ...	09-21-3
KNOCK SENSOR INSPECTION .....	01-40-17
KNOCK SENSOR	
REMOVAL/INSTALLATION .....	01-40-17



# ALPHABETICAL INDEX

## L

LICENSE PLATE LIGHT  
REMOVAL/INSTALLATION ..... 09-18-4  
LOWER PANEL  
REMOVAL/INSTALLATION ..... 09-17-6

## M

MAGNETIC CLUTCH ADJUSTMENT ..... 07-40-3  
MAGNETIC CLUTCH  
DISASSEMBLY/ASSEMBLY ..... 07-40-3  
MAGNETIC CLUTCH INSPECTION ..... 07-40-2  
MAIN FUSE REMOVAL/INSTALLATION ... 09-21-1  
MAIN RELAY INSPECTION ..... 01-40-22  
MANUAL ANTENNA INSPECTION ..... 09-20-3  
MANUAL ANTENNA  
REMOVAL/INSTALLATION ..... 09-20-3  
MANUAL OUTSIDE MIRROR  
REMOVAL/INSTALLATION ..... 09-12-21  
MANUAL TRANSMISSION  
REMOVAL/INSTALLATION ..... 05-11-3  
MANUAL WINDOW REGULATOR  
REMOVAL/INSTALLATION ..... 09-12-9  
MASS AIR FLOW SENSOR  
INSPECTION ..... 01-40-10  
MASTER CYLINDER  
DISASSEMBLY/ASSEMBLY ..... 04-11-9  
MASTER CYLINDER  
REMOVAL/INSTALLATION ..... 04-11-5  
MECHANICAL SYSTEM TEST ..... 05-13-2  
METER HOOD  
REMOVAL/INSTALLATION ..... 09-17-7

## N

NEUTRAL SWITCH INSPECTION ..... 01-40-21  
NONRETURN VALVE INSPECTION ..... 01-14-6

## O

O/D OFF SWITCH INSPECTION ..... 05-13-11  
O/D OFF SWITCH  
REMOVAL/INSTALLATION ..... 05-13-11  
OIL COOLER  
REMOVAL/INSTALLATION ..... 01-11-3  
OIL COOLER  
REMOVAL/INSTALLATION ..... 05-13-27  
OIL FILTER REPLACEMENT ..... 01-11-2  
OIL PAN REMOVAL/INSTALLATION ..... 01-11-4  
OIL PRESSURE INSPECTION ..... 01-11-2  
OIL PRESSURE SWITCH INSPECTION ... 09-22-7  
OIL SEAL (REAR) REPLACEMENT ..... 05-11-2  
OIL SEAL (TRANSMISSION)  
REPLACEMENT ..... 05-13-24  
OIL SEAL REPLACEMENT ..... 03-14-2  
OUTPUT SPEED SENSOR  
INSPECTION ..... 05-13-15  
OUTPUT SPEED SENSOR  
REMOVAL/INSTALLATION ..... 05-13-15  
OUTSIDE MIRROR GLASS  
INSTALLATION ..... 09-12-22  
OUTSIDE MIRROR GLASS REMOVAL ... 09-12-21

## P

P POSITION SWITCH INSPECTION ..... 05-14-3  
PANEL LIGHT CONTROL SWITCH  
INSPECTION ..... 09-18-14  
PANEL LIGHT CONTROL SWITCH  
REMOVAL/INSTALLATION ..... 09-18-14  
PARKING BRAKE ADJUSTMENT ..... 04-12-1  
PARKING BRAKE CABLE  
REMOVAL/INSTALLATION ..... 04-12-2  
PARKING BRAKE INSPECTION ..... 04-12-1  
PARKING BRAKE LEVER  
REMOVAL/INSTALLATION ..... 04-12-1  
PARKING LIGHT/FRONT TURN LIGHT BULB  
REMOVAL/INSTALLATION ..... 09-18-2  
PASSENGER AIR BAG DEACTIVATION (PAD)  
SWITCH INSPECTION ..... 08-10-7  
PASSENGER AIR BAG DEACTIVATION (PAD)  
SWITCH REMOVAL/INSTALLATION .... 08-10-6  
PASSENGER AIR BAG DEACTIVATION (PAD)  
SWITCH WARNING LIGHT BULB AND  
PASSENGER AIR BAG DEACTIVATION (PAD)  
SWITCH ILLUMINATION BULB  
REMOVAL/INSTALLATION ..... 08-10-7  
PASSENGER-SIDE AIR BAG MODULE  
REMOVAL/INSTALLATION ..... 08-10-4  
PCM REMOVAL/INSTALLATION ..... 01-40-3  
PCV VALVE INSPECTION ..... 01-16-12  
PID/DATA MONITOR INSPECTION ..... 01-40-4  
PILOT BEARING INSPECTION ..... 05-10-13  
PLATE REMOVAL/INSTALLATION ..... 01-40-14  
POWER ANTENNA  
DISASSEMBLY/ASSEMBLY ..... 09-20-4  
POWER ANTENNA INSPECTION ..... 09-20-5  
POWER ANTENNA  
REMOVAL/INSTALLATION ..... 09-20-4  
POWER BRAKE UNIT INSPECTION ..... 04-11-10  
POWER BRAKE UNIT  
REMOVAL/INSTALLATION ..... 04-11-11  
POWER OUTSIDE MIRROR  
INSPECTION ..... 09-12-19  
POWER OUTSIDE MIRROR  
REMOVAL/INSTALLATION ..... 09-12-20  
POWER OUTSIDE MIRROR SWITCH  
INSPECTION ..... 09-12-23  
POWER OUTSIDE MIRROR SWITCH  
REMOVAL/INSTALLATION ..... 09-12-22  
POWER STEERING FLUID INSPECTION .. 06-12-1  
POWER STEERING OIL PUMP  
DISASSEMBLY/ASSEMBLY ..... 06-12-12  
POWER STEERING OIL PUMP  
REMOVAL/INSTALLATION ..... 06-12-11  
POWER STEERING PRESSURE SWITCH  
INSPECTION ..... 01-40-21  
POWER WINDOW MOTOR INSPECTION . 09-12-8  
POWER WINDOW REGULATOR  
ASSEMBLY ..... 09-12-7  
POWER WINDOW REGULATOR  
DISASSEMBLY ..... 09-12-6  
POWER WINDOW REGULATOR  
REMOVAL/INSTALLATION ..... 09-12-6  
POWER WINDOW SWITCH  
INSPECTION ..... 09-12-10  
POWER WINDOW SWITCH  
REMOVAL/INSTALLATION ..... 09-12-9

AI

# ALPHABETICAL INDEX

PRE-DELIVERY INSPECTION ..... 00-00-20  
 PRECAUTION ..... 04-01-2  
 PRECAUTION (BRAKES) ..... 04-10-1  
 PRECAUTION (DRIVELINE/AXLE) ..... 03-10-1  
 PRECAUTION (STEERING) ..... 06-10-1  
 PRECAUTION (SUSPENSION) ..... 02-10-1  
 PRESSURE REGULATOR INSPECTION .. 01-14-16  
 PRESSURE REGULATOR  
 REMOVAL/INSTALLATION ..... 01-14-16  
 PROPELLER SHAFT INSPECTION ..... 03-15-2  
 PROPELLER SHAFT  
 REMOVAL/INSTALLATION ..... 03-15-1  
 PROPORTIONING BYPASS VALVE  
 INSPECTION ..... 04-11-12  
 PROPORTIONING BYPASS VALVE  
 REPLACEMENT ..... 04-11-12  
 PULSATION DAMPER No.1  
 REMOVAL/INSTALLATION ..... 01-14-18  
 PULSATION DAMPER No.1, No.2  
 INSPECTION ..... 01-14-18  
 PULSATION DAMPER No.2  
 REMOVAL/INSTALLATION ..... 01-14-18  
 PURGE SOLENOID VALVE INSPECTION .. 01-16-9  
 PURGE SOLENOID VALVE  
 REMOVAL/INSTALLATION ..... 01-16-8

## Q

QUARTER TRIM  
 REMOVAL/INSTALLATION ..... 09-17-8

## R

RADIATOR CAP INSPECTION ..... 01-12-3  
 RADIATOR REMOVAL/INSTALLATION .... 01-12-4  
 REAR ABS WHEEL-SPEED SENSOR  
 INSPECTION ..... 04-13-11  
 REAR ABS WHEEL-SPEED SENSOR  
 REMOVAL/INSTALLATION ..... 04-13-11  
 REAR ANTENNA FEEDER INSPECTION .. 09-20-7  
 REAR ANTENNA FEEDER  
 REMOVAL/INSTALLATION ..... 09-20-7  
 REAR BRAKE (DISC) INSPECTION ..... 04-11-17  
 REAR BRAKE (DISC)  
 REMOVAL/INSTALLATION ..... 04-11-18  
 REAR BUMPER  
 REMOVAL/INSTALLATION ..... 09-10-6  
 REAR COMBINATION LIGHT  
 REMOVAL/INSTALLATION ..... 09-18-3  
 REAR CROSSMEMBER  
 REMOVAL/INSTALLATION ..... 02-14-7  
 REAR END MAT  
 REMOVAL/INSTALLATION ..... 09-17-11  
 REAR LOWER ARM  
 REMOVAL/INSTALLATION ..... 02-14-3  
 REAR OIL SEAL REPLACEMENT ..... 01-10-14  
 REAR PACKAGE TRIM  
 REMOVAL/INSTALLATION ..... 09-17-9  
 REAR SHOCK ABSORBER AND COIL  
 SPRING REMOVAL/INSTALLATION ..... 02-14-1  
 REAR SHOCK ABSORBER DISPOSAL .... 02-14-2  
 REAR SHOCK ABSORBER INSPECTION .. 02-14-2  
 REAR STABILIZER  
 REMOVAL/INSTALLATION ..... 02-14-6

REAR UPPER ARM  
 REMOVAL/INSTALLATION ..... 02-14-5  
 REAR WHEEL ALIGNMENT ..... 02-11-3  
 REAR WINDOW DEFROSTER POWER-CUT  
 SWITCH INSPECTION ..... 09-12-18  
 REAR WINDOW DEFROSTER POWER-CUT  
 SWITCH REMOVAL/INSTALLATION .... 09-12-18  
 REAR WINDOW DEFROSTER RELAY  
 INSPECTION ..... 09-12-19  
 REAR WINDOW DEFROSTER RELAY  
 REMOVAL/INSTALLATION ..... 09-12-19  
 REAR WINDOW DEFROSTER SWITCH  
 INSPECTION ..... 09-12-17  
 REAR WINDOW DEFROSTER SWITCH  
 REMOVAL/INSTALLATION ..... 09-12-17  
 REAR WINDOW GLASS INSTALLATION .. 09-12-12  
 REAR WINDOW GLASS REMOVAL ..... 09-12-11  
 REAR WINDOW MOLDING  
 INSTALLATION ..... 09-16-2  
 REAR WINDOW MOLDING REMOVAL .... 09-16-2  
 REARVIEW MIRROR INSTALLATION .... 09-12-24  
 REARVIEW MIRROR REMOVAL ..... 09-12-23  
 RECEIVER/DRIER  
 REMOVAL/INSTALLATION ..... 07-11-8  
 REFRIGERANT CHARGE CHECK ..... 07-10-2  
 REFRIGERANT CHARGING ..... 07-10-3  
 REFRIGERANT LINES  
 REMOVAL/INSTALLATION ..... 07-11-9  
 REFRIGERANT PRESSURE CHECK ..... 07-10-3  
 REFRIGERANT PRESSURE SWITCH  
 INSPECTION ..... 07-40-5  
 REFRIGERANT PRESSURE SWITCH  
 REMOVAL/INSTALLATION ..... 07-40-6  
 REFRIGERANT SYSTEM GENERAL  
 PROCEDURES ..... 07-10-2  
 REFRIGERANT SYSTEM PERFORMANCE  
 TEST ..... 07-10-2  
 REFRIGERANT SYSTEM SERVICE  
 CAUTIONS ..... 07-10-1  
 REFRIGERANT SYSTEM SERVICE  
 WARNINGS ..... 07-10-1  
 REGULATOR HANDLE INSTALLATION ... 09-12-11  
 REGULATOR HANDLE REMOVAL ..... 09-12-10  
 RESISTOR INSPECTION ..... 07-40-2  
 RESISTOR REMOVAL/INSTALLATION .... 07-40-2  
 RETAINER ADJUSTMENT ..... 09-16-12  
 ROAD TEST ..... 05-13-4  
 ROLLOVER VALVE INSPECTION ..... 01-16-5  
 ROLLOVER VALVE  
 REMOVAL/INSTALLATION ..... 01-16-5  
 ROOM FUSE INSTALLATION ..... 09-21-2

## S

SAE STANDARDS ..... 00-00-9  
 SAS CONTROL MODULE  
 REMOVAL/INSTALLATION ..... 08-10-8  
 SCHEDULED MAINTENANCE ..... 00-00-21  
 SCUFF PLATE REMOVAL/INSTALLATION .. 09-17-9  
 SEAT BELT INSPECTION ..... 08-11-1  
 SEAT BELT REMOVAL/INSTALLATION .... 08-11-2  
 SEAT DISASSEMBLY/ASSEMBLY ..... 09-13-2  
 SEAT REMOVAL/INSTALLATION ..... 09-13-1  
 SELECTOR LEVER ADJUSTMENT ..... 05-14-6

# ALPHABETICAL INDEX

SELECTOR LEVER	
DISASSEMBLY/ASSEMBLY .....	05-14-8
SELECTOR LEVER INSPECTION .....	05-14-5
SELECTOR LEVER	
REMOVAL/INSTALLATION .....	05-14-7
SHIFT-LOCK ACTUATOR INSPECTION ...	05-14-3
SHIFT-LOCK ACTUATOR	
REMOVAL/INSTALLATION .....	05-14-5
SOLENOID VALVES INSPECTION .....	05-13-16
SOLENOID VALVES	
REMOVAL/INSTALLATION .....	05-13-17
SPARK PLUG INSPECTION .....	01-18-3
SPARK PLUG REMOVAL/INSTALLATION ..	01-18-3
STABILIZER CONTROL LINK	
INSPECTION .....	02-13-10
STABILIZER CONTROL LINK	
INSPECTION .....	02-14-7
STARTER DISASSEMBLY/ASSEMBLY ....	01-19-5
STARTER INSPECTION .....	01-19-2
STARTER INTERLOCK SWITCH	
INSPECTION (MT) .....	01-19-5
STARTER REMOVAL/INSTALLATION .....	01-19-1
STEERING GEAR AND LINKAGE	
DISASSEMBLY/ASSEMBLY .....	06-11-5
STEERING GEAR AND LINKAGE	
DISASSEMBLY/ASSEMBLY .....	06-12-6
STEERING GEAR AND LINKAGE	
INSPECTION .....	06-11-10
STEERING GEAR AND LINKAGE	
INSPECTION .....	06-12-10
STEERING GEAR AND LINKAGE	
REMOVAL/INSTALLATION .....	06-11-4
STEERING GEAR AND LINKAGE	
REMOVAL/INSTALLATION .....	06-12-5
STEERING SHAFT	
DISASSEMBLY/ASSEMBLY .....	06-11-3
STEERING SHAFT	
DISASSEMBLY/ASSEMBLY .....	06-12-4
STEERING SHAFT INSPECTION .....	06-11-4
STEERING SHAFT INSPECTION .....	06-12-4
STEERING WHEEL AND COLUMN	
INSPECTION .....	06-11-1
STEERING WHEEL AND COLUMN	
INSPECTION .....	06-12-4
STEERING WHEEL AND COLUMN	
REMOVAL/INSTALLATION .....	06-11-2
STEERING WHEEL AND COLUMN	
REMOVAL/INSTALLATION .....	06-12-4
SYMPTOM TROUBLESHOOTING .....	07-01-2

## T

TANK PRESSURE CONTROL VALVE (TPCV)	
INSPECTION .....	01-16-6
TAPPET AND ADJUSTMENT SHIM	
REMOVAL/INSTALLATION .....	01-10-11
THERMOSTAT INSPECTION .....	01-12-5
THERMOSTAT REMOVAL/INSTALLATION ..	01-12-5
THERMOSWITCH INSPECTION .....	07-40-6
THROTTLE CABLE ADJUSTMENT .....	05-13-8
THROTTLE CABLE INSPECTION .....	05-13-8
THROTTLE CABLE	
REMOVAL/INSTALLATION .....	05-13-9
THROTTLE POSITION SENSOR	
INSPECTION .....	01-40-11

THROTTLE POSITION SENSOR	
REPLACEMENT .....	01-40-11
TIMING BELT REMOVAL/INSTALLATION ..	01-10-6
TNS RELAY INSPECTION .....	09-18-9
TNS RELAY REMOVAL/INSTALLATION ...	09-18-9
TOP FABRIC REMOVAL/INSTALLATION ..	09-16-14
TOP FABRIC REPAIR .....	09-16-12
TORQUE CONVERTER	
REMOVAL/INSTALLATION .....	05-13-26
TOWING .....	00-00-18
TRANSMISSION CONTROL MODULE	
INSPECTION .....	05-13-18
TRANSMISSION CONTROL MODULE	
REMOVAL/INSTALLATION .....	05-13-20
TRANSMISSION OIL INSPECTION .....	05-11-1
TRANSMISSION OIL REPLACEMENT ....	05-11-2
TRANSMISSION RANGE SWITCH	
ADJUSTMENT .....	05-13-13
TRANSMISSION RANGE SWITCH	
INSPECTION .....	05-13-12
TRANSMISSION RANGE SWITCH	
REMOVAL/INSTALLATION .....	05-13-13
TROUBLESHOOTING INDEX .....	07-01-1
TROUBLESHOOTING NOTE .....	04-01-1
TRUNK END TRIM	
REMOVAL/INSTALLATION .....	09-17-10
TRUNK LID ADJUSTMENT .....	09-10-3
TRUNK LID LOCK AND OPENER	
REMOVAL/INSTALLATION .....	09-14-6
TRUNK LID REMOVAL/INSTALLATION ....	09-10-4
TRUNK LID STRIKER	
REMOVAL/INSTALLATION .....	09-14-7
TRUNK SIDE TRIM	
REMOVAL/INSTALLATION .....	09-17-10
TWEETER SPEAKER INSPECTION .....	09-20-2
TWEETER SPEAKER	
REMOVAL/INSTALLATION .....	09-20-2

## U

UNITS .....	00-00-8
-------------	---------

## V

VACUUM HOSE ROUTING DIAGRAM .....	01-13-1
VACUUM LINE INSPECTION .....	04-11-2
VALVE CLEARANCE ADJUSTMENT .....	01-10-4
VALVE CLEARANCE INSPECTION .....	01-10-3
VEHICLE LIFT (2 SUPPORTS) AND SAFETY	
STAND (RIGID RACK) POSITION .....	00-00-17
VEHICLE SPEEDOMETER SENSOR	
INSPECTION .....	05-11-3
VEHICLE SPEEDOMETER SENSOR	
REMOVAL/INSTALLATION .....	05-11-3
VENT CUT VALVE INSPECTION .....	01-14-20
VICS CHECK VALVE (ONE-WAY)	
INSPECTION .....	01-13-4
VICS CHECK VALVE (ONE-WAY)	
REMOVAL/INSTALLATION .....	01-13-4
VICS SHUTTER VALVE ACTUATOR	
INSPECTION .....	01-13-5
VICS SHUTTER VALVE ACTUATOR	
REMOVAL/INSTALLATION .....	01-13-5
VICS SOLENOID VALVE INSPECTION ....	01-13-6

AI

## ALPHABETICAL INDEX

VICS SOLENOID VALVE  
REMOVAL/INSTALLATION ..... 01-13-6

### W

WARNING AND INDICATOR LIGHT BULB  
REMOVAL/INSTALLATION ..... 09-22-6  
WATER PUMP REMOVAL/INSTALLATION . 01-12-6  
WHEEL ALIGNMENT PREINSPECTION ... 02-11-1  
WHEEL HUB BOLT  
REPLACEMENT ..... 03-11-1  
WHEEL HUB, KNUCKLE  
PREINSPECTION ..... 03-12-1  
WHEEL HUB, KNUCKLE  
REMOVAL/INSTALLATION ..... 03-12-2  
WHEEL HUB, STEERING KNUCKLE  
PREINSPECTION ..... 03-11-1  
WHEEL HUB, STEERING KNUCKLE  
REMOVAL/INSTALLATION ..... 03-11-2  
WINDSHIELD INSTALLATION ..... 09-12-14  
WINDSHIELD MOLDING INSTALLATION .. 09-16-4  
WINDSHIELD MOLDING REMOVAL ..... 09-16-4  
WINDSHIELD REMOVAL ..... 09-12-13  
WINDSHIELD WASHER MOTOR  
INSPECTION ..... 09-19-4  
WINDSHIELD WASHER MOTOR  
REMOVAL/INSTALLATION ..... 09-19-4  
WINDSHIELD WASHER NOZZLE  
ADJUSTMENT ..... 09-19-5  
WINDSHIELD WASHER NOZZLE  
INSTALLATION ..... 09-19-5  
WINDSHIELD WASHER NOZZLE  
REMOVAL ..... 09-19-5  
WINDSHIELD WASHER PIPE  
REMOVAL/INSTALLATION ..... 09-19-6  
WINDSHIELD WASHER TANK  
REMOVAL/INSTALLATION ..... 09-19-3  
WINDSHIELD WIPER ARM AND BLADE  
ADJUSTMENT ..... 09-19-1  
WINDSHIELD WIPER ARM AND BLADE  
REMOVAL/INSTALLATION ..... 09-19-1  
WINDSHIELD WIPER LINK  
REMOVAL/INSTALLATION ..... 09-19-2  
WINDSHIELD WIPER MOTOR  
INSPECTION ..... 09-19-2  
WINDSHIELD WIPER MOTOR  
REMOVAL/INSTALLATION ..... 09-19-2