
How to Use the SAMA5D2 PWM Under Linux

Introduction

This application note describes how to get started using the SAMA5D2 PWM under Linux.

With the introduction of the generic PWM framework into the kernel, it is easy to implement the driver for a PWM device and access it in user space via sysfs. The device driver of the SAMA5D2 PWM has been released in the Microchip Linux BSP; however, with the default settings, the PWM device was not enabled in the Linux device tree. For more information, refer to the sections [Device Tree](#) and [Hands-On](#).

Reference Documents

Title	Reference	Available
SAMA5D2 Series Datasheet	DS60001476	https://www.microchip.com/design-centers/32-bit-mpus
SAMA5D27 SOM1 Kit1 User Guide	DS50002667	https://www.microchip.com/DevelopmentTools/ProductDetails/PartNO/ATSAMA5D27-SOM1-EK1

Prerequisites

- Hardware
 - PC
 - SAMA5D27 SOM1 Evaluation Kit (Part Number: ATSAMA5D27-SOM1-EK1)
 - SDCard
- Software

This demo runs on the AT91 Linux platform built by Buildroot. The first step is to set up the AT91 Buildroot development environment. Refer to the web site: <http://www.at91.com/linux4sam/bin/view/Linux4SAM/BuildRoot>





Table of Contents

Introduction.....	1
Reference Documents.....	1
Prerequisites.....	1
1. Hardware Design.....	4
1.1. Interface.....	4
2. Software Design.....	5
2.1. Device Tree.....	5
2.2. Kernel.....	6
2.3. Rootfs.....	7
3. Hands-On.....	9
3.1. Hands-On with PWM_mBUS1.....	9
3.2. Hands-On with LED_Green.....	10
3.3. Hands-On with Synchronous Channels.....	10
4. Microchip Peripheral I/O Python® (MPIO).....	12
4.1. MPIO in buildroot.....	12
4.2. Examples.....	14
5. Revision History.....	15
5.1. Rev. A - 09/2019.....	15
The Microchip Website.....	16
Product Change Notification Service.....	16
Customer Support.....	16
Microchip Devices Code Protection Feature.....	16
Legal Notice.....	16
Trademarks.....	17
Quality Management System.....	17
Worldwide Sales and Service.....	18

1. Hardware Design

1.1 Interface



The connectors mikroBUS1 and mikroBUS2 are used for easy testing and monitoring.

The PWM channel PWML0 is connected to the PWM_mBUS2 via GPIO PA31 on the SAMA5D27-SOM-EK1:


- PWML0 (PWM waveform output low for channel 0) → PA31 → PWM_mBUS2

The PWM channel PWML1 is connected to the PWM_mBUS1 via GPIO PB1 on SAMA5D27-SOM-EK1:

- PWML1 (PWM waveform output low for channel 1) → PB1 → PWM_mBUS1

For more details about the pin multiplexing of the SAMA5D2, refer to the table “Pin Description (all packages)” in the SAMA5D2 data sheet.

These PWM channels also connect to LED_Green and LED_blue, as illustrated below:



2. Software Design

The Microchip Linux platform was built using Buildroot with the following configuration:

`atmel_sama5d27_som1_ek_mmc_dev_defconfig`

A PWM driver has been selected in this configuration, but the PWM device was not enabled in the device tree. To enable the PWM function, the device tree must be modified.

2.1 Device Tree

- Action: need to change
 - Change 1:
 - With the default setting, the PWM device is disabled in the device tree. The bold font below shows how to enable the PWM in `at91-sama5d27_som1_ek.dts`.
 - Change 2:
 - There is a GPIO conflict between the PWM device and the LED device. As a result, the LED device must be disabled.
- Location: `buildroot-at91/output/build/linux-linux4sam_6.0/arch/arm/boot/dts`
- Sources:
 - `sama5d2.dtsi`
 - `at91-sama5d27_som1_ek.dts`

Device tree for PWM0 in `sama5d2.dtsi`:

```
pwm0: pwm@f802c000 {
    compatible = "atmel,sama5d2-pwm"; // specify which driver will be used for this PWM device
    reg = <0xf802c000 0x4000>; // PWM0 base address is 0xf802c000, size of register block is //0x4000
    interrupts = <38 IRQ_TYPE_LEVEL_HIGH 7>; // PID of PWM0 is 38, high level triggered, // priority is 7
    #pwm-cells = <3>;
    clocks = <&pwm_clk>; // definition for pwm0 clock source
};

pwm_clk: pwm_clk {
    #clock-cells = <0>;
    reg = <38>; // PID of PWM0 is 38, this definition of offset will be used to enable PWM0 // clock in PMC
    atmel,clk-output-range = <0 83000000>; // PWM0 input clock, max frequency is 83MHz
};
```

Device tree for PWM0 in `at91-sama5d27_som1_ek.dts`:

```
pwm0: pwm@f802c000 {
    pinctrl-names = "default";
    pinctrl-0 = <&pinctrl_mikrobus1_pwm &pinctrl_mikrobus2_pwm>; // pin definition for PWM0
    status = "okay"; /* Conflict with leds. */ // This is change 1, set status of pwm0 to // "okay", enable pwm0 device
};

pinctrl_mikrobus1_pwm: mikrobus1_pwm {
    pinmux = <PIN_PB1_PWML1>; // the mux of PB1 will be switched to PWML1
    bias-disable; // pull up/down feature disabled
};

pinctrl_mikrobus2_pwm: mikrobus2_pwm {
    pinmux = <PIN_PA31_PWML0>; // the mux of PA31 will be switched to PWML0
    bias-disable; // pull up/down feature disabled
};

leds {
    compatible = "gpio-leds";
    pinctrl-names = "default";
    pinctrl-0 = <&pinctrl_led_gpio_default>;
    status = "disabled"; /* Conflict with pwm0. */ // This is change 2, set status of leds to
```

```
// "disabled", disable leds device

red {
    label = "red";
    gpios = <&pioA PIN_PA10 GPIO_ACTIVE_HIGH>;
};

green {
    label = "green";
    gpios = <&pioA PIN_PB1 GPIO_ACTIVE_HIGH>;
};

blue {
    label = "blue";
    gpios = <&pioA PIN_PA31 GPIO_ACTIVE_HIGH>;
    linux,default-trigger = "heartbeat";
};
};
```

2.2 Kernel


- Action: no need to change
- Location: buildroot-at91/output/build/linux-linux4sam_6.0/
- Defconfig: sama5_defconfig
- Driver files: drivers/pwm/pwm-atmel.c

Check the kernel configuration for the PWM function:

```
user@at91:~/buildroot-at91$ make linux-menuconfig
```

Device Drivers > Pulse-Width Modulation (PWM) Support >Atmel PWM support

With the default setting, the Atmel PWM driver has been selected.



File systems > Pseudo filesystems >sysfs file system support

With the default setting, the sysfs feature has been selected.

There is no device node file created for the PWM device. The PWM driver is accessed via sysfs in user space.

```
.config - linux/arm 4.14.73-linux4sam_6.0 Kernel Configuration
> File systems > Pseudo filesystems -
Pseudo filesystems
Arrow keys navigate the menu. <Enter> selects submenus ---- (or empty submenus ----). Highlighted letters are
hotkeys. Pressing <Y> includes, <N> excludes, <M> modularizes features. Press <Esc><Esc> to exit, <?> for Help, </>
for Search. Legend: [*] built-in [ ] excluded <M> module < > module capable

[*] /proc file system support
[*] Sysctl support (/proc/sys)
[*] Enable /proc page monitoring
[ ] Include /proc/<pid>/task/<tid>/children file
[*] sysfs file system support
[*] Tmpfs virtual memory file system support (former shm fs)
[ ] Tmpfs POSIX Access Control Lists
[ ] Tmpfs extended attributes
[*] Userspace-driven configuration filesystem
```

2.3 Rootfs

- Action: no need to change
- Location: buildroot-at91/output/images/rootfs.tar

The PWM driver can be accessed via the following sysfs path in user space:

- `/sys/class/pwm`

Several files and sub-folders can be found in this path:

For more details on the PWM in Linux, see `kernel_dir/documentation/pwm.txt`.

- `/sys/class/pwm/pwmchipN`
 - Each probed PWM controller/chip will be exported as `pwmchipN`, where N is the base of the PWM chip
- `/sys/class/pwm/pwmchipN/npwm`
 - The number of PWM channels which this chip supports (read-only).
- `/sys/class/pwm/pwmchipN/export`
 - Exports a PWM channel with sysfs (write-only).
 - The PWM channels are numbered using a per-chip index from 0 to `npwm-1`.
- `/sys/class/pwm/pwmchipN/unexport`
 - Unexports a PWM channel from sysfs (write-only).

When a PWM channel is exported, a `pwmX` directory is created in the `pwmchipN` directory, where X is the number of the channel that was exported.

The following properties are available:

- `/sys/class/pwm/pwmchipN/pwmX/period`
 - The total period of the PWM signal (read/write).
 - Value is in nanoseconds and is the sum of the active and inactive time of the PWM.
- `/sys/class/pwm/pwmchipN/pwmX/duty_cycle`
 - The active time of the PWM signal (read/write).
 - Value is in nanoseconds and must be less than the period.
- `/sys/class/pwm/pwmchipN/pwmX/polarity`
 - Change the polarity of the PWM signal (read/write).
 - This property only works if the PWM chip supports changing the polarity. The polarity can only be changed if the PWM is not enabled. Value is the string “normal” or “inversed”.
- `/sys/class/pwm/pwmchipN/pwmX/enable`
 - Enable/disable the PWM signal (read/write).

- 0: disabled
- 1: enabled

3. Hands-On


3.1 Hands-On with PWM_mBUS1

1. Reset the target board before the hands-on:

```
# reboot
```

2. Then set up a 10 kHz 90% duty cycle PWM output:

```
# cd /sys/class/pwm/
# ls
pwmchip0
# cd pwmchip0/
# echo 1 > export
# ls
device      npwm      pwm1      uevent
export      power     subsystem unexport
# cd pwm1/
# ls
capture      enable      polarity    uevent
duty_cycle   period      power
# echo 100000 > period
# echo 90000 > duty_cycle
# echo 1 > enable
```



3.2 Hands-On with LED_Green

1. Reset the target board before the hands-on:

```
# reboot
```

2. Turn off the LED_Red:

```
# echo 10 > /sys/class/gpio/export
# echo out > /sys/class/gpio/PA10/direction
# echo 0 > /sys/class/gpio/PA10/value
```

3. Turn off the LED_Blue:

```
# echo 0 > /sys/class/pwm/pwmchip0/export
# echo 10000000 > /sys/class/pwm/pwmchip0/pwm0/period
# echo 10000000 > /sys/class/pwm/pwmchip0/pwm0/duty_cycle
# echo 1 > /sys/class/pwm/pwmchip0/pwm0/enable
```

4. Set up PWM channel 1 output:

```
# cd /sys/class/pwm/pwmchip0/
# echo 1 > export
# cd pwm1/
```

5. Adjust LED_Green brightness:

```
# echo 10000000 > period
# echo 10000000 > duty_cycle
# echo 1 > enable
# echo 9000000 > duty_cycle
# echo 8000000 > duty_cycle
# echo 7000000 > duty_cycle
# echo 6000000 > duty_cycle
# echo 5000000 > duty_cycle
# echo 4000000 > duty_cycle
# echo 3000000 > duty_cycle
# echo 2000000 > duty_cycle
# echo 1000000 > duty_cycle
```

6. Set the LED_Green to blink:

```
# echo 0 > enable
# echo 100000000 > period
# echo 50000000 > duty_cycle
# echo 1 > enable
```

3.3 Hands-On with Synchronous Channels

Some channels can be linked together as synchronous channels. For details about this feature, refer to the section “Synchronous Channels” in the SAMA5D2 data sheet .

In Linux, the current PWM device model does not support this feature. We can test this feature through a direct register setting via the devmem2 command.

Follow the sequence below to use PWM0 and PWM1 as synchronous channels.

1. Reset the target board before the hands-on:

```
# reboot
```

2. Commands to initialize the PWM channels:

- 2.1. Enable PWM0 and PWM1 SYNC feature:

```
# devmem2 0xF802C020 w 0x3
# cd /sys/class/pwm/pwmchip0/
# echo 0 > export
# echo 1 > export
# echo 10000000 > pwm1/period
# echo 9000000 > pwm1/duty_cycle
```

2.2. This is dummy enabling for PWM1, used for writing duty cycle configurations:

```
# echo 1 > pwm1/enable
```

2.3. Since the SYNC feature of PWM1 has been enabled, all SYNC channels are enabled together by enabling the channel 0:

```
# echo 10000000 > pwm0/period
# echo 2000000 > pwm0/duty_cycle
```


2.4. Here the output of PWM0 and PWM1 is enabled together:

```
# echo 1 > pwm0/enable
```

3. Command to update the channel configuration:

3.1. Write the bit UPDULOCK in PWM_SCUC after adjusting the configuration of the PWM channel.

```
# devmem2 0xF802C028 w 1
```



4. Microchip Peripheral I/O Python® (MPIO)

The Microchip Peripheral I/O (MPIO) Python package provides easy access to various hardware peripherals found on Microchip MPU processors and evaluation boards running Linux. The API is clean, consistent, flexible, documented, and well tested. It makes navigating and exercising even the most complex hardware peripherals a trivial task.

For more information, see <https://github.com/linux4sam/mpio>. Code examples showing how to work with the MPIO interface modules are provided in the folder `mpio/examples`.

4.1 MPIO in buildroot

In order to benefit from MPIO in your buildroot configuration, follow the steps below:

1. Enable Python


```
user@at91:~/buildroot-at91$ make menuconfig
```

Select “**python**” to enable python support:

- Target packages > Interpreter languages and scripting > [*] **python**

Then enter “**python module format to install**” and select “**.py sources and .pyc compiled**”.

- Target packages > Interpreter languages and scripting > python > python module format to install > **.py sources and .pyc compiled**



Some additional python modules must be selected. Enter “**core python modules**” and select “**curses module**”, “**readline**” and “**hashlib module**”.

- Target packages > Interpreter languages and scripting > core python modules > [*] **curses module**
- Target packages > Interpreter languages and scripting > core python modules > [*] **readline**

- Target packages > Interpreter languages and scripting > core python modules > [*] hashlib module

```

/home/user/tmp/mpio/test/buildroot-at91/.config - Buildroot 2018.02 Configuration
> Target packages > Interpreter languages and scripting > core python modules
core python modules
Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty submenus ----). Highlighted letters are hotkeys. Pressing <Y> selects a feature, while <N> excludes a feature. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*] feature is selected [ ] feature is excluded

*** The following modules are unusual or require extra libraries ***
[ ] bzip2 module (NEW)
[ ] bsddb module (NEW)
[ ] codecs module (NEW)
[*] curses module
[ ] ossaudiodev module (NEW)
[*] readline
[ ] ssl (NEW)
[ ] unicodedata module
[ ] sqlite module
[ ] xml module (NEW)
[ ] zlib module (NEW)
[*] hashlib module

```

Enter “External python modules” and select “python-setuptools”.

- Target packages > Interpreter languages and scripting > External python modules > [*] python-setuptools

```

/home/user/tmp/mpio/test/buildroot-at91/.config - Buildroot 2018.02 Configuration
> Target packages > Interpreter languages and scripting > External python modules
External python modules
Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty submenus ----). Highlighted letters are hotkeys. Pressing <Y> selects a feature, while <N> excludes a feature. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*] feature is selected [ ] feature is excluded

^(-)=
[ ] python-pyudev (NEW)
[ ] python-pyusb (NEW)
[ ] python-pyxb (NEW)
[ ] python-pyxml (NEW)
[ ] python-pyzmq (NEW)
[ ] python-raven (NEW)
[ ] python-remi (NEW)
[ ] python-requests (NEW)
[ ] python-requests-oauthlib (NEW)
[ ] python-requests-toolbelt (NEW)
[ ] python-rpi-gpio (NEW)
[ ] python-rtplib-fb (NEW)
[ ] python-scandir (NEW)
[ ] python-schedule (NEW)
[ ] python-sdnotify (NEW)
[ ] python-secretstorage (NEW)
[ ] python-see (NEW)
[ ] python-serial (NEW)
[ ] python-service-identity (NEW)
[ ] python-setorocitle (NEW)
[*] python-setuptools
[ ] python-sh (NEW)
[ ] python-shutilwhich (NEW)

```

2. Enable the MPIO Module

Enter “External options” and select “python-mpio”.

- External options > [*] python-mpio

```

/home/user/tmp/mpio/test/buildroot-at91/.config - Buildroot 2018.02 Configuration
> External options
External options
Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty submenus ----). Highlighted letters are hotkeys. Pressing <Y> selects a feature, while <N> excludes a feature. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*] feature is selected [ ] feature is excluded

*** MCHP (in /home/user/tmp/mpio/test/buildroot-external-microchip) ***
[ ] gl-decoder
*** gst1-at91 needs a toolchain w/ glibc ***
*** libplanes depends on libdrm, cairo, lua, and cJSON ***
[ ] ptc_examples
*** python-iocontrol depends on pyqt5 and mpio ***
[*] python-mpio
[ ] dt-overlay-at91
Init configuration (none) ----

```

3. Finish the buildroot Configuration and Build

Enter “Filesystem images” and set the exact size of rootfs to 120MB.

- Filesystem images > (120M) exact size

```

/home/user/tmp/mpio/test/buildroot-at91/.config - Buildroot 2018.02 Configuration
Filesystem Images
Filesystem Images
Arrow keys navigate the menu. <Enter> selects submenus --- (or empty submenus ---). Highlighted letters are hotkeys. Pressing <Y> selects a
feature, while <N> excludes a feature. Press <Esc><Esc> to exit, <?> for Help, </> for Search. Legend: [*] feature is selected [ ] feature is
excluded

[ ] axfs root filesystem
[ ] cloop root filesystem for the target device
[ ] cpio the root filesystem (for use as an initial RAM filesystem)
[ ] cramfs root filesystem
[*] ext2/3/4 root filesystem
    ext2/3/4 variant (ext4) --->
    ( ) filesystem label
    (120M) exact size
    (0) exact number of inodes (leave at 0 for auto calculation)
    (5) reserved blocks percentage
    (-O ^64bit) additional mke2fs options
    Compression method (no compression) --->

```

After saving, the following new settings are added to the configuration file of buildroot:

```

.....
BR2_PACKAGE_PYTHON=y
BR2_PACKAGE_PYTHON_PY_PYC=y
BR2_PACKAGE_PYTHON_CURSES=y
BR2_PACKAGE_PYTHON_READLINE=y
BR2_PACKAGE_PYTHON_HASHLIB=y
BR2_PACKAGE_PYTHON_SETUPTOOLS=y
BR2_PACKAGE_PYTHON_MPIO=y
BR2_TARGET_ROOTFS_EXT2_SIZE="120M"
.....

```

Then re-configure and build buildroot:

```

user@at91:~/buildroot-at91$ make atmel_sama5d27_som1_ek_mmc_dev_defconfig
user@at91:~/buildroot-at91$ make

```

4.2 Examples

After building successfully, burn your SD card with buildroot-at91/output/images/sdcard.img.

Execute the python codes on the target board, for example:

```

# ./adc2.py DEVICE
# ./gpio1.py PIN
# ./pwm_led.py DEVICE CHANNEL
.....

```

Note: The python example code can be found in <https://github.com/linux4sam/mpio/examples>

5. Revision History

5.1 Rev. A - 10/2019

First issue.

The Microchip Website

Microchip provides online support via our website at <http://www.microchip.com/>. This website is used to make files and information easily available to customers. Some of the content available includes:

- **Product Support** – Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** – Frequently Asked Questions (FAQs), technical support requests, online discussion groups, Microchip design partner program member listing
- **Business of Microchip** – Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

Product Change Notification Service

Microchip's product change notification service helps keep customers current on Microchip products. Subscribers will receive email notification whenever there are changes, updates, revisions or errata related to a specified product family or development tool of interest.

To register, go to <http://www.microchip.com/pcn> and follow the registration instructions.

Customer Support

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Embedded Solutions Engineer (ESE)
- Technical Support

Customers should contact their distributor, representative or ESE for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in this document.

Technical support is available through the website at: <http://www.microchip.com/support>

Microchip Devices Code Protection Feature

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Legal Notice

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with

your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Trademarks

The Microchip name and logo, the Microchip logo, Adaptec, AnyRate, AVR, AVR logo, AVR Freaks, BesTime, BitCloud, chipKIT, chipKIT logo, CryptoMemory, CryptoRF, dsPIC, FlashFlex, flexPWR, HELDO, IGLOO, JukeBlox, KeeLoq, Klear, LANCheck, LinkMD, maXStylus, maXTouch, MediaLB, megaAVR, Microsemi, Microsemi logo, MOST, MOST logo, MPLAB, OptoLyzer, PackeTime, PIC, picoPower, PICSTART, PIC32 logo, PolarFire, Prochip Designer, QTouch, SAM-BA, SenGenuity, SpyNIC, SST, SST Logo, SuperFlash, Symmetricom, SyncServer, Tachyon, TempTrackr, TimeSource, tinyAVR, UNI/O, Vectron, and XMEGA are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

APT, ClockWorks, The Embedded Control Solutions Company, EtherSynch, FlashTec, Hyper Speed Control, HyperLight Load, IntelliMOS, Libero, motorBench, mTouch, Powermite 3, Precision Edge, ProASIC, ProASIC Plus, ProASIC Plus logo, Quiet-Wire, SmartFusion, SyncWorld, Temux, TimeCesium, TimeHub, TimePictra, TimeProvider, Vite, WinPath, and ZL are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Adjacent Key Suppression, AKS, Analog-for-the-Digital Age, Any Capacitor, AnyIn, AnyOut, BlueSky, BodyCom, CodeGuard, CryptoAuthentication, CryptoAutomotive, CryptoCompanion, CryptoController, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, EtherGREEN, In-Circuit Serial Programming, ICSP, INICnet, Inter-Chip Connectivity, JitterBlocker, KlearNet, KlearNet logo, memBrain, Mindi, MiWi, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICTail, PowerSmart, PureSilicon, QMatrix, REAL ICE, Ripple Blocker, SAM-ICE, Serial Quad I/O, SMART-I.S., SQI, SuperSwitcher, SuperSwitcher II, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

The Adaptec logo, Frequency on Demand, Silicon Storage Technology, and Symmcom are registered trademarks of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2019, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

ISBN: 978-1-5224-5130-3

AMBA, Arm, Arm7, Arm7TDMI, Arm9, Arm11, Artisan, big.LITTLE, Cordio, CoreLink, CoreSight, Cortex, DesignStart, DynamiQ, Jazelle, Keil, Mali, Mbed, Mbed Enabled, NEON, POP, RealView, SecurCore, Socrates, Thumb, TrustZone, ULINK, ULINK2, ULINK-ME, ULINK-PLUS, ULINKpro, μ Vision, Versatile are trademarks or registered trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere.

Quality Management System

For information regarding Microchip's Quality Management Systems, please visit <http://www.microchip.com/quality>.

Worldwide Sales and Service

AMERICAS	ASIA/PACIFIC	ASIA/PACIFIC	EUROPE
Corporate Office 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support: http://www.microchip.com/support Web Address: http://www.microchip.com	Australia - Sydney Tel: 61-2-9868-6733 China - Beijing Tel: 86-10-8569-7000 China - Chengdu Tel: 86-28-8665-5511 China - Chongqing Tel: 86-23-8980-9588 China - Dongguan Tel: 86-769-8702-9880 China - Guangzhou Tel: 86-20-8755-8029 China - Hangzhou Tel: 86-571-8792-8115 China - Hong Kong SAR Tel: 852-2943-5100 China - Nanjing Tel: 86-25-8473-2460 China - Qingdao Tel: 86-532-8502-7355 China - Shanghai Tel: 86-21-3326-8000 China - Shenyang Tel: 86-24-2334-2829 China - Shenzhen Tel: 86-755-8864-2200 China - Suzhou Tel: 86-186-6233-1526 China - Wuhan Tel: 86-27-5980-5300 China - Xian Tel: 86-29-8833-7252 China - Xiamen Tel: 86-592-2388138 China - Zhuhai Tel: 86-756-3210040	India - Bangalore Tel: 91-80-3090-4444 India - New Delhi Tel: 91-11-4160-8631 India - Pune Tel: 91-20-4121-0141 Japan - Osaka Tel: 81-6-6152-7160 Japan - Tokyo Tel: 81-3-6880-3770 Korea - Daegu Tel: 82-53-744-4301 Korea - Seoul Tel: 82-2-554-7200 Malaysia - Kuala Lumpur Tel: 60-3-7651-7906 Malaysia - Penang Tel: 60-4-227-8870 Philippines - Manila Tel: 63-2-634-9065 Singapore Tel: 65-6334-8870 Taiwan - Hsin Chu Tel: 886-3-577-8366 Taiwan - Kaohsiung Tel: 886-7-213-7830 Taiwan - Taipei Tel: 886-2-2508-8600 Thailand - Bangkok Tel: 66-2-694-1351 Vietnam - Ho Chi Minh Tel: 84-28-5448-2100	Austria - Wels Tel: 43-7242-2244-39 Fax: 43-7242-2244-393 Denmark - Copenhagen Tel: 45-4450-2828 Fax: 45-4485-2829 Finland - Espoo Tel: 358-9-4520-820 France - Paris Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79 Germany - Garching Tel: 49-8931-9700 Germany - Haan Tel: 49-2129-3766400 Germany - Heilbronn Tel: 49-7131-72400 Germany - Karlsruhe Tel: 49-721-625370 Germany - Munich Tel: 49-89-627-144-0 Fax: 49-89-627-144-44 Germany - Rosenheim Tel: 49-8031-354-560 Israel - Ra'anana Tel: 972-9-744-7705 Italy - Milan Tel: 39-0331-742611 Fax: 39-0331-466781 Italy - Padova Tel: 39-049-7625286 Netherlands - Drunen Tel: 31-416-690399 Fax: 31-416-690340 Norway - Trondheim Tel: 47-72884388 Poland - Warsaw Tel: 48-22-3325737 Romania - Bucharest Tel: 40-21-407-87-50 Spain - Madrid Tel: 34-91-708-08-90 Fax: 34-91-708-08-91 Sweden - Gothenberg Tel: 46-31-704-60-40 Sweden - Stockholm Tel: 46-8-5090-4654 UK - Wokingham Tel: 44-118-921-5800 Fax: 44-118-921-5820